

---

---

## FOREWORD

---




This Arctic Cat Service Manual contains service, maintenance, and troubleshooting information for certain 2012 Arctic Cat ATV models (see cover). The complete manual is designed to aid service personnel in service-oriented applications.

Arctic Cat offers additional publications (when they become available) to aid in servicing other ATV models. To service models not included in this manual, please refer to the following publications:

- 2012 Y-12+ Service Manual
- 2012 T-14 Service Manual
- 2012 300 DVX/Utility Service Manual
- 2012 350 Service Manual
- 2012 425 Service Manual
- 2012 700 Diesel Service Manual
- 2012 450 XC Service Manual
- 2012 650 Service Manual
- 2012 450/1000 Service Manual

This manual is divided into sections. Each section covers a specific ATV component or system and, in addition to the standard service procedures, includes disassembling, inspecting, and assembling instructions. When using this manual as a guide, the technician should use discretion as to how much disassembly is needed to correct any given condition.

The service technician should become familiar with the operation and construction of each component or system by carefully studying the complete manual. This manual will assist the service technician in becoming more aware of and efficient with servicing procedures. Such efficiency not only helps build consumer confidence but also saves time and labor.

All Arctic Cat ATV publications and decals display the words Warning, Caution, Note, and At This Point to emphasize important information. The symbol  **WARNING** identifies personal safety-related information. Be sure to follow the directive because it deals with the possibility of severe personal injury or even death. A **CAUTION** identifies unsafe practices which may result in ATV-related damage. Follow the directive because it deals with the possibility of damaging part or parts of the ATV. The symbol  **NOTE:** identifies supplementary information worthy of particular attention. The symbol  **AT THIS POINT** directs the technician to certain and specific procedures to promote efficiency and to improve clarity.

At the time of publication, all information, photographs, and illustrations were technically correct. Some photographs used in this manual are used for clarity purposes only and are not designed to depict actual conditions. Because Arctic Cat Inc. constantly refines and improves its products, no retroactive obligation is incurred.

All materials and specifications are subject to change without notice.


Keep this manual accessible in the shop area for reference.

**Product Service and  
Warranty Department  
Arctic Cat Inc.**

## **TABLE OF CONTENTS**

Note: To navigate through this manual, use the PAGE UP/PAGE DOWN buttons on the keyboard, click on the Table of Contents bookmarks on the left side of the screen, or click the blue text below. To return to this page, click the Manual Table of Contents button at the bottom of each page.

**8adW adV**

- 
- 1. General Information/Specifications** **1**
  - 2. Periodic Maintenance** **2**
  - 3. Engine/Transmission** **3**
  - 4. Fuel/Lubrication/Cooling** **4**
  - 5. Electrical System** **5**
  - 6. Drive System/Brake System** **6**
  - 7. Suspension** **7**
  - 8. Steering/Frame** **8**

550 Models  
700 Models

**ARCTIC CAT**<sup>®</sup>  
SHARE OUR PASSION.™



# SECTION 1 - GENERAL INFORMATION/ SPECIFICATIONS

1

---

---

## TABLE OF CONTENTS

---

---

General Specifications .....	1-2
Torque Specifications .....	1-2
Torque Conversions (ft-lb/N-m) .....	1-3
Break-In Procedure .....	1-3
Gasoline - Oil - Lubricant .....	1-4
Genuine Parts .....	1-4
Preparation For Storage .....	1-5
Preparation After Storage.....	1-5

## General Specifications

CHASSIS	
Brake Type	Hydraulic w/Brake Lever Lock and Auxiliary Brake
Tire Size	Front - 25 x 8-12 Rear - 25 x 10-12 (700 Mud Pro) Front - 28 x 9-14 Rear - 28 x 11-14 (700 Mud Pro)
Tire Inflation Pressure	0.35 kg/cm <sup>2</sup> (5 psi) 0.49 kg/cm <sup>2</sup> (7 psi) - TRV/ Cruiser
MISCELLANY	
Spark Plug Type	NGK CPR8E
Spark Plug Gap	0.5-0.6 mm (0.019-0.024 in.)
Gas Tank Capacity	21.6 L (5.7 U.S. gal.) - FIS 21.9 L (5.8 U.S. gal.) - TBX 20.0 L (5.3 U.S. gal.) - TRV/ Cruiser
Coolant Capacity	2.9 L (3.0 U.S. qt)
Rear Drive Capacity	250 ml (8.5 fl oz)*
Front Differential Capacity	275 ml (9.3 fl oz)**
Engine Oil Capacity (approx)	2.5 L (2.6 U.S. qt) - Overhaul 1.9 L (2.0 U.S. qt) - Change
Gasoline (recommended)	87 Octane Regular Unleaded
Engine Oil (recommended)	Arctic Cat ACX All Weather (Synthetic)
Differential/Rear Drive Lubricant	SAE Approved 80W-90 Hypoid
Drive Belt Width (minimum)	35.6 mm (1.40 in.)
Brake Fluid	DOT 4
Taillight/Brakelight	12V/8W/27W
Headlight	12V/27W (2)
ELECTRICAL SYSTEM	
Ignition Timing	10° BTDC @ 1500 RPM
Spark Plug Cap	5000 ohms
Ignition Coil Resistance	(primary) Less than 5.0 ohms (terminal (+) to terminal (-)) (secondary) 12k-19k ohms (high tension - plug cap - to terminal (+))
Ignition Coil Primary Voltage	Battery Voltage (orange (+) to blue/white(-))
Stator Coil (crankshaft position sensor) Resistance	150-250 ohms (blue to green) (AC generator) Less than 1 ohm (yellow to yellow)
Crankshaft Position Sensor AC Voltage	2.0 volts (blue to green)
AC Generator Output (no load)	75 AC volts @ 5000 RPM (yellow to yellow)

Specifications subject to change without notice.

\* One inch below plug threads.

\*\* At the plug threads.

## Torque Specifications

EXHAUST COMPONENTS			
Part	Part Bolted To	Torque	
		ft-lb	N-m
Exhaust Pipe	Engine	20	27
Spark Arrester	Muffler	48 in.-lb	5.5
ELECTRICAL COMPONENTS			
Engine/Harness Ground Cap Screw	Crankcase	8	11
Coil	Air Filter Housing	7	10
STEERING COMPONENTS			
Steering Post Bearing Housing	Frame	20	27
Steering Post Bearing Flange	Frame	20	27
Lower Steering Bearing Washer Cap Screw***	Steering Post	40	54
Tie Rod End	Knuckle/Steering Post	30	41
EPS Housing	Frame	35	47
BRAKE COMPONENTS			
Brake Disc*	Hub	15	20
Brake Hose	Caliper	20	27
Brake Hose (Banjo-Fitting)	Master Cylinder	20	27
Brake Hose	Auxiliary Brake Cylinder	20	27
Master Cylinder (Rear)	Frame	12	16
Hydraulic Caliper	Knuckle (w/"Patch-Lock")	20	27
Master Cylinder Clamp	Master Cylinder	6	8
Brake Pedal	Brake Pedal Axle	25	34
CHASSIS COMPONENTS			
Footrest	Frame (8 mm)	20	27
Footrest	Frame (10 mm)	40	54
SUSPENSION COMPONENTS (Front)			
A-Arm	Frame	50	68
Knuckle	Ball Joint	35	47
Shock Absorber	Frame/Upper A-Arm	50	68
Knuckle	A-Arm	50	68
SUSPENSION COMPONENTS (Rear)			
Shock Absorber (Upper)	Frame	50	68
Shock Absorber (Lower)	Lower A-Arm	20	27
A-Arm	Frame	50	68
Knuckle	A-Arm	35	47



DRIVE TRAIN COMPONENTS			
Part	Part Bolted To	Torque	
		ft-lb	N-m
Engine Mounting Through-Bolt	Frame	40	54
Engine (TRV)	Engine Cradle	40	54
Engine Cradle (TRV)**	Rubber Mount	25	34
Rubber Mount (TRV)	Frame Bracket	35	47
Front Differential*	Frame/Differential Bracket	38	52
Output Flange	Rear Flange Output Joint	20	27
Pinion Housing	Differential Housing	23	31
Differential Housing Cover***	Differential Housing	23	31
Drive Bevel Gear Nut***	Shaft	72	98
Differential Gear Case***	Hub	19	26
Lock Collar	Differential Housing	125	169
Hub Nut	Shaft/Axle (max)	200	272
Oil Drain Plug	Front Differential/ Rear Drive	45 in.-lb	5
Oil Fill Plug	Front Differential/ Rear Drive	16	22
Oil Drain Plug	Engine	16	22
Rear Drive Input Shaft/Housing	Differential Housing	23	31
Wheel (Steel)	Hub	40	54
Wheel (Aluminum)	Hub	80	108
Rear Drive Gear Case*	Frame	38	52
Engine Output Shaft **	Rear Gear Case Input Flange	20	27
Thrust Button**	Gear Case Cover	8	11
ENGINE/TRANSMISSION			
Crankshaft Bushing	Crankshaft	25	34
Speed Sensor Housing	Crankcase	8	11
Clutch Shoe**	Crankshaft	221	300
Clutch Cover/Housing Assembly	Crankcase	8	11
Crankcase Half (6 mm)	Crankcase Half	8	11
Crankcase Half (8 mm)	Crankcase Half	20	27
Cylinder Head (Cap Screw)	Crankcase	40	54
Cylinder Head Nut (6 mm)	Cylinder	8	11
Cylinder Head Nut (8 mm)	Cylinder	18	24
Valve Cover****	Cylinder Head	8.5	11.5
Driven Pulley Nut	Driveshaft	80	108
Ground Wire	Engine	8	11
Magneto Cover	Crankcase	8	11
Oil Pump Drive Gear**	Crank Balancer Shaft	63	85
Output Shaft Nut	Output Shaft	59	80
Outer Magneto Cover	Left-Side Cover	6	8
Magneto Rotor Nut	Crankshaft	107	145
Cam Sprocket**	Camshaft	10	13.5
Starter Motor	Crankcase	8	11
V-Belt Cover	Clutch Cover	8	11
Drive Pulley Nut**	Clutch Shaft	165	224
Movable Drive Face Nut**	Clutch Shaft	165	224
Secondary Shaft Bearing Housing	Crankcase Half	28	38
Stator Coil**	Crankcase	8	11
Starter One-Way Clutch**	Flywheel	26	35
Output Yoke Nut	Output Shaft	74	100

\* w/Blue Loctite #243  
 \*\* w/Red Loctite #271  
 \*\*\* w/Green Loctite #609  
 \*\*\*\* w/Three Bond Sealant

## Torque Conversions (ft-lb/N-m)

ft-lb	N-m	ft-lb	N-m	ft-lb	N-m	ft-lb	N-m
1	1.4	26	35.4	51	69.4	76	103.4
2	2.7	27	36.7	52	70.7	77	104.7
3	4.1	28	38.1	53	72.1	78	106.1
4	5.4	29	39.4	54	73.4	79	107.4
5	6.8	30	40.8	55	74.8	80	108.8
6	8.2	31	42.2	56	76.2	81	110.2
7	9.5	32	43.5	57	77.5	82	111.5
8	10.9	33	44.9	58	78.9	83	112.9
9	12.2	34	46.2	59	80.2	84	114.2
10	13.6	35	47.6	60	81.6	85	115.6
11	15	36	49	61	83	86	117
12	16.3	37	50.3	62	84.3	87	118.3
13	17.7	38	51.7	63	85.7	88	119.7
14	19	39	53	64	87	89	121
15	20.4	40	54.4	65	88.4	90	122.4
16	21.8	41	55.8	66	89.8	91	123.8
17	23.1	42	57.1	67	91.1	92	125.1
18	24.5	43	58.5	68	92.5	93	126.5
19	25.8	44	59.8	69	93.8	94	127.8
20	27.2	45	61.2	70	95.2	95	129.2
21	28.6	46	62.6	71	96.6	96	130.6
22	29.9	47	63.9	72	97.9	97	131.9
23	31.3	48	65.3	73	99.3	98	133.3
24	32.6	49	66.6	74	100.6	99	134.6
25	34	50	68	75	102	100	136



## Break-In Procedure

A new ATV and an overhauled ATV engine require a “break-in” period. The first 10 hours (or 200 miles) are most critical to the life of this ATV. Proper operation during this break-in period will help assure maximum life and performance from the ATV.

During the first 10 hours (or 200 miles) of operation, always use less than 1/2 throttle. Varying the engine RPM during the break-in period allows the components to “load” (aiding the mating process) and then “unload” (allowing components to cool). Although it is essential to place some stress on the engine components during break-in, care should be taken not to overload the engine too often. Do not pull a trailer or carry heavy loads during the 10-hour break-in period.

When the engine starts, allow it to warm up properly. Idle the engine several minutes until the engine has reached normal operating temperature. Do not idle the engine for excessively long periods of time.

During the break-in period, a maximum of 1/2 throttle is recommended; however, brief full-throttle accelerations and variations in driving speeds contribute to good engine break-in.

After the completion of the break-in period, the engine oil and oil filter should be changed. Other maintenance after break-in should include checking of all prescribed adjustments and tightening of all fasteners (see Periodic Maintenance Chart in Section 2).

## Gasoline - Oil - Lubricant

### RECOMMENDED GASOLINE

The recommended gasoline to use is 87 minimum octane regular unleaded. In many areas, oxygenates (either ethanol or MTBE) are added to the gasoline. Oxygenated gasolines containing up to 10% ethanol, 5% methane, or 5% MTBE are acceptable gasolines.

When using ethanol blended gasoline, it is not necessary to add a gasoline antifreeze since ethanol will prevent the accumulation of moisture in the fuel system.

#### CAUTION

Do not use white gas. Only Arctic Cat approved gasoline additives should be used.


### RECOMMENDED ENGINE/ TRANSMISSION OIL

#### CAUTION

Any oil used in place of the recommended oil could cause serious engine damage. Do not use oils which contain graphite or molybdenum additives. These oils can adversely affect clutch operation. Also, not recommended are racing, vegetable, non-detergent, and castor-based oils.

The recommended oil to use is Arctic Cat ACX All Weather synthetic engine oil, which has been specifically formulated for use in this Arctic Cat engine. Although Arctic Cat ACX All Weather synthetic engine oil is the only oil recommended for use in this engine, use of any API certified SM 0W-40 oil is acceptable.

#### Multi-Grade Engine Oil



OILCHARTJ

### RECOMMENDED FRONT DIFFERENTIAL/REAR DRIVE LUBRICANT

The recommended lubricant is Arctic Cat Gear Lube or an equivalent gear lube which is SAE approved 80W-90 hypoid. This lubricant meets all of the lubrication requirements of the Arctic Cat ATV front differentials and rear drives.

#### CAUTION


Any lubricant used in place of the recommended lubricant could cause serious front differential/rear drive damage.

### FILLING GAS TANK

#### ⚠ WARNING

Always fill the gas tank in a well-ventilated area. Never add fuel to the ATV gas tank near any open flames or with the engine running. DO NOT SMOKE while filling the gas tank.

Since gasoline expands as its temperature rises, the gas tank must be filled to its rated capacity only. Expansion room must be maintained in the tank particularly if the tank is filled with cold gasoline and then moved to a warm area.



ATV0049B

#### ⚠ WARNING

Do not overflow gasoline when filling the gas tank. A fire hazard could materialize. Always allow the engine to cool before filling the gas tank.

#### ⚠ WARNING

Do not over-fill the gas tank.

Tighten the gas tank cap securely after filling the tank.

## Genuine Parts

When replacement of parts is necessary, use only genuine Arctic Cat ATV parts. They are precision-made to ensure high quality and correct fit. Refer to the appropriate Illustrated Parts Manual for the correct part number, quantity, and description.



## Preparation For Storage

### CAUTION

Prior to storing the ATV, it must be properly serviced to prevent rusting and component deterioration.

Arctic Cat recommends the following procedure to prepare the ATV for storage.

1. Clean the seat cushion (cover and base) with a damp cloth and allow it to dry.
2. Clean the ATV thoroughly by washing dirt, oil, grass, and other foreign matter from the entire ATV. Allow the ATV to dry thoroughly. DO NOT get water into any part of the engine or air intake.
3. Either drain the gas tank or add Fuel Stabilizer to the gas in the gas tank. Remove the air filter housing cover and air filter. Start the engine and allow it to idle; then using Arctic Cat Engine Storage Preserver, rapidly inject the preserver into the air filter opening for a period of 10 to 20 seconds. Stop the engine. Install the air filter and housing cover.

### CAUTION

If the interior of the air filter housing is dirty, clean the area before starting the engine.

4. Plug the exhaust hole in the exhaust system with a clean cloth.
5. Apply light oil to the upper steering post bushing and plungers of the shock absorbers.
6. Tighten all nuts, bolts, cap screws, and screws. Make sure rivets holding components together are tight. Replace all loose rivets. Care must be taken that all calibrated nuts, cap screws, and bolts are tightened to specifications.
7. Fill the cooling system to the bottom of the stand pipe in the radiator neck with properly mixed coolant.
8. Disconnect the battery cables; then remove the battery, clean the battery posts and cables, and store in a clean, dry area.

9. Store the ATV indoors in a level position.

### CAUTION

Avoid storing outside in direct sunlight and avoid using a plastic cover as moisture will collect on the ATV causing rusting.

## Preparation After Storage

Taking the ATV out of storage and correctly preparing it will assure many miles and hours of trouble-free riding. Arctic Cat recommends the following procedure to prepare the ATV.

1. Clean the ATV thoroughly.
2. Clean the engine. Remove the cloth from the exhaust system.
3. Check all control wires and cables for signs of wear or fraying. Replace if necessary.
4. Change the engine/transmission oil and filter.
5. Check the coolant level and add properly mixed coolant as necessary.
6. Charge the battery; then install. Connect the battery cables.

### CAUTION

The ignition switch must be in the OFF position prior to installing the battery or damage may occur to the ignition system.

### CAUTION

Connect the positive battery cable first; then the negative.

7. Check the entire brake systems (fluid level, pads, etc.), all controls, headlights, taillight, brakelight, and headlight aim; adjust or replace as necessary.
8. Tighten all nuts, bolts, cap screws, and screws making sure all calibrated nuts, cap screws, and bolts are tightened to specifications.
9. Check tire pressure. Inflate to recommended pressure as necessary.
10. Make sure the steering moves freely and does not bind.
11. Check the spark plug. Clean or replace as necessary.

1

# SECTION 2 - PERIODIC MAINTENANCE

2

---

---

## TABLE OF CONTENTS

---

---

Periodic Maintenance Chart.....	2-2
Periodic Maintenance.....	2-3
Lubrication Points.....	2-3
Air Filter.....	2-3
Valve/Tappet Clearance .....	2-4
Testing Engine Compression .....	2-4
Spark Plug.....	2-5
Muffler/Spark Arrester .....	2-5
Engine/Transmission Oil - Filter - Strainer .....	2-6
Liquid Cooling System .....	2-7
Front Differential/Rear Drive Lubricant.....	2-8
Nuts/Bolts/Cap Screws.....	2-9
Headlights/Taillight-Brakelight .....	2-9
Shift Lever .....	2-10
Hydraulic Brake Systems .....	2-11
Burnishing Brake Pads.....	2-13
Checking/Replacing V-Belt.....	2-13



## Periodic Maintenance Chart

A = Adjust    I = Inspect  
 C = Clean    L = Lubricate  
 D = Drain    R = Replace  
 T = Tighten

Item	Initial Service After Break-In (First Month or 100 Miles)	Every Day	Every Month or Every 100 Miles	Every 3 Months or Every 300 Miles	Every 6 Months or Every 500 Miles	Every Year or Every 1500 Miles	As Needed
Battery	I		I				C
Fuses				I			R
Air Filter	I			I			R
Valve/Tappet Clearance	I				I		A
Engine Compression						I	
Spark Plug	I			I			R (4000 Mi or 18 Mo)
Muffler/Spark Arrester					C		R
Gas/Vent Hoses	I	I					R (2 Yrs)
Throttle Cable	I	I			C-L		A-R
Engine-Transmission Oil Level		I					A
Engine-Transmission Oil/Filter	R			R*/R**/R***			R
Oil Strainer							C
Front Differential/Rear Drive Lubricant	I		I				R (4 Yrs)
Tires/Air Pressure	I	I					R
Steering Components	I	I		I			R
V-Belt	I				I		R
Suspension (Ball joint boots, drive axle boots front and rear, tie rods, differential and rear drive bellows)	I	I					R
Nuts/Cap Screws/Screws	I		I				T
Ignition Timing						I	
Headlight/Taillight-Brakelight	I	I					R
Switches	I	I					R
Shift Lever					I		A-L
Handlebar Grips		I					R
Handlebar	I	I					R
Gauges/Indicators	I	I					R
Frame/Welds/Racks	I				I		
Electrical Connections	I				I		C
Complete Brake System (Hydraulic & Auxiliary)	I	I		C			L-R
Brake Pads	I			I*			R
Brake Fluid	I			I			R (2 Yrs)
Brake Hoses	I			I			R (4 Yrs)
Coolant/Cooling System	I		I				R (2 Yrs)

\* Service/Inspect more frequently when operating in adverse conditions.

\*\* When using an API certified SM 0W-40 oil.

\*\*\* When using Arctic Cat ACX All Weather synthetic oil, oil change interval can be increased to every 1,000 miles or every year.

## Periodic Maintenance

This section has been organized into sub-sections which show common maintenance procedures for the Arctic Cat ATV.

■ **NOTE:** Arctic Cat recommends the use of new gaskets, lock nuts, and seals and lubricating all internal components when servicing the engine/transmission.

■ **NOTE:** Some photographs and illustrations used in this section are used for clarity purposes only and are not designed to depict actual conditions.

■ **NOTE:** Critical torque specifications are located in Section 1.

### SPECIAL TOOLS

A number of special tools must be available to the technician when performing service procedures in this section.

Description	p/n
Compression Tester Kit	0444-213
Oil Filter Wrench	0644-389
Tachometer	0644-275
Timing Light	0644-296
Valve Clearance Adjuster	0444-255

■ **NOTE:** Special tools are available from the Arctic Cat Service Department.

## Lubrication Points


It is advisable to lubricate certain components periodically to ensure free movement. Apply light oil to the components using the following list as reference.

- A. Throttle Lever Pivot
- B. Brake Lever Pivot
- C. Auxiliary Brake Pedal Pivot

## Air Filter

Use the following procedure to remove the filter and inspect and/or clean it.

1. Remove the fasteners securing the storage compartment and remove the storage compartment.
2. Remove the air filter housing cover and the air filter/frame assembly.
3. Remove the foam element from the frame making sure not to tear the element.



CD747

4. Fill a wash pan larger than the element with a non-flammable solvent; then dip the element in the solvent and wash it.

■ **NOTE:** Foam Air Filter Cleaner and Foam Air Filter Oil are available from Arctic Cat.

5. Squeeze the element by pressing it between the palms of both hands to remove excess solvent. Do not twist or ring the element or it will develop cracks.
6. Dry the element.
7. Put the element in a plastic bag; then pour in air filter oil and work the oil into the element.
8. Squeeze the element to remove excess oil.


### CAUTION

A torn air filter can cause damage to the ATV engine. Dirt and dust may get inside the engine if the element is torn. Carefully examine the element for tears before and after cleaning it. Replace the element with a new one if it is torn.

9. Clean any dirt or debris from inside the air cleaner.
10. Install the air filter/frame assembly and cover.
11. Install the storage compartment and cover.

### CHECKING AND CLEANING DRAINS

1. Inspect the drains beneath the main housing for debris and for proper sealing.



KX045A