



INTRODUCTION

AISIN WARNER 50-42LE

*Published
July, 2004*

The Aisin Warner 50-42LE transmission first appeared in the Volvo 850, in model year 1992. Saab and Daewoo also implemented the 50-42LE in some of their models. This manual was produced using a 1995 model Volvo transmission for the photos. There are a few subtle differences between the Volvo, Saab and Daewoo versions and these differences are mentioned in the rebuilding process. Overall, the transmissions in all of these vehicle applications operate exactly the same. This manual will cover much needed information for diagnosis, service, repair and rebuild, including electrical information and hydraulic passage identification.

*We wish to thank Lory's transmission parts
for supplying the transmission to make
this book possible*

No part of any ATSG publication may be reproduced, stored in any retrieval system or transmitted in any form or by any means, including but not limited to electronic, mechanical, photocopying, recording or otherwise, without written permission of Automatic Transmission Service Group. This includes all text illustrations, tables and charts.

*The information and part numbers contained in this booklet have
been carefully compiled from industry sources known for their
reliability, but ATSG does not guarantee its accuracy.*

Copyright © ATSG 2004

DALE ENGLAND
FIELD SERVICE CONSULTANT

WAYNE COLONNA
TECHNICAL SUPERVISOR

PETER LUBAN
TECHNICAL CONSULTANT

JON GLATSTEIN
TECHNICAL CONSULTANT

JERRY GOTT
TECHNICAL CONSULTANT

GERALD CAMPBELL
TECHNICAL CONSULTANT

JIM DIAL
TECHNICAL CONSULTANT

ED KRUSE
TECHNICAL CONSULTANT

GREGORY LIPNICK
TECHNICAL CONSULTANT

DAVID CHALKER
TECHNICAL CONSULTANT

STANTON ANDERSON
TECHNICAL CONSULTANT

ROLAND ALVAREZ
TECHNICAL CONSULTANT

MIKE SOUZA
TECHNICAL CONSULTANT

AUTOMATIC TRANSMISSION SERVICE GROUP
9200 S. DADELAND BLVD. SUITE 720
MIAMI, FLORIDA 33156
(305) 670-4161



AISIN WARNER 50-42LE


INDEX

<i>50-42LE IDENTIFICATION TAG INFORMATION.....</i>	<i>3</i>
<i>CUT-AWAY VIEW, CLUTCH AND SOLENOID APPLICATION.....</i>	<i>4</i>
<i>GEAR RATIOS AND SPECIFICATIONS.....</i>	<i>5</i>
<i>COMPONENT RESISTANCE CHARTS.....</i>	<i>6</i>
<i>TRANSMISSION RANGE SWITCH CHECK.....</i>	<i>7</i>
<i>VOLVO TCM WIRE SCHEMATIC.....</i>	<i>8</i>
<i>SAAB TCM WIRE SCHEMATIC.....</i>	<i>9</i>
<i>DAEWOO TCM WIRE SCHEMATIC.....</i>	<i>10</i>
<i>VOLVO TROUBLE CODES AND RETRIEVAL.....</i>	<i>11</i>
<i>SAAB TROUBLE CODES AND RETRIEVAL.....</i>	<i>15</i>
<i>DAEWOO TROUBLE CODES AND RETRIEVAL.....</i>	<i>16</i>
<i>VALVE BODY MAPPING AND PASSAGE IDENTIFICATION.....</i>	<i>17</i>
<i>VALVE BODY MAPPING CIRCUIT DIAGRAM.....</i>	<i>34</i>
OIL CIRCUIT DIAGRAMS	
<i>"PARK" POSITION.....</i>	<i>35</i>
<i>"REVERSE" POSITION.....</i>	<i>36</i>
<i>"D" POSITION 1ST GEAR.....</i>	<i>37</i>
<i>"D" POSITION 2ND GEAR.....</i>	<i>38</i>
<i>"D" POSITION 3RD GEAR.....</i>	<i>39</i>
<i>"D" POSITION 4TH GEAR.....</i>	<i>40</i>
<i>"D" POSITION 4TH GEAR TCC ON.....</i>	<i>41</i>
<i>"D3" POSITION 3RD GEAR.....</i>	<i>42</i>
<i>"D1" POSITION MANUAL 1ST GEAR.....</i>	<i>43</i>
<i>TRANSMISSION DISASSEMBLY.....</i>	<i>44</i>
SUB-ASSEMBLIES SECTION	
<i>PUMP.....</i>	<i>56</i>
<i>B2 COAST BRAKE HUB AND F1 SPRAG.....</i>	<i>62</i>
<i>C3 UNDERDRIVE CLUTCH DRUM.....</i>	<i>64</i>
<i>F3 UNDERDRIVE SPRAG.....</i>	<i>66</i>
<i>UNDERDRIVE PLANETARY AND PINION GEAR ASSY.....</i>	<i>68</i>
<i>F2 FREEWHEEL (LOW SPRAG).....</i>	<i>72</i>
<i>COUNTER DRIVE GEAR.....</i>	<i>74</i>
<i>C1-C2 DRUM.....</i>	<i>76</i>
<i>REAR COVER.....</i>	<i>79</i>
<i>VALVE BODY.....</i>	<i>81</i>
<i>CHECK BALL LOCATIONS.....</i>	<i>89</i>
<i>B3 BRAKE ASSEMBLY.....</i>	<i>92</i>
<i>TRANSMISSION RE-ASSEMBLY.....</i>	<i>92</i>
<i>CASE AIR CHECKS.....</i>	<i>104</i>


AUTOMATIC TRANSMISSION SERVICE GROUP
9200 S. DADELAND BLVD. SUITE 720
MIAMI, FLORIDA 33156
(305) 670-4161

Copyright © ATSG 2004

TRANSMISSION IDENTIFICATION




I.D. TAG



Copyright © 2004 ATSG

Figure 1

CLUTCH/BAND AND SOLENOID APPLICATION CHART



S1 = SHIFT SOLENOID "A"
 S2 = SHIFT SOLENOID "B"

C1 = FORWARD CLUTCH
 C2 = DIRECT CLUTCH
 C3 = UNDERDRIVE CLUTCH

B1 = OVERRUN CLUTCH
 B2 = INTERMEDIATE CLUTCH
 B3 = LOW & REVERSE CLUTCH
 B4 = UNDERDRIVE BRAKE BAND

F1 = INTERMEDIATE SPRAG
 F2 = LOW SPRAG
 F3 = UNDERDRIVE SPRAG

SHIFT POSITION		S1	S2	C1	C2	C3	B1	B2	B3	B4	F1	F2	F3
P	PARK	OFF	ON							ON			
R	UNDER 4 MPH REVERSE	OFF	ON		ON				ON	ON			
	REVERSE INHIBIT VSS OVER 4 MPH	ON	ON		ON					ON			
N	NEUTRAL	OFF	ON							ON			
D	FIRST	OFF	ON	ON						ON			ON
	SECOND	ON	ON	ON			ON	ON		ON	ON		ON
	THIRD	ON	OFF	ON		ON	ON	ON			ON		
	FOURTH	OFF	OFF	ON	ON	ON		ON					
3	FIRST	OFF	ON	ON						ON		ON	ON
	SECOND	ON	ON	ON			ON	ON		ON	ON		ON
	THIRD	ON	OFF	ON		ON	ON	ON			ON		
*2	SECOND	ON	ON	ON			ON	ON		ON	ON		ON
	THIRD	ON	OFF	ON		ON	ON	ON			ON		
1	FIRST	OFF	ON	ON					ON	ON		ON	ON
	SECOND	ON	ON	ON			ON	ON		ON	ON		ON

*SAAB ONLY

Copyright © 2004 ATSG

Figure 2

SPECIFICATIONS

GEAR RATIOS:

GEAR	VOLVO	DAEWOO
1st Gear	3.61 : 1	3.900 : 1
2nd Gear	2.06 : 1	2.228 : 1
3rd Gear	1.37 : 1	1.477 : 1
4th Gear	0.98 : 1	1.062 : 1
Reverse	3.95 : 1	4.271 : 1

FLUID TYPE :


ATF - Type.....Dexron II E
 ATF - Type.....Volvo part number 1381166-6

FLUID CAPACITY:

Dry Fill.....5.1 liters (5.4 US qts)
 Torque converter.....2.5 liters (2.6 US qts)

LINE PRESSURE SPECIFICATIONS:

Base line pressure in Drive.....57-65 psi.
 Stall line pressure in Drive.....150-190psi.
 Base line pressure in Reverse.....85-100psi.
 Stall line pressure in Reverse.....280-290psi.




Copyright © 2004 ATSG

Figure 3

COMPONENT RESISTANCE CHARTS VOLVO

<i>COMPONENT</i>	<i>OHMS</i>	<i>TERMINALS</i>
SOLENOID 1	11-15	21 & GND
SOLENOID 2	11-15	22 & GND
LOCK UP SOLENOID	11-15	23 & GND
STH SOLENOID (Line Pressure)	2-6	24 & 25
OIL TEMP SENSOR	900 @ 68°F (20°C) 75 @ 212°F (100°C)	12 & 13
TURBINE SENSOR	300-600	16 & 17
OUTPUT SENSOR	300-600	NOT ROUTED THRU CONNECTOR


**VOLVO CONNECTOR
NUMBER 3/71**



SAAB

<i>COMPONENT</i>	<i>OHMS</i>	<i>TERMINALS</i>
SOLENOID 1	11-15	1 & GND
SOLENOID 2	11-15	9 & GND
LOCK UP SOLENOID	11-15	10 & GND
ST SOLENOID (Line Pressure)	2-6	11 & 3
OIL TEMP SENSOR	900 @ 68°F (20°C) 75 @ 212°F (100°C)	12 & 4
TURBINE SENSOR	300-600	5 & 13
OUTPUT SENSOR	300-600	14 & 6


**SAAB CONNECTOR
NUMBER H16-3**



DAEWOO

<i>COMPONENT</i>	<i>OHMS</i>	<i>TERMINALS</i>
SOLENOID 1	11-15	6 & GND
SOLENOID 2	11-15	12 & GND
LOCK UP SOLENOID	11-15	11 & GND
STH SOLENOID (Line Pressure)	2-6	4 & 10
OIL TEMP SENSOR	900 @ 68°F (20°C) 75 @ 212°F (100°C)	3 & 9
TURBINE SENSOR	300-600	5 & 13
OUTPUT SENSOR	300-600	14 & 6

**DAEWOO CONNECTOR
NUMBER C110**




Copyright © 2004 ATSG

Figure 4

TRANSMISSION RANGE SWITCH OR GEAR POSITION SENSOR CHECK

VOLVO	PIN/SWITCH COMBINATIONS			
RANGE	PIN 1 (A)	PIN 2 (B)	PIN 3 (C)	PIN 4 (PA)
PARK	CLOSED	OPEN	OPEN	CLOSED
REVERSE	CLOSED	CLOSED	OPEN	OPEN
NEUTRAL	OPEN	CLOSED	OPEN	CLOSED
D	OPEN	CLOSED	CLOSED	OPEN
3	CLOSED	CLOSED	CLOSED	CLOSED
L	CLOSED	OPEN	CLOSED	OPEN


VOLVO CONNECTOR NUMBER 3/71



CONNECT POSITIVE LEAD TO THE SPECIFIED PIN AND THE GROUND LEAD TO THE CASE.
OPEN = O.L. CLOSED = CONTINUITY

SAAB	PIN/SWITCH COMBINATIONS			
RANGE	PIN 1 (A)	PIN 3 (B)	PIN 2 (C)	PIN 4 (PA)
PARK	CLOSED	OPEN	OPEN	CLOSED
REVERSE	CLOSED	CLOSED	OPEN	OPEN
NEUTRAL	OPEN	CLOSED	OPEN	CLOSED
D	OPEN	CLOSED	CLOSED	OPEN
3	CLOSED	CLOSED	CLOSED	CLOSED
2	CLOSED	OPEN	CLOSED	OPEN
1	OPEN	OPEN	CLOSED	CLOSED

SAAB CONNECTOR NUMBER H10-1




CONNECT POSITIVE LEAD TO THE PIN 8 AND THE GROUND LEAD TO THE SPECIFIED PIN
OPEN = O.L. CLOSED = CONTINUITY

DAEWOO

RANGE	PIN 4	PIN 8	PIN 9	PIN 10	PIN 11	PIN 1	PIN 2
PARK	●	●					
REVERSE	●		●				
NEUTRAL	●			●			
D	●				●		
3	●					●	
L	●						●

DAEWOO CONNECTOR



CONNECT POSITIVE LEAD TO PIN 4 AND THE GROUND LEAD TO THE SPECIFIED PIN.
CONTINUITY MUST BE PRESENT BETWEEN THE PINS CONNECTED IN THE CHART ABOVE.

Figure 5

VOLVO TCM WIRE SCHEMATIC

CONNECTOR NUMBER 3/71


TCM CONNECTOR
A

VOLVO TCM

TCM CONNECTOR
B

TCM CONNECTOR
A

TCM CONNECTOR
B



Copyright © 2004 ATSG

Figure 6

AUTOMATIC TRANSMISSION SERVICE GROUP

SAAB TCM WIRE SCHEMATIC

SAAB TCM CONNECTOR




Figure 7




Technical Service Information

DAEWOO TCM WIRE SCHEMATIC

DAEWOO TCM CONNECTOR

1	2		3	4					5	6		7	8	
9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
24	25		26	27	28	29		30	31	32	33		34	35



TCM is located below dash near steering column.

Copyright © 2004 ATSG

Figure 8

AUTOMATIC TRANSMISSION SERVICE GROUP