


# BMW 5-Series

## Service Manual

525i, 530i, 535i, 540i, including Touring  
1989, 1990, 1991, 1992,  
1993, 1994, 1995



Bentley Publishers

Foreword.....	v
Warnings and Cautions.....	vii
Index.....	back of book

## General Data and Maintenance

010	Fundamentals for the Do-it-yourself Owner
020	Maintenance Program

## Engine

100	Engine—General	119	Lubrication System
110	Engine Removal and Installation	120	Ignition System—DME
113	Cylinder Head Removal and Installation	121	Battery, Starter, Alternator
116	Cylinder Head and Valvetrain	130	Fuel Injection—DME
117	Camshaft Timing Chain	160	Fuel Tank and Fuel Pump
118	Camshaft Timing Belt	170	Radiator and Cooling System
		180	Exhaust System

## Transmission

200	Transmission—General	240	Automatic Transmission
210	Clutch	250	Gearshift Linkage
230	Manual Transmission	260	Driveshaft

## Suspension, Steering and Brakes

300	Suspension, Steering and Brakes—General	330	Rear Suspension
310	Front Suspension	331	Final Drive
320	Steering and Wheel Alignment	340	Brakes

## Body

400	Body—General	411	Doors
410	Fenders, Engine Hood	412	Trunklid, Tailgate

## Body Equipment

510	Exterior Trim, Bumpers	515	Central Locking
512	Door Windows	520	Seats
513	Interior Trim	540	Sunroof

## Electrical System

600	Electrical System—General	620	Instruments
610	Fuses and Relays	630	Exterior Lighting
611	Wipers and Washers	640	Heating and Air Conditioning
612	Switches and Electrical Accessories	650	Radio

## Equipment and Accessories

720	Seat Belts
721	Airbag System (SRS)

## Electrical Wiring Diagrams

## Selected Books and Electronic Editions From Bentley Publishers

### Driving

The Unfair Advantage

Mark Donahue

ISBN 0-8376-0073-1 (he); 0-8376-0069-3(pb)

Driving Forces: The Grand Prix Racing World Caught in the Maelstrom of the Third Reich

Peter Stevenson ISBN 0-8376-0217-3

A French Kiss With Death: Steve McQueen and the Making of *Le Mans*

Michael Keyser ISBN 0-8376-0234-3

The Speed Merchants: A Journey Through the World of Motor Racing 1969-1972

Michael Keyser ISBN 0-8376(4)232-7

Going Faster! Mastering the Art of Race Driving

The Skip Murker Racing School

ISBN 0-8376-0227-0

The Racing Driver

Denis Jenkinson ISBN 0-8376-0201-7

Sports Car and Competition Driving

Paul Frere with foreword by Phil Hill

ISBN 0-8376-0202-5

### Engineering

Maximum Boost: Designing, Testing, and Installing Turbocharger Systems

Corky Bell ISBN 0-8376-0160-6

Bosch Fuel Injection and Engine Management

Charles O. Probst, SAL ISBN 0-8376-0300-5

Race Car Aerodynamics

Joseph Katz ISBN 0-8376-0142-8

### Reference

Road & Track Illustrated Automotive Dictionary

John Dinkel ISBN 0-8376-0143-6

### Audi

Audi TT Official Factory Repair Manual MY 2000 Electronic Edition

Audi of America ISBN 0-8376-0758-2

Audi A4/S4 Official Factory Repair Manual 1996-2000 Electronic Edition

Bentley Publishers ISBN 0-8376-0761-2

Audi 80, 90 Coupe, Quattro Official Factory Repair Manual: 1988-1992

Audi of America ISBN 0-8376-0368-4

### BMW

Complete Roundel 1969-1998

8 CD-ROM set: 30 Years of the Magazine of the BMW Car Club of America, Inc.

BMW Car Club of America ISBN 0-8376-0322-6

BMW 3-Series (E30) Service Manual: 1984-1990 318i, 325, 325e(es), 325i(is), and 325i Convertible

Bentley Publishers ISBN 0-8376-0325-0

BMW 3 Series (E36) Service Manual: 1992-1998, 318i/is/iC, 323is/iC, 325i/is/iC, 328i/is/iC, M3

Bentley Publishers ISBN 0-8376-0326-9

BMW 3 Series (E46) Service Manual:

1999-2001, 323i/Ci, 325i/Ci/xi, 328i/Ci, 330i/Ci/xi Sedan, Coupe, Convertible and Sport Wagon

Bentley Publishers ISBN 0-8376-0320-X

BMW 5-Series (E28) Service Manual: 1982-1988 528e, 533i, 535i, 535is

Bentley Publishers ISBN 0-8376-0318-8

BMW 5-Series (E34) Service Manual: 1989-1995 525i, 530i, 535i, 540i, including Touring

Bentley Publishers ISBN 0-8376-0319-6

BMW 7 Series (E32) Service Manual:

1988-1994, 735i, 735iL, 740i, 740iL, 750iL

Bentley Publishers ISBN 0-8376-0328-5

BMW Z3 Roadster Service Manual:

1996-1998, 4- and 6-cylinder engines

Bentley Publishers ISBN 0-8376-0328-5

BMW Enthusiast's Companion™

BMW Car Club of America

ISBN 0-8376-0321-8

BMW 3 Series Enthusiast's

Companion™

Jeremy Walton ISBN 0-8376-0220-3

BMW 6 Series Enthusiast's

Companion™

Jeremy Walton ISBN 0-8376-0149-5

Unbeatable BMW: Eighty Years of

Engineering and Motorsport Success

Jeremy Walton ISBN 0-8376-0206-8

### Chevrolet

Chevrolet by the Numbers 1955-1959:

The Essential Chevrolet Parts Reference

Alan Colvin ISBN 0-8376-0875-9

Chevrolet by the Numbers 1960-1964:

The Essential Chevrolet Parts Reference

Alan Colvin ISBN 0-8376-0936-4

Corvette 427: Practical Restoration of a

'67 Roadster

Don Sherman ISBN 0-8376-0218-1

Corvette Fuel Injection & Electronic

Engine Management: 1982-2001

Charles O. Probst, SAC ISBN 0-8376-0861-9

### Ford

Ford Fuel Injection and Electronic Engine

Control: 1988-1993

Charles O. Probst, SAE ISBN 0-8376-0301-3

The Official Ford Mustang 5.0 Technical

Reference & Performance Handbook

1979-1993

Al Kirschenbaum ISBN 0-8376-0210-6

### Harley-Davidson

Harley-Davidson Evolution V-Twin

Owner's Bible™

Moses Ludel ISBN 0-8376-0146-0

### Honda

Civic Duty: The Ultimate Guide to the

World's Most Popular Sport Compact

Car, the Honda Civic

Alan Paradise ISBN 0-8376-0215-7

### Jeep

Jeep Owner's Bible™

Moses Ludel ISBN 0-8376-0154-1

### Porsche

Porsche 911 Carrera Service Manual:

1984-1989, Coupe, Targa and Cabriolet

Bentley Publishers ISBN 0-8376-0291-2

Porsche 911 SC Service Manual:

1978-1983, Coupe, Targa and Cabriolet

Bentley Publishers ISBN 0-8376-0290-4

### Saab

Saab 900 16 Valve Official Service

Manual: 1985-1993

Bentley Publishers ISBN 0-8376-0312-9

Saab 900 8 Valve Official Service Manual:

1981-1988

Bentley Publishers ISBN 0-8376-0310-2

### Toyota

Toyota Truck & Land Cruiser Owner's

Bible™

Moses Ludel ISBN 0-8376-0159-2

### Volkswagen

Battle for the Beetle: The Story of the Battle

for the Giant VW Factory and the Car that

Became an Icon Around the Globe

Karl Ludvigsen ISBN 08376-0071-5

Volkswagen Sport Tuning for Street and

Competition

Per Schroder ISBN 0-8376-0161-4

Jetta, Golf, GTI Service Manual: 1999-2002

2.0L Gasoline, 1.9L TDI Diesel, 2.8L VR6,

1.8L Turbo

Bentley Publishers ISBN 0-8376-0388-9

Jetta, Golf, GTI, Cabrio Service Manual:

1993-1999, including Jetta<sub>m</sub> and Coif<sub>m</sub>,

Bentley Publishers ISBN 0-8376-0366-8

Passat Official Factory Repair Manual

1998-2000 Electronic Edition

Bentley Publishers ISBN 0-8376-0763-9

### Volvo

Volvo 240 Service Manual: 1983-1993

Bentley Publishers ISBN 0-8376-0285-8



AUTOMOTIVE BOOKS AND MANUALS

Bentley Publishers has published service manuals and automobile books since 1950. Please write Bentley Publishers at 1734 Massachusetts Ave., Cambridge, MA 02138, visit our web site at [www.BentleyPublishers.com](http://www.BentleyPublishers.com), or call 1-800-423-4595 for a free copy of our complete catalog.

# Foreword

This BMW 5-Series Service Manual covers the 1989 through 1995 525i models, the 1989 through 1993 535i models, and the 1994 and 1995 530i and 540i models, and is specifically designed to cover only those models built for sale in the United States.

BMW and most accessories and parts sellers specializing in BMWs refer to the 5-Series covered by this manual as the E34 model. The code "E34" is BMW's internal code for the basic platform shared by all of the cars covered by this manual. Except for the engine and a few other components, the models covered by this manual share many of same components such as suspension parts, body panels, and the interior pieces. When ordering parts, especially body parts, knowing the E34 code may be helpful.

BMW also uses an internal code for the various engines used in the E34 models. The engines used in the 525i models are either M20, M50, or M50TU. The engine used in the 535i is known as the M30. The engine used in the 530i and 540i is known as the M60. This information is primarily used internally by BMW, but may be helpful if you have access to BMW technical information.

For the BMW owner with basic mechanical skills, this manual gives detailed maintenance and repair information. In addition, the BMW owner who has no intention of working on his or her own car will find that owning and reading this manual will make it possible to be better informed and to discuss repairs more intelligently with a professional technician. This manual has been prepared from the repair information that BMW provides to its factory-trained technicians and has been developed primarily with the do-it-yourself BMW owner in mind. The aim throughout has been clarity and understanding with practical functional descriptions, step-by-step procedures, and accurate specifications.

The BMW owner intending to do maintenance and repair should have a set of tools including a set of metric wrenches and sockets, screwdrivers, a torque wrench, and feeler gauges, since these basic tools will be used to do the majority of the maintenance and repair procedures described in this manual. This manual includes detailed information on these basic tools and other tips for the beginner in the first section of the manual, entitled Fundamentals for the Do-It-Yourself Owner. For some of the repairs described in this manual, BMW technicians use special tools. The text will note when a repair requires these special tools and, where possible, will recommend practical alternatives.

We have endeavoured to ensure the highest degree of accuracy possible. When the vast array of data presented in the manual is taken into account, however, no claim to infallibility can be made. We therefore cannot be responsible for the result of any errors that may have crept into the text. The publisher encourages comments from the readers of this manual in regard to any errors and, also, suggestions for improvement in the presentation of technical material. These communications have been and will be carefully considered in the preparation of future printings of this and other manuals. Please write to Robert Bentley, Inc., Cambridge, Massachusetts 02138.

BMW offers extensive warranties, especially on components of the fuel delivery and emissions control systems. Therefore, before deciding to repair a BMW that may still be covered wholly or in part by any warranties issued by BMW of North America, consult your authorized BMW dealer. You may find that he can make the repair either free or at minimum cost.

Regardless of its age and whether or not it is still protected by warranty, your BMW is both an easy car to service and an easy car to get serviced. So if at any time a repair is needed that you feel is too difficult to do yourself, a trained BMW technician is ready to do the job for you. Each authorized BMW dealer service department has made a significant investment in service and diagnostic test equipment, special tools, and BMW original parts. He is also the best source of the most up-to-date repair and service techniques, which includes factory training and technical literature. Servicing your BMW through an authorized BMW dealer will insure that your investment will be protected while maintaining the highest degree of service standards.

**Robert Bentley**

## **Please read these warnings and cautions before proceeding with maintenance and repair work.**

### WARNING—

- Some repairs may be beyond your capability. If you lack the skills, tools and equipment, or a suitable workplace for any procedure described in this manual, we suggest you leave such repairs to an authorized BMW dealer service department, or other qualified shop.
- Do not re-use any fasteners that are worn or deformed in normal use. Many fasteners are designed to be used only once and become unreliable and may fail when used a second time. This includes, but is not limited to, nuts, bolts, washers, self-locking nuts or bolts, circlips and cotter pins. Always replace these fasteners with new parts.
- Never work under a lifted car unless it is solidly supported on stands designed for the purpose. Do not support a car on cinder blocks, hollow tiles or other props that may crumble under continuous load. Never work under a car that is supported solely by a jack. Never work under the car while the engine is running.
- If you are going to work under a car on the ground, make sure that the ground is level. Block the wheels to keep the car from rolling. Disconnect the battery negative (-) terminal (Ground strap) to prevent others from starting the car while you are under it.
- Never run the engine unless the work area is well ventilated. Carbon monoxide kills.
- Finger rings, bracelets and other jewelry should be removed so that they cannot cause electrical shorts, get caught in running machinery, or be crushed by heavy parts.
- Tie long hair behind your head. Do not wear a necktie, a scarf, loose clothing, or a necklace when you work near machine tools or running engines. If your hair, clothing, or jewelry were to get caught in the machinery, severe injury could result.
- Do not attempt to work on your car if you do not feel well. You increase the danger of injury to yourself and others if you are tired, upset or have taken medication or any other substance that may keep you from being fully alert.
- Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the car. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.
- Catch draining fuel, oil, or brake fluid in suitable containers. Do not use food or beverage containers that might mislead someone into drinking from them. Store flammable fluids away from fire hazards. Wipe up spills at once, but do not store the oily rags, which can ignite and burn spontaneously.
- Always observe good workshop practices. Wear goggles when you operate machine tools or work with battery acid. Gloves or other protective clothing should be worn whenever the job requires working with harmful substances.
- Greases, lubricants and other automotive chemicals contain toxic substances, many of which are absorbed directly through the skin. Read manufacturer's instructions and warnings carefully. Use hand and eye protection. Avoid direct skin contact.
- Friction materials such as brake or clutch discs may contain asbestos fibers. Do not create dust by grinding, sanding, or by cleaning with compressed air. Avoid breathing asbestos fibers and asbestos dust. Breathing asbestos can cause serious diseases such as asbestosis or cancer, and may result in death.
- Disconnect the battery negative (-) terminal (Ground strap) whenever you work on the fuel system or the electrical system. Do not smoke or work near heaters or other fire hazards. Keep an approved fire extinguisher handy.
- Batteries give off explosive hydrogen gas during charging. Keep sparks, lighted matches and open flame away from the top of the battery. If hydrogen gas escaping from the cap vents is ignited, it will ignite gas trapped in the cells and cause the battery to explode.
- Connect and disconnect battery cables, jumper cables or a battery charger only with the ignition switched off, to prevent sparks. Do not disconnect the battery while the engine is running.
- Do not quick-charge the battery (for boost starting) for longer than one minute. Wait at least one minute before boosting the battery a second time.
- Do not allow battery charging voltage to exceed 16.5 volts. If the battery begins producing gas or boiling violently, reduce the charging rate. Boosting a sulfated battery at a high charging rate can cause an explosion.
- The air-conditioning system is filled with chemical refrigerant, which is hazardous. The A/C system should be serviced only by trained technicians using approved refrigerant recovery/recycling equipment, trained in related safety precautions, and familiar with regulations governing the discharging and disposal of automotive chemical refrigerants.
- Do not expose any part of the A/C system to high temperatures such as open flame. Excessive heat will increase system pressure and may cause the system to burst.
- Some aerosol tire inflators are highly flammable. Be extremely cautious when repairing a tire that may have been inflated using an aerosol tire inflator. Keep sparks, open flame or other sources of ignition away from the tire repair area. Inflate and deflate the tire at least four times before breaking the bead from the rim. Completely remove the tire from the rim before attempting any repair.
- Some cars covered by this manual are equipped with a supplemental restraint system (SRS), that automatically deploys an airbag in the event of a frontal impact. The airbag is inflated by an explosive device. Handled improperly or without adequate safeguards, it can be accidentally activated and cause serious injury.
- On cars equipped with anti-lock brakes (ABS), the ABS modular assembly is capable of "self-pressuring" up to 210 bar (3045 psi). Serious injury may result if the unit is not properly depressurized before servicing the system.

**continued on next page**

## **Please read these warnings and cautions before proceeding with maintenance and repair work.**

### CAUTION—

- If you lack the skills, tools and equipment, or a suitable workshop for any procedure described in this manual, we suggest you leave such repairs to an authorized BMW dealer or other qualified shop.
- BMW is constantly improving its cars and sometimes these changes, both in parts and specifications, are made applicable to earlier models. Therefore, part numbers listed in this manual are for reference only. Always check with your authorized BMW dealer parts department for the latest information.
- Before starting a job, make certain that you have all the necessary tools and parts on hand. Read all the instructions thoroughly, do not attempt shortcuts. Use tools appropriate to the work and use only replacement parts meeting BMW specifications. Make-shift tools, parts and procedures will not make good repairs.
- Use pneumatic and electric tools only to loosen threaded parts and fasteners. Never use these tools to tighten fasteners, especially on light alloy parts. Always use a torque wrench to tighten fasteners to the tightening torque specification listed.
- Be mindful of the environment and ecology. Before you drain the crankcase, find out the proper way to dispose of the oil. Do not pour oil onto the ground, down a drain, or into a stream, pond or lake. Consult local ordinances that govern the disposal of wastes.
- On cars equipped with the anti-lock brakes (ABS), the ABS control unit cannot withstand temperatures from a paint-drying booth or a heat lamp in excess of 203°F (95°C) and should not be subjected to temperatures in excess of 185°F (85°C) for more than two hours.
- Before doing any electrical welding on cars equipped with ABS, disconnect the battery negative (-) terminal (Ground strap) and the ABS control unit connector.
- On cars equipped with anti-theft radios, make sure you know the correct radio activation code before disconnecting the battery or removing the radio. If the wrong code is entered into the radio when power is restored, that radio may lock up and be rendered inoperable, even if the correct code is then entered.
- Connect and disconnect a battery charger only with the battery charger switched off.
- Do not quick-charge the battery (for boost starting) for longer than one minute. Wait at least one minute before boosting the battery a second time.
- Sealed or "maintenance free" batteries should be slow-charged only, at an amperage rate that is approximately 10% of the battery's ampere-hour (Ah) rating.
- Do not allow battery charging voltage to exceed 16.5 volts. If the battery begins producing gas or boiling violently, reduce the charging rate. Boosting a sulfated battery at a high charging rate can cause an explosion.

## 010 FUNDAMENTALS FOR THE DO-IT-YOURSELF OWNER

GENERAL	010-1	TOOLS	010-7
HOW TO USE THIS MANUAL	010-2	Basic Tool Requirements	010-8
Warnings, Cautions and Notes	010-2	Jack Stands	010-9
GETTING STARTED	010-2	Oil Change Equipment	010-10
Safety	010-2	Torque Wrench	010-10
Lifting the Car	010-3	Feeler Gauges	010-10
To raise car safely	010-3	Volt-Ohm Meter (VOM) or Multimeter	010-11
To work safely under car	010-4	BMW Special Tools	010-11
ADVICE FOR THE BEGINNER	010-4	EMERGENCIES	010-11
Planning Ahead	010-4	Changing a Tire	010-11
Cleanliness	010-4	Car Will Not Start	010-12
Non-reusable Fasteners	010-4	Jump Starting	010-12
Tightening Fasteners	010-4	To jump start car	010-12
Gaskets and Seals	010-5	Overheating	010-13
Electrical Testing	010-5	Low Oil Pressure	010-13
Wire Repairs	010-6	Brake Fluid Level	010-13
BUYING PARTS	010-6	Check Engine Warning Light	010-13
Genuine BMW Parts	010-6	Dim Lights	010-13
Non-returnable Parts	010-6	Towing	010-14
Information You Need To Know	010-7	Spare Parts Kit	010-14
SERVICE	010-7		

### TABLES

a. General Bolt Tightening Torques in Nm (max. permissible)	010-5
---	-------

### GENERAL

Although the BMW is a sophisticated and complex machine, basic maintenance can be accomplished by an interested owner with mechanical skills and the right information. Most of the preventive maintenance that is required in the lifetime of the average BMW is well within the capabilities of the do-it-yourselfer.

#### WARNING —

*Do not use this manual unless you are familiar with basic automotive repair procedures and safe workshop practices. This manual illustrates the workshop procedures required for most service work; it is not a substitute for full and up-to-date information from the vehicle manufacturer or for proper training as an automotive technician. Note that it is not possible for us to anticipate all of the ways or conditions under which vehicles may be serviced or to provide cautions as to all of the possible hazards that may result.*

#### WARNING —

*Your common sense and good judgment are crucial to safe and successful service work. Read procedures through before starting them. Think about whether the condition of your car, your level of mechanical skill, or your level of reading comprehension might result in or contribute in some way to an occurrence that might cause you injury, damage your car, or result in an unsafe repair. If you have doubts for these or other reasons about your ability to perform safe repair work on your car, have the work done at an authorized BMW dealer or other qualified shop.*

This section of the manual is intended to help the beginner get started. To begin with there is a discussion on **How To Use This Manual**. Tips on mechanic's skills and workshop practices that can help the beginner do a faster and more thorough job can be found under **Getting Started**. The basic tools needed to do most of the procedures in this manual are found under **Tools**. The section ends with a quick reference guide to **Emergencies**, including basic troubleshooting and information on how to gauge the seriousness of a problem.

GENERAL



## 010-2 FUNDAMENTALS FOR THE DO-IT-YOURSELF OWNER

### HOW TO USE THIS MANUAL

The manual is divided into nine sections:

- 0 GENERAL DATA AND MAINTENANCE
- 1 ENGINE
- 2 TRANSMISSION
- 3 SUSPENSION, STEERING AND BRAKES
- 4 BODY
- 5 BODY EQUIPMENT
- 6 ELECTRICAL SYSTEM
- 7 EQUIPMENT AND ACCESSORIES
- ELECTRICAL WIRING DIAGRAMS

**0 GENERAL DATA AND MAINTENANCE** covers the recommended maintenance schedules and service procedures needed to do BMW scheduled maintenance work. Also within this section is the **010 Fundamentals for the Do-it-yourself Owner** section, which contains basic instructions, tips and helpful hints for do-it-yourself maintenance and repair.

The next seven sections (1 through 7) are repair based and are further broken down into three digit repair groups. Each major section begins with a **General** repair group, e.g. **100 Engine—General**. These "00" (double zero) groups are mostly descriptive in nature, covering topics such as theory of operation and troubleshooting. The remainder of the repair groups contain the more involved repair information. The last major section contains detailed electrical wiring diagram schematics.

A master listing of the 9 major sections and the corresponding individual repair groups can be found on the inside front cover.

Each repair group begins with a Table of Contents listing the major subject headings within the group. Page numbers throughout the manual are organized according to the repair group system. For example, you can expect to find repair information on brakes (Repair Group 340) beginning on page 340-1. A comprehensive index can be found at the back of the manual.

### Warnings, Cautions and Notes

Throughout this manual are many passages with the headings **WARNING**, **CAUTION**, or **NOTE**. These very important headings have different meanings.

#### WARNING —

*The text under this heading warns of unsafe practices that are very likely to cause injury, either by direct threat to the person(s) doing the work or by increased risk of accident or mechanical failure while driving.*

#### CAUTION —

*A caution calls attention to important precautions to be observed during the repair work that will help prevent accidentally damaging the car or its parts.*

#### NOTE —

*A note contains helpful information, tips that will help in doing a better job and completing it more easily.*

Please read every **WARNING**, **CAUTION**, and **NOTE** at the front of the manual and as they appear in repair procedures. They are very important. Read them before you begin any maintenance or repair job.

Some **WARNINGS** and **CAUTIONS** are repeated wherever they apply. Read them all. Do not skip any. These messages are important, even to the owner who never intends to work on the car.

### GETTING STARTED

Most of the necessary maintenance and minor repair that an automobile will need can be done with ordinary tools, even by owners with little or no experience in car repair. Below is some important information on how to work safely, a discussion of what tools will be needed and how to use them, and a series of mechanic's tips on methods and workmanship.

### Safety

Although an automobile presents many hazards, common sense and good equipment can help ensure safety. Many accidents happen because of carelessness. Pay attention and stick to these few important safety rules.

#### WARNING —

- *Never run the engine in the work area unless it is well-ventilated. The exhaust should be vented to the outside. Carbon Monoxide (CO) in the exhaust kills.*
- *Remove all neckties, scarfs, loose clothing, or jewelry when working near running engines or power tools. Tuck in shirts. Tie long hair and secure it under a cap. Severe injury can result from these things being caught in rotating parts.*
- *Remove rings, watches, and bracelets. Aside from the dangers of moving parts, metallic jewelry conducts electricity and may cause shorts, sparks, burns, or damage to the electrical system when accidentally contacting the battery or other electrical terminals.*
- *Disconnect the battery negative (-) cable whenever working on or near the fuel system or anything that is electrically powered. Accidental electrical contact may damage the electrical system or cause a fire.*

### GETTING STARTED

WARNING —


- Never work under a lifted car unless it is solidly supported on jack stands that are intended for that purpose. Do not support a car on cinder blocks, bricks, or other objects that may shift or crumble under continuous load. Never work under a car that is supported only by the lifting jack.
- Fuel is highly flammable. When working around fuel, do not smoke or work near heaters or other fire hazards. Keep an approved fire extinguisher handy.
- Illuminate the work area adequately and safely. Use a portable safety light for working inside or under the car. A fluorescent type light is best because it gives off less heat. If using a light with a normal incandescent bulb, use rough service bulbs to avoid breakage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.
- Keep sparks, lighted matches, and any open flame away from the top of the battery. Hydrogen gas emitted by the battery is highly flammable. Any nearby source of ignition may cause the battery to explode.
- Never lay tools or parts in the engine compartment or on top of the battery. They may fall into confined spaces and be difficult to retrieve, become caught in belts or other rotating parts when the engine is started, or cause electrical shorts and damage to the electrical system.
- The fuel system is designed to retain pressure even when the ignition is off. When working with the fuel system, loosen the fuel lines slowly to allow the residual pressure to dissipate gradually. Take precautions to avoid spraying fuel.

### Lifting the Car

For those repairs that require raising the car, the proper jacking points should be used to raise the car safely and avoid damage. There are four jacking points from which the car can be safely raised. The jack supplied with the car by BMW can only be used at the four side points—just behind the front wheel or just in front of the rear wheel. See Fig. 1.

WARNING —

- When raising the car using a floor jack or a hydraulic lift, carefully position the jack pad to prevent damaging the car body. A suitable liner (wood, rubber, etc.) should be placed between the jack and the car to prevent body damage.
- Watch the jack closely. Make sure it stays stable and does not shift or tilt. As the car is raised, the car may roll slightly and the jack may shift.



B348.FUN.B

Fig. 1. BMW jacking points (arrows).

### To raise car safely

1. Park the car on a flat, level surface.
2. Place the jack in position. See Fig. 2. Make sure the jack is resting on flat, solid ground. Use a board or other support to provide a firm surface for the jack, if necessary.



B11038  
B11038

Fig. 2. BMW supplied jack correctly positioned under front jacking point.

3. Raise the car slowly while constantly checking the position of the jack and the car.
4. Once the car is raised, block the wheel that is opposite and farthest from the jack to prevent the car from unexpectedly rolling.

## 010-4 FUNDAMENTALS FOR THE DO-IT-YOURSELF OWNER

### WARNING —

- Do not rely on the transmission or the emergency brake to keep the car from rolling. They are not a substitute for positively blocking the opposite wheel.
- Never work under a car that is supported only by a jack. Use jack stands that are properly designed to support the car. See **Tools**.

### To work safely under car

1. Disconnect the battery negative (-) cable so that no one else can start the car. Let others know what you will be doing.
2. Raise the car slowly as described above.
3. Use at least two jack stands to support the car. A jack is a temporary lifting device and should not be used alone to support the car while you are under it. Use jack stands designed for the purpose of supporting a car. For more information on jack stands, see **Tools** below.

### WARNING —

Do not use wood, concrete blocks, or bricks to support a car. Wood may split. Blocks or bricks, while strong, are not designed for that kind of load, and may break or collapse.

4. Place the jack stands on a firm, solid surface. If necessary, use a flat board or similar solid object to provide a firm footing.
5. Lower the car slowly until its weight is fully supported by the jack stands. Watch to make sure that the jack stands do not tip or lean as the car settles on them.
6. Observe all jacking precautions again when raising the car to remove the jack stands.

### ADVICE FOR THE BEGINNER

The tips in the paragraphs that follow are general advice to help any do-it-yourself BMW owner perform repairs and maintenance tasks more easily and more professionally.

### Planning Ahead

Most of the repairs and maintenance tasks described in this manual can be successfully completed by anyone with basic tools and abilities. Some cannot. To prevent getting in too deep, know what the whole job requires before starting. Read the procedure thoroughly, from beginning to end, in order to know just what to expect and what parts will have to be replaced.

### ADVICE FOR THE BEGINNER

### Cleanliness

Keeping things organized, neat, and clean is essential to doing a good job. When working under the hood, fender covers will protect the finish from scratches and other damage. Make sure the car is relatively clean so that dirt under the cover does not scratch the finish.

Any repair job will be less troublesome if the parts are clean. For cleaning old parts, many solvents and parts cleaners are available commercially.

For cleaning parts prior to assembly, commercially available aerosol cans of carburetor cleaner or brake cleaner are handy to use, and the cleaner will evaporate completely.

### WARNING —

Virtually all solvents used for cleaning parts are highly flammable, especially in aerosol form. Use with extreme care. Do not smoke. Do not use these products near any source of sparks or flame.

Let any solvent or cleaning product dry completely. Low-pressure, dry compressed air is helpful if available. Also, use only lint-free rags for cleaning and drying.

### WARNING —

Avoid getting tools or clothing near the battery. Battery electrolyte is a corrosive acid. Be careful with brake fluid, as it can damage the car's paint. Finally, keep rubber parts such as hoses and belts free from oil or gasoline, as they will cause the material to soften and fail prematurely.

### Non-reusable Fasteners

Many fasteners used on the cars covered by this manual must be replaced with new ones once they are removed. These include but are not limited to: bolts, nuts (self-locking, nylock, etc.), cotter pins, studs, brake fittings, roll pins, clips, and washers. Genuine BMW parts should be the only replacement parts used for this purpose.

Some bolts are designed to stretch during assembly and are permanently altered, rendering them unusable again. Always replace fasteners where instructed to do so. See an authorized BMW dealer for applications and ordering information.


### Tightening Fasteners

When tightening the bolts or nuts that attach a component, it is always good practice to tighten the bolts gradually and evenly to avoid misalignment or over stressing any one portion of the component. For components sealed with gaskets, this method helps to ensure that the gasket will seal properly and completely.

## 010-4 FUNDAMENTALS FOR THE DO-IT-YOURSELF OWNER

Where there are several fasteners, tighten them in a sequence alternating between opposite sides of the component. Fig. 3 shows such a sequence for tightening six bolts attaching a typical component. Repeat the sequence until all the bolts are evenly tightened to the proper specification.

For some repairs a specific tightening sequence is necessary, or a particular order of assembly is required. Such special conditions are noted in the text, and the necessary sequence is described or illustrated. Where no specific torque is listed, **Table a** can be used as a general guide for tightening fasteners.



EDIFNG  
B001.FNG

Fig. 3. General sequence for alternately tightening multiple fasteners.

### WARNING —

Table a is a general reference only. The values listed in the table are not intended to be used as a substitute for torques specifically called out in the text throughout this manual.

### NOTE —

- Metric bolt classes or grades are marked on the bolt head.
- Do not confuse wrench size with bolt diameter size. For a listing of the common wrenches used on various bolt diameters, see Basic Tool Requirements.

Table a. General Bolt Tightening Torques in Nm (max. permissible)

Bolt diameter	Bolt Class (according to DIN 267)					
	5.6	5.8	6.8	8.8	10.9	12.9
M5	2.5	3.5	4.5	6	8	10
M6	4.5	6	7.5	10	14	17
M8	11	15	18	24	34	40
M10	23	30	36	47	66	79
M12	39	52	62	82	115	140
M14	62	82	98	130	180	220
M16	94	126	150	200	280	340
M18	130	174	210	280	390	470

## Gaskets and Seals

The smoothest metal mating surfaces still have imperfections that can allow leakage. To prevent leakage at critical joints, gaskets of soft, form-fitting material are used to fill in the imperfections.

To be most effective, gaskets are designed to crush and become thinner as the mating parts are bolted together. Once a gasket has been used, it is no longer capable of making as good a seal as when new, and is much more likely to leak. For this reason, gaskets should not be reused. Always plan to use new gaskets for any reassembly. Some gaskets—such as headgaskets—are directional. Make sure that these are installed correctly. This same logic applies to any part used for sealing, including rubber O-rings and copper sealing washers.

In places where a shaft must pass through a housing, flexible lip seals are used to keep the lubricating oil or grease from leaking out past the rotating shaft. Seals should never be reused once they have been removed. When removing a seal, be careful not to scratch or otherwise damage the metal surfaces. Even minor damage to sealing surfaces can cause seal damage and leakage.

The key to seal installation is to get the seal in straight without damaging it. Use an object that is the same diameter as the seal housing to gently and evenly drive it into place. If a proper size seal driver is not available, a socket of the right size will do.

When installing a seal, coat the entire seal with oil to help it go in more easily. Seals are directional. Make sure that it is installed with the lip facing the correct way. Normally the lip faces the inside. Note the installation direction of the old seal before removing it.

## Electrical Testing

A great many electrical problems can be understood and solved with only a little fundamental knowledge of how electrical circuits function.

Electric current only flows in a complete circuit. To operate, every electrical device in the car requires a complete circuit including a voltage source and a path to ground. The positive (+) side of the battery is the original voltage source, and ground is any return path to the negative (-) side of the battery, whether through the wiring harness or the car body. Except for portions of the charging system, all electrical current in the car is direct current (DC) and flows from positive (+) to negative (-).

Switches are used to turn components on or off by completing or interrupting the circuit. A switch is "open" when the circuit is interrupted, and "closed" when the circuit is completed. Fig. 4 shows a complete circuit schematically. See **600 Electrical System—General** for electrical troubleshooting.

ADVICE FOR THE BEGINNER




Fig. 4. Schematic representation of simple circuit for light bulb. Switch is shown closed, making circuit complete.

## Wire Repairs

Repairs to a wiring harness deserve special care to make the repair permanent. The wire ends must be clean. If frayed or otherwise damaged, cut off the end. If the wire is too short, splice in a new piece of wire of the same size and make two connections.

Use connectors that are designed for the purpose. Crimped-on or soldered-on connectors are best. Crimp connectors and special crimping pliers are widely available. If soldering, use a needlenose pliers to hold the wire near the solder joint and create a "heat dam". This keeps the heat and the solder from traveling up the wire. Always use a solder made specifically for electrical work (rosin core).

*NOTE —*

*Twisting wires together is only a temporary repair, since corrosion and vibration will eventually spoil the connection.*

Insulate the finished connection. Electronics stores can supply heat-shrinkable insulating tubing that can be placed onto the wire before connecting, slid over the finished joint, and shrunk to a tight fit with a heat gun or hair dryer. The next best alternative is electrical tape. Make sure the wire is clean and free of solder flux or other contamination. Wrap the joint tightly to seal out moisture.

## BUYING PARTS

### BUYING PARTS

Many of the maintenance and repair tasks in this manual call for the installation of new parts, or the use of new gaskets and other materials when reinstalling parts. Most often, the parts that will be needed should be on hand before beginning the job. Read the introductory text and the complete procedure to determine which parts will be needed.

*NOTE —*

*For some bigger jobs, partial disassembly and inspection are required to determine a complete parts list. Read the procedure carefully and, if necessary, make other arrangements to get the necessary parts while your car is disassembled.*

### Genuine BMW Parts

Genuine BMW replacement parts from an authorized BMW dealer are designed and manufactured to the same high standards as the original parts. They will be the correct material, manufactured to the same specifications, and guaranteed to fit and work as intended by the engineers who designed the car. Some genuine BMW parts have a limited warranty.

Many independent repair shops make a point of using genuine BMW parts, even though they may at times be more expensive. They know the value of doing the job right with the right parts. Parts from other sources can be as good, particularly if manufactured by one of BMW's original equipment suppliers, but it is often difficult to know.

BMW is constantly updating and improving their cars, often making improvements during a given model year. BMW may recommend a newer, improved part as a replacement, and your authorized dealer's parts department will know about it and provide it. The BMW parts organization is best equipped to deal with any BMW parts needs.

### Non-returnable Parts

Some parts cannot be returned for credit, even if they are the wrong parts for the car. The best example is electrical parts, which are almost universally considered non-returnable because they are so easily damaged internally.

Buy electrical parts carefully, and be as sure as possible that a replacement is needed, especially for expensive parts such as electronic control units. It may be wise to let an authorized BMW dealer or other qualified shop confirm your diagnosis before replacing an expensive part that cannot be returned.

## 010-10 FUNDAMENTALS FOR THE DO-IT-YOURSELF OWNER


### Information You Need To Know

**Model.** When ordering parts it is important that you know the correct model designation for your car. Models covered in this manual are 525i, 530i, 535i, and 540i, including Touring models.

**Model Year.** This is not necessarily the same as date of manufacture or date of sale. A 1989 model may have been manufactured in late 1988, and perhaps not sold until early 1990. It is still a 1989 model. Model years covered by this manual are 1989 through 1995.

**Date of Manufacture.** This information is helpful when ordering replacement parts or determining if any of the warranty recalls are applicable to your car. The label on the driver's door below the door latch will specify the month and year that the car was built.

**Vehicle Identification Number (VIN).** This is a combination of letters and numbers that identify the particular car. The VIN appears on the state registration document, and on the car itself. One location, shown in Fig. 5, is in the rear of the engine compartment, below the passenger side wiper arm.



B11039

Fig. 5. Location of vehicle identification number (VIN) in rear of engine compartment (arrow).

The National Highway Traffic Safety Administration (NHTSA) requires passenger cars with a high theft rate to have the VIN marked on specific parts of the car when manufactured. On BMW cars, these parts are identified by an adhesive label.

Original parts are identified by a label bearing the VIN and two BMW roundel logos. Replacement parts have a similar label, bearing one BMW roundel logo and the letters DOT-R. See Fig. 6. Parts or assemblies bearing the label are the engine, transmission, front and rear bumpers, front fenders, rear quarter panels, hood, trunk lid and doors. These labels should not be removed as they will tear apart.

§) WBADK000000000000 @  
0 000 000

® 1DO'T-R

B328-FUN.B  
B328.FUN.B

Fig. 6. Labels used to identify parts. Original equipment label with VIN number and roundel logos (top) and replacement part label with one roundel logo.

**Engine.** BMWs covered in this manual are powered by various 6- and 8-cylinder engines. For information on engine codes and engine application, see **100 Engine—General**.

**Transmission.** The transmission type with its identifying code may be important when buying clutch parts, seals, gaskets, and other transmission-related parts. For information on transmission codes and applications, see **200 Transmission—General**.

### SERVICE

BMW dealers are uniquely qualified to provide service for BMW cars. Their authorized relationship with the large BMW service organization means that they are constantly receiving new tools and equipment, together with the latest and most accurate repair information.

The BMW dealer's service technicians are highly trained and very capable. Unlike most independent repair shops, authorized BMW dealers are intensely committed to supporting the BMW product. They share the owner's interest in BMW value, performance, and reliability. On the other hand, there are many independent shops that specialize in BMW service and are capable of doing high quality repair work. Checking with other BMW owners for recommendations on service facilities is a good way to learn of reputable BMW shops in your area.

### TOOLS

Most maintenance can be accomplished with a small selection of the right tools. Tools range in quality from inexpensive junk, which may break at first use, to very expensive and well-made tools for the professional. The best tools for most do-it-yourself BMW owners lie somewhere in between.

TOOLS

## 010-10 FUNDAMENTALS FOR THE DO-IT-YOURSELF OWNER

Many reputable tool manufacturers offer good quality, moderately priced tools with a lifetime guarantee. A broken tool can be exchanged for a new one, for the life of the tool. These are your best buy. They cost a little more, but they are good quality tools that will do what is expected of them. Sears' Craftsman® line is one such source of good quality, reasonably priced, and guaranteed tools.

Some of the repairs covered in this manual require the use of special tools, such as a custom puller or specialized electrical test equipment. These special tools are called out in text and can be purchased through an authorized BMW dealer. As an alternative, some special tools mentioned may be purchased from the following tool manufacturers and/or distributors:

- Assenmacher Specialty Tools  
6440 Odell Place. Boulder. CO 80301  
(303) 530-2424
- Baum Tools Unltd. Inc.  
P.O. Box 87. Longboat Key, FL 34228  
(800) 848-6657
- Schley Products Inc.  
5350 E. Hunter Ave., Anaheim Hills, CA 92807  
(714) 693-7666
- Zelenda Machine and Tool Corp.  
66-02 Austin Street, Forest Hills, NY 11375  
(718) 896-2288

### Basic Tool Requirements

The basic hand tools described below can be used to accomplish most of the simple maintenance and repair tasks.

**Screwdrivers.** The common flat-blade type and the Phillips type will handle almost all screws used on BMWs. Two or three different sizes of each type will be best, since a screwdriver of the wrong size will damage the screw head. See Fig. 7.

A complete set of screwdrivers should also include Torx " type screwdrivers.

**Wrenches.** Wrenches come in different styles for different uses. Fig. 8 shows several. The basic open-end wrench is the most widely used, but grips on only two sides. It can spread apart and slip off more easily. The box-end wrench has better grip, on all six sides of a nut or bolt.

A 12-point box-end can loosen a nut or bolt where there is less room for movement, while a 6-point box-end provides better grip. For hex fasteners on fluid lines, like brake lines and fuel lines, a flare-nut wrench offers the advantages of a box-end wrench with a slot that allows it to fit over the line.

The combination wrench is the most universal. It has one open-end and one box-end. 10mm and 13mm wrenches are the most common sizes needed. A more complete set of wrenches would include 6mm through 19mm sizes.




Fig. 7. Common flat-blade (top) and Phillips (bottom) screwdrivers. Offset screwdriver (right) is used for screws with limited access.




Fig. 8. Types of wrench heads. From left, open-end, 12-point box-end, 6-point box-end, flare nut.

**Sockets.** Sockets perform the same job as box-end wrenches, but offer greater flexibility. They are used with a ratchet handle for speed and convenience and can be combined with extensions and universal joints (swivels) to reach fasteners more easily. Sockets come with different size connections to drive handles or extensions, called the drive size. The most common drive sizes are 1/4 in., 3/8 in., and 1/2 in.


Sockets come in 6-point and 12-point styles. For use with a ratchet, the 6-point offers a better grip on tight nuts and bolts. 6mm to 19mm sockets are the most needed sizes. Below is a list of typical bolt diameters and the corresponding wrench sizes.

## 010-10 FUNDAMENTALS FOR THE DO-IT-YOURSELF OWNER

### Bolt Diameter and Wrench Size

- M5 .....8mm
- M6 .....10mm
- M8 .....12mm or 13mm
- M10 .....17mm
- M12 .....19mm
- M14 .....22mm


**Spark Plug Socket.** A special socket for spark plugs is the correct size, is deep enough to accommodate a spark plug's length, and includes a rubber insert to both protect the spark plug from damage and grip it for easier removal. On all engines except M50 engines, use a  $\frac{13}{16}$  in. socket. On the multi-valve M50 engine, use a  $\frac{5}{8}$  in. socket. See Fig. 9.



B003FNG  
B003FNG

Fig. 9. Spark plug socket.

**Pliers.** A few of the many types of pliers are shown in Fig. 10. Most are used for holding irregular objects, bending, or crimping. Some have special applications.




B006FNG  
B006.FNG

Fig. 10. Pliers. From left, snap-ring, needlenose, adjustable-joint (Channel-lock\*), slip-joint, and locking (Vise-Grip®).

A needlenose plier is used for gripping small and poorly accessible objects, and is useful for wiring and other electrical work. A locking plier such as the Vise-Grip® is useful because of its tight grip.

Snap-ring and circlip pliers with special tipped jaws are used to remove and install snap-rings or circlips. A Channel-lock" or water pump plier has adjustable jaws that can be quickly changed to match the size of the object being held to give greater leverage.

An adjustable wrench can be a useful addition to a small tool kit. See Fig. 11. It can substitute in a pinch, if two wrenches of the same size are needed to remove a nut and bolt. Use extra care with adjustable wrenches, as they tend to loosen, slip, and damage fasteners.



B008FNG  
B008FNG

Fig. 11. Adjustable wrench.

Compared to a wrench of the correct size, an adjustable wrench is always second best. They should only be used when the correct size wrench is not available. Choose one of average size range, about 6 to 8 inches in length.

### Jack Stands


Strong jack stands are extremely important for any work that is done under the car. Jacks are designed only for short term use and are not solid enough to support the car for a long period. A jack should never be used alone to support the car while working underneath.

Use only jack stands that are designed for the purpose. Blocks of wood, concrete, bricks, etc. are not safe or suitable substitutes.

Jack stands are available in several styles. A typical jack stand is shown in Fig. 12. The best ones are made of heavy material for strength, have a wide base for stability, and are equipped to positively lock in their raised positions. Get the best ones available.



## 010-10 FUNDAMENTALS FOR THE DO-IT-YOURSELF OWNER




B021FNG  
B021FNG

Fig. 12. Jack stand for safely supporting car to work underneath.

### Oil Change Equipment

Changing engine oil requires a 17mm socket to loosen and tighten the drain plug, a drain pan (at least 8 qt. capacity), and an oil filter wrench. These items are shown in Fig. 13. A wide, low drain pan will fit more easily under the car. Use a funnel to pour the new oil into the engine.




B022FNG  
B022FNG

Fig. 13. Oil change equipment includes drain plug wrench (17mm), 8 qt. drain pan, oil filter wrench, and funnel.

### Torque Wrench

A torque wrench is used to precisely tighten threaded fasteners to a predetermined value. Nearly all of the repair procedures in this manual include BMW-specified torque values in Newton-meters (Nm) and the equivalent values in foot-pounds (ft-lb).

Several types of torque wrenches are widely available. They all do the same job, but offer different convenience features at different prices. Two typical torque wrenches are shown in Fig. 14. The most convenient ones have a built-in ratchet, and can be preset to indicate when a specific torque value has been reached. Follow the wrench manufacturer's directions for use to achieve the greatest accuracy.




B018FNG  
B018FNG

Fig. 14. Torque wrenches. Inexpensive beam-type (top) is adequate but must be read visually. Ratchet-type (bottom) can be preset to indicate when torque value has been reached.

A torque wrench with a range up to about 150 Nm (185 ft-lb) has adequate capacity for most of the repairs covered in this manual. For recommended torque values of 10 Nm or below, the English system equivalent is given in inch-pounds (in-lb). These small values may be most easily reached using a torque wrench calibrated in inch-pounds. To convert inch-pounds to foot-pounds, divide by 12.

### Feeler Gauges

Feeler gauges are thin metal strips of precise thickness, used to measure small clearances. They are normally available as a set, covering a range of sizes.



B020FNG

Fig. 15. Feeler gauge set, used for precise measurement jobs, such as checking valve clearances.

### Volt-Ohm Meter (VOM) or Multimeter

Many of the electrical tests in this manual call for the measurement of resistance (ohms) or voltage values. For safe and accurate tests of ignition, fuel injection, and emission control systems, the multimeter, shown in Fig. 16, should be digital, with high (at least 10,000 ohms) input impedance. Some meters have automotive functions such as dwell and pulse width that are useful for troubleshooting ignition and fuel injection problems.



B019FNG

B019FNG

Fig. 16. Multimeter or Digital Volt/Ohmmeter (DVOM).

**CAUTION** —

*The DME system, central body electronics, and other electronic systems may be damaged by the high current draw of a test light with a normal incandescent bulb. As a general rule, use a high impedance digital multimeter or an LED test light for all electrical testing.*

### BMW Special Tools

Some of the more challenging repairs covered in this manual call for the use of BMW special tools. This, however, does not automatically mean that the job is too complicated or out of reach of the novice.

Many of the BMW special tools mentioned in this manual are simply the best thing to use to do the job correctly. In these cases, the tool is identified with a BMW part number. See your authorized BMW dealer parts department for information on how to order special tools.

There are some jobs for which expensive special tools are essential, and not a cost-effective purchase for one-time repair by the do-it-yourself owner. This manual includes such repairs for the benefit of those with the necessary experience and access to tools. For the do-it-yourselfer, the need for special tools is noted in the text, and whether or not BMW dealer service is recommended.

## EMERGENCIES

### Changing a Tire

If a tire goes flat while driving, pull well off the road. Changing a tire on a busy street or highway is very dangerous. If necessary, drive a short distance on the flat tire to get to a safe place. It is much better to ruin a tire or rim than to risk being hit.

Stop the car on as flat a surface as possible, in a place where you can be easily seen by other drivers. Avoid stopping just over the crest of a hill. Turn on the emergency flashers, and set out flares or emergency markers well behind the car. Passengers should get out of the car and stand well away from the road. Take the jack, tools, and spare wheel from the trunk. Chock the wheel diagonally opposite to the one being changed.

Loosen the wheel bolts while the car is on the ground, but leave them a little snug. Place the jack under the lifting point nearest the wheel being changed (lifting points are shown in Fig. 1). Use a board to provide a firm footing for the jack if the ground is soft. Raise the car only far enough so that the wheel is off the ground, and then remove the wheel nuts and the wheel.

Install the spare wheel. Install the wheel nuts and tighten them by hand, then lower the car. With all wheels on the ground, fully tighten the nuts in a crisscross pattern. Torque the wheel nuts when installing the wheel. Check the inflation pressure of the spare tire.

#### Tightening Torques

- Wheel bolts to wheel hub. . . . . 100 ± 10 Nm (74 ± 7 ft-lb)

## FUNDAMENTALS FOR THE DO-IT-YOURSELF OWNER 010-11

### Car Will Not Start

If the engine turns over slowly or not at all, especially on cold mornings, the battery may not be sufficiently charged. Jump-starting the battery from another car may help.

#### WARNING —

*On cars with manual transmission, push starting (or tow starting) a car is not recommended by BMW.*

#### NOTE —

*Be sure to read the cautions under Jump Starting prior to boosting a low battery. Failure to follow the cautions may result in damage to the electronic components in the car.*

If the engine is turning over at normal speed with the starter motor, the battery and starter are fine. Check to make sure that there is fuel in the tank. Do not rely on the fuel gauge, it may be faulty. Instead, remove the gas filler cap and rock the car. If there is gas in the tank, you should hear a sloshing sound at the filler neck. If there is plenty of fuel in the tank, see **100 Engine—General** for in-depth diagnostics and troubleshooting procedures.

### Jump Starting

Cars with discharged or dead batteries can be jump-started using the good battery from another car. When jump-starting the engine, always heed the following warnings.

#### WARNING —

*Battery acid (electrolyte) can cause severe burns, and will damage the car and clothing. If electrolyte is spilled, wash the surface with large quantities of water. Hit gets into eyes, flush them with water for several minutes and call a doctor.*

- *Batteries produce explosive and noxious gases. Keep sparks and flames away. Do not smoke near batteries.*
- *Do not jump-start the engine if you suspect that the battery is frozen. Trapped gas may explode. Allow the battery to thaw first.*
- *Do not quick-charge the battery (for boost starting) for longer than one minute, and do not exceed 15 volts at the battery with the boosting cables attached. Wait at least one minute before boosting the battery a second time.*

### EMERGENCIES

### To jump start car

1. Place the cars close together, but do not allow them to touch each other. Turn off the engine of the car with the good battery.
2. Connect one end of the positive (+) cable to the positive (+) post of the good battery. Remove the cover from the positive (B+) junction post in the engine compartment and connect the other end of the positive (+) cable to the junction post. See Fig. 17.

#### NOTE —

*The positive post is marked with a plus (+) sign.*




Fig. 17. Positive (B+) junction post in rear of engine compartment. Connect positive (+) jumper cable to post (arrow).

3. Connect one end of the negative (-) cable to the negative (-) battery post of the good battery. Connect the opposite end of the negative cable (-) to the engine block of the car with the dead battery.
4. Start the car with the good battery and run the engine at about 2.000 rpm, then start the car with the dead battery.
5. With the engine at idle, switch on the headlights, blower motor and rear window defogger to avoid damaging the cars electrical system. Then carefully disconnect the jumper cables, starting with the negative cable on the engine block. Turn all electrical consumers off.

#### NOTE —

*The engine will need to run for at least an hour to recharge the battery.*

## FUNDAMENTALS FOR THE DO-IT-YOURSELF OWNER 010-11

## Overheating

If the temperature gauge needle goes into the red band on the gauge face or the check control displays "COOLANT TEMP", the coolant temperature is too high. Find a safe place to stop and turn the engine off. Open the hood and allow the engine to cool until the temperature gauge needle is at the lower third of the scale. Continuing to drive an overheated car can cause extensive engine damage.

**WARNING** —

*Do not remove the coolant reservoir or radiator cap with the engine hot. Undoing either could spray hot coolant and cause burns or damage the engine.*

**CAUTION** —

*Do not add cold water or coolant to a hot engine. Engine damage could result from the sudden temperature change.*

**NOTE** —

*If the engine cannot be safely turned off, make sure the air conditioner is off and turn the heater to high. This will help cool the engine until a safe stopping place can be reached.*

Overheating may be caused by low coolant level or a damaged engine drive belt. Visually check the coolant level and engine belts as described in **020 Maintenance Program**. If the coolant level is low, check the filler cap, hoses, clamps and radiator for signs of leakage. Check for leaks at the water pump on the front of the engine.

If no leaks are found, add coolant after the engine has cooled. The car can be driven, but have the cooling system thoroughly checked as soon as possible. If replacement coolant is not available, then plain water can be used, but the coolant should later be drained and refilled with the proper mixture of anti-freeze and water.

If steam is coming from the engine compartment then there is most likely a burst coolant hose or a large leak in the cooling system. To find the leak, look for signs of coolant leakage on hoses, at hose connections, or on the radiator. Let the engine cool thoroughly, then add coolant or water to fill the system and start the engine. If a great deal of water or coolant flows out of the hole, then the car should not be driven until repairs are made. If there is a slight seepage, then it may be possible to drive a short distance, adding coolant as needed.

## Low Oil Pressure

If either the red engine oil pressure warning light comes on or the check control displays "ENGINE OIL PRESS" anytime the engine is running, immediately stop the car and turn off the engine. Do not run the engine at all and have the car towed. If the light or graphic display remains on, do not run the car at all. Have it towed.

**NOTE** —

*Detailed information on checking the oil pressure is covered in 119 Lubrication System*

## Brake Fluid Level

The red brake fluid level warning light may be an indicator of brake fluid loss. Problems with the brake system should be checked and repaired immediately. See **340 Brakes** for more information.

## Check Engine Warning Light

If the "CHECK ENGINE" warning light comes on or flashes, it indicates that an emissions-related fault has occurred. Faults such as a failed oxygen sensor or a faulty fuel injector can turn the light on, causing the exhaust or evaporative emissions to exceed a specified limit. The engine can be safely driven with the light on, although the emission systems should be checked as soon as possible. See **100 Engine—General** for more information on the Check Engine Light and the On-board diagnostic system.

## Dim Lights

Headlights and instrument panel illumination that are dim or gradually getting dimmer generally indicate a problem with the battery or charging system. The battery charge indicator light may come on as the lights are dimming. In either case, the engine and accessories are running off of the battery alone, and will soon discharge it altogether.

If possible, do not stop the engine unless you have the capability to jump start it. There may not be enough power in the starting system to restart the engine. Instead, turn off as many electrical consumers as possible. This will reduce the current drain and will allow the car to be driven farther before you lose all battery power.

With the engine and ignition off, check for loose or corroded battery cables or wires at the battery or the alternator. Disconnecting, cleaning, and reinstalling corroded wires and connectors may solve the problem. Also check drive belt tension as described in **020 Maintenance Program**.

EMERGENCIES