

# **Section**

# **1001**

**SAFETY, GENERAL INFORMATION  
AND TORQUE SPECIFICATIONS**

## TABLE OF CONTENTS

SAFETY.....	3
TWIN WHEELS .....	5
Safety rules .....	5
Safety instructions.....	5
GENERAL INFORMATION .....	6
CORRECT USE OF TORQUE WRENCHES .....	7
HARDWARE TIGHTENING ORDER .....	8
STANDARD SCREW A TORQUE SPECIFICATIONS.....	9
Correct screw identification .....	9
METAL CAP REFERENCES.....	10
PLASTIC PLUG AND CAP REFERENCE CHART .....	11

## SAFETY



**WARNING:** This symbol means **WARNING ! BE VIGILANT ! YOUR SAFETY IS AT RISK**. The message that follows the symbol contains important safety information. Read it carefully. Be sure you understand the possible risks of injury or even death.

To avoid all risks, always follow the safety notes contained in this section and throughout this manual.

Put the warning tag shown below on the key for the keyswitch when servicing or repairing the machine. One warning tag is supplied with each machine. Additional tags, Part Number 321-4614, are available from your service parts supplier.



PDG0328



**WARNING:** Read the Operator's Manual carefully and make sure you understand how to operate the controls correctly.



**WARNING:** Never operate the machine and attachment controls unless you are seated in the operator's seat. If you are not in the operator's seat, you run the risk of serious injury.



**WARNING:** The machine is built to carry the operator only. Do not allow passengers to ride on the machine.



**WARNING :** Prior to starting up the engine read the safety messages contained in the operator's manual carefully. Read all safety stickers on the machine. Have people move back from the machine. Learn how to use the controls before starting up the machine. It is your responsibility to follow the manufacturer's instructions on how to operate and maintain the machine. It is your responsibility to follow applicable rules and regulations. Service and Operator's Manuals are available from your J.I. Case Dealer.



**WARNING:** If you wear loose clothing or if you omit to use safety equipment for your work, you risk injury. Always wear clothes that do not risk getting caught in the machine. Other safety equipment may be necessary, in particular : helmets, safety shoes, ear plugs, safety glasses, protection mask, thick gloves and reflecting clothes.



**WARNING:** When working close to the fan with the engine running, avoid wearing loose clothing and operate with extreme caution.



**WARNING:** When checking the hydraulic circuits, follow procedures to the letter. **DO NOT CHANGE** procedures.



**WARNING:** Prior to operating the hydraulic cylinders of this machine for setting or to bleed the circuit, have all people standing around the machine move away.



**WARNING:** Wear gloves or insulated mittens when working on hot parts.



**WARNING:** Lower all attachments to the ground or rest them on stands before carrying out maintenance jobs.



**WARNING:** Fine sprays of hydraulic oil under pressure can penetrate the skin and cause serious infection. If hydraulic oil under pressure penetrates the skin, see a doctor immediately. Maintain all hoses and pipes in good condition. Make sure that all connections are properly tightened. Change all hoses or pipes that have been damaged or that are suspect. **DO NOT CHECK** for leaks with bare hands. Use a piece of cardboard or wood.



**WARNING:** To remove a hardened pin such as a pivot pin, or a hardened shaft, use a soft head hammer (brass or bronze) or a brass or bronze strip and a steel head hammer.



**WARNING:** When using a hammer to remove or reassemble pivot pins, or when using compressed air, or when using a grinder make sure to wear safety glasses that protect the eyes from all sides.



**WARNING:** Use proper lifting/hoisting equipment to lift wheels or tracks and always work on safe ground. Prevent the machine from moving using correct safety chocks.



**WARNING:** When performing maintenance or repair operations on the machine, make sure that the work shop floor, the cab and the steps of the excavator are free from oil, water, grease, tools etc. Use oil absorbing material or rags as necessary. Always think safety.



**WARNING:** Certain components of this machine are very heavy. Use hoisting tools or additional assistance as recommended in this manual.



**WARNING:** Exhaust fumes can cause death. If it is necessary to start up the engine in a closed building, evacuate exhaust fumes using an exhaust pipe extension. Open the doors and let fresh air into the building.



**WARNING:** When battery liquid is frozen, the battery can explode if : (1) you try to charge the battery or (2) you try to start the engine by connecting an auxiliary power source. To prevent battery electrolyte from freezing keep the battery fully charged. If you do not follow these instructions, you or others nearby may be injured.



**WARNING:** Batteries contain acid and explosive gases. A spark, a flame or an improper cable connection may cause an explosion. For proper connection of cables to the battery of this machine see the Operator's Manual. If you do not follow these instructions, you risk severe injury.

## TWIN WHEELS

### Safety rules



**WARNING:** *In all cases, before removing twin wheels, always deflate both tyres completely.*



**WARNING:** *If a tyre bursts it can cause serious injury. Check tyres regularly to see that they are in good condition and always be sure to inflate them to the correct pressure.*



**WARNING:** *Never face a tyre when checking pressure or adding air. Always stand in front of the tread. Use an inflation cage if the wheel has been removed from the machine. Make sure all people standing in the area move well away.*



**WARNING:** *Never weld near a tyre. If this can not be avoided, it is mandatory to remove the tyre before performing any welding operations.*



**WARNING:** *Make sure that all decals on the machine are perfectly legible, clean them regularly and replace any decals which are damaged, missing or painted over, with new ones.*

### Safety instructions

- Use appropriate, good quality tools to disassemble the various wheel components. Never use a hammer. Use a rubber, plastic or copper-faced mallet.

**IMPORTANT:** *Never remove the inner tyre valve extension, as this will be necessary afterwards for inflating and deflating the tyre.*

**IMPORTANT:** *If the valve or the valve extension are no longer accessible, take the necessary precautions and then, imperatively, puncture the tyre.*

- Use suitable grease to facilitate the installation and removal of the tyre.
- Never re-inflate a tyre on the machine which has been used at a pressure lower than 5.6 bar.
- Check the various components: tyre, rim, shoulder, retaining ring and replace any defective items.
- Never reuse a retaining ring which is distorted or rusty.

## GENERAL INFORMATION

### CLEANING

Clean all metal parts except bearings with white spirit or steam. Do not use caustic soda when steam cleaning. After cleaning, dry and lubricate all parts. Clean hydraulic lines with compressed air. Clean bearings with kerosene, then dry them and lubricate them.

### INSPECTION

Check all parts when disassembled. Change all parts showing wear or damage. Scratches that are not too deep can be removed by honing or with a rag dipped into buffing compound. A full visual inspection to detect wear and pitting and subsequent changing of parts will prevent premature failure.

### BEARINGS

Check that bearings rotate freely. If their adjustment is too loose or if they do not run regularly, change them. Wash bearings with a good solvent or kerosene and let them dry. **DO NOT DRY BEARINGS WITH COMPRESSED AIR.**

### NEEDLE BEARINGS

Before inserting needle bearings into a bore, remove all metal particles from the edge of the bore. Prior to mounting bearings with a press, coat the inside and the outside of the bearing with vaseline.

### GEARS

Check all the gears for wear or damage. Change worn or damaged gears.

### SEAL RINGS, O-RINGS, GASKETS

Always use new seal rings. O-rings and gaskets. Coat sealing rings and O-rings with vaseline.

### SHAFTS

Check all shafts showing signs of wear or damage. Check that the surface of a shaft running in a bearing is not damaged.










### SPARE PARTS

Always use original CASE spare parts. To order spare parts, see the Spare Parts Catalogue to indicate the proper reference of original CASE spare parts. Failures caused by the use of parts that are not original CASE spare parts are not covered by the warranty.












### LUBRICATION

Use only oils and lubricants specified in the Operator's and Service Manuals. Failures due to the use of oils and lubricants not specified are not covered by the warranty.

# CORRECT USE OF TORQUE WRENCHES

<p><b>TORQUE WRENCHES</b></p>	 <p style="text-align: right;">PDG0315</p>
<p><b>CORRECT USE</b></p> <p>a - Hold the wrench by the handle provided.</p> <p>b - When tightening, always keep the wrench perpendicular to the screw.</p> <p>c - Keep one hand on the leverage point handle on the wrench.</p> <p>d - Tighten progressively in one movement.</p> <p>e - Position a correctly dimensioned socket or open-ended wrench on the flats of the screw head.</p>	<div style="text-align: center;"> <p><b>NO</b></p>   </div> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p><b>HAND</b></p>  </div> <div style="text-align: center;"> <p><b>NO</b></p>  </div> </div> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;"> <p><b>NO</b></p>  </div> </div> <div style="display: flex; justify-content: space-around; margin-top: 20px;"> <div style="text-align: center;">  </div> <div style="text-align: center;"> <p><b>NO</b></p>  </div> </div> <p style="text-align: right;">PDG0316</p>


## HARDWARE TIGHTENING ORDER

<p><b>TORQUE WRENCHES</b></p>	 <p style="text-align: right; font-size: small;">PDG0317</p>
<p><b>INITIAL TORQUE</b></p> <p style="margin-top: 20px;">a - Torque wrench.</p> <p style="margin-top: 10px;">- Follow the correct order of procedure when tightening.</p> <p style="margin-top: 10px;">- Cross or diagonal pattern tightening.</p>	<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> </div> <div style="display: flex; justify-content: space-around; align-items: flex-start; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> </div> <p style="text-align: right; font-size: small;">PDG0318</p>
<p><b>FINAL TORQUE</b></p> <p style="margin-top: 20px;">Always tighten in clockwise order.</p>	<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> </div> <div style="display: flex; justify-content: space-around; align-items: flex-start; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> </div> <p style="text-align: right; font-size: small;">PDG0319</p>












# STANDARD SCREW A TORQUE SPECIFICATIONS

## Correct screw identification





PDG0320

	Diameter x thread size Grade 8.8	Key  		Torque			
				Nm		lb.ft	
							
Two-part hydraulic connector (to SAE J518 specifications)  	M5 x 0.8	4	8	5.5	5.5	4.1	4.1
	M6 x 1	5	10	9	9	6.7	6.7
	M8 x 1.5	6	13	22.5	22.5	16.6	16.6
	M10 x 1.5	8	17	45	45	33.2	33.2
	M12 x 1.75	10	19	70	80	51.6	59
	M14 x 2	12	22	100	120	73.8	88.6
	M16 x 2	14	24	170	200	125.5	147.6
	M18 x 2.5	14	27	250	300	184.5	221.4
	M20 x 2.5	17	30	350	400	258.3	295.2
	M22 x 2.5	17	32	500	600	369	442.8
	M24 x 3	-	36	600	700	442.8	516.6
	M27 x 3	-	41	900	1000	664.2	738
M30 x 3.5	-	46	1200	1400	885.6	1033.2	
Components assembled by screws and bolts <b>SCREW</b>      <b>BOLT</b>	<b>Grade 10.9</b>						
	M5 x 0.8	4	8	75	75	5.6	5.6
	M6 x 1	5	10	12.5	12.5	9.3	9.3
	M8 x 1.5	6	13	35	35	25.8	25.8
	M10 x 1.5	8	17	60	70	44.3	51.6
	M12 x 1.75	10	19	100	120	73.8	88.6
	M14 x 2	12	22	170	200	125.5	147.6
	M16 x 2	14	24	250	300	184.5	221.4
	M18 x 2.5	14	27	350	400	258.3	295.2
	M20 x 2.5	17	30	500	600	369	442.8
	M22 x 2.5	17	32	700	800	516.6	442.8
	M24 x 3	-	36	900	1000	664.2	738
M27 x 3	-	41	1200	1400	885.6	1033.6	
M30 x 3.5	-	46	1700	1900	1254.6	1402.2	

PDG0321

PDG0322

-  Zinc bichromate
-  Phosphate





## METAL CAP REFERENCES

### To SAE J518 specifications

	NP 250 bar Ø ND	NP 400 bar Ø ND	Part number	
			A	B
<p style="text-align: center;">PDG0323</p>	13 mm	-	D5327838	E5327839
	19 mm	-	F5327840	G5327841
	25 mm	-	H5327842	J5327843
	32 mm	-	K5327844	L5327845
	38 mm	-	M5327846	N5327847
	-	13 mm	U5327830	V5327831
	-	19 mm	W5327832	X5327833
	-	25 mm	Z5327834	A5327835
	-	32 mm	B5327836	C5327837

NP = Nominal pressure  
 NP = Nominal diameter

## PLASTIC PLUG AND CAP REFERENCE CHART

	Dia. x pas	Part number	Dia. x pas	Part number
<b>Tapped orifices and connectors with tightening nuts = screw-type plugs</b>    PDG0324	M10 x 1.5 M12 x 1.5 M14 x 1.5 M16 x 1.5 M18 x 1.5	F3237416 G3237417 H3237418 J3237419 K3237420	M20 x 1.5 M22 x 1.5 M24 x 1.5 M27 x 2	L3237421 M3237422 N3237423 Q3237448
<b>Unions = Screw-type plugs</b>    PDG0325	M12 x 1.5 M14 x 1.5 M16 x 1.5 M18 x 1.5	X3237409 Z3237410 A3237411 B3237412	M20 x 1.5 M22 x 1.5 M30 x 1.5	C3237413 D3237414 E3237415
<b>S.A.E tube or hose collars = external plugs</b>    PDG0326	NP 250 bar 30.2 38.1 44.5 50.8 60.4	J2537460 K2537461 L2537462 M2537463 N2537464	NP 400 bar 31.8 41.3 47.6 54 63.6	P2537465 Q2537466 R2537467 S2537468 T2537469
<b>S.A.E orifices = caps for installation into tapped fitting orifices</b>    PDG0327	NP 250 bar L = 38.1 47.65 52.35 58.07 69.85	A2340480 B2340481 C2340482 D2340483 E2340484	NP 400 bar L = 40.5 50.8 57.15 66.7 79.4	K1640415 R1640421 S1640422 T1640423 Z1640479

NP = Nominal pressure  
 ND = Nominal diameter



# Section 1002

1002

## SPECIFICATIONS 588 CRAWLER EXCAVATORS

## TABLE OF CONTENTS

FLUIDS AND LUBRICANTS .....	3
Hydraulic fluid.....	3
Transmission component oil .....	3
Grease .....	3
Engine oil .....	4
Oil viscosity/Oil range.....	4
Fuel .....	5
Anti-freeze/Anti-corrosion.....	5
Environment .....	5
Plastic and resin parts.....	5
MACHINE GENERAL SPECIFICATIONS .....	6
Engine .....	6
Hydraulic system.....	6
Electrical system .....	7
Upperstructure .....	7
Cab.....	7
Operation .....	7
Undercarriage (depending on version).....	8
Safety devices.....	8
Indicators.....	8
Warning and indicator lamps.....	8
Attachments .....	8
Noise level.....	8
Ground pressure .....	8
Travel .....	9
WEIGHTS .....	10
Machine.....	10
Attachments .....	10
Counterweight .....	10
Cab.....	10
BUCKETS .....	11
CLAMSHELLS .....	12
MACHINE OVERALL DIMENSIONS .....	13
TRANSPORTATION OVERALL DIMENSIONS .....	14



**WARNING :** *This symbol is used in this manual to indicate important safety messages. Whenever you see this symbol, carefully read the message that follows, as there is a risk of serious injury.*

## FLUIDS AND LUBRICANTS

Lubricants must have the correct properties for each application.



**WARNING :** *The conditions of use for individual fluids and lubricants must be respected.*

### Hydraulic fluid

CASE hydraulic fluid is specially designed for high pressure applications and for the CASE hydraulic system. The type of fluid to be used depends on the ambient temperature.

#### Temperate climates

-20°C to +40°C

Fluid type ISO VG 46

CASE Reference POHYDR

#### Hot climates

0°C to +60°C

Fluid type ISO VG 100

CASE Reference POHYPC

#### Cold climates

-40°C to +20°C

Fluid type ISO VG 22

CASE Reference POHYPF

These different fluid grades must be in conformity with CASE France specification P9903201Z.

#### Temperate country biodegradable fluid :

This yellow fluid is compatible with standard fluid. If adopted, it is advisable to drain the circuit completely.

Fluid type ISO VG 46

CASE Reference CASYNTH46

This fluid grade must be in conformity with CASE France specification P9903203B.

### Transmission component oil

Extreme Pressure oil is used for all cased transmission components.

Extreme pressure oil TYPE API GL5 GRADE 80W90 and ISO VG 150

### Grease

The type of grease to use depends on ambient temperature.

#### Temperate and hot climates

-20°C to +60°C

EP NLGI grade 2 extreme pressure grease, containing molybdenum disulphide.

#### Cold climates

-40°C to +20°C

EP NLGI grade 0 extreme pressure grease.

## Engine oil

CASE No 1 motor oil is the oil recommended for your engine. This oil ensures correct lubrication of your engine in all working conditions.

If CASE No 1 Multiperformance or Performance engine oil cannot be obtained, use only oil of the API/CE category.

**NOTE:** Do not put any Performance Additive or other additive in the sump. Oil change intervals shown in this manual are based on tests carried out on CASE lubricants.




RF97F136



RB97F100

## Oil viscosity/Oil range



(A) FAHRENHEIT TEMPERATURE

(B) CELSIUS TEMPERATURE

(1) ALL SEASONS

(\*) USE OF AN ENGINE OIL HEATER, OR AND ENGINE COOLANT HEATER IS REQUIRED.

(2) WINTER

(3) TROPICAL

(4) ARTIC

CS98M561



## Fuel

Use fuel which is to ASTM (American Society for Testing and Materials) D975 standard.

Use Grade No 2 fuel. The use of other types of fuel can result in a loss of power and may cause high fuel consumption.

When the temperature is very cold, the use of a mixture of No 1 and No 2 fuel is permitted. See your fuel vendor for winter fuel requirements in your area.

If the temperature falls below the fuel cloud point (point at which wax begins to form) the wax crystals will cause power loss or will prevent the engine from starting.

**IMPORTANT :** *In cold weather, fill the fuel tank at the end of the day's work, in order to prevent the formation of condensation.*

### Fuel storage

Long storage can lead to the accumulation of impurities and condensation in the fuel. Engine trouble can often be traced to the presence of water in the fuel.

The storage tank must be placed outside and the temperature of the fuel should be kept as low as possible. Drain off water and impurities regularly.

### Anti-freeze/Anti-corrosion

Use anti-freeze in all seasons to protect the cooling system from corrosion and all risk of freezing.

For areas where ambient temperature is over -36°C, use a blend of 50% ethylene-glycol based anti-freeze.

For areas where the temperature is below -36°C, it is advisable to use a blend of 40% water and 60% anti-freeze.

## Environment

Before carrying out any maintenance operation on this machine and before disposing of used fluids or lubricants, always think of the environment. Never pour oil or fluid onto the ground and never place it in leaking receptacles.

Contact your local ecological recycling centre or to obtain information on the correct method of disposing of these materials.

### Plastic and resin parts

When cleaning polycarbonate windows, the console, instrument panel, indicators, etc., do not use petrol, paraffin, paint solvents, etc. Use only water, soap and a soft cloth.

The use of petrol, paraffin, paint solvents, etc. will cause discoloration, cracks or warping of these parts.

## MACHINE GENERAL SPECIFICATIONS

### Engine

Make and model .....	CASE 4T 390
Total SAE power rating at 2800 rpm .....	79.8 kW (108 hp)
4 stroke, 4 cylinder diesel engine .....	turbocharged
Displacement .....	3920 cm <sup>3</sup>
Bore .....	102 mm
Stroke .....	120 mm
Cooling .....	water-cooled
Battery start .....	Two 12-volt batteries, 24 V, 100 Ah

### Working specifications

Speed .....	2000 rpm
Power rating : SAE .....	68.5 kW (93 hp)
DIN 70020 - DIN 6271 .....	65 kW (88 hp)
EEC 80/1269 - ISO 9249 .....	65 kW (88 hp)
Performance maintained up to 3000 m altitude at a temperature of 25°C.	
Capacities : Oil sump .....	10 L
Fuel tank .....	150 L
Electric fuel tank filler pump .....	optional
Average hourly consumption .....	12 L/h
Engine and pump assembly mounted on rubber blocks.	
Heavy-duty dust filtration.	

### Hydraulic system

Variable flow circuit with all functions independent and simultaneous.

Working pressure .....	350 bar
Total capacity of hydraulic reservoir .....	115 L
Total capacity of system .....	184 L

2-body pump :

1 variable displacement body for the attachment and travel circuits .....	flow 210 L/min
1 fixed flow body for the upperstructure frame swing .....	flow 44 L/min

Direct drive by flexible coupling.

Installed hydraulic power .....	55.5 kW (75.4 hp)
---------------------------------	-------------------

Fixed displacement pumps for servo-duties.

Attachment and travel control valves, parallel, closed centre, acting on the "Load Sensing" pump regulation.

Flow rates per function independent of pressures.

Oil cooler with air cooling from engine.

High pressure, multi-spiral hoses

minimum safety factor .....	2 to 4 times working pressure
-----------------------------	-------------------------------

Self-lubricating hydraulic swivel.

## Electrical system

System voltage .....24 volts, negative earth  
 Batteries .....two 12-volt, low maintenance batteries  
 All electrical system safety functions are grouped in an electrical cabinet with a printed circuit.  
 Instrument panel with printed circuit.  
 Automatic instrument panel lamp testing.  
 Two-stage alarm system.  
 Upperstructure electrical power connection (24 V, 15 Amp.).  
 Battery master switch.

## Upperstructure

### All welded frame

Modular structure.  
 Transverse access walkway to different components.  
 Sound-proofed, lockable cowling meeting all current regulations.  
 Tool box with tool set.

### Swing

Hydraulic motor with reduction gear and automatic static brake.  
 Swing speed ..... 7.6 rpm  
 Turntable bearing..... Alternate rollers, inner ring gear teeth  
 Bearing race and ring gear tooth lubrication..... centralized

## Cab

Removable, sound-proofed, on flexible mounting blocks.  
 Up and over windshield.  
 Tinted windshield.  
 Pre-fitted for radio installation.  
 Sliding window on door.  
 Transparent roof hatch ..... optional  
 Polycarbonate windows ..... optional  
 Cab safety guard .....available on request  
 Cab elevator .....available on request  
 Anti-vandal cab..... optional

## Operation

De-luxe seat with armrests and multi-position adjustment (vibration level III/ISO 7096).  
 Hydraulically assisted controls.  
 Attachment and swing ..... 2 levers  
 Travel..... 2 pedals  
 Speed programmer, also providing automatic speed range change on the two-speed version.  
 Single-speed windshield wiper, plus intermittent action, windshield washer, heating system, de-frosting, two-speed ventilation, cab light, cigarette lighter, sun shield.  
 Working/lights :  
     On upperstructure .....2 x 70/75 W  
     On attachment..... 70 W  
     Rear (on cab) ..... 70 W  
     Front (on cab)..... optional  
 Air conditioning ..... optional  
 Cab visor ..... optional  
 Cab fan ..... optional

1002-8

## Undercarriage (depending on version)

Monoblock chassis, with all-welded sections.  
Permanently greased rollers.  
Tractor type tracks; track tensioning by grease cylinders; shock absorber.  
Removable drive sprocket ring gears.  
Front chain guide (rear guide optional).

## Safety devices

In the event of engine failure, the attachment can be lowered, under control, to the ground.  
Cancellation of controls by lifting the left-hand control arm.

Tinted safety-glass windows, horn.

Cab safety guard .....	available on request
Safety valves .....	optional
Overload indicator .....	optional
Inertia type safety belt .....	optional
Fire extinguisher .....	optional
Rotary light .....	specific to certain countries

## Indicators

Engine coolant solution temperature, hydraulic fluid temperature, fuel level and hourmeter.

## Warning and indicator lamps

Engine oil pressure, battery charge, hydraulic oil filter and engine air filter restriction.  
Warning/indicator lamp test.

## Attachments

Sealed linkaged, all linkages greased from ground level or from the walkway.  
Double acting cylinders fitted with end-of-stroke shock absorbers

## Noise level

Certified by the manufacturer.

In accordance with European directive 86/662/EEC.

Internal noise level (LpA) .....	77 decibels
External noise level (LwA) .....	101 decibels

## Vibration levels in operator's cab

Lower limbs .....	less than 2.5 m/s <sup>2</sup>
Body .....	less than 0.5 m/s <sup>2</sup>

## Ground pressure

With attachment : 4.30 m boom, 2.10 m dipper and 480 L bucket

Machine fitted with 0.50 m pads .....	0.420 bar
Machine fitted with 0.60 m pads .....	0.350 bar
Machine fitted with 0.70 m pads .....	0.310 bar
Machine fitted with 0.85 m pads .....	0.260 bar