

Caterpillar D8k Parts Book

Full download: <http://manualplace.com/download/caterpillar-d8k-parts-book/>

TM 5-2410-234-14&P-2

TECHNICAL MANUAL

**OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT
AND GENERAL SUPPORT
MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS INFORMATION
AND SUPPLEMENTAL
MAINTENANCE AND REPAIR PARTS INSTRUCTIONS)
TRACTOR, FULL TRACKED, LOW SPEED,
HEAVY DRAWBAR PULL, (SIZE T-1 1)
W/ANGLE DOZER, WINCH AND ROPS
CATERPILLAR MODEL D8K-8A-58 (CCE)
NSN 2410-00-574-7597
AND
W/BULLDOZER (SEMI-U-TILT), RIPPER
AND ROPS
CATERPILLAR MODEL D8K-8S-8 (CCE)
NSN 2410-00-574-7598**

HEADQUARTERS, DEPARTMENT OF THE ARMY

This copy is a reprint which includes current pages from Change 1.
21 JULY 1981

WARNING

The proper and safe lubrication and maintenance procedures for this machine, recommended by Caterpillar, are outlined in the LUBRICATION & MAINTENANCE GUIDE for this machine. Improper performance of lubrication or maintenance procedures is dangerous and could result in injury or death. Read and understand the LUBRICATION & MAINTENANCE GUIDE before performing any lubrication or maintenance.

WARNING

To avoid possible weakening of this ROPS, consult a Caterpillar dealer before altering this ROPS in any way.

WARNING

The protection offered by this ROPS will be impaired if it has been structurally damaged or has been involved in an overturn accident.

WARNING

Seat adjustment should be checked at the beginning of each shift and when operators change.

WARNING

Always use seat belts when operating machine.

WARNING

Always check condition of seat belt and connecting brackets.

WARNING

Attach ground cable last, and remove first, to prevent sparks from occurring near the battery which could cause battery vapors to explode. Attach ground cable from booster battery to frame of machine to be started at a point away from, and below, the battery on the machine to be started.

WARNING

Use starting fluid sparingly. Follow manufacturer's instructions carefully.

WARNING

Do not store starting fluid in operator's compartment.

WARNING

Keep tractor under control at all times. Do not neutralize transmission or forward-reverse lever, or disengage fly-wheel clutch to allow machine to coast.

WARNING

Select gear range necessary before starting downgrade. Do not change gears while going downhill.

WARNING

Do not allow tractor to coast downhill.

WARNING

When load is pushing tractor, put gear selector in first speed before starting downhill.

WARNING

Do not release clutch or shift transmission while moving.

WARNING

Use extra caution when crossing side hills, ridges, logs and ditches.

WARNING

Make certain personnel are clear of cable when there is a load on the cable. Cable can break and cause personal injury.

WARNING

Exercise care with suspended loads. If engine speed is too low, the weight of the load may cause it to drop, even though the winch is in the Reel In position.

WARNING

Check travel route for overpass clearances. Make sure there will be adequate clearance if vehicle being transported is equipped with ROPS, cab or canopy.

WARNING

If the rack setting or the high idle speed is higher than the setting in the book RACK SETTING INFORMATION for the 'altitude' (height above sea level) at which the engine is operated, there can be damage to the engine or to parts of the turbocharger.

WARNING

Be sure to make an adjustment to the regulator so the air supply in the tank is a maximum of 15 psi (1.05 kg/cm²).

WARNING

When making the (cooling system) checks, fasten the transmission in neutral, put the parking brakes on and lower all equipment. Make all checks at engine LOW IDLE and on the side of the radiator opposite the fan. Wear eye protection.

WARNING

Never disconnect any charging unit circuit or battery circuit cable from battery when the charging unit is producing a charge.

WARNING

Disconnect batteries before performance of any service work.

WARNING

The (valve) locks can be thrown from the valve when the valve spring compressor is released. Make sure the locks are in the correct position on the valve.

WARNING

When (transmission) tests must be done in a closed area, activate the brakes and use blocks to prevent the machine from moving during the tests. Let only approved personnel on the machine. Keep other personnel off the machine and in view of the operator.

WARNING

Do not make any adjustments to the (transmission) linkage with the engine running.

WARNING

The adjuster cylinder for the track is under high hydraulic pressure. Do not visually inspect the relief valve to see if grease is being released. Check the adjuster cylinder that it moves to the rear into the front pilot for the recoil springs. Use this warning any time that the track is loosened or tightened.

WARNING

Make sure the hydraulic jack is tight against the track roller frame when the track is lifted.

WARNING

Make sure the hydraulic pressure in the track adjusting mechanism is completely released and the cylinder can be moved to the rear into the front pilot for the recoil spring before making a separation of the track or installing the track adjusting mechanism. On machines with badly worn tracks, it is possible for the hydraulic track adjuster to have a maximum forward adjustment and the stop will be against the front support for the track roller frame. The hydraulic track adjuster is under high pressure. Do not visually inspect the relief valve to see if grease is being released. Check the adjuster cylinder to see that it moves to the rear into the front pilot for the recoil spring. Use this warning any time that the track is loosened or tightened.

WARNING

Do not remove the front cover for the recoil springs until Step 4 (spring compression) is completed. If the front pilot for the recoil spring is broken, the procedure on page I140 must not be used. See RECOIL SPRINGS (with broken pilots) for correct procedures.

WARNING

The recoil springs are assembled under a force of several tons. This force is released against legs during disassembly. Caution must be used to make sure the correct tooling is used and the correct procedure is followed.

WARNING

The recoil springs are assembled under a force of several tons. This force is released against legs during disassembly. Caution must be used to make sure the correct tooling is used and the correct procedure is followed.

WARNING

Do not remove the hoist from the track roller frame at this time (following Step 6 of track roller frame disassembly).

WARNING

Make sure the track roller frame does not hit the equalizer bar when it is removed. Weight of the track roller frame is 8000 lb. (3629 kg).

WARNING

Do not hit the equalizer bar when the track roller frame is put in position.

WARNING

The recoil springs are under several tons of force. Do not remove cover until force is controlled by (proper) tooling.

WARNING

Do not put more than 50 ton (45t) of force on (pilot) bolt.

WARNING

(Valve assembly) Cover is under spring tension. Hold the cover in position when the bolts that hold it to the housing are removed.

WARNING

The access cover is under spring pressure. Hold the cover when the bolts that hold it are removed.

WARNING

Exercise care with suspended loads; if engine speed is too low, the weight of the load may cause it to drop, even though the winch is in the REEL IN position.

WARNING

Do not underwind cable onto winch drum unless the winch has been modified to operate in this manner.

WARNING

When testing or making an adjustment to the hydraulic system, move the machine to a location away from other moving machines. The operator must be sure that other personnel are not near the machine when the engine is running and he is making tests.

WARNING

To avoid possible weakening of the ROPS (Rollover Protective Structure), consult a Caterpillar Dealer before altering the ROPS in any way. The protection offered by the ROPS will be impaired if it has been subjected to structural damage or has been involved in any overturn accident.

WARNING

When using pressure air, wear safety glasses and protective clothing. Maximum air pressure must be below 30 psi (2 kg/cm²).

WARNING

(Corrosion) Inhibitor contains alkali, avoid contact with skin and eyes.

WARNING

Never service air cleaners with engine running.

WARNING

If track is sealed and lubricated type, secure track with chain before separating links. Sealed and lubricated track is very flexible. When disconnected, it can move and cause injury.

WARNING

Never visually inspect relief valve or fill valve to see if grease is escaping. Always observe the track to see if it has loosened.

WARNING

Never service air cleaners with engine running.

d

CHANGE
NO.1

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, D.C., 30 January 1987

**OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT AND
GENERAL SUPPORT MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS INFORMATION AND SUPPLEMENTAL
MAINTENANCE AND REPAIR PARTS INSTRUCTIONS)**

**TRACTOR, FULL TRACKED, LOW SPEED,
HEAVY DRAWBAR PULL, (SIZE T-11)
WIANGLE DOZER, WINCH AND ROPS
CATERPILLAR MODEL DSK-A--58 (CCE)
NSN 2410-00-574-7597
AND
WIBULLDOZER (SEMI-U-TILT), RIPPER
AND ROPS
CATERPILLAR MODEL D8K- 8S 8 (CCE)
NSN 2410-00-574-7598**

TM52410-234-14&P-2, 21 July 1981, is changed as follows:

1. The repair parts information contained in this manual has been replaced by TM5-2410-234-20P, Organizational Maintenance Repair Parts And Special Tools Lists, And TM5-2410-234-34P, Direct Support and General Support Maintenance Repair Parts And Special Tool Lists (Including Depot Maintenance Repair Parts And Special Tool Lists).

File this change sheet in front of the publication for reference purposes.

By Order of the Secretary of the Army:

Official:

JOHN A. WICKHAM, JR
General United States Army
Chief of Staff

R.L. DILWORTH
Brigadier General, United States Army
The Adjutant General

Distribution:

To be distributed in accordance with DA Form 12-25A-R, Operator, Organizational, Direct Support and General Support Maintenance requirements for Tractor, Full-tracked, Low Speed, with Angle Dozer Models D8K-8A-58, D8K-85-8.

This manual contains copyright material..

TECHNICAL MANUAL

No. 5-2410-234-14&P-2

}

TM 5-2410-234-14&P-2

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, 21 JULY 1981

**OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT
AND GENERAL SUPPORT
MAINTENANCE MANUAL**

**(INCLUDING REPAIR PARTS INFORMATION AND SUPPLEMENTAL
MAINTENANCE AND REPAIR PARTS INSTRUCTIONS)**

**TRACTOR, FULL TRACKED, LOW SPEED,
HEAVY DRAWBAR PULL, (SIZE T-11)**

**W/ANGLE DOZER, WINCH AND ROPS
CATERPILLAR MODEL D8K-8A-58 (CCE)**

NSN 2410-00-574-7597

AND

**W/BULLDOZER (SEMI-U-TILT), RIPPER
AND ROPS**

CATERPILLAR MODEL D8K-8S-8 (CCE)

NSN 2410-00-574-7598

REPORTING OF ERRORS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, US Army Tank-Automotive Command, ATTN: DRSTA-MBS, Warren, MI 48090.

A reply will be furnished to you.

Chapters 1 through 6 and Appendixes A through P are contained in Volume 1


VOLUME II

CHAPTER	7.	REPAIR PARTS
Section	I.	D342 Vehicular Engine
Section	II.	D8K Tractor (D342 Engine)
Section	III.	D8k Tractor
	IV.	183B Hydraulic Control
	V.	Bulldozers (8A, 8S & 8U)
	VI.	58 & 59 Winch
	VII.	Ripper

This technical manual is an authentication of the manufacturers' commercial literature and does not conform with the format and content specified in AR310-3, Military Publications. This technical manual does, however, contain available information that is essential to the operation and maintenance of the equipment.

i/(ii blank)

**CHAPTER 7
REPAIR PARTS**



CATERPILLAR
PARTS
BOOK SECTION I.

D342
VEHICULAR
EN'GINE

SERIAL
NUMBERS
17S1-UP

QUICK REFERENCE CHARTS

USE THESE CHARTS TO RECORD FREQUENTLY USED MAINTENANCE INFORMATION

MACHINE SERIAL NO.

EQUIPMENT NO.

FREQUENTLY REPLACED ITEMS

PART NO.	PART NAME


FLUIDS & LUBRICANTS

WHERE USED	TYPE	AMOUNT

OTHER MAINTENANCE ITEMS

CONTENTS

ALPHABETICAL INDEX OF GROUPS--3
CONVERSION EQUIVALENT
TABLES INSIDE BACK COVER
ORDERING PARTS-----2
QUICK REFERENCE
CHART INSIDE FRONT COVEF
USING THE PARTS BOOK-----2



PARTS BOOK

D342
VEHICULAR ENGINE

SERIAL NUMBER
17S1 -UP

PUBLISHED SEPTEMBER 1974
CATERPILLAR TRACTOR CO.
PUBLICATIONS DIV.-SERVICE G.O.
PEORIA, ILL. USA
COMPILED BY DOROTHY MOSES

CENTRAL STRUCTURE

UPPER STRUCTURE

FRONT STRUCTURE

REAR STRUCTURE

LOWER STRUCTURE

LUBRICATION SYSTEM

COOLING SYSTEM

INTAKE &
EXHAUST SYSTEM

FUEL SYSTEM
& GOVERNOR

ELECTRICAL SYSTEM

SERVICE EQUIPMENT
& SUPPLIES

ORDERING Quality Caterpillar Replacement parts are available from Caterpillar dealers PARTS throughout the world. Their parts stocks are up to date and include all parts normally required to protect your investment in Caterpillar machines.

When ordering parts, always use the Parts Book covering the serial number of your machine. Your order should specify the quantity, part number, part name and show the machine serial number for which the parts are needed. If in doubt about the part number, please provide your dealer with a complete description of the Serial Number Plate is Located needed item.

ENGINE MODEL	
SERIAL NUMBER	GIVE ALL NUMBERS IN ALL COMMUNICATIONS
ARRANGEMENT NUMBER	
MODIFICATION NUMBER	

HOW TO USE THE CATERPILLAR PARTS BOOK Caterpillar Parts Books include illustrations of the groups or assemblies which make up the machine. These illustrations show the standard components of the machine plus many of the attachments available for the machine.

The alphabetical index located in the front part of the book should be used to determine the page number on which specific illustrations are shown. Reference to those pages will identify each of the individual serviceable parts.

Captions

The caption under each illustration identifies the part number and name of the group or assembly shown. If more than one illustration is included for any group, the caption identifies the specific machine serial numbers to which each illustration applies. In some cases it is not possible to determine the specific machine serial numbers to which different illustrations are applicable. In those cases the caption identifies the illustration as "First Type", "Second Type", etc. Reference to the actual group or assembly is necessary in those cases to determine which illustration should be used.

Captions provide additional information such as page numbers where illustrations of sub assemblies are shown, information regarding quantities used and other information intended to assist the user in determining parts needs.

Indented Part Names

Within each illustration is a parts list identifying each serviceable part in the illustration. When a part name is indented in this list, it means that serviceable item is a part of the serviceable item under which it is indented.

Abbreviations and Symbols

Δ	Used to call attention to additional
•	information shown elsewhere with in the illustration.
R.H.	Right Hand Refers to the side of the
L.H.	Left Hand machine as viewed from the operator's compartment.
C	Indicates changes from the previous illustration of the same group or assembly.
O. D.	Outside Diameter
I.D.	Inside Diameter
N/S	Not Serviced
Assem.	Assembly
in.	Inch
ft	Foot
cm	Centimeter
dm	Decimeter

Note:

Continuing improvement and advancement of product design may cause changes to your machine which may not be included in this publication. Each publication is reviewed and revised, as required, to update and include these changes in later editions.

Whenever a question arises regarding your Caterpillar product, or this publication, please consult your Caterpillar dealer for the latest available information.

INDEX

ENGINE ARRANGEMENTS ARE LISTED STARTING ON PAGE 10

Central Structure (Page 16)		Lower Structure (Page 35)	
Name	Page	Name	Page
Camshaft	22	Name	
Connecting Rod and Piston.....	22	Oil Level Gauge-	35
Crankshaft	20	Oil Pan	36
Crankshaft Bearings.....	21		
Cylinder Block	16		
Cylinder Block Cover	19		
 Upper Structure (Page 23)			
Cylinder Head	23	Breather and Filler.....	48
Valve Mechanism	24	Oil Filter	46
Valve Mechanism Cover	25	Oil Lines	40
 Front Structure (Page 26)			
Fan Drive	27	Oil Pump	37
Front Housing	26	Oil Pump Drive	39
Front Housing Cover	26		
Pulley and Damper.....	28		
Water Pump Idler Gear	28		
 Rear Structure (Page 29)			
Flywheel	29		
Flywheel Housing	30		
Power Take-Off	31		
Power Take-Off Drive.....	30		
Support	34		
 Lubrication System (Page 37)			
		Breather and Filler.....	48
		Oil Filter	46
		Oil Lines	40
		Oil Pump	37
		Oil Pump Drive	39
 Cooling System (Page 50)			
		Oil Cooler	55
		Transmission Oil Cooler.....	55
		Water Lines	50
		Water Pump	54
 Intake & Exhaust System (Page 56)			
		Air Lines	59
		Exhaust Manifold.....	56
		Inlet Manifold	57
		Turbocharger	58
 Fuel System & Governor (Page 59)			
		Fuel Filter.....	61

Name	Page		Electrical System (Page 74)	
Fuel Injection Lines.....	63		Name	Page
Fuel Priming Pump	59		Alternator	78
Fuel Ratio Control.....	62		Electric Starting Motor	75
Fuel Transfer Pump.....	60		Glow Plug and Wiring	74
Governor Control.....	64			
Governor and Fuel Injection Pump	69			
Governor and Fuel Pump Drive	68			
Primary Fuel Filter	62			
Service Meter	73			
			Service Equipment and Supplies (Page 80)	
			Gasket Kits	80

INDEX ALPHABETIQUE

LES VERSIONS FOURNIES PAR LES USINES SONT INDIQUEES PAGE 10

Ensemble central (Page 16)			Ensemble arriere (Page 29)	
Designation	Page		Designation	Page
Arbre a cames	22		Carter avant (couvercle).....	26
Bielles et pistons.....	22		Entrainement de ventilateur	27
Bloc-cylindres/	16		Pompe a eau (engrenage intermediaire)	28
Bloc-cylindres (couvercle)	19		Poulie	28
Coussinets de vilebrequin	21			
Vilebrequin -	20			
Ensemble superieur (Page 23)			Ensemble inferieur (Page 35)	
Culasse	23		Carter inférieur	36
Soupapes (couvercle)	25		Jauge de niveau d'huile.....	35
Soupapes et train de commande	24			
Ensemble avant (Page 26)				
Amortisseur de vibrations				
d'arbre moteur	28			
Carter avant	26			

Circuit de graissage (Page 37)		Alimentation en carburant et regulateur (Page 59)	
Designation	Page	Designation	Page
Canalisafions de graissage	40	Canalisation d'injection de carburant	63
Entrainement de pompe a huile	39	Compteur d'entretien.....	73
Filtre a huile de graissage .-	46	Filtre a carburant	61
Pompe a huile	37	Limiteur d'injection	62
Reniflard et tubulure de remplissage d'huile.....	48	Pompe d'alimentation de carburant	60
 Circuit de refroidissement (Page 50)		 Installation electrique (Page 74)	
Canalisations d'eau	50	Alternateur	78
Pompe a eau -	54	Bougie de depart et cablage	74
Refroidisseur d'huile de graissage	55	D6marreur 6lectrique	75
Refroidisseur d'huile (transmission)	55	 Divers (Page 80)	
 Admission et echappement (Page 56)		Jeux de joints	80
Canalisation d'air	59		
Collecteur d'admission	57		
Collecteur d'echappement.....	56		
Turbocompresseur	58		

INDICE
LA LISTA DE CONJUNTOS DE MOTOR EMPIEZA EN LA PAGINA 10.

Estructura Central (Pagina 16)		Estructura Superior (Pagina 23)	
Nombre	Pagina	Nombre	Pagina
Arbol de levas	22	Cojinetes de bancada	21
Bielas y pistones.....	22	Tapas del bloque del motor	19
Bloque del motor	16	Culata	23
Cigueial	20		

Nombre	Pagina	Sistema de Enfriamiento (Pagina 50)
Mecanismo de las valvulas,	24	
Tapa del mecanismo de las valvulas	25	
Estructura Delantera (Pagina 26)		
Caja delantera	26	
Engranaje loco de la bomba del agua	28	
Mando del ventilador,	27	
Polea y amortiguador de vibraciones	28	
Tapa de caja delantera.....	26	
Estructura Trosera (Pdgina 29)		
Caja del volante	30	
Mando de toma de fuerza	30	
Soporte	34	
Toma de fuerza	31	
Volante	29	
Estructura Inferior (Pagina 35)		
Carter	36	
Indicador de nivel del aceite	35	
Sistema de Lubricacion (Pdgina 37)		
Bomba del aceite.....	37	
Filtro del aceite	46	
Mando de la bomba del aceite	39	
Respiradero y tubo de llenado,,	48	
Tuberias del aceite	40	
		Sistema de Enfriamiento (Pagina 50)
Nombre	Pagina	
Bomba del agua.....	54	
Enfriador del aceite	55	
Enfriador del aceite de la transmisi6n	55	
Tuberias del agua	50	
		Sistema de Admision y Escape (Pagine 56)
Multiple de admisi6n	57	
Multiple de escape	56	
Tuberias de aire	59	
Turboalimentador	58	
		Sistema del Combustible y Regulador (Pdgina 59)
Bomba de cebado del combustible	59	
Bomba de transferencia del combustible,	60	
Control del regulador.....	64	
Control de relaci6n del combustible	62	
Filtro del combustible	61	
Filtro primario del combustible	62	
Mando del regulador y bombas de inyeccion	68	
Medidor de servicio	73	
Regulador y bombas de inyeccion del combustible	69	
Tuberias de inyeccion del combustible	63	

**Sistema Electrico
(Pagina 74)**

Nombre	Pagina
Alternador	78
Bujias incandescentes y alambrado	74

Nombre Pagina

Motor de arranque electrico	75
-----------------------------------	----

**Materiales Diversos
(Pagina 80)**

Juegos de empaquetaduras	80
--------------------------------	----

INDICE

**OS ARRANJOS DISPONIVEIS DO MOTOR ESTAO RELACIONADOS
NA PAGINA 10 E SGUINTES**

**Parte media
(Pagina 16)**

Designacio	Pagina
Arvore de comando das valvulas	22
Arvore de manivelas.....	20
Biela e pistao	22
Bloco do motor	16
Mancais principais do motor.....	21
Tampa do bloco do motor	16

Designagao Phgina	
Polia e amortecedor	28

**Tampa das engrenagens de
distribuiqso 26**

Parte traseira (Pagina 29)	
Caixa do volante	30
Comando da tomada de forca ,	30
Suporte	34
Tomada de forca	31
Volante	29

**Parte superior
(Pagina 23)**

Cabecote	23
Mecanismo das valvulas	24
Tampa superior do motor ,	25

**Parte inferior
(Pagina 35)**

Carter do motor	36
Vareta de nivel do 6leo do carter	35

**Parte dianteira
(Pagina 26)**

Caixa das engrenagens de distribuiqao	26
Comando do ventilador,	27
Engrenagem intermediaria da bomba d'agua	28

**Sistema de lubrificaiao
(pagina 37)**

Bomba de oleo ,	37
Comando da bomba de 6oleo	39
Filtro de 6leo	46

Designacao	Pagina
Respiro e bocal de enchimento do carter ,	48
Tubulaqnes do 6leo	40

**Sistema de arrefecimento
(Pagina 50)**

Arrefecedor de oleo do motor -	55
Arrefecedor de oleo da caixa de mudancas	55
Bomba d'agua	54
Tubulaq5es d'agua.....	50

**Sistema de admissio
e escape
(Pagina 56)**

Colefor de admissao	57
Colefor de escape	56
Tubos de ar	59
Turbocompressor	58

**Sistema de alimentagaio e
regulador de velocidade
(Pagina 59)**

Bomba de purgacSo do combusfivel	59
----------------------------------	----

Designacao	Pagina
Bomba de transferencia do combustivel	60
Comando da bomba injefora regulador de velocidade	68
Controle de aceleraw-	64
Filtro prim a rio de combusfivel	62
Filtro principal de combustivel	61
Limitador de combusfivel	62
Marcador de horas de servico	73
Regulador de velocidade bomba injefora	69
Regulador de velocidade e comando da bomba injetora .	68

**Sistema eletrico
(Pdgina 74)**

Alternador	78
Motor de arranque eletrico	75
Velas de aquecimenfo e instalasao elefrica	74

**Equipamento para
manutenqaaoo e diversos
(Pagina 80)**

Jogos de junfas	80
-----------------------	----

**INHALTSVERZEICHNIS
MOTORAUSFOHRU SIND AB SEITE 10 AUFGEFOHRT**

**Motormittelteil
(Seite 16)**

Bezeichnung	Seite
Kurbellager	21
Kurbelwelle	20

Bezeichnung	Seite
Motorblock	16
Motorblockdeckel	19
Nockenwelle	22
Pleuel und Kolben	22

Motoroberteil
(Seite 23)

Bezeichnung	Seite
Hubose	22
Ven'tildeckel	25
Ventilsfeuerung	24
Zylinderkopf	23

Motorvorderteil
(Seite 26)

Lufteranfrieb	27
Riemenscheibe und Dampfer.....	28
Stirnradgehause	26
Stirnradgehausedeckel.....	26
Wasserpumpen-Zwischenrad	28

Motorheck
(Seite 29)

Aufhaigung	34
Schwungscheibe	29
Schwungscheibengehause.....	30
Zapfwelle	31
Zapfwellenantrieb	30

Motorunterteil
(Seite 35)

Olmestab	35
Olwanne	36

Schmiersystem
(Seite 37)

EnflUfter und Einfüllstutzen	48
Olleitungen	40
Schmierfilter	46
Schmierpumpe	-37
Schmierpumpenantrieb	}39

Kuhlianlage
(Seite 50)

Bezeichnung	Seite
GefrieeboekUhler	55
OlkUhler	55
Wasserleitungen	50
Wasserpumpe	54

Ansaug- und Abgasanlage
(Seite 56)

AnsaugkrUmmer	57
AuspuffkrUmmer	56
Druckluftleitungen	59
Turbolader	58

Krattstoffanlage und
Regler
(Seite 59)

Kraftstoffeinspritzleitungen.....	63
Kraffstoffentluftungspumpe	59
Kraftstofffilter	61
Kraftstofforderpumpe	-60
Kraftstoffgemischregler	62
Kraftstoffvorfilter	62
Regler und	
Kraftstoffeinspritzpumpe	-69
Regler und	
Kraffstoffpumpenantrieb.....	68
Reglersteuerung.....	64
Wartungsmesser	73

Elektr. Anlage
(Seite 74)

Anlasser, elektr	75
Drehstromlichtmaschine	-78
GIUhkerze und Verdrahtung	74

Wartungsgeräte und
Zubehör
(Seite 80)

Dichtungs saeze	80
-----------------------	----

Caterpillar D8k Parts Book

Full download: <http://manualplace.com/download/caterpillar-d8k-parts-book/>

CATERPILLAR D342 VEHICULAR ENGINE

CONSISTS OF:	PAGE	
CENTRAL STRUCTURE		
1	4N9873 CYLINDER BLOCK GROUE.....	16
1	4N5236 CRANKSHAFT GROUP.....	20
1	4.H9649 CAMSHAFT GROUP	22
6	4S6868 CONNECTING ROD AND PISTON GROUP.....	22
1	4N9875 CYLINDER BLOCK COVER GROUP.....	19
UPPER STRUCTURE		
1	4N9894 CYLINDER HEAD GROUP	23
1	4N9892 VALVE MECHANISM GROUP.....	24
1	4N9893 VALVE MECHANISM COVER GROUP.....	25
FRONT STRUCTURE		
1	4N9876 FRONT HOUSING GROUP	26
1	4N9878 FRONT HOUSING COVER GROUP	26
1	4N5235 PULLEY AND DAMPER GROUP	28
1	6N941 FAN DRIVE GROUP	27
1	5H4204 WATER PUMP IDLER GEAR	28
REAR STRUCTURE		
1	4N9874 FLYWHEEL HOUSING GROUP	30
1	457417 FLYWHEEL GROUP.....	29
1	4N5703 SUPPORT GROUP.....	34
1	9H6248 POWER TAKE-OFF DRIVE GROUP	30
1	351660 POWER TAKE-OFF GROUP	31
LOWER STRUCTURE		
1	4N3291 OIL LEVEL GAUGE GROUP	35
1	4N9877 OIL PAN GROUP	36
LUBRICATION SYSTEM		
1	2P5103 OIL FILTER GROUP	46
1	2P2538 BREATHER AND FILLER GROUP.....	48
1	3H3093 OIL PUMP GROUP	37
1	6N2412 OIL PUMP DRIVE GROUP	39
1	6N336 OIL LINES GROUP	40

4N4444 BASIC ENGINE ARRANGEMENT-Part 1

FOR USE WITH D8K DIRECT DRIVE TRACTOR

NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND
SERIAL NUMBER