

**CF65/75/85 Series ≥ 0E621376**

TECHNICAL DATA	<b>0</b>
DIAGNOSTICS	<b>1</b>
COMPONENTS	<b>2</b>
WIRING REPAIR	<b>3</b>
BATTERIES	<b>4</b>
	<b>5</b>
CONNECTION OF ACCESSORIES	<b>6</b>
READING DIAGRAMS	<b>7</b>
LOCATION OF COMPONENTS	<b>8</b>
LOCATION OF CONNECTORS	<b>9</b>
ELECTRICAL SYSTEM	<b>10</b>
CHANGES IN THE ELECTRICAL SYSTEM	<b>11</b>
ELECTRICAL SYSTEM: OPTIONS AND SPECIAL APPLICATIONS	<b>12</b>



CONTENTS

	Page	Date
1. COMPONENTS .....	1-1 ....	200404
1.1 General .....	1-1 ....	200404
1.2 Tightening torques .....	1-3 ....	200404





**0**

**Alternator**

**NCB1**



Max. current 80 A  
 Rated voltage 28 V

**NCB2**

Max. current 100 A  
 Rated voltage 28 V


**Micro relay**

Maximum cut in current making connection between points 3 and 5: 10 A  
 Maximum cut out current breaking connection between points 3 and 4: 5 A



**Mini relay**

Maximum cut in current making connection between points 30 and 87: 20 A  
 Maximum cut out current breaking connection between points 30 and 87a: 10 A



**Handheld transmitter CDS**

Battery type (2x) CR1620, 3 V

## 1.2 TIGHTENING TORQUES

### Tightening torques

Drive pulley	80 Nm $\pm$ 5 Nm
B+ connection	15 Nm
Chassis earth connection	65 Nm





## CONTENTS

	Page	Date
<b>1. FAULT FINDING</b> .....	1-1	200520
1.1 Short circuits .....	1-2	200520
1.2 Open circuit .....	1-3	200520
1.3 Earthing problems .....	1-4	200520
<b>2. BATTERIES</b> .....	2-1	200520
2.1 Fault-finding table .....	2-1	200520
2.2 Service life .....	2-4	200520
<b>3. ALTERNATOR</b> .....	3-1	200520
3.1 Fault-finding table .....	3-1	200520
<b>4. XENON LIGHTING</b> .....	4-1	200520
4.1 Fault-finding table .....	4-1	200520



## 1. FAULT FINDING

The following test equipment and tools can be used to trace faults.

1. The best instrument for this is a digital multimeter. This instrument can be used to measure voltages, currents and resistances avoiding reading errors, and it can be used to trace virtually any faults.
2. Many, but not all, faults are easily traced by means of warning lamps. Failures caused by poor earthing cannot normally be detected by a warning lamp or buzzer.

The most frequently occurring faults are:

- a. short circuit
- b. open circuits
- c. earthing problems (poor earthing due to corrosion).

## 1.1 SHORT CIRCUITS

A short circuit is caused by a positive wire shorting to earth somewhere. In most cases this will cause a fuse to blow.

To remedy this failure, use a test lamp of approximately 70W. First check the diagram to see which consumers are connected to the fuse in question, and then switch them all off.

Remove the fuse and connect the test lamp in its place. Now switch each of the consumers on and off one by one. If the lamp comes on very brightly when a consumer is switched on, the fault is almost certainly in the wiring of that consumer. Now check the diagram to see via which connectors the consumer is connected. Now disconnect the first wiring connection (as seen from the fuse).


If the lamp is still bright, the fault is between the fuse and this wiring connection.

If, however, the lamp goes out, the fault is somewhere further on in the wiring.

Now reconnect the connectors and disconnect the next wiring connection. If the lamp is still bright, the failure is between these two wiring connections.

However, if the lamp goes out again, the fault-finding procedure must be continued.

The faulty wiring section can be found in this way.



W 5 03 013

## 1.2 OPEN CIRCUIT

Suppose a consumer is not functioning. The fault may be in the consumer itself, or there may be an open circuit in the wiring.

First switch on the consumer. Then check the consumer for voltage using a test lamp. If no voltage is found, first check whether the fuse is still intact.

If there is voltage at the fuse, check the wiring from the fuse to the consumer. This means every wiring connection must be checked.


Stop at the first wiring connection that has no voltage. The open circuit will be between this connection and the previous one.

However, if there was a voltage at the consumer, there may still be an open circuit in the negative (earth) wiring. Check this using a test lamp.


Ensure that the relevant circuit is switched on. Connect one end of the test lamp to earth and the other end to the earth connection of the component to be checked.

If the test lamp lights up, the earth connection of the component is interrupted. If the test lamp does **not** light up, the earth connection will in many cases be in good condition.

If both the positive and negative connections are in good order, the consumer in question must be replaced.



W 5 03 015




W 5 03 016

### 1.3 EARTHING PROBLEMS

Earthing problems are mainly caused by corrosion between the contact surfaces of electrical connections.

A poor earth connection of the main earth circuit (2) between cab and chassis may result in a current through the steering shaft (1).



E502316

To check this main earth connection, two complementary tests must be carried out.

- A current measurement using a current probe.
- A voltage loss measurement using a multimeter.


A current probe, which is a special tool (DAF no. 1453183), must be used for a current measurement; this measures the current through the steering shaft (1).



**The current measurements have to be carried out while the cab is in the driving position.**

**INSPECTION 1, MEASURING THE SYSTEM CURRENT**

1. Open the grille.
2. Switch on vehicle ignition and as many consumers as possible, e.g.:
  - dipped beam
  - heater fan in position 4
  - spotlights, etc.
3. Use the current probe to check whether the power consumption through the battery cable at the battery is between 20 A and 40 A. Switch on extra consumers if this is not the case until the power consumption is between 20 A and 40 A.
4. Then measure the system current through the steering shaft (1) using the probe. Make sure that the current probe is placed in the right position (direction of current) and its jaws are closed around the steering shaft.
5. Depending on the measured current value, the following actions need to be carried out:



E502267

1

1

Measured current value	Measures to be taken
< 2.0 A	<ul style="list-style-type: none"> <li>- The main earth connections are in good order, end of inspection 1. Continue with inspection 2.</li> </ul>
≥ 2.0 A and < 5.0 A	<ul style="list-style-type: none"> <li>- Inspect - and if necessary repair - all main earth connections from the cab to the negative battery terminal between the following points:                             <ul style="list-style-type: none"> <li>- battery earth and cab earth</li> <li>- cab earth and flywheel housing earth</li> <li>- flywheel housing earth and chassis earth</li> <li>- chassis earth and battery earth</li> </ul> </li> </ul> <p><b>Note:</b>                      A voltage loss measurement must be carried out to identify which earthing point is in poor condition. This measurement is described later on in this procedure.</p> <ul style="list-style-type: none"> <li>- The current value through the steering shaft must be less than 2.0 A after repair. Otherwise one or more earth connections are not yet in good order and the main earth connections must be inspected again and if necessary repaired.</li> <li>- If the current value is &lt; 2.0 A, the main earth connections are in good order: end of inspection 1. Continue with inspection 2.</li> </ul>
≥ 5.0 A	<ul style="list-style-type: none"> <li>- Inspect - and if necessary repair - all main earth connections from the cab to the negative battery terminal between the following points:                             <ul style="list-style-type: none"> <li>- battery earth and cab earth</li> <li>- cab earth and flywheel housing earth</li> <li>- flywheel housing earth and chassis earth</li> <li>- chassis earth and battery earth</li> </ul> </li> </ul> <p><b>Note:</b>                      A voltage loss measurement must be carried out to identify which earthing point is in poor condition. This measurement is described later on in this procedure.</p> <ul style="list-style-type: none"> <li>- The current value through the steering shaft must be less than 2.0 A after repair. Otherwise one or more main earth connections are not yet in good order and the earth connections must be inspected again and if necessary repaired.</li> <li>- If the current value is &lt; 2.0 A, the earth connections are in good order.</li> </ul> <p><b>Note:</b>                      A high current through the steering shaft can affect the mechanical condition of the steering shaft bearing.</p>



**INSPECTION 2, MEASURING THE STARTING CURRENT**


Measure the starting current through the steering shaft while starting, using the current probe.

This measurement must be carried out with the probe's "Max Hold" function. Make sure that the current probe is placed in the right position (direction of current) and its jaws are closed around the steering shaft.

1

Measured current value	Measures to be taken
< 5.0 A	- Main earth connections are in good condition; end of inspection 2: vehicle is OK.
$\geq$ 5.0 A	<ul style="list-style-type: none"> <li>- Inspect - and if necessary repair - all main earth connections from the cab to the negative battery terminal between the following points:</li> <li>- battery earth and cab earth</li> <li>- cab earth and flywheel housing earth</li> <li>- flywheel housing earth and chassis earth</li> <li>- chassis earth and battery earth</li> </ul> <p><b>Note:</b> A voltage loss measurement must be carried out to identify which earthing point is in poor condition. This measurement is described later on in this procedure.</p> <ul style="list-style-type: none"> <li>- The starting current value through the steering shaft must be less than 5.0 A after repair. Otherwise one or more main earth connections are not yet in good order and the main earth connections must be inspected again and if necessary repaired.</li> <li>- If the current value is &lt; 5.0 A, the earth connections are in good order; end of inspection 2: vehicle is OK.</li> </ul>

## MEASURING VOLTAGE LOSS



E502269

- 1 negative battery terminal
- 2 flywheel housing
- 3 chassis
- 4 bulkhead lead-through connector

To find out whether a specific earthing point has a good earth connection, measure the voltage loss between the negative battery terminal and this earthing point.

The figure shown is an example; the actual course of the earth connection may differ somewhat depending on vehicle type and production date.

The consumers that were switched when the current was measured should now be switched on as well, i.e. the power consumption should be between 20 A and 40 A.

If the earth connection is good, the voltage loss should be less than 0.5 V.

## 2. BATTERIES

### 2.1 FAULT-FINDING TABLE

<b>SYMPTOM: NEW BATTERY HEATS UP CONSIDERABLY DURING FILLING</b>	
<b>Possible cause</b>	<b>Remedy</b>
Inadequate formation because of storage in unsuitable or damp conditions over a long period	Allow to cool Charge fully Check the relative density

<b>SYMPTOM: BATTERY ACID LEAKING FROM THE PLUG HOLES</b>	
<b>Possible cause</b>	<b>Remedy</b>
Battery overfilled	Siphon off some of the fluid
Overcharging	Check the charger and repair if necessary

<b>SYMPTOM: ELECTROLYTE LEVEL TOO LOW</b>	
<b>Possible cause</b>	<b>Remedy</b>
Leaking battery	Replace the battery
Excessive gas development due to charging current being set too high	Check/repair the charger

<b>SYMPTOM: RELATIVE DENSITY TOO LOW (&lt;1.240) STARTING TROUBLE</b>	
<b>Possible cause</b>	<b>Remedy</b>
Power consumer left on by mistake	Charge the battery
Insufficient charging	Check/repair the charger
Short circuit in the charging circuit	Check the charging circuit

<b>SYMPTOM: DENSITY IS TOO HIGH (&gt;1.290)</b>	
<b>Possible cause</b>	<b>Remedy</b>
Topped up with acid instead of distilled water	Siphon off the fluid and fill with distilled water If necessary, repeat this after mixing (charging)

**DIAGNOSTICS****5**

Batteries

**CF65/75/85** Series ≥ 0E621376

<b>SYMPTOM: STARTING TROUBLE POOR STARTING TEST RESULT POWER FAILS UNDER LOAD</b>	
<b>Possible cause</b>	<b>Remedy</b>
- Discharged battery	Charge the battery
- Worn battery (plates corroded and worn away)	Replace the battery
- Defective battery ("dead cell")	Replace the battery
- Battery too small	Replace with battery of a higher capacity
- Battery sulphated (plates have hardened)	Replace the battery

<b>Possible cause</b>	<b>Remedy</b>
- Discharged battery	Charge the battery
- Worn battery (plates corroded and worn away)	Replace the battery
- Defective battery ("dead cell")	Replace the battery
- Battery too small	Replace with battery of a higher capacity
- Battery sulphated (plates have hardened)	Replace the battery

<b>SYMPTOM: BURNT-IN BATTERY TERMINALS</b>	
<b>Possible cause</b>	<b>Remedy</b>
- Clamps not securely fitted, or poor contact	Have the battery terminals repaired, fit the clamps properly or replace the clamps if necessary

<b>Possible cause</b>	<b>Remedy</b>
- Clamps not securely fitted, or poor contact	Have the battery terminals repaired, fit the clamps properly or replace the clamps if necessary

<b>SYMPTOM: 1 OR 2 CELLS BUBBLE EXCESSIVELY UNDER HIGH LOADS (STARTING OR STARTING TEST)</b>	
<b>Possible cause</b>	<b>Remedy</b>
- Defective cells	Replace the battery
- Leaking cell partition	Replace the battery

<b>Possible cause</b>	<b>Remedy</b>
- Defective cells	Replace the battery
- Leaking cell partition	Replace the battery

<b>SYMPTOM: BATTERY DISCHARGES VERY FAST (DOES NOT RETAIN POWER)</b>	
<b>Possible cause</b>	<b>Remedy</b>
- Insufficient charging	Check the charging. Is the charging time (driving time) sufficient?
- Short circuit in charging circuit	Check the charging circuit
- Major self-discharging, for example due to contamination	Clean the battery
- Battery sulphated (on examining the plates, they are found to be hard and, in some cases, whitened)	Replace the battery

<b>Possible cause</b>	<b>Remedy</b>
- Insufficient charging	Check the charging. Is the charging time (driving time) sufficient?
- Short circuit in charging circuit	Check the charging circuit
- Major self-discharging, for example due to contamination	Clean the battery
- Battery sulphated (on examining the plates, they are found to be hard and, in some cases, whitened)	Replace the battery

<b>SYMPTOM: SHORT BATTERY LIFE</b>	
<b>Possible cause</b>	<b>Remedy</b>
- Wrong type of battery chosen (for example in the case of tail lifts)	Install Super Heavy Duty or semi-traction battery
- Often too deeply discharged	Intermediate charging with rectifier
- No recharging after deep discharge (white deposits)	Always charge the battery after deep discharge

<b>Possible cause</b>	<b>Remedy</b>
- Wrong type of battery chosen (for example in the case of tail lifts)	Install Super Heavy Duty or semi-traction battery
- Often too deeply discharged	Intermediate charging with rectifier
- No recharging after deep discharge (white deposits)	Always charge the battery after deep discharge