

DATSUN PICK-UP SERVICE MANUAL

1977

11.50

DATSUN PICK-UP

SERVICE MANUAL

MODEL
620 SERIES



NISSAN MOTOR CO., LTD.
TOKYO, JAPAN

QUICK REFERENCE INDEX

GENERAL INFORMATION	GI
ENGINE TUNE-UP	ET
ENGINE MECHANICAL	EM
ENGINE LUBRICATION SYSTEM	EL
COOLING SYSTEM	CO
ENGINE FUEL	EF
EMISSION CONTROL SYSTEM	EC
ENGINE ELECTRICAL SYSTEM	EE
ENGINE REMOVAL & INSTALLATION	ER
CLUTCH	CL
MANUAL TRANSMISSION	MT
AUTOMATIC TRANSMISSION	AT
PROPELLER SHAFT & DIFFERENTIAL CARRIER	PD
FRONT AXLE & FRONT SUSPENSION	FA
REAR AXLE & REAR SUSPENSION	RA
BRAKE SYSTEM	BR
WHEEL AND TIRE	WT
STEERING SYSTEM	ST
ENGINE CONTROL, FUEL & EXHAUST SYSTEMS	FE
BODY & FRAME	BF
BODY ELECTRICAL SYSTEM	BE
AIR CONDITIONING	AC
SERVICE EQUIPMENT	SE

FOREWORD

This service manual has been prepared for the purpose of assisting service personnel of authorized NISSAN/DATSUN dealers in providing effective service and maintenance of the 1977 Datsun Pick-up.

Since proper maintenance and service are absolutely essential in satisfying the Datsun owners, this manual should be kept in a handy place for ready reference and should be carefully studied.

This manual includes procedures for maintenance adjustments, minor service operations, removal and installation, and for disassembly and assembly of components.

Some of these service operations require the use of Special Tools especially designed for effective performance of service operations.

The special tools are presented in the "SE" section.

As you read through the maintenance procedures in this service manual, you will occasionally come across paragraphs headed NOTE or CAUTION. A NOTE is supplemental information that is important to a particular procedure. CAUTION warns of steps that must be followed to prevent personal injury and/or damage to some part of your DATSUN.

The Quick Reference Index on the first page enables the user to quickly locate the desired section. At the beginning of each individual section is a table of contents, which gives the page number on which each major subject begins. An index is placed at the beginning of each major subject within the section.

All information, illustrations and specifications contained in this manual are based on the latest product information available at the time of publication approval. If your DATSUN model differs from the specifications contained in this manual, consult your NISSAN/DATSUN dealer for information.

Rights for alteration at any time of specifications and methods are reserved.

Liability for any personal injury or property damage occasioned by the use of this service manual in effecting maintenance or repair of your Datsun is in no way assumed by Nissan Motor Co., Ltd.

Accordingly, anyone using a service procedure or tool which is not specifically recommended by Nissan must first completely satisfy himself that neither his safety nor the vehicle's safety will be jeopardized by the service method selected.

NISSAN MOTOR CO., LTD.
TOKYO, JAPAN

SERVICE MANUAL

DATSUN PICK-UP
MODEL 620 SERIES

SECTION GI

GI

GENERAL INFORMATION

GENERAL INFORMATION GI- 3



NISSAN MOTOR CO., LTD.
TOKYO, JAPAN

General Information




Fig. GI-1 Standard wheelbase model



Fig. GI-2 Deluxe Cab

GENERAL INFORMATION

CONTENTS

MODEL VARIATION	GI-3	APPROXIMATE REFILL CAPACITIES	GI-8
IDENTIFICATION NUMBERS	GI-5	RECOMMENDED FUEL	GI-8
LIFTING POINTS AND TOWING	GI-6	RECOMMENDED LUBRICANTS	GI-8
LIFTING POINTS	GI-6	RECOMMENDED SAE VISCOSITY	
SUPPORTABLE POINTS	GI-7	NUMBER	GI-8
TOWING	GI-7	LUBRICANT SPECIFICATIONS	GI-9
TIE DOWN	GI-7		


MODEL VARIATION

Destination	Class	Model	Engine	Transmission	Differential carrier model and gear ratio	Pay load kg (lb)		
U.S.A.	California and high altitude locations outside California	Standard wheelbase	California models	HL620TUV	F4W71B	H190 4.375	500 (1.100)	
				HL620FTUV	FS5W71B			
				HL620KTUV	3N71B			
		Long wheelbase		HLG620TUV	F4W71B			
				HLG620FTUV	FS5W71B			
				HLG620KTUV	3N71B			
		Deluxe Cab		KHL620TUV	F4W71B			
				KHL620FTUV	FS5W71B			
				KHL620KTUV	3N71B			
	All low altitude locations outside California	Standard wheelbase		Non California models	HL620TU			F4W71B
					HL620FTU			FS5W71B
					HL620KTU			3N71B
		Long wheelbase			HLG620TU			F4W71B
					HLG620FTU			FS5W71B
					HLG620KTU			3N71B
		Deluxe Cab			KHL620TU			F4W71B
					KHL620FTU			FS5W71B
					KHL620KTU			3N71B

General Information

Destination	Class	Model	Engine	Transmission	Differential carrier model and gear ratio	Pay load kg (lb)
Canada	Standard wheelbase	HL620TUN	L20B	F4W71B	H190 4.375	500 (1.100)
		HL620KTUN		3N71B		
	Long wheelbase	HLG620TUN		F4W71B		
		HLG620KTUN		3N71B		
	Deluxe Cab	KHL620TUN		F4W71B		
		KHL620FTUN		FS5W71B		
		KHL620KTUN		3N71B		

Model identification



Note: □ means no identification.


IDENTIFICATION NUMBERS

The unit and vehicle numbers are stamped and registered at the factory.

The engine and vehicle identification numbers are used on legal documents. These numbers are used for factory communications such as Technical Reports, Warranty Claims, Service Journals and other information.

Vehicle Identification plate

The vehicle identification plate is located at the hood ledge in the engine compartment.





SP029

Fig. GI-3 Vehicle identification plate location

Vehicle serial number

The vehicle serial number is stamped on the upper face of the right side member. The number is identified by the following figures as a serial number.





GI268

Fig. GI-4 Vehicle serial number location

Engine serial number

The engine serial number is stamped on the right-hand side of the cylinder block.




SP027

Fig. GI-5 Engine serial number location

Color code number

The color code number label is stuck on the radiator support.




GI326

Fig. GI-6 Color code number label location

M.V.S.S. certification label

The M.V.S.S. certification label is located at the driver side lock pillar.




SP031

Fig. GI-7 M.V.S.S. certification label location

Vehicle emission control information label

The vehicle emission control information label is stuck on the inside of the hood panel.




SP076

Fig. GI-8 Vehicle emission control information label location


Manual transmission number

The transmission serial number is stamped on the front upper face of transmission case.

(Number system)



General Information





TM235

Fig. GI-9 Manual transmission number location

Automatic transmission number

The transmission serial number is attached to the right-hand side of transmission case.

(Numbering system)



AT344

Fig. GI-10 Automatic transmission number location

LIFTING POINTS AND TOWING

LIFTING POINTS

Screw jack


Before using the jack, proceed as follows:

Apply parking brake firmly and block rear wheels if the front of the vehicle is to be raised.

Notes:

- Never get under the vehicle while it is supported only by the jack. Always use safety stands to support frame or rear axle case when you have to get beneath the vehicle.
- In no event should the jack be applied to any points except the following specified portions.


When jacking up the front side, place a screw jack under side frame [about 520 mm (20.5 in) at rear of front axle center].



WT012

Fig. GI-11 Front lifting point

When jacking up the rear side, place a screw jack under rear axle case close to the side of rear spring.



WH077

Fig. GI-12 Rear lifting point

Notes:

- When the yellow mark appears on the screw jack, it indicates the maximum permissible height. Do not jack up further.
- When the jack is at lower limit, do not add large force downward.



WH080


Fig. GI-13 Warning against over-stroke

Garage jack

Note: When carrying out operations with a garage jack, be sure to support the vehicle with stands in a safe manner.


When jacking up the front end, apply garage jack to front cross-member or center portion of suspension member.

When jacking up the rear end, apply the jack to rear axle case.



G1075

Fig. GI-14 Front lifting point



G1076


Fig. GI-15 Rear lifting point

General Information

SUPPORTABLE POINTS


The front supportable points are under frame side member.

The rear supportable points are under rear axle case.



G1077

Fig. GI-16 Front supportable points



G1078

Fig. GI-17 Rear supportable points


TOWING

When the vehicle is to be towed forward, connect a rope securely to the hook under the 1st crossmember. Before towing, make sure the parking brake is released.

To tow another car, connect the rope to rear leaf spring shackle.


Notes:

- A towing rope should not be connected to any position other than as described above.
- Avoid applying load suddenly to a towing rope, as it may cause damage.



WH131

Fig. GI-18 Front towing point



WH085

Fig. GI-19 Rear towing point

Manual transmission

Before towing, make sure the transmission is in neutral gear.

If the rear axle or transmission is inoperative, the vehicle should be towed with its rear wheels off the ground, or the propeller shaft must be removed.

Automatic transmission

When the vehicle is towed on its rear wheels, make sure the transmission is in "N" (Neutral) position. Don't exceed 30 km/h (20 MPH) and a distance of 10 km (6 miles). If the rear axle or transmission is inoperative, or if the speed exceeds the above conditions, the vehicle must be towed with its rear wheels off the ground, or the propeller shaft must be removed.

Note: When the vehicle is towed with its front wheels on the ground, the steering wheel should be secured to maintain a straight ahead position.

TIE-DOWN

The front two tie-down hooks are located under the 1st crossmember.

The hook is available as a towing hook. For rear tie-down, the rear leaf spring shackle be used. This point is also used as a towing point.

General Information

APPROXIMATE REFILL CAPACITIES

		Liter	U.S. measure	Imper. measure
Fuel tank		45 ℓ	11 7/8 gal.	9 3/4 gal.
Cooling system (with heater)	Manual transmission	8.0 ℓ	8 1/2 qt.	7 qt.
	Automatic transmission	7.8 ℓ	8 1/2 qt.	6 3/4 qt.
Engine lubrication system	with oil filter	4.3 ℓ	4 1/2 qt.	3 3/4 qt.
	without oil filter	3.8 ℓ	4 qt.	3 3/4 qt.
Manual transmission	4-speed transmission	1.7 ℓ	3 3/4 pt.	3 pt.
	5-speed transmission	2.0 ℓ	4 1/2 pt.	3 3/4 pt.
Automatic transmission		5.5 ℓ	5 3/4 qt.	4 3/4 qt.
Steering gear box		0.33 ℓ	1/2 pt.	1/2 pt.
Differential carrier		1.0 ℓ	2 1/2 pt.	1 1/2 pt.


RECOMMENDED FUEL

Use an unleaded or low-lead gasoline with a minimum octane rating of 91 RON (Research Octane Number). For California models, use

only unleaded gasoline to protect the catalytic converter from contamination.

RECOMMENDED LUBRICANTS

RECOMMENDED SAE VISCOSITY NUMBER



LUBRICANT SPECIFICATIONS

Item	Specifications	Remarks	
Gasoline engine oil	SAE Classification SD or SE	Furthermore refer to SAE recommended viscosity table. See Page GI-8.	
Gear oil	Transmission and steering	API GL-4	
	Differential	API GL-5	
Automatic T/M fluid	Type DEXRON		
Multipurpose grease	NLGI 2	Lithium soap base	
Brake and clutch fluid	DOT 3		
Antifreeze	—	Permanent anti-freeze (Ethylene glycol base)	

SERVICE MANUAL

DATSUN PICK-UP
MODEL 620 SERIES



NISSAN MOTOR CO., LTD.
TOKYO, JAPAN

SECTION ET

ET

ENGINE TUNE-UP


ENGINE TUNE-UP.....	ET- 2
BASIC MECHANICAL SYSTEM.....	ET- 7
IGNITION AND FUEL SYSTEM	ET- 9
EMISSION CONTROL SYSTEM	ET-13
SERVICE DATA AND SPECIFICATIONS	ET-25
TRouble DIAGNOSES AND CORRECTIONS	ET-27

ENGINE TUNE-UP

CONTENTS

LOCATION OF EMISSION CONTROL SYSTEM COMPONENTS (Non-California models)	ET-2	EMISSION CONTROL SYSTEM PIPING (Non-California models)	ET-4
LOCATION OF EMISSION CONTROL SYSTEM COMPONENTS (California models)	ET-3	EMISSION CONTROL SYSTEM PIPING (California models)	ET-5
		EMISSION CONTROL DEVICES	ET-6


LOCATION OF EMISSION CONTROL SYSTEM COMPONENTS (Non-California models)



ET365

Fig. ET-1 Location of emission control system components (Non-California models)


LOCATION OF EMISSION CONTROL SYSTEM COMPONENTS (California models)



ET366

Fig. ET-2 Location of emission control system components
(California models)

EMISSION CONTROL SYSTEM PIPING (Non-California models)




- 1 Vacuum tube to distributor (yellow)
- 2 Vacuum tube to carbon canister (yellow)
- 3 Vacuum tube to thermal vacuum valve (white)
- 4 Vacuum tube
- 5 Vacuum tube to carburetor (yellow)
- 6 Thermal vacuum valve to E.G.R. control valve (white)
- 7 Vacuum tube to carburetor (white)
- 8 A.B. valve to vacuum connector (green)
- 9 Vacuum tube to carbon canister (yellow)
- 10 S.D.V. to distributor (yellow)
- 11 Vacuum tube to S.D.V. (yellow)

ET367

Fig. ET-3 Emission control system piping (Non-California models)

EMISSION CONTROL SYSTEM PIPING (California models)



- 1 Vacuum tube to distributor (yellow)
- 2 Vacuum tube to carbon canister (yellow)
- 3 Thermal vacuum valve to E.G.R. control valve (white)
- 4 Vacuum tube to thermal vacuum valve (white)
- 5 Vacuum tube
- 6 Vacuum tube to carburetor (yellow)
- 7 Vacuum hose connector to intake manifold (green)
- 8 Vacuum tube to carburetor (white)
- 9 Air control valve to vacuum hose connector (green)
- 10 A.B. valve to vacuum connector (green)
- 11 B.C.D.D. to control valve (white)
- 12 B.C.D.D. control valve to intake manifold (green)
- 13 Vacuum hose connector to E.A.R. control valve (green)
- 14 B.C.D.D. control valve to air pump air cleaner

ET368

Fig. ET-4 Emission control system piping (California models)

BASIC MECHANICAL SYSTEM

CONTENTS

ADJUSTING INTAKE AND EXHAUST VALVE CLEARANCE	ET-7	PERMANENT ANTI-FREEZE COOLANT	ET-8
CHECKING AND ADJUSTING DRIVE BELT	ET-7	CHECKING COOLING SYSTEM HOSES AND CONNECTIONS	ET-8
RETIGHTENING CYLINDER HEAD BOLTS, MANIFOLD NUTS AND CARBURETOR SECURING NUTS	ET-7	INSPECTION OF RADIATOR CAP	ET-8
CHECKING ENGINE OIL	ET-8	COOLING SYSTEM PRESSURE TEST	ET-8
REPLACING OIL FILTER	ET-8	CHECKING VACUUM FITTINGS, HOSES, AND CONNECTIONS	ET-8
CHANGING ENGINE COOLANT	ET-8	CHECKING ENGINE COMPRESSION	ET-9
		COMPRESSION PRESSURE TEST	ET-9
		TEST RESULT	ET-9

ADJUSTING INTAKE AND EXHAUST VALVE CLEARANCE

Note: After tightening cylinder head bolts, adjust intake and exhaust valve clearances.

Valve clearance adjustment is impossible when the engine is in operation:

1. Loosen pivot locking nut and turn pivot screw until the specified clearance is obtained while cold.

Using service tool, tighten pivot locking nut securely after adjustment, and recheck the clearance.

2. Warm up engine for at least several minutes and stop it. Measure valve clearance while hot. If out of specifications, adjust.

Unit: mm (in)

Unit: mm (in)		
Cold	Intake	0.20 (0.008)
	Exhaust	0.25 (0.010)
Warm	Intake	0.25 (0.010)
	Exhaust	0.30 (0.012)





Fig. ET-5 Adjusting valve clearance

CHECKING AND ADJUSTING DRIVE BELT

1. Check for cracks or damage. Replace if necessary.

2. Normal drive belt deflection is 8 to 12 mm (0.315 to 0.472 in), when moderate thumb pressure is applied midway between pulleys.



AC456

Fig. ET-6 Drive belt tension

RETIGHTENING CYLINDER HEAD BOLTS, MANIFOLD NUTS AND CARBURETOR SECURING NUTS

Refer to the following tightening torque specifications.

- Tightening torque:
- Cylinder head bolts
 - 1st turn
 - 4.0 kg-m (29 ft-lb)
 - 2nd turn
 - 6.0 kg-m (43 ft-lb)
 - 3rd turn
 - 6.5 to 8.5 kg-m (47 to 61 ft-lb)

- Manifold nuts
 1.2 to 1.6 kg-m
 (8.7 to 11.6 ft-lb)
- Carburetor nuts
 0.5 to 1.0 kg-m
 (3.6 to 7.2 ft-lb)




Fig. ET-7 Tightening sequence

CHECKING ENGINE OIL

1. Check if oil is diluted with water or gasoline. Drain and refill oil if necessary.

Notes:

- A milky oil indicates the presence of cooling water. Isolate the cause and take corrective measure.
- An oil with extremely low viscosity indicates dilution with gasoline.

2. Check oil level. If below the specified level, raise it up to the H level.

- Engine oil capacity
 (including oil filter)
- Maximum (H level)
 4.3 liters
 (4 1/2 US qt, 3 1/2 Imp qt)
- Minimum (L level)
 3.3 liters
 (3 1/2 US qt, 2 1/2 Imp qt)

REPLACING OIL FILTER

The oil filter is a cartridge type and can be removed using Oil Filter Wrench ST19320000.

1. Check for oil leaks past gasketed flange. If leakage is found, retighten just enough to stop leakage. If retightening is no longer effective, replace filter as an assembly.

2. When installing oil filter, tighten by hand.

Note: Do not overtighten oil filter, lest leakage should occur.

CHANGING ENGINE COOLANT

PERMANENT ANTI-FREEZE COOLANT

Permanent anti-freeze coolant is an ethylene glycol base product containing chemical inhibitors to protect the cooling system against corrosion.

The anti-freeze does not contain any glycerine, ethyl or methyl alcohol. It will not evaporate or boil away and can be used with either high or low temperature thermostat.

It flows freely, transfers heat efficiently, and will not clog passages in the cooling system.

The anti-freeze must not be mixed with other products.

This coolant can be used throughout the seasons of the year.

Whenever coolant is changed, the cooling system should be flushed and refilled with a new coolant.


Check the level. See the instructions furnished by the manufacturer for the mixture ratio of anti-freeze to water.

CHECKING COOLING SYSTEM HOSES AND CONNECTIONS

Check hoses and fittings for loose connections or deterioration. Retighten or replace if necessary.

INSPECTION OF RADIATOR CAP

Apply reference pressure [0.9 kg/cm² (13 psi)] to radiator cap by means of a cap tester to see if it is satisfactory. Replace cap assembly if necessary.



ET012

Fig. ET-8 Testing radiator cap

COOLING SYSTEM PRESSURE TEST

With radiator cap removed, apply reference pressure [1.6 kg/cm² (23 psi)] to the cooling system by means of a tester to detect any leakage.

Water capacity

Without heater:


7.4 liters

(7 1/2 US qt, 6 1/2 Imp qt)

With heater:

8.0 liters

(8 1/2 US qt, 7 Imp qt)



ET013

Fig. ET-9 Cooling system pressure test

CHECKING VACUUM FITTINGS, HOSES, AND CONNECTIONS

Check the condition of fittings and hoses. Retighten or replace if necessary.

All vacuum hoses can be identified by colors.

White line

- Vacuum tube to carburetor (E.G.R. Tube)
- Vacuum tube to thermal vacuum valve
- Thermal vacuum valve to E.G.R. control valve