




# WORKSHOP MANUAL



Agrofarm 85  
Agrofarm 100



# TABLE OF CONTENTS

## 0 - INTRODUCTION

0.1 - Introduction	0-2
0.1.1 - Safety notes	0-3
0.1.2 - General safety rules	0-4
0.1.3 - Safety precautions for removal and refitting operations	0-6
0.1.4 - Lifting instructions	0-8
0.1.5 - Tightening torques	0-10
0.1.6 - Threadlockers, adhesives, sealants and lubricants	0-14
0.1.7 - Conversion factors	0-16

## 10 - TECHNICAL CHARACTERISTICS

10.1 - Transmission	10-2
10.1.1 - Transmission (Agrofarm 85)	10-2
10.1.2 - Transmission (Agrofarm 100)	10-10
10.1.3 - Rear. PTO	10-18
10.1.4 - 2 and 4-speed PTO and groundspeed PTO	10-23
10.2 - Front axle	10-25
10.2.1 - Front axle	10-25
10.3 - Hydraulic system	10-28
10.3.1 - Hydraulic system (Agrofarm 85)	10-28
10.3.2 - Hydraulic system (Agrofarm 100)	10-34
10.3.3 - Steering circuit pump - directional control valve circuit	10-39
10.3.4 - Power steering	10-41
10.3.5 - Auxiliary services directional control valve	10-42
10.3.6 - Hydraulic lift directional control valve (Agrofarm 85)	10-43
10.3.7 - Hydraulic lift directional control valve (Agrofarm 100)	10-47
10.3.8 - Braking system	10-51
10.3.9 - "Separate-Brake" valve	10-52
10.3.10 - Trailer braking valve	10-57
10.3.11 - Services solenoid valve assembly	10-60

## 20 - CALIBRATIONS AND ELECTRONIC DIAGNOSIS

20.1 - Diagnostic instrument	20-2
20.1.1 - All Round Tester	20-2
20.1.2 - Connecting the tester to the lift and engine control units	20-7
20.2 - Introduction to the tractor's electronic system	20-8
20.2.1 - Introduction to the tractor's electronic system	20-8
20.3 - Putting the tractor into service	20-10
20.3.1 - Putting the tractor into service	20-10
20.4 - ECU alarms	20-16
20.4.1 - Instrument panel alarms	20-16

## 30 - METHOD

30.1 - Engine	30-2
30.1.1 - Engine - Separation from the transmission (B0.00.02)	30-2

# TABLE OF CONTENTS

30.1.2 - Engine (B0.00.01)	30-7
30.1.3 - Fan belt	30-12
30.1.4 - Tensioning the fan drive belt	30-13
30.1.5 - Alternator and fuel pump drive belt	30-14
30.1.6 - Alternator and fuel pump belt tensioning	30-15
30.2 - Engine accessories	30-16
30.2.1 - RADIATOR - Tractor without front PTO (C0.01.01)	30-16
30.2.2 - RADIATOR - Tractor with front PTO (C0.01.01)	30-20
30.2.3 - Changing the coolant and flushing the circuit	30-24
30.2.4 - Fuel tank (C0.03.01)	30-26
30.2.5 - Starter motor	30-29
30.2.6 - Exhaust pipe - Tractor with cab (C0.06.01)	30-31
30.3 - Transmission	30-32
30.3.1 - Parking brake	30-32
30.3.2 - Clutch plate	30-34
30.3.3 - Clutch thrust bearing	30-36
30.3.4 - Clutch housing - assembly (D0.02.01) (Agrofarm 85)	30-37
30.3.5 - Clutch housing - assembly (D0.02.01) (Agrofarm 100)	30-42
30.3.6 - Gearbox and shuttle assy. - complete unit (D0.09.03)	30-47
30.3.7 - Disassembly of gearbox and shuttle assy. - complete unit	30-49
30.3.8 - Gearbox support and gear selector rods	30-53
30.3.9 - Shuttle shaft	30-56
30.3.10 - Primary shaft	30-60
30.3.11 - Secondary shaft (Agrofarm 85)	30-61
30.3.12 - Secondary shaft (Agrofarm 100)	30-66
30.3.13 - PTO output shaft (4 speed version)	30-71
30.3.14 - PTO output shaft disassembly (4 speed version)	30-74
30.3.15 - PTO output shaft (2 speed version)	30-77
30.3.16 - PTO output shaft disassembly (2 speed versions)	30-80
30.3.17 - PTO clutch	30-81
30.3.18 - PTO clutch disassembly	30-85
30.3.19 - PTO final shaft (2-speed version)	30-90
30.3.20 - PTO final shaft (4-speed version)	30-94
30.3.21 - Groundspeed PTO final shaft	30-98
30.3.22 - Groundspeed PTO engagement device	30-101
30.3.23 - Range and differential assembly - complete assembly	30-102
30.3.24 - Rear pinion (Agrofarm 85)	30-103
30.3.25 - Rear pinion (Agrofarm 100)	30-108
30.3.26 - Four-wheel drive output shaft	30-113
30.3.27 - Differential - Bevel gear pair	30-116
30.3.28 - Range selector assembly	30-125
30.3.29 - Changing transmission oil (D0.00.01)	30-127
30.3.30 - Pump drive PTO - Outer gear	30-129
30.3.31 - Pump drive PTO - Inner gear	30-131
30.3.32 - 4WD engagement device	30-133

# TABLE OF CONTENTS

30.4 - Rear axle	30-136
30.4.1 - RH rear axle (E0.02.01) (Agrofarm 85)	30-136
30.4.2 - LH rear axle (E0.02.02) (Agrofarm 85)	30-139
30.4.3 - RH/LH rear axle (Agrofarm 85)	30-143
30.4.4 - RH rear axle (Agrofarm 100)	30-148
30.4.5 - Planet carrier assembly (Agrofarm 85)	30-152
30.4.6 - LH rear axle (Agrofarm 100)	30-154
30.4.7 - RH/LH rear axle (Agrofarm 100)	30-158
30.4.8 - Planet carrier assembly (Agrofarm 100)	30-164
30.4.9 - Rear differential	30-166
30.4.10 - Rear differential disassembly (Agrofarm 85)	30-169
30.4.11 - Rear differential disassembly (Agrofarm 100)	30-172
30.4.12 - Rear axle brake discs	30-175
30.4.13 - Rear axle brake piston (Agrofarm 85)	30-176
30.4.14 - Rear axle brake piston (Agrofarm 100)	30-178
30.5 - Front axle	30-180
30.5.1 - Front carrier (F0.01.01)	30-180
30.5.2 - 4WD front axle (F0.03.01)	30-184
30.5.3 - Adjusting the front axle end float	30-186
30.5.4 - Steering cylinders	30-189
30.5.5 - Steering cylinders disassembly	30-191
30.5.6 - Final drive reduction unit	30-195
30.5.7 - Final drive reduction unit disassembly	30-197
30.5.8 - Steering knuckle housing and halfshaft	30-203
30.5.9 - Steering knuckle housing and halfshaft	30-209
30.5.10 - Differential unit	30-212
30.5.11 - Differential disassembly	30-214
30.5.12 - Differential unit adjustment	30-217
30.5.13 - Bevel gear pair (Agrofarm 85)	30-221
30.5.14 - Bevel gear pair disassembly (Agrofarm 85)	30-226
30.5.15 - Differential disassembly (Agrofarm 85)	30-236
30.5.16 - Bevel gear pair (Agrofarm 100)	30-238
30.5.17 - Bevel gear pair disassembly (Agrofarm 100)	30-243
30.5.18 - Differential disassembly (Agrofarm 100)	30-253
30.5.19 - Front brake discs	30-255
30.5.20 - Front axle brake piston	30-256
30.5.21 - 4WD shaft	30-257
30.6 - Bodywork - Cab - Platform	30-260
30.6.1 - Cab (G0.03.01)	30-260
30.6.2 - Front hoods (G0.01.01)	30-268
30.6.3 - Fenders	30-270
30.6.4 - Front instrument panel (G0.06.04)	30-271
30.6.5 - Air conditioning	30-274
30.6.6 - Compressor	30-277
30.6.7 - Clutch master cylinder	30-278
30.6.8 - Clutch piston	30-281

# TABLE OF CONTENTS

30.6.9 - Clutch control circuit	30-282
30.6.10 - Brake master cylinders	30-283
30.6.11 - Control levers (Agrofarm 85)	30-285
30.6.12 - Control levers (Agrofarm 100)	30-289
30.7 - Hydraulic system	30-294
30.7.1 - Pump for hydraulic lift and auxiliary services	30-294
30.7.2 - Power steering (H0.02.01)	30-296
30.7.3 - Pressure relief valve setting:	30-298
30.7.4 - Power steering disassembly	30-299
30.7.5 - Power steering pump	30-316
30.7.6 - Rear 4-way auxiliary services control valve (Agrofarm 85)	30-318
30.7.7 - Rear 6-way auxiliary services control valve (Agrofarm 100)	30-320
30.7.8 - Braking circuit (Agrofarm 85)	30-324
30.7.9 - Braking circuit (Agrofarm 100)	30-326
30.7.10 - Services solenoid valve assembly	30-329
30.8 - Front PTO	30-331
30.8.1 - Front PTO	30-331
30.8.2 - PTO assembly.	30-336
30.8.3 - Pump assy	30-347
30.8.4 - Clutch-brake assembly	30-349
30.8.5 - Solenoid valve assy	30-356
30.9 - Front lift	30-357
30.9.1 - Front lift	30-357
30.9.2 - Lift cylinders	30-359
30.10 - Rear lift	30-363
30.10.1 - Lift - Complete assembly (R0.02.03) (Agrofarm 85)	30-363
30.10.2 - Lift disassembly - complete assembly (Agrofarm 85)	30-366
30.10.3 - Lift - Complete assembly (R0.02.03) (Agrofarm 100)	30-371
30.10.4 - Lift disassembly - Complete assembly (Agrofarm 100)	30-375
30.10.5 - Lift cylinder (Agrofarm 100)	30-380
30.10.6 - Bushes (Agrofarm 100)	30-382
30.10.7 - Hydraulic lift directional control valve (Agrofarm 85)	30-383
30.10.8 - Lift control valve disassembly (Agrofarm 85)	30-384
30.10.9 - Lift control valve disassembly (Agrofarm 100)	30-390
30.10.10 - Mechanical draft sensor (Agrofarm 85)	30-396
30.10.11 - Mechanical draft sensor disassembly (Agrofarm 85)	30-397
30.10.12 - Mechanical draft sensor (Agrofarm 100)	30-399
30.10.13 - Mechanical draft sensor disassembly (Agrofarm 100)	30-400
30.10.14 - 3-point linkage	30-402
30.11 - Wheels	30-404
30.11.1 - Front wheels (S0.01.01)	30-404
30.11.2 - Rear wheels (S0.02.01)	30-405
30.12 - Ballast - Towing hitches	30-406
30.12.1 - Towing hitch slide (Agrofarm 85)	30-406
30.12.2 - Towing hitch slide (Agrofarm 100)	30-407



# TABLE OF CONTENTS

## 40 - WIRING DIAGRAMS

40.1 - Introduction	40-2
40.1.1 - Structure of the unit	40-2
40.1.2 - Wiring and components index	40-8
40.2 - Components	40-22
40.2.1 - Components	40-22
40.3 - Systems	40-33
40.3.1 - Earthing points	40-33
40.3.2 - Starting and pre-heating	40-35
40.3.3 - Lights selector - Tractor with cab	40-37
40.3.4 - Lights selector - Tractor with platform	40-39
40.3.5 - Diagnostic accessories - Tractor with standard cab	40-41
40.3.6 - Diagnostic accessories - Tractor with high-visibility cab	40-43
40.3.7 - Instrument panel	40-45
40.3.8 - Worklights - Tractor with standard cab	40-47
40.3.9 - Wipers - Tractor with standard cab	40-49
40.3.10 - Heating system - Tractor with standard cab	40-51
40.3.11 - Air conditioning system - Tractor with standard cab	40-53
40.3.12 - Worklights - Tractor with high-visibility cab	40-55
40.3.13 - Wipers - Tractor with high-visibility cab	40-57
40.3.14 - Heating system - Tractor with high-visibility cab	40-59
40.3.15 - Air conditioning system - Tractor with high-visibility cab	40-61
40.3.16 - Transmission	40-63
40.3.17 - PTO	40-65
40.3.18 - Brakes	40-67
40.3.19 - CAN BUS ELECTRONIC SYSTEM	40-69
40.4 - Wiring looms	40-70
40.4.1 - Hood lights wiring - 0.014.8107.4/20	40-70
40.4.2 - Hood lights wiring connector positions	40-71
40.4.3 - Engine wiring - version with front battery - 0.014.8629.4/20	40-73
40.4.4 - Engine wiring connector positions - version with front battery	40-74
40.4.5 - Engine wiring - version with lateral battery - 0.015.1597.4/10	40-77
40.4.6 - Engine wiring connector positions - version with lateral battery	40-78
40.4.7 - Battery wiring loom - 0.014.8806.4/20	40-81
40.4.8 - Battery wiring connector positions	40-82
40.4.9 - Preheating wiring loom - 0.014.9195.4/20	40-86
40.4.10 - Pre-heating wiring connector positions	40-87
40.4.11 - Power supply wiring - 0.015.1983.4/10	40-89
40.4.12 - Power supply wiring connector positions	40-90
40.4.13 - Instrument panel wiring - 0.014.8628.4/20	40-93
40.4.14 - Instrument panel wiring connector positions	40-97
40.4.15 - RH drivetrain wiring - 0.014.8630.4/20	40-101
40.4.16 - RH drivetrain wiring connector positions	40-102
40.4.17 - LH drivetrain wiring - 0.014.9193.4/20	40-104
40.4.18 - LH drivetrain wiring connector positions	40-105



## TABLE OF CONTENTS

40.4.19 - Power supply wiring - Tractor with standard cab - 0.014.9375.4/20	40-107
40.4.20 - Power supply wiring connector positions - Tractor with standard cab	40-108
40.4.21 - Roof line wiring - Tractor with standard cab - 0.009.7850.4/50	40-110
40.4.22 - Roof line wiring connector positions - Tractor with standard cab	40-112
40.4.23 - Heating wiring - Tractor with standard cab - 0.010.2147.2	40-115
40.4.24 - Heating system wiring connector positions - Tractor with standard cab	40-116
40.4.25 - Air conditioning wiring - Tractor with standard cab - 0.010.2153.2	40-118
40.4.26 - Air conditioner wiring connector positions - Tractor with standard cab	40-119
40.4.27 - Air conditioning cooler fan wiring - Tractor with standard cab - 0.009.7853.3/20	40-121
40.4.28 - Air conditioner exchanger fan wiring connector positions - Tractor with standard cab	40-122
40.4.29 - Front-rear worklights wiring - Tractor with standard cab - 0.009.7851.4/50	40-124
40.4.30 - Supplementary worklights wiring connector positions - Tractor with standard cab	40-126
40.4.31 - Supplementary worklights wiring - Tractor with standard cab - 0.015.1435.4/10	40-128
40.4.32 - Supplementary worklights wiring connector positions - Tractor with standard cab	40-130
40.4.33 - Windscreen wiper wiring - Tractor with standard cab - 0.010.4516.3	40-132
40.4.34 - Windscreen wiper connector positions wiring - Tractor with standard cab	40-133
40.4.35 - Loudspeaker wiring - Tractor with standard cab - 0.011.0729.4/10	40-135
40.4.36 - Loudspeaker wiring connector positions - Tractor with standard cab	40-137
40.4.37 - Cab power supply wiring - Tractor with high-visibility cab - 0.014.9376.4/10	40-139
40.4.38 - Cab power supply wiring connector positions - Tractor with high-visibility cab	40-140
40.4.39 - Roof line wiring - Tractor with high-visibility cab - 0.011.3606.4/50	40-142
40.4.40 - Roof line wiring connector positions - Tractor with high-visibility cab	40-145
40.4.41 - Heating system wiring - Tractor with high-visibility cab - 0.010.2554.2	40-147
40.4.42 - Heating system wiring connector positions - Tractor with high-visibility cab	40-149
40.4.43 - Air conditioning wiring - Tractor with high-visibility cab - 0.010.2560.0	40-151
40.4.44 - Air conditioner wiring connector positions - Tractor with high-visibility cab	40-153
40.4.45 - Air conditioning cooler fan wiring - Tractor with high-visibility cab - 0.011.3610.3/20	40-155
40.4.46 - Air conditioning exchanger fan wiring connector positions - Tractor with high-visibility cab	40-156
40.4.47 - Front-rear worklights wiring - Tractor with high-visibility cab - 0.011.3595.3/10	40-158
40.4.48 - Worklights wiring connector positions - Tractor with high-visibility cab	40-159
40.4.49 - Supplementary worklights wiring - Tractor with high-visibility cab - 0.015.1437.4/10	40-161
40.4.50 - Supplementary worklights wiring connector positions - Tractor with high-visibility cab	40-162
40.4.51 - Windscreen wiper wiring - Tractor with high-visibility cab - 0.011.3597.3	40-166
40.4.52 - Windscreen wiper wiring connector positions - Tractor with high-visibility cab	40-167
40.4.53 - Loudspeaker, radio, rear wiper, flashing light and clock wiring - Tractor with high-visibility cab - 0.011.3596.3/40	40-169
40.4.54 - Loudspeaker, radio, rear wiper, flashing light and clock wiring connector positions - Tractor with high-visibility cab	40-171
40.4.55 - Wiring for front lights - Tractor with cab - 0.010.8189.3/40	40-173
40.4.56 - Front lights wiring connector positions - Tractor with cab	40-174
40.4.57 - Wiring for lower front lights - Tractor with cab - 0441.1923.4	40-177
40.4.58 - Lower front lights wiring connector positions - Tractor with cab	40-178
40.4.59 - Wiring for front lights - Tractor with platform - 0.015.3094.4	40-180
40.4.60 - Front lights wiring connector positions - Tractor with platform	40-182
40.4.61 - Worklights wiring - Tractor with platform - 0.014.9281.4	40-184





## TABLE OF CONTENTS

---

40.4.62 - Worklights wiring connector positions - Tractor with platform	40-186
40.4.63 - Rotating beacon wiring - 0.012.9909.4	40-188
40.4.64 - Position of rotary beacon wiring connectors	40-189
40.4.65 - Trailer hydraulic braking wiring - 0.014.1645.4/10	40-191
40.4.66 - Trailer hydraulic braking wiring connector positions	40-192







# TABLE OF CONTENTS

---

PAGE LEFT INTENTIONALLY BLANK





---

# 0 - INTRODUCTION

---





# INTRODUCTION

---

## 0.1 - INTRODUCTION

The purpose of this workshop manual is to provide instruction for repair technicians and a practical guide to improving the quality of repairs. This manual enables repair technicians to acquire a thorough knowledge of the machine, indicating the correct methods for fault diagnosis, for working in safety and for accurate dimensional checks and visual inspections. The instructions also indicate the products to use, the tightening torques and the adjustment data. The technical material contained in this manual is reserved to Authorised Dealers and Service Centres who will be duly informed of any technical changes to the machines in question through the issue of documents regarding modifications, updates and supplements for optional equipment. All technicians and their colleagues are expressly forbidden from reproducing any part of this manual in any form or from communicating the contents to third parties without the express written permission of the Manufacturer, who remains the sole owner of this document with all rights reserved in accordance with applicable laws.





# INTRODUCTION

---

## 0.1.1 - Safety notes

To ensure that machines entrusted to Authorised Service Centres for repair or overhaul continue to function correctly, it is very important that all repair work is carried out in the prescribed manner. The procedures for checks and repairs indicated in this manual are safe and effective. Some of the operations described require the use of special tools and equipment; these tools have been specifically designed for the intended purpose and may be ordered directly from the Manufacturers. **DO NOT USE MAKESHIFT TOOLS**; not only is there a risk of personal injury, but such tools are rarely suited to the purpose for which they are used. In potentially hazardous situations, always give priority to personal safety and take the necessary actions to eliminate the danger





# INTRODUCTION

## 0.1.2 - General safety rules

- Even if you have a thorough knowledge of the machine as regards its components, operation and controls, always take special care when carrying out the following operations; Remember that the machine you are working on is in need of repair or overhaul and consequently may not always behave as expected.
- Before starting work, clean the tractor thoroughly to remove all mud, dust and road dirt. Also clean the cab to remove all traces of oil, snow and ice from the access steps and grab rails.
- When climbing up to or down from the cab, always ensure you maintain three points of contact at a time (foot or handholds) in order to keep your balance and prevent accidental falls.
- Always take special care when carrying out fault diagnosis operations; these operations often require two persons, who must never stand in front of the wheels when the engine is running.
- When carrying out checks and repairs, wear close-fitting clothing, safety goggles and protective gloves that are suitable for the task (cleaning, draining fluids, repairs). When working near moving parts, long hair should be gathered up and tied back safely under a cap to prevent the risk of entanglement and severe injury.
- Do not allow anyone who is not directly involved in the work to come near the tractor; ensure that they remain at a safe distance.
- Keep well clear of moving parts; when the engine is running, some moving parts are not easily visible and therefore present a risk of entanglement, even if protected by safety guards.
- Ensure that the area is well ventilated before starting the engine in order to avoid the formation of dangerous concentrations of toxic gases; always connect suitable fume extraction equipment to the exhaust pipe.
- Do not start the engine with the safety guards removed under any circumstances; all repair and adjustment operations must be carried out with the engine stopped.
- Do not top up fuel, oil or coolant levels when the engine is running.
- Never smoke and ensure there are no naked flames nearby when topping up fuel or oil. Always remove the battery from the machine before recharging.
- Before checking or removing the battery, stop the engine and remove the key from the starter switch.
- Remove the battery and recharge in a well-ventilated area where the temperature exceeds 0°C.
- When checking or recharging the battery, do not smoke or allow naked flames in the vicinity as the hydrogen gas given off by the battery is highly explosive.
- The liquid (electrolyte) contained in the battery is very harmful if it comes into contact with the skin and the eyes; for this reason, always wear gloves and safety goggles with side shields when checking or topping up the battery. Should any electrolyte accidentally come into contact with your skin, wash the affected areas immediately with plenty of fresh water; if electrolyte comes into contact with your clothing, this should be removed as soon as possible. In case of accidental ingestion of electrolyte, drink copious amounts of water, milk or vegetable oil and take antacids such as magnesium, bicarbonate, etc. and seek medical attention immediately.
- Before working on the electrical systems, always disconnect the battery terminals.



### DANGER

Always disconnect the negative lead (--) before the positive lead (+); when re-connecting the battery on completion of the work, first connect the positive terminal (+) and then the negative (--).

- Before carrying out any arc welding (permitted only on implements attached to the machine) always disconnect the battery terminals and unplug all the connectors of the electronic control units and the alternator.
- When topping up lubricants, always wear suitable protective gloves.
- Do not wear clothing contaminated by engine or hydraulic oil; prolonged contact with the skin can be harmful and may cause allergic reactions.







# INTRODUCTION

---

- Used engine oil and hydraulic oil must be disposed of properly; recover used lubricants and dispose of them in accordance with the applicable regulations.
- Before carrying out any work on the hydraulic or pneumatic systems, discharge all residual pressure from the circuits.
- Before carrying out any work on the hydraulic system or engine, allow the oil and engine coolant to cool down.
- When removing and refitting certain assemblies, it will be necessary to support the tractor; use stands, jacks or blocks capable of supporting the weight and arrange them in a triangular pattern to prevent the machine from overturning.
- To lift heavy components, use a hoist or crane. Check that wire ropes, chains or fibre slings are not worn and that hooks are not damaged.
- Always use lifting equipment of suitable capacity for the weight of the components to be removed. Ensure lifting equipment is attached correctly.
- When lifting or supporting an assembly or component, manoeuvre the parts slowly and carefully to avoid swinging movements or collision with other components.
- Never work on components suspended from a hoist or crane.
- When removing the retaining bolts of a component that could fall, always leave two opposing bolts in place for safety; before removing these last two bolts, attach the component to suitable lifting equipment or position support blocks.
- Any oil or fuel spilled during removal or dismantling operations should be cleaned up as soon as possible to prevent the risk of slipping and fire.
- When refitting electrical wiring looms and wires, ensure that they are properly secured with their original retaining straps or brackets to prevent the possibility of damage caused by vibration.
- Never insert your fingers or hands to check the alignment between fixing holes in components; always use a suitable dowel of soft material.
- When refitting assemblies or components, always use the specified tightening torques; the tightening torques indicated in the paragraphs regarding assembly/refitting operations have been determined through experimentation and must be scrupulously adhered to.
- When refitting parts that are subject to vibration or that rotate at high speed, take particular care when carrying out final installation checks.



# INTRODUCTION

## 0.1.3 - Safety precautions for removal and refitting operations

When removing or refitting parts, always take the following safety precautions.

### Precautions for removal operations

- Unless otherwise indicated, lower the lifting equipment until the component or assembly rests on the ground.
- After disconnecting hydraulic and fuel system pipes, always fit plugs to the open ends of the pipes to prevent ingress of dirt.
- Before removing a cylinder, fully retract the piston and secure it in this position using a retaining strap.
- Use containers of sufficient capacity when draining oil, coolant or fuel.
- Before removing a part from the machine, check for alignment markings indicating the correct assembly position. If necessary, make new markings to ensure correct assembly.
- When unplugging electrical connectors, always grip the connectors firmly to avoid pulling on the wires.
- Where necessary, label wires and pipes before removal to avoid confusion when reconnecting.
- Check the number and thickness of any shims removed and keep them together in a safe place.
- To lift the tractor or any of its main components, use lifting equipment of suitable capacity.
- When using eyebolts for lifting components, first check that they are not deformed or damaged; screw them fully home and then turn the bolt so that the eye is aligned with the lifting hook.
- Before removing a part, clean the surrounding area and, after removing the part, cover it to protect it from dirt and dust.

### Precautions for refitting operations

- Tighten nuts and screws to the specified tightening torques.
- When refitting flexible pipes and cables, take care not to twist or tangle them.
- Always fit new seals, O-rings, split pins and safety stop rings; make sure that the ends of the cotter pins are separated and bent back so that the pin cannot be withdrawn from the hole.
- Ensure that circlips are correctly installed in their seatings.
- When applying threadlocking compound, first clean the part to remove all oil and grease, then cover the thread evenly applying a few drops of the compound.
- When applying sealant, first clean the surface removing all traces of oil and grease and check for dirt or indentations, then apply the sealant evenly making sure that it forms a continuous film around any fixing holes.
- Clean all parts, removing dirt, oxidation, carbon deposits, burrs and indentations.
- Coat all moving parts with a thin film of engine oil.
- When reconnecting electrical wiring connectors, first remove all traces of oil, dust and water from the inside of the connector and then push the two halves together firmly; connectors with locking tabs should be pushed together until the tab engages the keeper.
- Bolt down flanged fittings evenly, tightening the screws gradually in a crosswise pattern.

### Precautions to be taken on completion of removal/refitting operations

- If coolant has been drained from the engine, refit the drain plug and pour in new coolant to the correct level. Start the engine to circulate the coolant and then check the level again and top up.
- After removing hydraulic components, top up the hydraulic oil to the specified level. Start the engine to circulate the oil in the hydraulic circuits and then recheck the level and top up as necessary.





# INTRODUCTION

---

- After having removed a variable displacement pump, connect the drain pipe and fill the pump casing with oil through the filler hole provided.
- Grease stub axle housings, cylinder pivot mountings and drive shafts thoroughly after assembly.



# INTRODUCTION

## 0.1.4 - Lifting instructions










### DANGER

Components weighing over 25 kg or of significant size must be supported and removed using suitable lifting equipment with wire rope or polyester slings.

## Wire ropes - slings

- Use wire ropes or polyester slings of suitable capacity for the parts to be lifted, referring to the following tables:

Tab.1

WIRE ROPES (standard twisted "S" or "Z" type)				POLYESTER SLINGS (eye-and-eye - simple loop)				
Ø rope mm	Capacity (kg)			Width (mm)	Capacity (kg)			
								
8	650	620	500	25	500	400	860	700
10	1000	1740	1420	50	1000	800	1730	1410
12	1450	2500	2050	62	1250	1000	2160	1760
14	2000	3460	2820	75	1400	1120	2420	1980
16	2600	4500	3670	100	2000	1600	3460	2820
18	3300	5710	4660	150	2500	2000	4330	3530



Lifting capacities are calculated with a safety coefficient.

- The lifting hook should be attached to the central part of the rope or sling; if the hook is attached near the ends of the rope/sling, this could cause the load to slip during lifting.
- Never lift a heavy load using a single rope; always use two or more symmetrically arranged ropes.




### DANGER

Suspension of a load from a single rope could cause the load to start rotating and consequently cause the rope strands to untwist or the load to slip; this could lead to serious injury.

- Never lift a heavy load when the two legs of the ropes form a wide angle. the permitted load (kg) decreases in inverse proportion to the angle of suspension; the table below indicates how the permitted load varies according to the angle of suspension for two Ø 10 mm ropes each with a load capacity of 1000 kg.

# INTRODUCTION



*Fig.1*



## 0.1.5 - Tightening torques

### Bolts and nuts



#### DANGER

The tightening torques for certain specific components and special tightening methods are indicated in the relative assembly paragraphs.

The tightening torques indicated below refer to screws and nuts assembled without lubrication and, where applicable, with anaerobic threadlocking compound. The values apply to tightening on steel or cast iron components; for soft materials such as aluminium, copper, plastic, sheet metal or panels, the indicated tightening torques must be reduced by 50%.





**Tab.2**

BOLT SIZE		BOLT CLASS					
		8.8		10.9		12.9	
		Nm	lb.ft.	Nm	lb.ft.	Nm	lb.ft.
COAR- SE	M6x1	8.0 – 8.8	5.9 – 6.5	11.8 – 13.0	8.7 – 9.6	13.8 – 15.2	10.2 – 11.2
	M8x1.25	19.4 – 21.4	14.3 – 15.8	28.5 – 31.5	21.0 – 23.2	33.3 – 36.9	24.5 – 27.2
	M10x1.5	38.4 – 42.4	28.3 – 31.2	56.4 – 62.4	41.6 – 46.0	67.4 – 74.4	49.7 – 54.8
	M12x1.75	66.5 – 73.5	49.0 – 54.2	96.9 – 107	71.4 – 78.9	115 – 128	84.8 – 94.3
	M14x2	106 – 117	78.1 – 86.2	156 – 172	115.0 – 126.8	184 – 204	135.6 – 150.3
	M16x2	164 – 182	120.9 – 134.1	241 – 267	117.6 – 196.8	282 – 312	207.8 – 229.9
	M18x2.5	228 – 252	168.0 – 185.7	334 – 370	246.2 – 272.7	391 – 432	288.2 – 318.4
	M20x2.5	321 – 355	236.6 – 261.6	472 – 522	347.9 – 384.7	553 – 611	407.6 – 450.3
	M22x2.5	441 – 487	325.0 – 358.9	647 – 715	476.8 – 527.0	751 – 830	553.5 – 611.7
	M24x3	553 – 611	407.6 – 450.3	812 – 898	598.4 – 661.8	950 – 1050	700.2 – 773.9
FINE	M8x1	20.8 – 23.0	15.3 – 17.0	30.6 – 33.8	22.6 – 24.9	35.8 – 39.6	26.4 – 29.2
	M10x1.25	40.6 – 44.8	29.9 – 33.0	59.7 – 65.9	44.0 – 48.6	71.2 – 78.6	52.5 – 57.9
	M12x1.25	72.2 – 79.8	53.2 – 58.8	106 – 118	78.1 – 87.0	126 – 140	92.9 – 103.2
	M12x1.5	69.4 – 76.7	51.1 – 56.5	102 – 112	75.2 – 82.5	121 – 134	89.2 – 98.8
	M14x1.5	114 – 126	84.0 – 92.9	168 – 186	123.8 – 137.1	199 – 220	146.7 – 162.1
	M16x1.5	175 – 194	129 – 143	257 – 285	189.4 – 210.0	301 – 333	221.8 – 245.4
	M18x1.5	256 – 282	188.7 – 207.8	375 – 415	276.4 – 305.9	439 – 485	323.5 – 357.4
	M20x1.5	355 – 393	261.6 – 289.6	523 – 578	385.5 – 426.0	611 – 676	450.3 – 498.2
	M22x1.5	482 – 532	355.2 – 392.1	708 – 782	521.8 – 576.3	821 – 908	605.1 – 669.2
	M24x2	602 – 666	443.7 – 490.8	884 – 978	651.5 – 720.8	1035 – 1143	762.8 – 842.4

### Fittings

The tightening torques indicated below refer to fittings assembled on any material.

**Tab.3**

ME- TRIC	Straight end fittings	T" end fittings	L" end fittings	90° end fittings
				



# INTRODUCTION

	Thread size	Wrench	Torque Nm ±10%	Wrench	Torque Nm ±10%	Wrench	Torque Nm ±10%	Wrench	Torque Nm ±10%
	M10x1.25	17	14	14	14	14	14	14	14
		19	14	17	14	17	14		
	M12x1.25	19	30	17	30	17	30	17	30
	M14x1.5	19	40	19	40	19	40	19	40
	M16x1.5	22	48	22	48	22	48	22	48
	M18x1.5	24	58	24	58	24	58	24	58
	M20x1.5	27	65	27	65	27	65	27	65
	M22x1.5	30	73	30	73	30	73	30	73
	M26x1.5	36	95	36	95	36	95	36	95
	M27x2	36	100	36	100	36	100	36	100
	M33x2	41	160	41	160	41	160	41	160
	M42x2	50	250	50	250	50	250	50	250
	M48x2	60	305	60	305	60	305	60	305
	G 1/8"	17	13	14	13	14	13	14	13
		19	13						
	G 1/4"	19	37	19	37	19	37	19	37
		22	37						
	G 3/8"	24	53	24	53	24	53	24	53
	G 1/2"	27	73	27	73	27	73	27	73
		30	73						
	G 3/4"	36	100	36	100	36	100	36	100
	G 1"	41	160	41	160	41	160	41	160
		46	160						
	G 1 1/4"	50	250	50	250	50	250	50	250
	G 1 1/2"	60	305	60	305	60	305	60	305

## Plugs

Tab.4

Thread size	Hex plugs		Threaded plugs with hex socket head	
	Wrench	Torque Nm ±10%	Wrench	Torque Nm ±10%