

WORKSHOP MANUAL

AGROPLUS 75

AGROPLUS 85

AGROPLUS 95

AGROPLUS 100

Introduction

This publication is intended for the trained technician who must operate on our tractors.

It contains all general information relating to our tractor range, and in particular it highlights the inspection, overhauling and adjustment procedures as well as the main instructions for dismantling and reassembling operations.

The workshop manual is a natural summary for the mechanic who has attended the vocational training and specialization courses, which are held every year at our Service School, to permit him to perform a precise and qualified work on tractor.

Its contents are therefore an exhaustive reference book for the experienced mechanic who desires to refresh his memory on the sequence of the operations to be done. It is then good practice for every authorized dealer mechanic to have at his disposal this publication, so that it may be consulted quickly when necessary.

We wish to thank in advance for the cooperation all those people, who will let us have their suggestions in order to make this publication more complete.

List of contents

- Agropius 75 - 85 - 95 - 100 tractor configurations 8
- Dimensions and weights 9
- Prescribed Lubricant and fuels 10
- Conversion tables 11
- Parts 12

1 - ENGINE

- Engine 13

2 - CLUTCH AND TRANSMISSION

- Gearshift clutch 14
 - General characteristics 14
 - Technical specifications 14
- Installation of the clutch release fork 19
- Cecking clutch 20
- Adjusting clutch control pedal 20
- Bleeding air from the hydraulic circuit 20
- Stripping the slave cylinder 21
- Inspections 21
- Notes on refitment 21
- Stripping the master cylinder 22
- Inspections and checks 23
- Reassembly 23
- Fault diagnosis 24
- Powershift unit 25
 - Technical specifications 25
- Fitment of the Powershift unit 29
- Adjustment of end float in the Powershift unit 31
- Main operations involved in assembly of Powershift unit 32
- Spring specifications 42
- Fault diagnosis 42

3 - TRANSMISSION

- Technical specifications 43
- Transmission configurations with 5 speed gearbox 44
- Gearbox removal 59
- Stripping the gearbox 60
- Examining parts removed 61
 - Gearbox case 61
 - Shafts 61
 - Gears 61
 - Synchronizers 61
 - Bearings 61
 - Installing circlips of variable thickness 62
 - Nominal dimensions of gearbox bushes 62
 - Installing the intermediate shaft bearing 63
 - Adjusting secondary shaft end float for the 5-speed gearbox 64
- Shimming the range gear input shaft on tractors without Powershift transmission 65
 - Calculating shim thickness 66
- Shimming the range gear input shaft on tractors with Powershift transmission 67
 - Calculating shim thickness 68
- "Powershuttle" electro-hydraulic shuttle control 69
 - Updating the EPROM of the Control unit 69
 - Powershuttle self-diagnostics tester 71
 - Installation of the shuttle unit 75
 - Assembly of the compound gears 76
- Adjustment of the shuttle unit 76

- Adjusting the bevel drive 78
- Refitting the bevel drive without replacing any components 78
- Replacing the crown wheel bearings 78
- Replacing the pinion bearings 78
- Installation of the support plate for the gear selector rods 80
- Orienting the gearbox shuttle control levers 81
- Surfaces where sealant is to be applied 82
- Main assembly operations involving transmission housing, rear axle, hydraulic lift and engine 88
- Tightening torques 92
- Rear power take-off 94
- Operation of Power take-off - Agroplus 75 - 85 - 95 (4 speeds) 99
- Operation of Power take-off - Agroplus 100 (4 speeds) 100
- Technical specifications 101
- Fitting the P.T.O. shaft 101
- Power take-off clutch 102
- Spring specifications 102
- Checking end float on the front shaft of the P.T.O. clutch 104
- Checking the clearance between discs 106
- Testing pressures in the clutch assembly 107
- Essential operations for refitment of the rear P.T.O. assembly 109
- Fault diagnosis 111

4 - DRIVE AXLES - AXLES

- Rear axle 112
- Assembly of rear halfshafts 115
- Removing and stripping the epicyclic hub assembly 117
- 2-W.D. extendible axle 118
- Removing the axle from the front support 120
- Centre steering lever 123
- Wheel hub 124
- Inspections and checks 125
 - Correct steering rod assembly 126
 - Adjusting end play 126
- Front-wheel drive 127
 - Technical specifications 127
 - Front drive axle ratios 127
 - Adjusting toe-in 127
 - Adjusting steering angles 127
 - Inspections and checks 129
- Wheel hub 130
- Final epicyclic reducer 131
 - Disassembling the hub 131
 - Stripping down the epicyclic 131
 - Installation 131
 - Shimming epicyclic reducer bearings 131
 - Brakes 132
 - Final epicyclic reducer 132
 - Axle shafts 132
 - Forks 132
 - Adjusting wheel fork bearing preloading 132
- Side hubs 133
- Fitting the bolts and pivots of the steering cylinder mounting 134
- Pins 134
- Axle shafts 134
- Gears 134
- Bearings 134
- Adjusting bevel gears 136
- Internal adjustment of mechanical type differential lock 137
- Installing the differential assembly into the drive axle 137
- Tightening torques 138
- Fitting the steering angle limiting bolts 138
- Fault diagnosis 140
- ASM System 141
- General characteristics 141

- Setting the angle of the ASM sensor positioning plate 142
- Fitting the steering angle sensor 142
- Removing the differential unit from the front axle 143
- Stripping the front differential lock clutch 143
- adjustment of front axle bevel gear pair on machines with ASM System 144
- Installation of differential unit in front axle 146
- Assembly and positioning of the ASM System brake switches 146
- Four wheel drive engagement clutches for machines with ASM System 147
- Technical specifications 147
- Front and rear differential lock clutches for machines with ASM System 148
- Technical specifications 148

5 - VEHICLE

- Brakes 149
 - General characteristics 149
 - Technical specifications 149
- Hydraulic pump 150
 - Disassembly and checking procedure 150
- Assembly of brake master cylinder 152
- Checking the discs of the 2WD and 4WD front brakes and rear brakes 153
- Adjusting service brake pedals 153
- Checking parking brake pads 154
- Parking brake control lever overall travel 154
- Bleeding air from the brake hydraulic system 155
- "Separate Brakes" valve 156
- Fault diagnosis 160
 - Technical specifications 161
- Electronic power-lift 162
- Electronic control unit: operator panel 162
 - Operation 165
 - Main control switch 165
 - Stop switch 165
- ALL ROUND TESTER (1st version) 166
- Resident diagnostics 171
- AUTO-MAN procedure for entering the wheel constant relative to a tyre not listed in the table 175
 - Setting the maximum lift height 175
- Setting up the draft control sensor 175
- Setting up the steering sensor 176
- Verify the operational efficiency of the system's electrical components 176
- Multifunction control handset mounted to seat armrest 176
- External buttons 176
- Position control sensor 176
- ASM System 176
 - Selecting the control type 177
 - Setting the maximum lift height 177
 - Lock/Unlock pushbutton 177
 - Ground-operated pushbutton controls 178
 - Main control knob 178
 - Lowering speed adjustment knob 178
 - Sensitivity adjustment knob 178
 - Up/Down indicator lights 178
 - Alarm warning light 178
 - Electronic lift type ELCII 179
 - Control panel 180
 - Lift operating controls 181
 - Lift setting controls 182
 - Safety features 182
 - Oscillation damping during transport 183
 - Operating conditions 183
 - Auxiliary service control switches 183
 - Procedure for setting up the electronic lift 184
 - RADAR / No RADAR 184
 - Entering the type of tyre 184
 - ALL ROUND TESTER (2nd version) 186

- Emergency manual control of the electronic lift 192
- Solenoid operated control valve, hydraulic lift 193
- Control of lift system operating pressure 194
- Electro-hydraulic power-lift distributor 195
- Fitment of lift arms position control sensor 201
- Operation of the directional control solenoid valves 201
- Correct fitment of draft control sensor 204
- Onboard radar 205
- Electronic power-lift safety precautions 205
- How an electronic system must be inspected 206
- Checking mechanical parts 206
- Fitting the lift arms cross shaft crank lever set screw 206
- Original type "load sensing" hydraulic power-lift 208
 - Controls 208
 - Fitment of cross shaft crank lever set screw 211
 - Fitment of cross shaft cam set screw 211
 - Fitment of piston seal 211
 - Adjusting power-lift system 218
 - Adjusting lifting control lever 218
 - Adjusting working depth control lever 218
 - Checking the lifting system 221
 - Checking the operating pressure of the lift system 221
 - Removing the directional control valve from the lift housing 221
 - Checking distributor when assembled 222
 - Inspection and checks 224
 - Reassembling the lift 224
- Sensing arm 225
 - Power-lift distributor valve spring setting specifications 228
 - Fault diagnosis 229
- Front hydraulic power-lift 230
 - Inspections 230
 - Technical specifications 231
 - Hydraulic pressure accumulator and anti-shock valve for the front power-lift 231
- Front power take-off 233
 - General characteristics 233
 - Technical data 233
 - Engagement stage 234
 - Disengagement stage 235
 - Checking clutch 239
 - Check the clearance of the clutch friction discs 239
- Checking the clutch assembly engagement pressure 239
 - With the P.T.O. engaged 239
 - With the P.T.O. disengaged 239
- Fault diagnosis 240
- Spring specifications 240

6 - CONTROLS

- Hydrostatic steering 241
 - General characteristics 241
- Inspections and checks 242
 - Steering pump 242
 - Directional control valve 242
 - Check the setting of the pressure relief valve 242
 - Bleeding the hydraulic circuit 242
 - Assembly of orbital pump unit 242
 - Steering wheel shaft 243
 - Steering cylinders 243
- Servicing 246
- Instructions for the hydrostatic steering distributor assembly 247
- Mechanical controls 252
 - Fitting and adjustment of the external controls of the mechanical governor 258
 - Accelerator pedal 258
 - Hand throttle 258
 - Connection of the accelerator pedal and hand throttle cables to the governor 258
- Electrohydraulic controls 262

- Front PTO clutch command 262
- Rear PTO clutch command 262
- ASM System control 262
- HARD/SOFT gearshift control 262
- Differential lock engagement control 262
- Front-wheel drive engagement 262
- PTO control 262
- Transmission 262
- “Powershuttle” with electro-hydraulic control 262
- Front and rear lift 262
- Rear differential lock control cylinder for machines not equipped with ASM System 274
- Four wheel drive disengagement cylinder for machines not equipped with ASM System 274
- Adjustment of front and rear differential lock control mechanism for machines not equipped with ASM System 275
- Adjustment of four wheel drive control linkage for machines not equipped with ASM System 276

7 - BODY

- Platform 277
- Cab 278
 - General characteristics 278
- Cab air filter 280
- Screen wash 280
- Screen wipers (front and rear) 280
- Removing the driving platform complete with cab 281
- Remove cab 282

8 - SYSTEMS

- Ventilation 283
- Heating System 283
- System configuration 284
- Air conditioning unit for cabs 287
- Operation and maintenance of the air-conditioning system 288
 - Air-conditioning process 288
 - How to operate the system 288
 - Checking the air-conditioning system charge 288
 - Electric fan unit 289
 - Tracing faults in the electric fan unit 289
- Checking system 291
- System safety elements 291
 - Minimum pressure switch 291
 - Maximum pressure switch 291
 - Condenser fan control pressure switch 291
- Temperature regulation 291
- Charging the system 292
- Filling the metering unit 292
- Refilling the system with oil 292
 - Filling the system with oil 293
 - Filling the system with R134a refrigerant 293
 - Final checks 293
- Verifying operation of the system after recharging 294
- Directions for tightening air conditioning system pipeline fittings 294
- Fault diagnosis 297
- Hydraulic system 298
- Oil filters 299
- Hydraulic pumps 299
- Checking the relief valves of the hydraulic lift system 299
- Stripping the hydraulic pump 300
 - Removal 301
 - Inspections and checks 302
 - Assembly 302
 - Tightening torques 302
- Auxiliary hydraulic service control valve 303

- Checking the pressure relief valve setting 312
 - Checking the operating pressure 312
 - Conversion of auxiliary spool valves from double acting to single acting operation . . 312
 - Checking the surface of the valve spools 312
- Trailer hydraulic braking system 313
 - Technical specifications 313
- Use of the tractor with CUNA 341/01 hydraulic trailer braking 314
- Installing the hydraulic braking valve for trailers equipped with "safety brake" (ITALY version) 320
- Electrical system 321
- General safety directions 322
 - Precautions against damage to electrical and electronic equipment 322
 - Precautions against accident and injury 322
- Jump start utilizing another battery 323
 - Precautions 323
 - Procedure 323
- Dashboard 325
 - Ignition switch 326
 - Ventilation control 326
 - Push button control 327
 - Work lights 328
 - Screen wiper-wash push button 328
 - Beacon push button 328
 - Relay 329
 - Electronic flasher unit 329
 - Interior roof light 330
 - Switch controlling: differential lock - P.T.O. clutch - 4WD - 540 1000 rpm/min
P.T.O. speed selector - Economy P.T.O. - Live P.t.o. - electric starter system 330
 - Switch for emergency brake 330
- Fuse box 331
 - Tractor fuse box 331
 - Cab fuse box 331
- Instrument panel with digital display 332
- Engine stop operation with a type 2MH engine control unit 334
- Electrical wiring 335

AGROPLUS 75 - 85 - 95 - 100 TRACTOR CONFIGURATIONS

AGROPLUS 75 - 85 - 95 - 100	2WD	WITH PLATFORM
	2WD	WITH CAB
	4WD	WITH PLATFORM
	4WD	WITH CAB
	2WD	WITH HIGH VISIBILITY CAB
	4WD	WITH HIGH VISIBILITY CAB

- CAB**
- ventilation + heating
 - with ventilation + heating + air conditioning

GEARBOX

On request, the tractors may be equipped with the following gearboxes, providing:
15 forward and 15 reverse speeds: 5 gears x 3 ranges (hair-tortoise-snail) + reverse shuttle;
20 forward and 20 reverse speeds: 5 gears x 4 ranges (hair-tortoise-snail-superslow) + reverse shuttle;
30 forward and 15 reverse gears: 5 gears x 3 ranges (hair-tortoise-snail) x 2 selections (normal-minireduction) + reverse shuttle;
40 forward and 20 reverse gears: 5 gears x 4 ranges (hair-tortoise-snail-superslow) x 2 selections (normal-minireduction) + reverse shuttle;

Optional: POWERSHIFT gearbox, which allows selection of all speeds  -  -  - in the selected version for a total of:

45 forward and 45 reverse speeds: 5 gears x 3 ranges (hair-tortoise-snail) x (3-speed POWERSHIFT) + reverse shuttle;

60 forward and 60 reverse speeds: 5 gears x 4 ranges (hair-tortoise-snail-superslow) x (3-speed POWERSHIFT) + reverse shuttle.

In addition, each gearbox can be equipped on request with POWER-SHUTTLE, which allows the driver to shift from forward to reverse without use of the clutch pedal.

CONTROLS

- clutch electrohydraulically operated rear PTO
- electrohydraulically operated 4WD and differential locks
- electrohydraulically operated 4WD and differential locks + ASM System

MECHANICALLY OPERATED REAR POWER-LIFT

- with supplementary rams
- without supplementary rams

ELECTRONIC REAR POWER-LIFT

- with supplementary rams
- without supplementary rams
- with slip control
- without slip control
- with ASM System + RADAR + Slip control

DOTAZIONI PRINCIPALI

- front PTO
- front lift
- high-capacity hydraulic pump 56 l/min
- hydraulic trailer braking
- 4-way or 6-way or 8-way control valves with "Flow Divider"
- PERFORMANCE MONITOR
- Ecc...

DIMENSIONS AND WEIGHTS

WEIGHTS


			75-85-95 CV	100 CV
Kerb weight	Front	Kg	1600	1670
	Rear	Kg	2200	2530
	Total	Kg	3800	4200
Maximum permissible load	Front	Kg	3000	3000
	Rear	Kg	4500	5000
	Total	Kg	6200	7200
Maximum imposed load	Front	Kg	1400	1330
	Rear	Kg	2300	2470
	Total	Kg	2400	3000

DIMENSIONS

			75-85-95 CV	100 CV
Max. length.				
- with rear linkage	(B)	mm	3988	4216
- with rear and front linkage	(B1)	mm	4660	4888
Max. height				
- at cab/safety frame*	(C)	mm	2677	2677
- from wheel centres to cab	(D)	mm	1879	1879
Ground clearance		mm	472	484
Wheel base	(A)	mm	2340	2568
Min. turning radius				
- without brakes		mm	4060	4370

* (Tyres 13.6R28/14.9R38)

7158-311



PRESCRIBED LUBRICANTS AND FUELS

(amounts in litres)

Part to be supplied	Amt	Oil type		
		Oil type	Grade API	CC, CD, CE, CF-4
Engine	9 *	Visco- sity index	Grade CCMC	D4
	12.5 *		multi-grade engine oil SAE 15W 40	
Gearbox and Rear axle Hydraulic Power-lift Auxiliary Systems Hydrostatic steering	73 **	API GL 4 SAE 10W 30		
Front PTO	2.5			
Front- wheel drive • Central axle • Side reductions	10.5 2.5 x 2			
Brakes and clutch control	Max. level	ATF DEXRON II		
Lubrication points		NLGI 2 LITIO/Ca		
Fuel tank	140			
Radiator antifreeze		16 litres for 4-cylinder engines 18 litres for 6-cylinder engines		

* Quantity of oil not including filter (with filter +1.5 litres).

** Indicative value, which may vary by a few litres according to the type of gearbox; always check the level on the transmission dipstick.

First engine oil change: after 50 hours duty.

<u>Intervals between oil changes:</u>	every 250 operating hours for lubricants with API-CC specifications
	every 500 operating hours for lubricants API-CD, API-CE, API-CF-4, CCMC-D4 specifications (see following note).

N.B. - Oil change intervals should be halved when:

- the operating temperature is <10°C (+14°F)
- the fuel contains more than 0.5% of sulphur
- “Bio-diesel” fuel is used

IMPORTANT: the oil must be changed **at least once a year**, regardless of the number of operating hours completed.

It is advisable to always use the same type of oil when replenishing.

CONVERSION TABLE

FROM	TO	multiply by:
inch	cm	2.540
cm	inch	0.394
foot	m	0.305
m	foot	3.281
yard	m	0.914
m	yard	1.094
Eng. miles	km	1.609
km	Eng. miles	0.622
Sq.in.	cm ²	6.452
cm ²	Sq.ft.	0.155
Sq.ft.	m ²	0.093
m ²	Sq.ft.	10.77
Sq.yard	m ²	0.835
m ²	Sq.yard	1.197
Cu.in.	cm ³	16.39
cm ³	Cu.in.	0.061
Cu.ft.	Liter	28.36
Liter	Cu.ft.	0.035
Cu.yard	m ³	0.763
m ³	Cu.yard	1.311
Imp.gall.	Liter	4.547
Liter	Imp.gall.	0.220
US gall.	Liter	3.785
Liter	US gall.	0.264
pint	Liter	0.568
Liter	pint	1.762
quart	Liter	1.137
Liter	quart	0.880
oz.	kg	0.028
kg	oz.	35.25
lb.	kg	0.454
kg	lb.	2.203
lb.ft.	kgm	0.139
kgm	lb.ft.	7.233
lb/in.	kg/m	17.87
kg/m	lb/in.	0.056
lb./sq.in.	kg/cm ²	0.070
kg/cm ²	lb./sq.in.	14.22
lb./Imp.gall.	kg/l	0.100
kg/l	lb./Imp.gall.	10.00
lb./US gall.	kg/l	0.120
kg/l	lb./US gall.	8.333
lb./cu.ft.	kg/m ³	16.21
kg/m ³	lb./cu.ft.	0.062
cu.ft./lb.	m ³ /kg	0.062
m ³ /kg	cu.ft./lb.	16.21
Nm	kgm	0.102
kgm	Nm	9.81
kW	PS	1.36
PS	kW	0.736
bar	kg/cm ²	1.014
kg/cm ²	bar	0.981
dm ³	l	1
l	dm ³	1


HOW TO ORDER SPARE PARTS

To ensure perfect tractor efficiency and avoid serious drawbacks, as well as optimize your investment and operational expenses, the use of "ORIGINAL SPARE PARTS" is recommended.


Spare parts orders must specify the following:

- Tractor's serial number and engine's serial number(if the engine is concerned).
- Denomination and reference number of the required spare part.

TRACTOR IDENTIFICATION DATA PLATE



Hersteller / manufacturer	
DEUTZ-FARH Agrarsysteme GmbH	
D-89145 Lauingen	
Typ	<input type="checkbox"/>
TYPE	77/537/EWG
<input type="text"/>	<input type="checkbox"/>
FAHRZEUG-IDENTIFIZIERUNGS-NR. PRODUCT IDENTIFICATION NO.	ECE R24
<input type="text"/>	



Mot.-Typ	Code	Mot.-Nr.	kW(G)ref	EP	K	E	11/13/19/21
kW (G)	kW (S)	1/min	—	—	—		
kW (W)							
DEUTZ		DEUTZ AG		MADE IN GERMANY			

DFA AAAAA ☆ 0000 ☆

ENGINE TYPE AND SERIAL NUMBER

TRACTOR TYPE AND SERIAL NUMBER


ENGINE

AGROPLUS 75 - 85 - 95 - 100 are powered by BF4 M1012 E - BF4 M1012 EC - BF6 M1012 E engines. The workshop manual for these engines could be ordered to the following address:

DEUTZ-FAHR Agrarsysteme GmbH
Abt. LT-ZE
Deutz-Fahr-Straße 1
89415 Lauingen
Telefax-Nr.: 09072/997-360 or -353

Using the following code:

0297 7393



2

Clutch and transmission

23

Clutch

Gearshift clutch

General specifications

The clutch, a single stage type, comprises a friction disc, a pressure plate and a diaphragm spring.

The hydrostatic control is self-adjusting: a master cylinder operated by the pedal directs oil to the slave cylinder mounted to the left hand side of the intermediate housing, which in turn operates the clutch release lever.

Technical specifications

Technical specifications		AGROPLUS 75-85-95	AGROPLUS 100
Type of clutch		single disc dry organic facing	single disc dry organic facing
Type of operation		hydrostatic with automatic take-up of free travel	
Disc diameter	mm	330	350
Minimum permissible thickness of disc	mm	6	6
Thickness of friction disc	mm	8.5 ^{+0.3} _{-0.3}	8.5 ^{+0.3} _{-0.3}
Type of facing material on friction disc		TEXTAR T385	TEXTAR T385
Type of master cylinder		Benditalia 3/4"	
Type of oil		AKROS MATIC	
Spring specifications to Belleville washer for the clutch engagement:		11000 Nm	
Load on the pressure plate		11000 Nm	




Fig. 1 - **A:** Flywheel pick-up coil
B: Clutch shaft pick-up unit

Fitting and testing of the 2 pickup units

Flywheel pickup unit (A)

The pickup unit must be fitted as follows:

Adjustment of a new pickup unit

Screw the pickup unit into the threaded hole (M16 pitch 1.5) in the bell housing until it touches the ring gear, then tighten the locknut;

Adjustment of a used pickup unit

If the pickup unit has already been used, screw it in until touches the ring gear, then screw it out a 1/2 turn and secure in position at a distance of 0.65 - 0.75 mm from the ring gear.

Clutch shaft pickup unit (B)

This pickup unit does not operate in contact with the clutch shaft and therefore is simply screwed fully into its bore.

Resistance value

Flywheel pickup unit	1000 Ω
Clutch shaft pickup unit	2.5 KΩ





Fig. 2 - Checking the pickup unit resistance

Clutch and transmission

2



Clutch

23





Fig. 3 - Clutch assembly.



2 Clutch and transmission

23 Clutch




Fig. 4 - Clutch unit for **AGROPLUS 75-85-95**.






Fig. 5 - Clutch unit for **AGROPLUS 100**.



INSTALLATION OF THE CLUTCH RELEASE FORK

Before refitting the clutch fork inside the clutch housing, fill part **A** (Fig. 7), with Molycote GN-PLUS.

Fit plate **B** using a suitable tool **C** as shown in the detail of figure 7.

Secure the clutch fork pivot shaft by applying Loctite 242 to thread **D**.





Fig. 7 - Fitting the clutch release fork.



2

Clutch and transmission

23

Clutch




Fig. 8 - Checking clutch disk thickness.




Fig. 9 - Installing clutch assembly through n. 5.9030.256.4/10 equipment.




Fig. 10 - Clutch assembly hydraulic operating cylinder.




Fig. 11 - Bleeding the air from the clutch hydraulic circuit.

Checking clutch

Check the disk lining for signs of chipping and the disk friction face for scoring which may prevent the clutch from operating properly.

Check that the sliding surface of the engine flywheel is not scored; if signs of scoring are evident, machine the surface.

Check the disk thrust plate for scoring or bluish areas caused by tempering and also ensure the diaphragm-type spring has not lost its efficiency; if so the whole clutch assembly shall be replaced.

Be sure the clutch disk is free to move in its housing and the friction lining securing rivets are duly riveted.

On reassembly ascertain dimension **A** (see Fig. 10) between the operating cylinder fixing face and the push rod contacting the engagement lever is 195 mm.

NOTE: To facilitate correct clutch disk assembly the use of number 5.9030.256.4/10 centering tool is recommended.

Warning: with engine running, never ride the clutch pedal with your foot to prevent the clutch disk from being damaged because of overheating.

Important: The thrust bearing is prelubricated, and must never on any account be cleaned with fuel oil or other solvents as these will render the prelubrication treatment ineffective.

Adjusting clutch control pedal

Make sure the distance between pump fixing surface and fork hole centre is 106 ± 1 (Fig. 18); otherwise loosen nut **A** and operate adjusting stay rod **B** (Fig. 18).

Bleeding air from the hydraulic circuit

Operate the clutch pedal several times, then keeping the clutch pedal in fully depressed position, slightly unscrew and soon after tighten the air bleeding screw valve again (this being located on thrust lever operating cylinder). This operation should be repeated as many times as the oil flows out of the bleeding screw valve without air bubbles.

IMPORTANT: If the clutch has been removed, when refitting, take care to position it as shown by the arrow in figure 3, as the clutch disc is not symmetrical.