

# Systems Operation

# Description of Fault Codes

---

## **Lift Trucks**

## **Three Speed Power Shift**

## **Transmission**

## **3WG 116/161**

**FV - 00001 ~ UP**

**FX - 00001 ~ UP**

**GS - 00001 ~ UP**

**F1 - 00003 ~ UP**

**F2 - 00004 ~ UP**

**F3 - 00010 ~ UP**



# Important Safety Information

Most accidents involving product operation, maintenance and repair are caused by failure to observe basic safety rules or precautions. An accident can often be avoided by recognizing potentially hazardous situations before an accident occurs. A person must be alert to potential hazards. This person should also have the necessary training, skills and tools to perform these functions properly.

**Read and understand all safety precautions and warnings before operating or performing lubrication, maintenance and repair on this product.**

Basic safety precautions are listed in the "Safety" section of the Service or Technical Manual. Additional safety precautions are listed in the "Safety" section of the owner/operation/maintenance publication. Specific safety warnings for all these publications are provided in the description of operations where hazards exist. WARNING labels have also been put on the product to provide instructions and to identify specific hazards. If these hazard warnings are not heeded, bodily injury or death could occur to you or other persons. Warnings in this publication and on the product labels are identified by the following symbol.



**Improper operation, lubrication, maintenance or repair of this product can be dangerous and could result in injury or death.**

**Do not operate or perform any lubrication, maintenance or repair on this product, until you have read and understood the operation, lubrication, maintenance and repair information.**

Operations that may cause product damage are identified by NOTICE labels on the product and in this publication.

DAEWOO cannot anticipate every possible circumstance that might involve a potential hazard. The warnings in this publication and on the product are therefore not all inclusive. If a tool, procedure, work method or operating technique not specifically recommended by DAEWOO is used, you must satisfy yourself that it is safe for you and others. You should also ensure that the product will not be damaged or made unsafe by the operation, lubrication, maintenance or repair procedures you choose.

The information, specifications, and illustrations in this publication are on the basis of information available at the time it was written. The specifications, torques, pressures, measurements, adjustments, illustrations, and other items can change at any time. These changes can affect the service given to the product.

Obtain the complete and most current information before starting any job. DAEWOO dealers have the most current information available.



# Index

**Important Instructions ..... 5****Systems Operation**

Controller DW-3 .....	8
Display .....	8
Error code definition .....	11
Possible Indications on the Display .....	8
Electronic Control unit TCU .....	11
Electronic Controls for Powershift transmissions.12	
Description of the Basic functions .....	12
Independent calibration of the Shifting elements (AEB) .....	13
Inching device.....	14
Function of the Converter .....	6
Function of a hydrodynamic Torque converter (Schematic view) .....	6
Powershift transmission.....	7
Transmission control.....	7

**Operation**

AEB Starter .....	17
- Display during AEB-Mode .....	18
- Display during ISK mode.....	19
- Introduction.....	17
- List of abbreviations .....	17
- Procedure to start AEB .....	17
- Procedure to start ISK .....	19
Cold start .....	16
Controller DW - 3 (Table - 11) .....	32
Driving and Shifting.....	15
Driving preparation and Maintenance.....	15
Electro - Hydraulic control with proportional valves (Table- 9) .....	29
Fully - Automatic control EST - 37A	
Circuit diagram standard (Table - 10) .....	30
Gearbox Diagram (Table - 6) .....	26
Installation Front view (Table - 2).....	21
Installation Rear view (Table - 3) .....	22
Layout(Table - 1).....	20
Oil circuit diagram	
Forward 1st Speed (Table - 5) .....	25
Oil temperature .....	16
Power flow Forward speed (Table - 7) .....	27
Power flow Reverse speed (Table - 8).....	28
Schedule of measuring points and connections (Table - 4) .....	23
Stopping and Parking.....	16
Towing.....	16
Transmission control in the Driving mode Automatic.....	16

**Description of Fault Codes**

Definition of operating modes .....	37
Limp-Home .....	37
Normal .....	37
Substitute Clutch Control .....	37
Table of fault codes .....	38
TCU- Shutdown .....	37
Tranmission-Shutdown .....	37
Introduction .....	33
Abbreviations .....	33
Display .....	33
Display during AEB-Mode .....	35
Display during Inchedal Calibration .....	36
Display during operation .....	34
Measuring of resistance at actuator/sensors and cable.....	56
actuator .....	56
cable .....	56