

Table of Contents

Part I Engine	1
Chapter 1 Engine Assembly (MR479Q, MR479QA, MR481QA)	1
Section 1 Routine Inspection	1
Section 2 Drive Belt Replacement	5
Section 3 Valve Clearance Adjustment	6
Chapter 2 Engine Components Replacement (MR479Q, MR479QA, MR481QA)	10
Section 1 Engine Components	10
Section 2 Engine Components Replacement	13
Section 3 Timing Belt Replacement	17
Section 4 Camshaft Replacement	22
Section 5 Cylinder Head Gasket Replacement	28
Section 6 Oil Pump Oil Seal Replacement	33
Section 7 Engine Rear Oil Seal Replacement	34
Chapter 3 Lubrication System (MR479Q, MR479QA, MR481QA)	35
Section 1 Oil Pressure Gage Sensor Replacement	35
Section 2 Oil Pump Assembly Replacement	36
Section 3 Oil Filter Replacement	38
Section 4 Starter Replacement	39
Section 5 Generator Replacement	40
Chapter 4 Fuel System (MR7131A, MR7151A, MR7161A)	41
Section 1 Check Fuel System Pressure	41
Section 2 Fuel Pump Inspection	42
Section 3 Fuel Injector Replacement	43
Section 4 Fuel Pump Replacement	45
Section 5 Fuel Emission Control System	47
Section 6 Carbon Canister Replacement	48
Chapter 5 Exhaust System (MR7131A, MR7151A, MR7161A)	50

Chapter 6 Cooling System Inspection (MR7131A, MR7151A, MR7161A)	52
Section 1 System Check	52
Section 2 Water Pump, Thermostat and Radiator Replacement	54
Chapter 7 Clutch (MR7131A, MR7151A, MR7161A)	56
Section 1 Clutch Replacement	57
Chapter 8 Maunal Transaxle Assembly (MR7131A, MR7151A, MR7161A)	59
Section 1 Manual Transaxle Replacement	60
Section 2 Vehicle Speed Sensor Replacement	61
Section 3 Transmission Case Oil Seal	62
Section 4 Transaxle Case Oil Seal Replacement	63
Chapter 9 General Engine Troubles and Their Troubleshooting	64
Section 1 Overview	64
Section 2 General Engine Fault and Troubleshooting	64
Section 3 Engine Noise Diagnosis and Troubleshooting	77
Chapter 10 Engine Management Unit	81
Section 1 System Description	81
Section 2 System Component and Working Principle	82
Part II Chassis	85
Chapter 1 Transmission Control Device	85
Section 1 Transmission Control Device	85
Section 2 Lever Type Transmission Control Device	85
Section 3 Cable Type Transmission Control Module	87
Chapter 2 Accelerator Pedal	90
Section 1 Accelerator Pedal	90
Chapter 3 Clutch Control System	91
Section 1 Clutch Control System	91
Section 2 Clutch Cable Control Mechanism	91
Section 3 Clutch hydraulic Control Device	94
Chapter 4 Propeller Shaft	97

Section 1 Propeller Shaft	97
Chapter 5 Front Suspension System	103
Section 1 Front Suspension System	103
Section 2 Front Suspension	105
Section 3 Front Wheel Alignment	106
Section 4 Front Strut Assembly	107
Section 5 Lower Swing Arm Assembly	110
Section 6 Front Stabilizer Bar and Link Rod Assembly	113
Chapter 6 Rear Suspension System	116
Section 1 Rear Suspension System	116
Section 2 Rear Suspension	117
Section 3 Rear Wheel Alignment	118
Section 4 Left & Right Rear Strut Assembly	119
Section 5 Rear stabilizer bar assembly, strut rod components	121
Section 6 Left & Right Trailing Rod Assembly	123
Section 7 No. 1 Transverse Arm Assembly	124
Section 8 No. 2 Transverse Arm Assembly	125
Chapter 7 Wheel	126
Section 1 Tire Inspection	126
Section 2 Wheel Replacement	127
Chapter 8 Power Steering System	128
Section 1 Power Steering System	128
Section 2 Steering Drive and Control Mechanism	130
Section 3 Steering Pipeline Component	133
Section 4 Power Steering Gear Retaining Device	136
Chapter 9 Brake System	139
Section 1 Brake System	139
Section 2 Brake Fluid	140
Section 3 Brake Pedal	141
Section 4 Vacuum Booster with Brake Master Cylinder Assembly	143
Section 5 Front Brake Assembly	144
Section 6 Rear Brake	147
Section 7 Brake Line	151

Section 8 Parking Brake System	155
Part III Electrical Equipment	157
Chapter 1 Survey.....	157
Chapter 2 Starting and Charging System	161
Section 1 Starting System (MR479Q MR479QA MR481QA)	161
Section 2 Charging System (MR479Q, MR479QA, MR481QA)	164
Chapter 3 Combination Meter System	171
Section 1 Circuit Diagram of Combination Meter and Location of Multi-pin Plug-in Terminal	171
Section 2 Malfunction Symptom Table and Solution Procedure	174
Section 3 Combination Meter	187
Chapter 4 Wiper and Washer System	193
Section 1 Wiper and Washer System Inspection	193
Section 2 Replacement and Adjustment	196
Chapter 5 Light System	198
Section 1 Survey of Light System	198
Section 2 Light System Symptom Inspection	202
Section 3 Headlamp Replacement	211
Section 4 Front Fog Lamp Replacement	215
Section 5 Rear Combination Lamp Replacement	217
Section 6 High Mounted Stop Lamp Replacement	218
Section 7 Interior Dome Lamp Replacement	219
Section 8 Rear Row Reading Lamp Replacement	220
Section 9 License Plate Lamp Replacement	220
Chapter 6 Audio System	221
Section 1 Audio System Description	221
Section 2 Audio System Connector Terminal Layout	224
Section 3 Audio System Inspection	225
Section 4 Audio and Video System Replacement	238
Chapter 7 SRS (Supplemental Restraint System)	242
Section 1 SRS-General Information	242
Section 2 Troubleshooting	251

Section 3 Removal & Installation	262
Chapter 8 MK-20 ABS System	272
Section 1 ABS Diagnosis	272
Section 2 ABS System Check	276
Section 3 Removal and Installation	292
Part IV Air Conditioner and Inside & Outside Trim	297
Chapter 1 A/C System	297
Section 1 The Structure & Working Principle of Refrigeration System	297
Section 2 Heating System	299
Section 3 A/C controlling system	302
Section 4 Service Caution & Notice	304
Section 5 The Refrigeration System Operation Procedure	305
Section 6 Basic System	308
Section 7 A/C System Faults Check & Troubleshooting	313
Chapter 2 Inside & outside Trim and Accessory	318
Section 1 Configuration Index	318
(I) Outside Trim And Front Accessory	318
(II) Outside Trim and Rear Accessory	319
(III) Front inside trim	320
(IV) Rear inside trim	321
Section 2 Inside & Outside Trim and Accessories Removal and Installation	322
(I) Front Bumper	322
(II) Engine Hood	324
(III) Outside Rear View Mirror	326
(IV) Rear trunk Lid	327
(V) Rear Bumper	329
(VI) Seat Removal, Installation and Adjustment	331
(VII) Seat Belt	335
(VIII) Instrument panel and auxiliary console	338
(IX) A pillar inside trim and front door sill	343
(X) B pillar inside trim	344
(XI) C pillar inside trim and rear door sill	345
(XII) Roof inside trim	346
(XIII) Carpet and Heat Insulator	347

(XIV) Rear trunk Inside Trim	348
(XV) Engine Hood Inside Trim	349
(XVI) Door	350
Part V Body	359
Chapter 1 General Information.....	359
Section 1 Body Structure	359
Chapter 2 Body Repair	369
Section 1 Body Damage Forms and Requirements for Repair	369
Section 2 Typical Technology Of Body Panel Repair	372
Section 3 Repair after Body Damage	372
Section 4 Features and Composition of Automobile Body	377
Section 5 Painting Technique after Body Repair	383
Section 6 Service Data For Body	385

Part I Engine

Chapter 1 Engine Assembly (MR479Q, MR479QA, MR481QA)

Section 1 Routine Inspection

1. Check coolant
2. Check engine oil
3. Check battery
4. Check air cleaner element assembly
5. Check spark plug
6. Check drive belt




Figure 1

Belt deflection See (Table 1)		
Belt pressure: 98N		
	New Belt mm	Old Belt mm
Fan Belt	7~9	11.5, -13.5
Power steering Belt	5~6	6~8
A/C Belt	6.5~7	8~9

Notice:

- Check the belt deflection at the specified point See (Figure 1).
- Set tension to specified value when installing new belt.
- Check the deflection to ensure it is below the specified value after the belt runs for over 5 minutes.
- Reinstall the belt which has been running for over 5 minutes. The deflection of the old belt is regarded as the standard for inspection.
- Check V-belt for tension and distortion after the engine cranks for 2 turns.

7. Check ignition timing See (Figure 2)

- a) Warm up the engine.
- b) When using fault diagnosis tester

Connect fault diagnosis tester to fault diagnosis interface socket.




Figure 2

Ignition timing:

MR479Q: $10 \pm 2^\circ$ BTDC (before top dead center) at idle

MR479QA: $10 \pm 2^\circ$ BTDC at idle

MR481QA: $10 \pm 2^\circ$ BTDC at idle

c) When fault diagnosis tester is not used

- (1) Shorting fault diagnosis interface socket 13 (TC) terminal and 4(CG) terminal.

Notice:

- Ensure correct connection, otherwise the engine will be damaged.
 - Switch off all electrical appliance system.
 - Check when disconnecting cooling fan motor.
- (2) Using timing light to check ignition timing.

Ignition timing: $10 \pm 2^\circ$ BTDC at idle

Notice:

- (1) Transmission shift lever should be in neutral position when checking ignition timing.
- (2) Running engine at 1,000-1,300rpm for 5s and check at idle.
- (3) Remove the tester on fault diagnosis socket.
- (4) Ignition timing advance angle becomes larger when the engine roate speed is higher.
- (5) Remove timing light.

8. Check engine idle See (Figure 3)

- (a) Warm up the engine.
- (b) Connect fault diagnosis tester to fault diagnosis interface socket.
- (c) Connect tachometer testing pen to fault diagnosis socket terminal 9 when not using fault tester.
- (d) Check idle See (Table 2).




Figure 3

Table 2

MR479Q	800 ± 50 (rpm)
MR479QA	800 ± 50 (rpm)
MR481QA	800 ± 50 (rpm)

Notice:

- Check idle when cooling fan motor is disconnected.
- Switch off all electrical accessories and A/C.

9. Check compression pressure See (Figure 4)

- (a) Engine switched off.
- (b) Detach high voltage cable.
- (c) Detach spark plug.
- (d) Check the compression pressure in the cylinder.
 - (1) Insert pressure gauge into the hole of the spark plug.
 - (2) Throttle valve full open.
 - (3) Crank the engine, measure the compression pressure.




Figure 4

The Min. compression pressure: 980 kPa

The tolerance range of the cylinders pressure: 100 kPa

Notice:

- Ensure sufficient battery power and the engine speed is no less than 250 RPM (revolutions per minute).
 - Check the compression pressure of other cylinders in the same way.
 - Complete the measure as quick as possible.
- (4) If the compression pressure in several cylinder is too low, fill some engine oil to the cylinder via the hole of the spark plug. Check by repeating step 1-3.

Hint:

- If the compression pressure is improved after filling oil, the piston ring or the cylinder may be abraded or damaged.
- If the pressure is still too low, the valve is stagnation or poor seal, or there is a leakage in gasket.

10. Check CO/HC

- (a) Start engine.
- (b) Running engine at 2500rpm for approximately 3 minutes.
- (c) Insert CO/HC meter testing probe into tailpipe at least 40cm during idling.
- (d) Check CO/HC concentration at idle and 2500rpm.

Hint:

- Complete measurement within 3 minutes.
 - Test the CO/HC emission concentration at idle and 2500 rpm on QC/T630-1999 standard.
- (e) Take the following steps to diagnose the fault if the CO/HC concentration does not comply with standard .
- (1) Check the oxygen sensor operation.
 - (2) See (Table 3) for the possible cause and check and repair.

Table 3

CO	HC	Problems	Causes
Normal	High	Rough idle	1. Fault . Incorrect ignition timing . Fouled, shorted or improperly clearance of spark plug 2. Incorrect valve clearance 3. Leaky intake & exhaust valves 4. Leaky cylinders
Low	High	Rough idle	1. Air leaks . PCV hoses, intake manifold . Throttle body . Brake booster circuit 2. Lean mixture gas causing misfire
High	High	Rough idle (Black smoke from exhaust pipe)	1. Clogged air filter 2. Clogged PCV valve . Faulty ECU . Faulty fuel pressure regulator . Faulty water temperature sensor . Faulty air compressor . Faulty injectors . Faulty throttle position sensor

Section 2 Drive Belt Replacement

1. Disconnect all engine pipe hose and wire joint. Remove engine assembly from the engine compartment, jack up the body, take out the engine assembly slowly (See Provision 20, Section Two, Chapter Two for detailed information)

2. Remove generator V-belt See (Figure 5)

3. Remove No. 1 V-belt A/C compressor to crankshaft pulley

4. Remove water pump belt See (Figure 6)




Figure 5




Figure 6

5. Install water pump V-belt

6. Adjust V-belt of steering assisting pump

(a) Adjust power steering belt tension, tighten bolt B.

(b) Tighten bolt A.

Torque : 39N. m

7. Install V-belt A/C compressor No. 1 to crankshaft pulley

8. Adjust V-belt A/C compressor No. 1 to crankshaft pulley

(a) Adjust A/C belt tension by tightening bolt B.

(b) Tighten nut A.

Torque : 39N. m




Figure 7

9. Install Generator V-belt See (Figure 7)

10. Adjust Generator V-belt.

Tighten bolt A and then bolt B.

Torque: Bolt A 18N. m Bolt B 58N. m

11. Check driving belt for distortion and tension

Section 3 Valve Clearance Adjustment

1. Remove right camshaft timing gear

2. Remove ignition coil and high voltage cable

3. Remove cylinder head cover sub-assembly See (Figure 8)

- (a) Disconnect generator wire joint..
- (b) Disconnect generator circuit.
- (c) Disconnect oil pressure switch connector.
- (d) Disconnect A/C compressor switch connector.
- (e) Open the wire harness clip.
- (f) Remove wire harness from cylinder head cover.
- (g) Separate 2 ventilation hoses from cylinder head cover.
- (h) Remove 4 screw nuts, 4 oil seal gaskets, cylinder head and gasket.




Figure 8

4. Adjust piston of Cylinder 1 to the compression position

- (a) Turn crankshaft pulley, align notch to timing mark "0" on Cylinder 1. See (Figure 9).
- (b) Align mark "K" on camshaft timing pulley to the timing mark on bearing cap. See (Figure 10) Crank 360° if it is not aligned.




Figure 9




Figure 10

5. Check valve clearance (cool). See (Table 5)

Table 5

	Intake Valve mm	Exhaust Valve mm
MR479Q	0.20 ± 0.05	0.30 ± 0.05
MR479QA	0.20 ± 0.05	0.30 ± 0.05
MR481QA	0.20 ± 0.05	0.30 ± 0.05

(a) Turn the crankshaft pulley for 360°. Align notch to timing mark "0" on timing belt cover No. 1.

(b) Only check the valve as shown in the figure. Valve clearance measurement. See (Figure 11).




Figure 11

6. Adjust intake valve clearance

- Detach intake camshaft

Notice:

Because the camshaft end play is quite small, keep camshaft horizontal when removing it. If not, cylinder head may be partially damaged by the thrust force—it may stuck or damage camshaft when turning crankshaft. Take the following steps to avoid the damage:

- (1) Turn the pulley to access the hole on the camshaft drive gear where the counter gear is installed. See (Figure 12).

Hint:

The above condition allows the cylinders No. 1 and No. 3 of the intake camshaft to push up the valve tappet.




Figure 12




Figure 13

- (2) Remove bolt and bearing cap No. 1.
- (3) Install camshaft counter gear to drive gear with service bolt. See (Figure 13).
- (4) Uniformly loose and remove 8 bearing cap bolts in several passes as shown in the figure. See (Figure 14).
- (5) Remove 4 bearing caps and camshafts.




Figure 14

Notice:

Due to the small end play on camshaft, the cylinder head may be damaged by the thrust force when removing it, it may stuck or damage camshaft. Take the following steps to avoid damage:

- (1) Turn the crankshaft pulley to make exhaust camshaft dowel pin is a bit higher than the cylinder head. See (Figure 15).
- (2) Align the matchmark on each gear to engage intake camshaft gear and exhaust camshaft gear. See (Figure 16).
- (3) When the gears are engaged, install the intake camshaft bearing onto bearing journal.




Figure 15




Figure 16

Hint:

The intake camshaft lobe of cylinder 1 and 3 can jack up their own valve tappet.

- (5) Install 4 bearing caps to the right position.
- (6) Apply a light layer of engine oil on the thread and under the head of bearing cap bolts.
- (7) Uniformly install and tighten 8 bearing cap bolts in several times, in the sequence shown in the figure.
Torque: 13N. m
- (8) Remove service screw.
- (9) Install the bearing cap No. 1. in the direction of the forward arrow mark.
- (10) Apply a light layer of engine oil on the thread and under the head of bearing cap bolts.
- (11) Alternatively tighten and install 2 bearing bolts.

Torque: 13N. m

7. Adjust exhaust valve clearance. See (Figure 17)

Remove adjust gasket.

- (1) Crank to keep the camshaft head upward.
- (2) Face valve tappet nick to vehicle front.
- (3) Press valve tappet, put special tool between camshaft and valve tappet.




Figure 17

Hint:

- Lean the end with mark "9" into the position in (Figure 18).




Figure 18

- (4) Alternatively press valve tappet with the special tool (A) (B). Check valve clearance. See (Figure 19).

8. Install cylinder head sub-assembly

- (a) Remove all old gasket material.
- (b) Apply the seal glue to the cylinder head.
- (c) Connect wire harness and clip.
- (d) Install gasket under of cylinder head.
- (e) Install the cylinder head cover with 4 seal gaskets and 4 screw caps.

Torque: 7.8N. m

- (f) Install 2 ventilation hoses to cylinder head cover.
- (g) Connect generator wire joint.
- (h) Connect generator wires.
- (i) Connect oil pressure switch connector.
- (j) Install wire clip.
- (k) Connect A/C compressor switch connector.

9. Install electronic ignition coil and high voltage cable

10. Check engine oil for leakage




Figure 19

Chapter 2 Engine Components Replacement

(MR479Q, MR479QA, MR481QA)

Section 1 Engine Components

Component 1




Figure 20

Component 2




Figure 21

Component 3




Figure 22

Section 2 Engine Components Replacement

1. Avoid gasoline ejection when work.
2. Drain the coolant to empty.
3. Remove air filter assembly with hose. See (Figure 23)
4. Remove battery
5. Remove fuel delivery pipe sub-assembly
6. Disconnect water hoses, disconnect heater outlet hose from A/C hose.
7. Loose nut, remove accelerator control cable
8. Remove throttle body assembly
9. Remove power steering pump reservoir assembly
10. Remove front exhaust pipe assembly
11. Remove steering gear boot
12. Separate steering column assembly. See (Figure 24)
13. Remove front wheel hub nut
14. Disconnect front wheel vehicle speed sensor (with ABS)
15. Detach steering tie rod ball stud pin assembly
16. Detach front lower swing arm sub-assembly
17. Detach front propeller assembly. See (Figure 25)




Figure 23

18. Disconnect transmission shift cable or gear shift level assembly
19. Disconnect clutch cylinder assembly or disconnect clutch cable
20. Detach engine assembly and transaxle

- (a) Hoisting engine ;
- (b) Remove 3 bolts. Detach the right engine mounting bracket. See (Figure 26) ;
- (c) Remove 1 bolt. Detach the left engine mounting bracket;
- (d) Remove 1 bolt. Detach the rear engine mounting bracket;
- (e) Remove engine and transaxle and put them on the pallet;
- (f) Jack up the body.



Figure 24



Figure 25




Figure 26

- 21. Remove radiator assembly**
- 22. Remove engine V-belt**
- 23. Remove No. 1 V- belt (A/C compressor to crankshaft pulley)**
- 24. Remove generator assembly**
- 25. Remove A/C compressor**
- 26. Remove compressor installing No. 1 bracket. Remove 4 bolts and compressor installing No. 1 bracket.**
- 27. Remove starter assembly**
- 28. Remove power steering pump V- belt**
- 29. Detach power steering pump assembly**
- 30. Remove power steering pump, adjust the bracket**
- 31. Detach manual transaxle assembly (Separate automatic transaxle assembly)**
- 32. Detach clutch cover panel assembly.**
- 33. Detach clutch pressure plate assembly.**
- 34. Detach flywheel sub-assembly.**
- 35. Remove engine rear end cover.**
- 36. Remove injector assembly and remove intake manifold.
Remove 2 bolts and intake manifold support and remove 7 bolts,
2 nuts, intake manifold and gasket. See (Figure 27).**
- 37. Remove knock sensor**
- 38. Remove water temperature gauge sensor**
- 39. Remove crankshaft position sensor**
- 40. Remove engine oil pressure switch**
- 41. Remove water inlet hose housing**
- 42. Remove water outlet hose joint**
- 43. Detach exhaust manifold. See (Figure 28)**
- 44. Remove engion oil filter sub-assembly**
- 45. Remove ignition coil and high voltage cable**
- 46. Install engine sub-assembly**
- 47. Install ignition coil and high voltage cable**
- 48. Install engine oil filter sub-assembly**
- 49. Install exhaust manifold**

(a) Install new gasket and exhaust manifold stay with 5 nuts.

Torque: 34N. m

(b) Install exhaust manifold stay with two bolts.

Torque: 59N. m

(c) Install upper heat shield with 4 bolts.

Torque: 17N. m




Figure 27




Figure 28