

Body Electrical System

GENERAL

TROUBLESHOOTING INFORMATION BE -3

AUDIO SYSTEM

SPECIFICATION BE -6
 COMPONENT LOCATION BE -7
 AUDIO UNIT
 COMPONENT BE -8
 REPLACEMENT BE -11
 INSPECTION BE -11
 SPEAKERS
 REPLACEMENT BE -12
 INSPECTION BE -13
 ANTENNA
 INSPECTION BE -14
 AUDIO REMOTE CONTROL
 REPLACEMENT BE -16
 INSPECTION BE -16
 CIRCUIT DIAGRAM BE -17
 TROUBLESHOOTING BE -18

MULTI FUNCTION SWITCH

SPECIFICATIONS BE -28
 COMPONENTS BE -29
 REPLACEMENT BE -30
 INSPECTION BE -31

HORNS

COMPONENT LOCATION BE -33
 REPLACEMENT BE -34
 INSPECTION BE -34

KEYLESS ENTRY AND BURGLAR ALARM

COMPONENT LOCATION BE -35
 DESCRIPTION BE -36
 FUNCTION BE -36
 INSPECTION BE -39
 TRANSMITTER
 SPECIFICATIONS BE -44
 INSPECTION BE -44
 TRANSMITTER CODE
 REGISTRATION BE -45
 TROUBLESHOOTING BE -47

ETACS (ELECTRONIC TIME AND ALARM CONTROL SYSTEM)

BODY CONTROL MODULE
 DESCRIPTION BE -51
 SPECIFICATIONS BE -52
 CIRCUIT DIAGRAM BE -53
 REPLACEMENT BE -56

INSPECTION BE -57
 TROUBLE DIAGNOSIS WHEN USING
 DIAGNOSIS TOOL BE -62

TRUNK LID OPENER

COMPONENT LOCATION BE -64
 TRUNK LID RELEASE ACTUATOR BE -65
 TRUNK LID OPEN SWITCH BE -66

FUEL FILLER DOOR OPENER

COMPONENT LOCATION BE -67
 FUEL FILLER DOOR RELEASE ACTUATOR BE -68
 FUEL FILLER DOOR OPEN SWITCH BE -69

FUSES AND RELAYS

COMPONENT LOCATION BE -70
 RELAY BOX (ENGINE COMPARTMENT)
 COMPONENTS BE -72
 INSPECTION BE -73
 RELAY BOX (PASSENGER COMPARTMENT)
 COMPONENTS BE -75
 FUSE INSPECTION BE -76
 ICM (INTEGRATED CIRCUIT MODULE)
 RELAY BOX BE -77

INDICATORS AND GAUGES

COMPONENT LOCATION BE -78
 INSTRUMENT CLUSTER
 COMPONENTS BE -79
 CIRCUIT DIAGRAM BE -80
 REPLACEMENT BE -81
 INSPECTION BE -82
 TROUBLESHOOTING BE -87

POWER DOOR LOCKS

COMPONENT LOCATION BE -88
 POWER DOOR LOCK ACTUATORS BE -89
 POWER DOOR LOCK RELAY BE -92
 POWER DOOR LOCK SWITCH BE -93
 TROUBLESHOOTING BE -94

POWER DOOR MIRRORS

COMPONENT LOCATION BE -97
 POWER DOOR MIRROR SWITCH
 CIRCUIT DIAGRAM BE -98
 INSPECTION BE -99
 POWER DOOR MIRROR ACTUATOR
 INSPECTION BE -100
 DOOR MIRROR FOLDING CONTROL MODULE
 CIRCUIT DIAGRAM BE -101
 INSPECTION BE -102
 REPLACEMENT BE -102



POWER WINDOWS

COMPONENT LOCATION	BE -103
SAFETY POWER WINDOW	BE -104
POWER WINDOW MOTOR	BE -105
POWER WINDOW SWITCH	BE -107
POWER WINDOW RELAY	BE -112
TROUBLESHOOTING	BE -113

WINDSHIELD DEICER

COMPONENT LOCATION	BE -115
WINDSHIELD DEICER	BE -116
WINDSHIELD DEICER SWITCH	BE -117
WINDSHIELD DEICER TIMER	BE -118
WINDSHIELD DEICER RELAY	BE -119

REAR WINDOW DEFOGGER

COMPONENT LOCATION	BE -120
REAR WINDOW DEFOGGER PRINTED HEATER	BE -121
REAR WINDOW DEFOGGER SWITCH	BE -123
REAR WINDOW DEFOGGER RELAY	BE -124
REAR WINDOW DEFOGGER TIMER	BE -125

WINDSHIELD WIPER / WASHER

COMPONENT LOCATION	BE -126
WINDSHIELD WIPER / WASHER SWITCH	BE -127
FRONT WIPER MOTOR	BE -128
FRONT WASHER MOTOR	BE -131
TROUBLESHOOTING	BE -132

ELECTRO CHROMIC INSIDE REAR VIEW MIRROR

DESCRIPTION	BE -133
INSPECTION	BE -133
REPLACEMENT	BE -134

POWER SEAT

COMPONENT LOCATION	BE -135
POWER SEAT MOTOR	BE -136
POWER SEAT SWITCH	BE -138

SEAT WARMER

COMPONENT LOCATION	BE -139
SEAT WARMER SWITCH	BE -140
SEAT WARMER	BE -141

SUNROOF

COMPONENT LOCATION	BE -142
CIRCUIT DIAGRAM	BE -143
SUN ROOF SWITCH	BE -144
SUN ROOF MOTOR	BE -145

LIGHTING SYSTEM

COMPONENTS	BE -147
SPECIFICATION	BE -148
HEAD LAMPS	BE -148
TURN SIGNAL LAMP	BE -152
ROOM LAMP	BE -153
OVERHEAD CONSOLE LAMP	BE -154
TURN / HAZARD LAMPS	BE -155
FLASHER UNIT	BE -156
RHEOSTAT	BE -157
FRONT FOG LAMPS	BE -158
REAR FOG LAMPS	BE -159
LICENSE LAMPS	BE -160
STOP LAMPS	BE -161

TRUNK LAMPS	BE -162
TROUBLESHOOTING	BE -163

AUTO LIGHTING CONTROL SYSTEM

COMPONENT LOCATION	BE -165
DESCRIPTION	BE -165
SPECIFICATION	BE -165
CIRCUIT DIAGRAM	BE -166
INSPECTION	BE -167
AUTO LIGHT SWITCH	BE -167
AUTO LIGHT SENSOR	BE -168

DAYTIME RUNNING LIGHTS

INSPECTION	BE -169
------------------	---------

HEAD LAMP LEVELING DEVICE

COMPONENT LOCATION	BE -170
CIRCUIT DIAGRAM	BE -171
HEAD LAMP LEVELING SWITCH	BE -172
HEAD LAMP LEVELING ACTUATOR	BE -173

HEAD LAMP WASHER

COMPONENT LOCATION	BE -174
CIRCUIT DIAGRAM	BE -175
HEAD LAMP WASHER SWITCH	BE -175
HEAD LAMP WASHER RELAY	BE -176
HEAD LAMP WASHER MOTOR	BE -177

IMMOBILIZER CONTROL SYSTEM

DESCRIPTION	BE -178
COMPONENTS OPERATIONS	BE -178
SYSTEM BLOCK DIAGRAM	BE -180
CIRCUIT DIAGRAM	BE -181
TEACHING PROCEDURES	BE -183
LIMP HOME FUNCTION	BE -188
DIAGNOSIS OF IMMOBILIZER FAULTS	BE -190
IMMOBILIZER CONTROL UNIT	BE -194
COIL ANTENNA	BE -195
DTC CODES	
P1674	BE -196
P1675	BE -198
P1676	BE -199
P1690	BE -200
P1691	BE -209
P1693	BE -212
P1694	BE -213
P1695	BE -215
P1696	BE -216
P1699	BE -217

BACK WARNING SYSTEM

DESCRIPTION	BE -220
COMPONENT LOCATION	BE -220
SPECIFICATION	BE -221
CIRCUIT DIAGRAM	BE -222
ALARM RANGE	BE -223
BACK WARNING CONTROL MODULE	BE -225
ULTRASONIC SENSOR	BE -226
BUZZER	BE -229

IGNITION SYSTEM

IGNITION SWITCH	
REPLACEMENT	BE -230
INSPECTION	BE -231

GENERAL

GENERAL TROUBLESHOOTING INFORMATION

E60BE67C

BEFORE TROUBLESHOOTING

1. Check applicable fuses in the appropriate fuse/relay box.
2. Check the battery for damage, state of charge, and clean and tight connections.


NOTE

- Do not quick-charge a battery unless the battery ground cable has been disconnected, otherwise you will damage the alternator diodes.
- Do not attempt to crank the engine with the battery ground cable loosely connected or you will severely damage the wiring.

3. Check the alternator belt tension.

HANDLING CONNECTORS


1. Make sure the connectors are clean and have no loose wire terminals.
2. Make sure multiple cavity connectors are packed with grease (except watertight connectors).
3. All connectors have push-down release type locks (A).



ETKD150A


4. Some connectors have a clip on their side used to attach them to a mount bracket on the body or on another component. This clip has a pull type lock.

5. Some mounted connectors cannot be disconnected unless you first release the lock and remove the connector from its mount bracket (A).




ETKD150B

6. Never try to disconnect connectors by pulling on their wires; pull on the connector halves instead.
7. Always reinstall plastic covers.




ETKD150C

8. Before connecting connectors, make sure the terminals (A) are in place and not bent.



ETKD150D


9. Check for loose retainer (A) and rubber seals (B).



ETKD150E


HANDLING WIRES AND HARNESSSES

1. Secure wires and wire harnesses to the frame with their respective wire ties at the designated locations.
2. Remove clips carefully; don't damage their locks (A).




ETKD150H

10. The backs of some connectors are packed with grease. Add grease if necessary. If the grease (A) is contaminated, replace it.



ETKD150F


3. Slip pliers (A) under the clip base and through the hole at an angle, and then squeeze the expansion tabs to release the clip.



ETKD150I

11. Insert the connector all the way and make sure it is securely locked.


12. Position wires so that the open end of the cover faces down.



ETKD150G

4. After installing harness clips, make sure the harness doesn't interfere with any moving parts.
5. Keep wire harnesses away from exhaust pipes and other hot parts, from sharp edges of brackets and holes, and from exposed screws and bolts.


6. Seat grommets in their grooves properly (A). Do not leave grommets distorted (B).
5. Use a probe with a tapered tip.




ETKD150J

TESTING AND REPAIRS

1. Do not use wires or harnesses with broken insulation. Replace them or repair them by wrapping the break with electrical tape.
2. After installing parts, make sure that no wires are pinched under them.
3. When using electrical test equipment, follow the manufacturer's instructions and those described in this manual.
4. If possible, insert the probe of the tester from the wire side (except waterproof connector).



ETKD150K



ETKD150L

FIVE-STEP TROUBLESHOOTING


1. **Verify the complaint**
Turn on all the components in the problem circuit to verify the customer complaint. Note the symptoms. Do not begin disassembly or testing until you have narrowed down the problem area.
2. **Analyze the schematic**
Look up the schematic for the problem circuit. Determine how the circuit is supposed to work by tracing the current paths from the power feed through the circuit components to ground. If several circuits fail at the same time, the fuse or ground is a likely cause. Based on the symptoms and your understanding of the circuit operation, identify one or more possible causes of the problem.
3. **Isolate the problem by testing the circuit.**
Make circuit tests to check the diagnosis you made in step 2. Keep in mind that a logical, simple procedure is the key to efficient troubleshooting. Test for the most likely cause of failure first. Try to make tests at points that are easily accessible.
4. **Fix the problem**
Once the specific problem is identified, make the repair. Be sure to use proper tools and safe procedures.
5. **Make sure the circuit works**
Turn on all components in the repaired circuit in all modes to make sure you've fixed the entire problem. If the problem was a blown fuse, be sure to test all of the circuits on the fuse. Make sure no new problems turn up and the original problem does not recur.

AUDIO SYSTEM

SPECIFICATION EEAFCD8F

Item		Specification		
Model		AM/FM/Cassette (M440)	AM/FM/Cassette /MP3 (M455)	AM/FM/Cassette /6CDC (M465)
Power supply		DC 14.4V		
Rated output		Max 43W x 4		Maw 50W x 4
Speaker impedance		4Ω x 4		2Ω x 4
Antenna		80PF 75Ω		
Tuning type		PLL synthesized type		
The others		-		External amp, woofer speaker
Frequency range / Channel space	FM	87.5~108 MHz/ 100KHz (General), 50KHz(Europe)		
	AM	531~1602 KHz/ 9KHz (General)		
	MW	522~1620 KHz/ 9KHz (Europe)		
	LW	153~279 KHz/ 1KHz (Europe)		
	FM	76.0~90.0 MHz/ 100KHz (Japan)		
	AM	522~1629KHz/ 9KHz (Japan)		

COMPONENT LOCATION ED97CCA8




- 1. Audio unit
- 2. External amp
- 3. Woofer speaker
- 4. Glass antenna

- 5. Front door speaker
- 6. Rear door speaker
- 7. Antenna feeder cable

AUDIO UNIT


COMPONENT EF935C55

[AM/FM/Cassette-M440]





24P Connector

Antenna





Audio connector	Terminal	Description	Terminal	Description
	1	Ground	13	Remote control ground
	2	Battery	14	Steering remote control
	3	Antenna B+	15	Illumination (-)
	4	ACC	16	Illumination (+)
	5	-	17	Rear left speaker (-)
	6	-	18	Rear left speaker (+)
	7	Tweeter in (R)	19	Rear right speaker (-)
	8	Tweeter in (L)	20	Rear right speaker (+)
	9	Ground	21	Front right speaker (-)
	10	Twiter ground	22	Front right speaker (+)
	11	MUTE	23	Front left speaker (-)
	12	Rear-arm remote control	24	Front left speaker (+)

[AM/FM/Cassette/MP3-M455]



Audio connector	Terminal	Description	Terminal	Description
	1	Ground	13	Remote control ground
	2	Battery	14	Steering remote control
	3	Antenna B+	15	Illumination (-)
	4	ACC	16	Illumination (+)
	5	-	17	Rear left speaker (-)
	6	-	18	Rear left speaker (+)
	7	Tweeter in (R)	19	Rear right speaker (-)
	8	Tweeter in (L)	20	Rear right speaker (+)
	9	Ground	21	Front right speaker (-)
	10	Twiter ground	22	Front right speaker (+)
	11	MUTE	23	Front left speaker (-)
	12	Rear-arm remote control	24	Front left speaker (+)

[AM/FM/Cassette/6CDC-M465]



Audio connector	Terminal	Description	Terminal	Description
	1	Ground	13	Remote control ground
	2	Battery	14	Steering remote control
	3	Antenna B+	15	Illumination (-)
	4	ACC	16	Illumination (+)
	5	-	17	Rear left speaker (-)
	6	-	18	Rear left speaker (+)
	7	Tweeter in (R)	19	Rear right speaker (-)
	8	Tweeter in (L)	20	Rear right speaker (+)
	9	Ground	21	Front right speaker (-)
	10	Twiter ground	22	Front right speaker (+)
	11	MUTE	23	Front left speaker (-)
	12	Rear-arm remote control	24	Front left speaker (+)



REPLACEMENT

E4A99BCB

1. Disconnect the negative (-) battery terminal.
2. Remove the crash pad garnish (A) after pulling it by using regular screw driver (-). Take care of fixing clips.
3. Remove the center facia panel (B) after loosening the screws.


Fastener Locations

▷ : Screw, 2 ▶ : Clip, 4



ETRF021A



4. Remove the connectors(A).



LSRE170G

5. Remove the mounting screws then remove the audio unit (A).

▷ : Screw location, 6



ETRF021E


6. Installation is the reverse of removal.

INSPECTION

E06AC3AC

TAPE HEAD AND CAPSTAN CLEANING

1. To obtain optimum performance clean the head, and capstan as often as necessary, depending on frequency of use and tape cleanness.
2. To clean the tape head and capstan, use a cotton swab dipped in ordinary rubbing an alcohol. Wipe the head and capstan.




LTAC005A

SPEAKERS

REPLACEMENT E27DDFBF

FRONT SPEAKER

1. Remove the front door trim panel (Refer to the Body group - front door).
2. Remove the front speaker (A) after removing 4 rivets.




KTRE022B

3. Installation is the reverse of removal.

REAR SPEAKER

1. Remove the rear door trim panel (Refer to the Body group -- rear door).
2. Remove the rear speaker (A) after removing 4 rivets.




ATIE022C

3. Installation is the reverse of removal.

TWEETER SPEAKER

1. Remove the front door quadrant inner cover (A) (Refer to the Body group - front door).
2. Remove the tweeter speaker after disconnecting the connector.




KTRE022D

3. Installation is the reverse of removal.

WOOFER SPEAKER

1. Remove the rear seat. (Refer to the Body group - rear seats)
2. Remove the rear package tray. (Refer to the Body group - package tray)
3. Remove the woofer speaker (A) after removing 4 bolts.




KTRE022E

4. Installation is the reverse of removal.

EXTERNAL AMP

1. Remove the luggage side trim.
2. Remove the external amp (B) from the quarter inner panel after removing 3 nuts.




KTRE022F

3. Installation is the reverse of removal.

INSPECTION

E4B4BBA0

1. Check the speaker with an ohmmeter. If an ohmmeter indicates the correct impedance of the speaker when checking between the speaker (+) and speaker (-) of the same channel, the speaker is OK.
2. If a clicking sound is emitted from the speaker when the ohmmeter is connected to the speaker terminals, the speaker is OK.




KTMB060A

ANTENNA

INSPECTION ED0ACAFA


GLASS ANTENNA TEST

1. Wrap aluminum foil (A) around the tip of the tester probe (B) as shown.



ETRF023C

2. Touch one tester probe to the glass antenna terminal (A) here, and move the other tester probe along the antenna wires to check that continuity exists.




ETRF023D

GLASS ANTENNA REPAIR

NOTE

To make an effective repair, the broken section must be no longer than one inch.

1. Lightly rub the area around the broken section (A) with fine steel wool, and then clean it with alcohol.




ETKD004K

2. Carefully mask above and below the broken portion of the glass antenna wire (B) with cellophane tape (C).
3. Using a small brush, apply a heavy coat of silver conductive paint (A) extending about 1/8" on both sides of the break. Allow 30 minutes to dry.

NOTE

Thoroughly mix the paint before use.




KTKD006Z

4. Check for continuity in the repaired wire.
5. Apply a second coat of paint in the same way. Let it dry three hours before removing the tape.

GLASS ANTENNA CIRCUIT INSPECTION

1. Remove the right side rear pillar trim. Then disconnect the 2P power connector from the glass antenna amp (A).
2. Turn the radio ON.
Measure the voltage between terminal 2 of the harness side power connector (A) and body ground.


OK : approximately 12V (ACC+)



Harness side connector

ETRF023A

3. Disconnect the 2P connector of radio wiring from the glass antenna amp (A).
4. Check for continuity between terminals of harness side connector and antenna grid terminals (AM, FM).



ETRF023B


5. Check the grid lines that continuity exists.
6. When a poor radio reception is not repaired through the above inspection methods, replace the amp.
If the radio reception is still poor, check the radio cable for short and radio head unit for failure.

AUDIO REMOTE CONTROL

INSPECTION E5DFFC6A


REPLACEMENT EBF43BD0

1. Disconnect the negative (-) battery terminal.
2. Remove the driver airbag module. (Refer to the airbag group)



KPRE201C


3. Remove the audio remote control switch (A) after remove the steering wheel remote control switch connector and 2 screws.



KTRE024A

4. Installation is the reverse of removal.


1. Check for resistance between No.2 and No.3 terminals in each switch position.



KTRE024B

Switch	Connector terminal	Resistance (±5%)
VOLUME DOWN	2 - 3 (Right)	6.81 kΩ
VOLUME UP	2 - 3 (Right)	4.61 kΩ
SEEK UP	2 - 3 (Left)	430 Ω
SEEK DOWN	2 - 3 (Right)	1.11 kΩ
MODE	2 - 3 (Left)	2.11 kΩ
MUTE	2 - 3 (Right)	3.11 kΩ

CIRCUIT DIAGRAM EA6859EE



TROUBLESHOOTING ED6221A9

There are six areas where a problem can occur: wiring harness, the radio, the cassette tape deck, the CD player, and speaker. Troubleshooting enables you to confine the problem to a particular area.







CHART 1





LTIF001C

CHART 2



BTIF001D