

JOHN DEERE 400 WHEEL TRACTORS & WHEEL LOADERS



JOHN DEERE

SERVICE MANUAL JOHN DEERE 400 WHEEL TRACTORS & WHEEL LOADERS

SM2074 (01JAN74) English

JOHN DEERE DUBUQUE WORKS
SM2074 (01JAN74)

LITHO IN THE U.S.A.
ENGLISH





SERVICE MANUAL

JOHN DEERE JD400 WHEEL TRACTORS AND WHEEL LOADERS

CONTENTS

	Section
Description and Specifications	10
Tractor Separation	20
Periodic Lubrication	30
Engine Tune-Up and Tractor Adjustment	40
Basic Engine	50
Engine Lubrication System	60
Governor and Speed Control Linkage	70
Engine Cooling System	80
Fuel Systems	90
Electrical System	100
Engine and PTO Clutches	110
Transmission and Differential	120
Continuous-Running PTO	130
Transmission-Driven PTO	140
Independent PTO	145
Reverser	150
Final Drive System	160
Hydraulic Brakes	170
Manual Steering	180
Power Steering (Open Center Type)	190
Power Steering (Closed Center Type)	195
Front Axles, Front End Support, and Steering Linkage	200
Seats	210
Hydraulic System	220
Hydraulic Pumps	230
Rockshaft and 3-Point Hitch	240
Remote Cylinder Selective Control Valve (Early Tractors)	250
Selective Control Valve (Balanced Poppet Type) (Later Tractors)	255
Hose Couplers and Remote Cylinders	260
Wheels, Tires, and Weights	280
Trouble Shooting	290
Special Service Tools	300

Copyright 1965
DEERE & COMPANY
Moline, Illinois
All rights reserved

TO THE JOHN DEERE SERVICEMAN

This service manual contains maintenance instructions for John Deere JD400 Tractors. Included are complete instructions for removal, disassembly, inspection, repair, assembly and installation of the major parts and assemblies of the tractor.

In addition, the manual contains brief descriptions of the more complicated systems of the tractor, and tells how they operate. Tests and adjustments, required to keep the tractor operating efficiently, are explained in detail.


Groups on "Specifications" at the end of each section list dimensions of many new parts as an aid in determining when parts replacement is necessary.

A section on "Tune-Up and Adjustment" contains instructions for performing the services necessary to help the tractor perform ef-

ficiently and economically after it has been in the field for some time.

This manual was planned and written for the Service Department; its place is in the shop. Use the manual whenever in doubt about correct maintenance procedures. Use it as a text book for training new Service Department personnel who are unfamiliar with John Deere Tractors.

Daily use of the Service Manual as a guide for any and all service problems will reduce error and costly delay to a minimum and assure you the best in finished service work. In many instances your customer's confidence in your work will be improved when he see you using the Service Manual. He knows you are following approved maintenance procedures and making proper adjustments. There is no guesswork when you use the manual.



T 14359

Cutaway View of John Deere JD400 Loader with 94 Backhoe

COMPLETE PAGE LISTING
WITH LATEST DATE LINES

I, II	(Jan-74)	50-30-1, 2	(Oct-65)	100-25-1, 2	(Oct-65)
III, IV	(Jul-74)	50-30-3, 4	(May-70)	100-25-3, 4	(Jul-69)
		50-30-5, 6	(Nov-66)	100-25-5, 6	(Jul-69)
10-5-1, 2	(Nov-66)	50-35-1, 2	(Jan-74)	100-25-7, 8	(Oct-65)
10-5-3, 4	(Nov-66)	50-35-3, 4	(Feb-72)	100-30-1, 2	(Nov-66)
10-5-5, 6	(Nov-66)	50-35-5, 6	(Jan-74)	100-30-3, 4	(Feb-72)
10-10-1, 2	(Mar-71)			100-30-5, 6	(Nov-66)
10-10-3, 4	(Mar-71)	60-5-1, 2	(Jan-74)	100-30-7, 8	(Nov-66)
		60-5-3, 4	(Jan-74)	100-35-1, 2	(Oct-65)
20-5-1, 2	(Feb-72)	60-5-5, 6	(Jan-74)	100-35-3, 4	(Oct-65)
20-5-3, 4	(Mar-68)	60-5-7, 8	(Jun-73)	100-40-1, 2	(Mar-71)
20-10-1, 2	(Mar-68)			100-45-1, 2	(Mar-71)
20-15-1, 2	(Oct-65)	70-5-1, 2	(Oct-65)		
20-15-3, 4	(Oct-65)	70-5-3, 4	(Oct-65)	110-5-1, 2	(Oct-65)
20-20-1, 2	(Oct-65)	70-10-1, 2	(Mar-68)	110-5-3, 4	(Oct-65)
20-25-1, 2	(Oct-65)	70-10-3, 4	(Mar-68)	110-10-1, 2	(May-70)
		70-10-5, 6	(Mar-68)	110-10-3, 4	(Jul-69)
30-5-1, 2	(Mar-73)			110-15-1, 2	(Dec-72)
30-5-3, 4	(Jul-69)	80-5-1, 2	(Oct-65)	110-15-3, 4	(Mar-68)
30-5-5, 6	(Jul-69)	80-10-1, 2	(Oct-65)	110-20-1, 2	(Dec-72)
		80-15-1, 2	(Feb-72)	110-20-3, 4	(Dec-72)
40-5-1, 2	(Oct-65)	80-15-3, 4	(Feb-72)		
40-10-1, 2	(Nov-66)	80-15-5, 6	(Jul-69)	120-5-1, 2	(Oct-65)
40-10-3, 4	(Nov-66)			120-5-3, 4	(Oct-65)
40-10-5, 6	(Nov-66)	90-5-1, 2	(Mar-71)	120-5-5, 6	(Oct-65)
40-10-7, 8	(Nov-66)	90-10-1, 2	(Nov-66)	120-5-7, 8	(Oct-65)
40-10-9, 10	(Mar-68)	90-15-1, 2	(Mar-71)	120-5-9, 10	(Oct-65)
40-10-11, 12	(Mar-68)	90-15-3, 4	(Feb-72)	120-10-1, 2	(Feb-72)
40-10-13, 14	(Mar-71)	90-15-5, 6	(Mar-71)	120-10-3, 4	(Dec-72)
40-10-15, 16	(Jul-69)	90-20-1, 2	(Mar-68)	120-10-5, 6	(Nov-66)
40-15-1, 2	(Jul-69)	90-25-1, 2	(Nov-66)	120-15-1, 2	(Oct-65)
40-15-3, 4	(Jul-69)	90-25-3, 4	(Nov-66)	120-15-3, 4	(Feb-72)
40-15-5, 6	(Mar-68)	90-25-5, 6	(Nov-66)	120-15-5, 6	(Jan-74)
		90-25-7, 8	(Nov-66)	120-15-7, 8	(Nov-66)
		90-25-9, 10	(Nov-66)	120-15-9, 10	(Feb-72)
50-5-1, 2	(Feb-72)	90-30-1, 2	(Mar-71)	120-20-1, 2	(Oct-65)
50-5-3, 4	(Oct-65)	90-30-3, 4	(Feb-72)	120-20-3, 4	(May-70)
50-10-1, 2	(Jan-74)	90-30-5, 6	(Mar-71)	120-25-1, 2	(Nov-66)
50-10-3, 4	(Oct-65)	90-30-7, 8	(Jan-74)		
50-10-5, 6	(Dec-72)	90-30-9, 10	(Dec-72)	130-5-1, 2	(Oct-65)
50-10-7, 8	(Feb-72)	90-30-11, 12	(Jul-69)	130-10-1, 2	(Mar-71)
50-15-1, 2	(May-70)	90-30-13, 14	(Dec-72)	130-10-3, 4	(Mar-71)
50-15-3, 4	(Mar-71)	90-35-1, 2	(Dec-72)	130-15-1, 2	(Mar-71)
50-15-5, 6	(Jan-74)				
50-15-7, 8	(Mar-73)	100-5-1, 2	(Oct-65)	140-5-1, 2	(Oct-65)
50-15-9, 10	(Mar-73)	100-5-3, 4	(Oct-65)	140-10-1, 2	(Mar-71)
50-20-1, 2	(Oct-65)	100-15-1, 2	(Oct-65)	140-10-3, 4	(Mar-71)
50-20-3, 4	(Jan-74)	100-15-3, 4	(Oct-65)		
50-20-5, 6	(Nov-66)	100-15-5, 6	(Oct-65)	145-5-1, 2	(Jul-69)
50-25-1, 2	(Oct-65)	100-15-7, 8	(Jul-69)	145-5-3, 4	(Jul-69)
50-25-3, 4	(Mar-71)	100-15-9, 10	(Nov-66)	145-5-5, 6	(Dec-72)
50-25-5, 6	(Oct-65)			145-5-7, 8	(Dec-72)

Vertical lines indicate pages included with this revision.

COMPLETE PAGE LISTING
WITH LATEST DATE LINES

150-5-1, 2	(Oct-65)	200-5-1, 2	(Oct-65)	240-10-1, 2	(Jul-69)
150-5-3, 4	(May-70)	200-10-1, 2	(Nov-66)	240-10-3, 4	(Oct-65)
150-5-5, 6	(Jan-74)	200-10-3, 4	(Nov-66)	240-10-5, 6	(Mar-68)
150-5-7, 8	(Oct-65)	200-15-1, 2	(Oct-65)	240-10-7, 8	(Jul-69)
150-5-9, 10	(Oct-65)			240-10-9, 10	(Oct-65)
150-10-1, 2	(May-70)	210-5-1, 2	(Oct-65)	240-10-11, 12	(Mar-68)
150-10-3, 4	(May-70)	210-5-3, 4	(Oct-65)	240-15-1, 2	(Feb-72)
150-15-1, 2	(Mar-71)	210-10-1, 2	(Oct-65)	240-15-3, 4	(Feb-72)
150-15-3, 4	(Mar-71)			240-20-1, 2	(Feb-72)
150-15-5, 6	(Jan-74)	220-5-1, 2	(Nov-66)	240-20-3, 4	(Mar-68)
150-15-7, 8	(Feb-72)	220-5-3, 4	(Mar-68)		
150-15-9, 10	(Feb-72)	220-5-5, 6	(Nov-66)	250-5-1, 2	(Oct-65)
150-15-11, 12	(Oct-65)	220-5-7, 8	(Feb-72)	250-5-3, 4	(Oct-65)
150-15-13, 14	(Mar-71)	220-10-1, 2	(Mar-68)	250-10-1, 2	(Oct-65)
150-15-15, 16	(Oct-65)	220-10-3, 4	(Mar-68)	250-10-3, 4	(Feb-72)
150-20-1, 2	(Jul-69)	220-10-5, 6	(Mar-73)	250-10-5, 6	(Feb-72)
		220-10-7, 8	(Feb-72)	250-10-7, 8	(Feb-72)
160-5-1, 2	(Oct-65)	220-10-9, 10	(Feb-72)	250-15-1, 2	(Oct-65)
160-10-1, 2	(Mar-71)	220-10-11, 12	(Nov-66)		
160-10-3, 4	(Mar-68)	220-15-1, 2	(Mar-68)	255-5-1, 2	(Jul-69)
		220-15-3, 4	(Mar-68)	255-5-3, 4	(Feb-72)
170-5-1, 2	(Oct-65)	220-15-5, 6	(Nov-66)	255-5-5, 6	(Feb-72)
170-5-3, 4	(Oct-65)	220-20-1, 2	(Mar-68)	255-5-7, 8	(Jul-69)
170-10-1, 2	(Oct-65)	220-20-3, 4	(Mar-68)		
170-10-3, 4	(Feb-72)	220-20-5, 6	(Oct-65)	260-5-1, 2	(Oct-65)
170-10-5, 6	(Feb-72)	220-20-7, 8	(Mar-68)	260-5-3, 4	(Feb-72)
170-15-1, 2	(Feb-72)	220-20-9, 10	(Oct-65)	260-15-1, 2	(Oct-65)
		220-25-1, 2	(Mar-68)	260-15-3, 4	(Feb-72)
180-5-1, 2	(Oct-65)	220-25-3, 4	(Mar-68)		
180-10-1, 2	(Oct-65)	220-25-5, 6	(Jan-74)	280-5-1, 2	(Nov-66)
180-10-3, 4	(Nov-66)			280-10-1, 2	(Nov-66)
180-10-5, 6	(Jul-69)	230-5-1, 2	(Oct-65)	280-15-1, 2	(Mar-71)
		230-5-3, 4	(Nov-66)		
190-5-1, 2	(Nov-66)	230-5-5, 6	(Jul-69)	290-5-1, 2	(Oct-65)
190-5-3, 4	(Nov-66)	230-5-7, 8	(Jul-69)	290-10-1, 2	(Oct-65)
190-5-5, 6	(Oct-65)	230-5-9, 10	(Jul-74)	290-10-3, 4	(Oct-65)
190-5-7, 8	(Oct-65)	230-10-1, 2	(Oct-65)	290-15-1, 2	(Oct-65)
190-10-1, 2	(Oct-65)	230-10-3, 4	(Dec-72)	290-20-1, 2	(Oct-65)
190-10-3, 4	(Nov-66)	230-10-5, 6	(Jul-74)	290-25-1, 2	(Oct-65)
190-10-5, 6	(Mar-68)	230-10-7, 8	(Oct-65)	290-25-3, 4	(Oct-65)
190-10-7, 8	(Nov-66)	230-10-9, 10	(Jul-74)	290-30-1, 2	(Nov-66)
190-15-1, 2	(Nov-66)	230-15-1, 2	(Nov-66)	290-30-3, 4	(Nov-66)
190-15-3, 4	(Nov-66)	230-20-1, 2	(Jul-74)	290-30-5, 6	(Nov-66)
190-20-1, 2	(Nov-66)			290-40-1, 2	(Mar-71)
		240-5-1, 2	(Oct-65)		
195-5-1, 2	(Nov-66)	240-5-3, 4	(Oct-65)	300-5-1, 2	(Feb-72)
195-5-3, 4	(Nov-66)	240-5-5, 6	(Oct-65)	300-5-3, 4	(Mar-68)
195-10-1, 2	(Nov-66)	240-5-7, 8	(Oct-65)	300-5-5, 6	(Feb-72)
195-10-3, 4	(Mar-71)	240-5-9, 10	(Oct-65)		
195-10-5, 6	(Mar-73)	240-5-11, 12	(Oct-65)	Index-1, 2	(Nov-66)
195-10-7, 8	(Mar-73)	240-5-13, 14	(Oct-65)	Index-3, 4	(Nov-66)

Vertical lines indicate pages included with this revision.




Section 10

10-5-1

DESCRIPTION AND SPECIFICATIONS

Group 5 DESCRIPTION



T 12530

Fig. 10-5-1—Right Side View of JD400 Wheel Tractor

The John Deere JD400 is a heavy-duty wheel tractor designed to operate with industrial equipment such as loaders and backhoes, and to perform various pulling and hauling operations on construction projects.

The main features of the JD400 Tractor are described in the paragraphs which follow. Full descriptions of components are given in other sections throughout this manual.

SERIAL NUMBERS

The engine serial number is stamped on a plate at the right side of the engine cylinder block.

The tractor serial number is located at the right side of the transmission case. *NOTE: When ordering tractor and engine parts, record all the digits on the serial number pad. An explanation of the serial number digits is given on the next page.*




Fig. 10-5-2—Engine Serial Number Location





Fig. 10-5-3—Tractor Serial Number Location
(Early Model Shown)

BASIC ENGINE SERIAL NUMBER EXPLANATION




1. The first three letters designate "serial number" and "engine"
 - SN* - Serial Number
 - M - Engine
2. The number designates the series 5 - 4 cylinder
3. This number designates the fuel type of the engine
 - 1 - Gasoline
 - 3 - Diesel
4. Using factory T - Dubuque
5. Application. W - Industrial
6. Sequence serial number of six digits Differs for each engine
7. This letter designates the manufacturer. T - John Deere Dubuque Tractor Works

BASIC TRACTOR SERIAL NUMBER BREAKDOWN



1. The first three letters designate "serial number" and "tractor" SN* - Serial Number
T - Tractor
2. This number designates the series 5 - JD400
3. This letter designates the tractor style W - Industrial
4. This number designates the fuel type of engine
 - 1 - Gasoline
 - 3 - Diesel
5. This letter designates the type of transmission
 - C - Collar Shift
 - D - Collar Shift with Reverser
6. Sequence serial number of six digits Differs for each tractor
7. This letter designates the manufacturer. T - John Deere Dubuque Tractor Works

*"SN" digits are used on early models only.



T 12095

Fig. 10-5-4—Left Side View of JD400 Loader

MODEL NUMBERS

The distributor, the carburetor, the fuel injection pump, and the alternator have identifying model numbers.

ENGINES

The vertical, 4 cylinder, valve-in-head, four-stroke cycle engine is available in either gasoline or diesel models. The engines have four in-line cylinders which use individual wet-sleeve liners of the replaceable type.

ENGINE LUBRICATION SYSTEM

The engine lubrication system is a force-feed and splash type. The system has a positive displacement, gear-type oil pump, with an externally adjustable pressure regulating valve, and a full-flow oil filter.

ENGINE GOVERNOR SYSTEM

Gasoline engine speeds are controlled by a flyweight type governor, driven from the engine crankshaft. Diesel engine speeds are governed by flyweights in the fuel injection pump.

ENGINE COOLING SYSTEM

All engines are liquid cooled and are equipped with pressure cooling systems having a centrifugal water pump and a bypass-type thermostat.

FUEL SYSTEMS

The large capacity fuel tank on all tractors is located at the front under the hood in a enclosed, protected position.

GASOLINE


Gasoline fuel systems are fed by a fuel transfer pump driven by the engine camshaft.

DIESEL

Diesel fuel systems are fed by a fuel transfer pump drive by the engine camshaft.

Diesel fuel is filtered by a single stage replaceable micronic filter element or an optional two-stage filter element. Fuel sediment bowls are located under the filters.

Fuel is delivered to 9.5 mm injector nozzles by means of a distributor type fuel injection pump.



T 12531

Fig. 10-5-5—Left Side View of JD400 Wheel Tractor

ELECTRICAL SYSTEM

All units have a 12-volt negative grounded electrical system. Current is generated by an alternator-regulator circuit. A solenoid-shift starting motor is used to start the engine.

Gasoline units may be equipped with a single 41 ampere or single 70 ampere battery or two 70 ampere batteries. Diesel units may have a single 70 ampere or two 70 ampere batteries. Wheel loader units are always equipped with two 70 ampere batteries.

LIGHTING SYSTEM

The lighting system is optional and includes headlights, rear work light, and tractor warning lamp mounted on the fenders. An auxiliary outlet socket mounted on the rear of the rockshaft housing is available as special equipment.

TRANSMISSION

The standard transmission is a collar shift type with helical-cut gears. The eight forward and four reverse speeds are selected by manual levers while clutching.

REVERSER (Optional)

The optional reverser unit can be shifted on the go without declutching. Wet-disk type clutches provide forward and reverse speeds comparable to low and reverse transmission speeds. (Reverse speeds are 16% faster.) A lockout mechanism prevents operation in high range speeds.

ENGINE AND LIVE PTO CLUTCHES

ENGINE CLUTCH

The engine clutch is a single spring-loaded, dry disk type clutch with friction facings molded to either side of the driven disk. When in the engaged position, these facings contact the rear surface of the engine flywheel and the pressure plate.

LIVE PTO CLUTCH

This clutch also consists of a single spring-loaded, dry disk type clutch with friction facings molded to either side of the driven disk. When in the engaged position the facings contact the surface of the powershaft clutch plate and the clutch cover.

When mounted in tandem with the engine clutch, the front clutch supplies power to the transmission clutch shaft and the rear clutch supplies power to the power take-off.

POWER TAKE-OFF (PTO) AND BELT PULLEY

Tractors are available without power take-off, with single 540 rpm transmission driven, single 540 rpm continuous running, or dual 540-1000 rpm continuous running power take-off.

A mid power take-off is also available with either continuous running PTO options. The mid power take-off operates at 1000 rpm only.

A belt pulley is available for mounting on the rear PTO shaft. The pulley is 12 inches in diameter with 3100 fpm belt speed at 2100 rpm rated engine speed.

DRAWBAR

Tractors can be purchased with a swinging drawbar or a fixed drawbar. The swinging drawbar is used on tractors equipped with rockshaft and 3-point hitch. The fixed drawbar is used on tractors without PTO or 3-point hitch and does not meet ASAE-SAE standards for PTO-machine operation.

FRONT WHEELS

The tractor is equipped with a fixed front axle. Various tire options are available. For detailed information, see Sections 200 and 280 of this manual.

REAR WHEELS

The tractor is equipped with a flanged rear axle. Tread adjustment is made by changing the rim position on the wheel and by reversing the dish of the wheel.

HYDRAULIC SYSTEM

Hydraulic oil is supplied by a variable displacement, constant pressure pump driven off the front of the engine crankshaft.

Three sizes of pumps are available: (1) a four-piston pump with a 6.5 gpm output at 2500 rpm; (2) an eight-piston pump with a 13 gpm output; and (3) an eight-piston pump with a 28 gpm output.

The hydraulic system is a constant pressure, closed center, "live" type. That is, it can be operated when the engine is running, whether the tractor is moving or not.

The system may be equipped with either one or two remote cylinder selective control valves and one or two pairs of breakaway or disconnect couplers.

The single selective control valve operates one remote hydraulic cylinder only. Two selective control valves permit use of two remote cylinders, which can be operated either separately or simultaneously. The cylinders may be either single-acting or double-acting.

Tractors can be equipped with a single rockshaft and 3-point hitch which utilize hydraulic power to control rear-mounted tools to best advantage in various soil conditions.

HYDRAULIC BRAKES

The hydraulic brakes are operated by two pedals located at the right front of the operator's platform. The brakes can be applied independently or simultaneously. The brakes are of the disk type, operating in oil, and are hydraulically actuated.

POWER STEERING

The tractor may be equipped with power steering (standard on loader units).

Early tractors use an open-center type hydraulic system supplied by a power steering pump at the front of the engine.

Later tractors use a closed-center type system in circuit with the tractor main hydraulic system. Oil is supplied by the main hydraulic pump.

On both types of power steering, mechanical linkage is used between the steering wheel and the front axle. In case of oil supply failure, the tractor can be steered manually.

SEATS

Tractors can be equipped with either a regular or a deluxe seat. The deluxe seat contains a compression spring and shock absorber to provide a "float-ride" suspension. Both seats are equipped with a mounted padded backrest and semi-circular foam padding which surrounds the operator. Seat belts and a protective canopy are also available.

JD400 LOADER

The JD400 Loader is a versatile unit that can be used for digging, loading, grading, and leveling. The loader operates off of the closed-center hydraulic system of the tractor. All hydraulic functions of the loader are controlled by a single control lever. Two double-acting cylinders raise and lower the boom, and two double-acting cylinders dump and retract the bucket.

Group 10 SPECIFICATIONS

ENGINE	Gasoline	Diesel	REVERSER UNIT	Hydraulic wet-disk clutches and compound planetary set, reversing "on the go" without clutching.
Flywheel horsepower (observed) at 2500 rpm	59.0	59.0		
Maximum torque, ft-lbs, at 1300 rpm (observed) (nominal)	145.0	145.0	TRANSMISSION	
Number of cylinders	4	4	Type	Collar shift
Bore and stroke, inches	3.86 x 3.86	3.86 x 4.33	Gear selections	8 forward and 4 reverse
Displacement in cubic inches	180.0	202.0	Shifting	4 speeds each in high, low and reverse ranges. Park lock included.
Compression ratio	7.5 to 1*	16.3 to 1		
Firing order	1-3-4-2	1-3-4-2	DIFFERENTIAL AND FINAL DRIVES	
N.A.C.C. or A.M.A. horsepower rating for tax purposes	23.84	23.84	Type	Planetary reduction final drives with spiral bevel gear drive differential.
Intake valve clearance	0.014-inch	0.014-inch	Differential lock	Hand- or foot-operated mechanical lock, spring-loaded out of engagement.
Exhaust valve clearance	0.022-inch	0.018-inch		
Slow idle	600 rpm	800 rpm	POWER TAKE-OFF	
Fast idle	2680 rpm	2650 rpm**	Type	Continuous-running or transmission driven types available in 540 and/or 1000 rpm options.
Working speed range	1500 to 2500	1500 to 2500		
ELECTRICAL SYSTEM			HYDRAULIC SYSTEM	
Battery dry voltage	12 volts		Type	Closed center, constant pressure.
Battery specific gravity at full charge (corrected to 80° F.)	1.260		Standby oil pressure	2250 psi
Battery terminal grounded	negative			
CAPACITIES (U.S. Standard Measures)			BRAKES	Hydraulically activated, wet-disk type.
Fuel tank	19-1/2 gals.			
Cooling system	3 gals.			
Crankcase (including filter)	6 qts.			
Transmission - hydraulic system	10 gals.			
Belt pulley	2-1/2 pts.			
CLUTCH	Single or dual stage spring-loaded, dry disk, foot-operated.			

*8.6 to 1 with high altitude pistons.

**2660 rpm on later units with Model "C" Injection Pumps.

TRAVEL SPEEDS, MPH (With Zero Slip)
(Based on Tractor with 14.9 x 28 Rear Tires)

Gear	Engine Speeds		
	1500 rpm	2100 rpm	2500 rpm
1st	.8	1.2	1.4
2nd	1.2	1.7	2.0
3rd	1.8	2.4	2.9
4th	2.4	3.4	4.1
5th	3.3	4.4	5.5
6th	4.7	6.5	7.8
7th	6.9	10.0	11.5
8th	9.7	13.6	16.1
R1	1.0	1.4	1.6
R2	1.4	1.9	2.3
R3	2.0	2.7	3.4
R4	2.8	4.0	4.8

NOTE: If tractor is equipped with a reverser, multiply forward speeds by 1.16 to obtain true reverse speeds.

TRACTOR DIMENSIONS (With 14.9 x 28 Rear Tires, 7.50 x 16 Front Tires)

Height to top of hood 55 in.
 Clearance (front axle) 18 in.
 Over-all width 73-1/2 in.
 Over-all length (with 3-point hitch) . 130 in.
 Wheelbase 82 in.
 Turning radius (with brakes applied) 132 in.
 Curb clearance circle 271-1/2 in.
 Shipping weight (approx.)
 (gasoline) 4720 lbs.
 (diesel) 4800 lbs.

FRONT WHEEL TREAD 56 inches

REAR WHEEL TREADS


Steel Disk Wheel 60 inches
 Cast Disk Wheel 50 to 78 inches in 2-inch steps

FRONT TIRE OPTIONS

Size	Type	Ply Rating
6.00 x 16	I-1	4
6.00 x 16	I-1	6
7.50 x 16	I-1	6
7.50 x 16	I-1	10
9:00 x 10	F-3	10
11.00 x 15	I-1	6
12.00 x 12	Terra	4

REAR TIRE OPTIONS. . 12.4 x 28, 4 ply rating
 13.6 x 28, 4 ply rating
 14.9 x 24, 6 ply rating
 14.9 x 28, 8 ply rating
 16.9 x 24, 6 ply rating
 16.9 x 24, 8 ply rating
 23.1 x 26, 8 ply rating*
 30 x 20 x 16A, 4 ply (Terra)

**For use only with Seaman Impactor.*



LOADER DIMENSIONS

Maximum height (excluding muffler)	64-1/2 in.
Over-all length (without counterweights)	177-1/4 in.
Total weight (without counterweights)	7230 lbs.
Dumping reach (full height)	29 in.
Dumping clearance (full height)	99 in.
Height to bucket pivot pin (maximum lift)	122-3/4 in.
Digging depth below ground (bucket level)	4 in.
Bucket width	65-1/2 in.
Dump angle (full height)	47°
Bucket roll-back (ground level)	30°
Grading angle	70°

LOADER OPERATING INFORMATION

Pump capacity (2500 engine rpm)	28 gpm
System pressure	2250 psi
Bucket capacity	5/8 cu. yd.
Breakout capacity	4000 lbs., loaders (-64799) 5000 lbs., loaders (64800-Up)
Lift (full height)	2500 lbs., loaders (-64799) 3200 lbs., loaders (64800-Up)
Raising time	3.5 sec.
Lowering time	2.3 sec.
Dumping time	1.3 sec.

(Specifications and design subject to change without notice. Wherever applicable, specifications are in accordance with I.E.M.C. standards.)



Section 20

TRACTOR SEPARATION

Group 5

SEPARATING FRONT END FROM ENGINE


Disconnect battery ground straps for safety.

Remove front ballast (if used).



Fig. 20-5-1—Removing Grille Screens

Pull out on top edge of each grille screen (Fig. 20-5-1). Lift screen to clear pins in front end support. Disconnect springs and remove screens.



*Fig. 20-5-2—Hood Attaching Points
(Early Unit Shown)*

On each side of hood, remove retaining cap screws (Fig. 20-5-1). Remove cap screws attaching hood to grille housing. Lift off hood.


Remove tool box from tractor side frames (if equipped). Remove side frames.

Remove radiator top support rod from radiator. Disconnect fuel return line from tank (diesel).

Disconnect fuel gauge sender wire from fuel tank (if used).

Disconnect all bleed lines from top of hydraulic oil reservoir.

Disconnect air cleaner hose from intake manifold (diesel) or carburetor (gasoline). Remove intake tube.



*Fig. 20-5-3—Removing Radiator
(Unit Without Reverser Shown)*

Drain radiator and disconnect water inlet and outlet hoses. Remove return line from hydraulic oil reservoir.

If tractor is equipped with a reverser, also disconnect cooler return line from bottom of oil cooler and cooler inlet line from top of cooler.

Remove fan shroud from radiator and slip back over fan. Remove cap screws securing radiator to front end support mounting pads and slide radiator out left side of tractor (Fig. 20-5-3).

Close fuel shut-off valve at bottom of fuel tank by screwing in until finger tight.

Disconnect fuel line between fuel tank and fuel pump.

Remove fuel pump from engine. Remove fuel inlet line.


Loosen set screw in hydraulic pump solid drive coupling (see Fig. 20-5-5).

NOTE: Do not lose key from drive coupling when pump shaft is pulled from coupling.


NOTE: Do not lose check valve assembly in end of main pump inlet line when pulling line.

Disconnect main hydraulic pump pressure line at connection at front of engine.

Disconnect steering drag link rod from front steering arm.



Units Without Reverser



Units With Reverser

Fig. 20-5-4—Disconnecting Hydraulic Lines

Remove clamps securing hydraulic oil line to engine oil pan (Fig. 20-5-4). On tractors with power steering, disconnect power steering system outlet line from nipple on main pump inlet line.

Remove retainer from main pump inlet line and reservoir return line at front of clutch housing.




Fig. 20-5-5—Front End Support Attaching Points

Support rear of tractor under clutch housing. Insert wooden blocks between front axle and front end support to keep front end from tipping.

Install JDG-2K tractor splitting stand under front end as shown in Fig. 20-5-6. Modify the stand by slotting one hole in each side so that two screws can be installed on each side of support.

Remove attaching cap screws from front end support (Fig. 20-5-5). Roll front end away from engine as shown in Fig. 20-5-6.

CAUTION: Use caution to prevent front assembly from tipping forward. If fuel tank contains much fuel, either drain it or block front end. Also remove any front weights before splitting tractor.




Fig. 20-5-6—Separating Front End Support From Engine

INSTALLATION

Carefully roll front end toward engine (Fig. 20-5-6). Guide pump shaft into drive coupling. Be sure Woodruff key is in place.

IMPORTANT: Position main pump inlet line and reservoir return line retainer between lines and against clutch housing before inserting lines into clutch housing. Also insert check valve assembly in main pump inlet line before installing line.

Secure front end support to engine block. Tighten four 5/8-inch front end support attaching cap screws to 170 ft-lbs. On later models, tighten the two additional 9/16-inch attaching cap screws (with dowels) to 130 ft-lbs.

Tighten pump drive coupling set screw.

IMPORTANT: Do not secure drive shaft to coupling until front end support is secured to engine block.

Position fuel line near right side of engine block and install fuel transfer pump making sure line fits under and behind transfer pump to filter line. Connect line to pump. On diesel engines, also connect fuel return line to tank. Open fuel shut-off valve at bottom of fuel tank. Connect fuel gauge sending wire to unit on fuel tank (if used).




Fig. 20-5-7—Securing Front End Support

Position fan shroud over fan blade and insert radiator in from left side of tractor as shown in Fig. 20-5-3. Secure to front end support with attaching cap screws. Connect water inlet and outlet hoses.

Connect cooler return line to bottom of cooler and connect cooler inlet to top of cooler.

Connect all bleed lines to fitting on hydraulic oil reservoir.

Connect return line at top of reservoir.

On tractors with power steering, connect power steering system outlet line to nipple on main pump inlet line.

Secure oil lines with clamps to engine oil pan. See Fig. 20-5-4.

Connect air cleaner hose to air intake manifold (diesel) or to carburetor (gasoline).

Connect steering drag link rod to front steering arm.

Install side frames and tool box (if equipped).

Install hood and grille screens. See Fig. 20-5-1 and 2.

Fill radiator with clean soft water and add anti-freeze or John Deere Summer Engine Coolant Conditioner. See Section 80.

Connect battery ground strap.

CAUTION: Batteries are **NEGATIVE** grounded only. Do not polarize the alternator as this will damage the electrical system.

Start engine and check fuel lines, hydraulic lines and radiator hoses for leaks.

