


This manual is brought to you by:

[www.magnamaniac.com](http://www.magnamaniac.com)



Removing gearbox cover

- Unfasten screw (1) for idle speed detent and remove coil.
- Remove retaining screws from gearbox cover.
- Heat gearbox cover to 100 °C at the bearing seats.
- Place sliding sleeve, BMW No. 23 4 632, on the input shaft.
- Press off gearbox cover evenly.
- Remove ball (3) from neutral stop.
- Remove spacers (4).

Here you can find Service Manuals for over 200 different motorcycles



<http://manuals.magnamaniac.com>



**Kawasaki**

**KX250F**



# **Motorcycle Service Manual**

<http://manuals.magnamaniac.com>



# Quick Reference Guide

<b>General Information</b>	<b>1</b>
<b>Periodic Maintenance</b>	<b>2</b>
<b>Fuel System</b>	<b>3</b>
<b>Cooling System</b>	<b>4</b>
<b>Engine Top End</b>	<b>5</b>
<b>Engine Right Side</b>	<b>6</b>
<b>Engine Lubrication System</b>	<b>7</b>
<b>Engine Removal/Installation</b>	<b>8</b>
<b>Crankshaft/Transmission</b>	<b>9</b>
<b>Wheels/Tires</b>	<b>10</b>
<b>Final Drive</b>	<b>11</b>
<b>Brakes</b>	<b>12</b>
<b>Suspension</b>	<b>13</b>
<b>Steering</b>	<b>14</b>
<b>Frame</b>	<b>15</b>
<b>Electrical System</b>	<b>16</b>
<b>Appendix</b>	<b>17</b>

This quick reference guide will assist you in locating a desired topic or procedure.

- Bend the pages back to match the black tab of the desired chapter number with the black tab on the edge at each table of contents page.
- Refer to the sectional table of contents for the exact pages to locate the specific topic required.





**KX250F**

# Motorcycle Service Manual

---

All rights reserved. No parts of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic mechanical photocopying, recording or otherwise, without the prior written permission of Quality Assurance Department/Consumer Products & Machinery Company/Kawasaki Heavy Industries, Ltd., Japan.

No liability can be accepted for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible.

The right is reserved to make changes at any time without prior notice and without incurring an obligation to make such changes to products manufactured previously. See your Motorcycle dealer for the latest information on product improvements incorporated after this publication.

All information contained in this publication is based on the latest product information available at the time of publication. Illustrations and photographs in this publication are intended for reference use only and may not depict actual model component parts.

<http://manuals.magnamaniac.com>

## LIST OF ABBREVIATIONS

A	ampere(s)	lb	pound(s)
ABDC	after bottom dead center	m	meter(s)
AC	alternating current	min	minute(s)
ATDC	after top dead center	N	newton(s)
BBDC	before bottom dead center	Pa	pascal(s)
BDC	bottom dead center	PS	horsepower
BTDC	before top dead center	psi	pound(s) per square inch
°C	degree(s) Celsius	r	revolution
DC	direct current	r/min, rpm	revolution(s) per minute
F	farad(s)	TDC	top dead center
°F	degree(s) Fahrenheit	TIR	total indicator reading
ft	foot, feet	V	volt(s)
g	gram(s) (mass)	W	watt(s)
h	hour(s)	Ω	ohm(s)
kg	(mass)		
kgf	(force)		
L	liter(s)		

# Foreword

This manual is designed primarily for use by trained mechanics in a properly equipped shop. However, it contains enough detail and basic information to make it useful to the owner who desires to perform his own basic maintenance and repair work. A basic knowledge of mechanics, the proper use of tools, and workshop procedures must be understood in order to carry out maintenance and repair satisfactorily. Whenever the owner has insufficient experience or doubts his ability to do the work, all adjustments, maintenance, and repair should be carried out only by qualified mechanics.

In order to perform the work efficiently and to avoid costly mistakes, read the text, thoroughly familiarize yourself with the procedures before starting work, and then do the work carefully in a clean area. Whenever special tools or equipment are specified, do not use makeshift tools or equipment. Precision measurements can only be made if the proper instruments are used, and the use of substitute tools may adversely affect safe operation.

To get the longest life out of your vehicle:

- Follow the Periodic Maintenance Chart in the Service Manual.
- Be alert for problems and non-scheduled maintenance.
- Use proper tools and genuine Kawasaki Motorcycle parts. Special tools, gauges, and testers that are necessary when servicing Kawasaki motorcycles are introduced by the Special Tool Catalog or Manual. Genuine parts provided as spare parts are listed in the Parts Catalog.
- Follow the procedures in this manual carefully. Don't take shortcuts.
- Remember to keep complete records of maintenance and repair with dates and any new parts installed.

---

## How to Use This Manual

---

In preparing this manual, we divided the product into its major systems. These systems became the manual's chapters. All information for a particular system from adjustment through disassembly and inspection is located in a single chapter.

The Quick Reference Guide shows you all of the product's system and assists in locating their chapters. Each chapter in turn has its own comprehensive Table of Contents.

The Periodic Maintenance Chart is located in the Periodic Maintenance chapter. The chart gives a time schedule for required maintenance operations.

If you want spark plug information, for example, go to the Periodic Maintenance Chart first. The chart tells you how frequently to clean and gap the plug. Next, use the Quick Reference Guide to locate the Periodic Maintenance chapter. Then, use the Table of Contents on the first page of the chapter to find the Spark Plug section.

Whenever you see these WARNING and CAUTION symbols, heed their instructions! Always follow safe operating and maintenance practices.

### WARNING

**This warning symbol identifies special instructions or procedures which, if not correctly followed, could result in personal injury, or loss of life.**

### CAUTION

**This caution symbol identifies special instructions or procedures which, if not strictly observed, could result in damage to or destruction of equipment.**

This manual contains four more symbols (in addition to WARNING and CAUTION) which will help you distinguish different types of information.



## NOTE

○ *This note symbol indicates points of particular interest for more efficient and convenient operation.*

● Indicates a procedural step or work to be done.

○ Indicates a procedural sub-step or how to do the work of the procedural step it follows. It also precedes the text of a NOTE.

★ Indicates a conditional step or what action to take based on the results of the test or inspection in the procedural step or sub-step it follows.

In most chapters an exploded view illustration of the system components follows the Table of Contents. In these illustrations you will find the instructions indicating which parts require specified tightening torque, oil, grease or a locking agent during assembly.

# General Information



## Table of Contents

Before Servicing .....	1-2
Model Identification.....	1-7
General Specifications.....	1-8
Unit Conversion Table .....	1-10

## 1-2 GENERAL INFORMATION


### Before Servicing

Before starting to perform an inspection service or carry out a disassembly and reassembly operation on a motorcycle, read the precautions given below. To facilitate actual operations, notes, illustrations, photographs, cautions, and detailed descriptions have been included in each chapter wherever necessary. This section explains the items that require particular attention during the removal and reinstallation or disassembly and reassembly of general parts.

Especially note the following:


#### *Edges of Parts*

Lift large or heavy parts wearing gloves to prevent injury from possible sharp edges on the parts.




#### *Solvent*

Use a high flash point solvent when cleaning parts. High flash point solvent should be used according to directions of the solvent manufacturer.




#### *Cleaning vehicle before disassembly*

Clean the vehicle thoroughly before disassembly. Dirt or other foreign materials entering into sealed areas during vehicle disassembly can cause excessive wear and decrease performance of the vehicle.



#### *Arrangement and Cleaning of Removed Parts*


Disassembled parts are easy to confuse. Arrange the parts according to the order the parts were disassembled and clean the parts in order prior to assembly.



## Before Servicing


### *Storage of Removed Parts*

After all the parts including subassembly parts have been cleaned, store the parts in a clean area. Put a clean cloth or plastic sheet over the parts to protect from any foreign materials that may collect before re-assembly.




### *Inspection*

Reuse of worn or damaged parts may lead to serious accident. Visually inspect removed parts for corrosion, discoloration, or other damage. Refer to the appropriate sections of this manual for service limits on individual parts. Replace the parts if any damage has been found or if the part is beyond its service limit.




### *Replacement Parts*

Replacement Parts must be KAWASAKI genuine or recommended by KAWASAKI. Gaskets, O rings, Oil seals, Grease seals, circlips or cotter pins must be replaced with new ones whenever disassembled.




### *Assembly Order*

In most cases assembly order is the reverse of disassembly, however, if assembly order is provided in this Service Manual, follow the procedures given.



### *Tightening Sequence*

Bolts, nuts, or screws must be tightened according to the specified sequence to prevent case warpage or deformation which can lead to malfunction. If the specified tightening sequence is not indicated, tighten the fasteners alternating diagonally.




## 1-4 GENERAL INFORMATION

### Before Servicing

#### *Tightening Torque*


Incorrect torque applied to a bolt, nut, or screw may lead to serious damage. Tighten fasteners to the specified torque using a good quality torque wrench.

Often, the tightening sequence is followed twice—initial tightening and final tightening with torque wrench.




#### *Force*

Use common sense during disassembly and assembly, excessive force can cause expensive or hard to repair damage. When necessary, remove screws that have a non-permanent locking agent applied using an impact driver. Use a plastic-faced mallet whenever tapping is necessary.



#### *Gasket, Oring*

Hardening, shrinkage, or damage of both gaskets and O-rings after disassembly can reduce sealing performance. Remove old gaskets and clean the sealing surfaces thoroughly so that no gasket material or other material remains. Install new gaskets and replace used O-rings when re-assembling.




#### *Liquid Gasket, Locking Agent*

For applications that require Liquid Gasket or a Locking agent, clean the surfaces so that no oil residue remains before applying liquid gasket or locking agent. Do not apply them excessively. Excessive application can clog oil passages and cause serious damage.



#### *Press*

For items such as bearings or oil seals that must be pressed into place, apply small amount of oil to the contact area. Be sure to maintain proper alignment and use smooth movements when installing.




**Before Servicing**

***Ball Bearing and Needle Bearing***


Do not remove pressed ball or needle unless removal is absolutely necessary. Replace with new ones whenever removed. Press bearings with the manufacturer and size marks facing out. Press the bearing into place by putting pressure on the correct bearing race as shown.

Pressing the incorrect race can cause pressure between the inner and outer race and result in bearing damage.




***Oil Seal, Grease Seal***

Do not remove pressed oil or grease seals unless removal is necessary. Replace with new ones whenever removed. Press new oil seals with manufacture and size marks facing out. Make sure the seal is aligned properly when installing.




***Circlips, Cotter Pins***

Replace circlips or cotter pins that were removed with new ones. Install the circlip with its sharp edge facing outward and its chamfered side facing inward to prevent the clip from being pushed out of its groove when loaded. Take care not to open the clip excessively when installing to prevent deformation.




***Lubrication***

It is important to lubricate rotating or sliding parts during assembly to minimize wear during initial operation. Lubrication points are called out throughout this manual, apply the specific oil or grease as specified.



***Direction of Engine Rotation***

When rotating the crankshaft by hand, the free play amount of rotating direction will affect the adjustment. Rotate the crankshaft to positive direction (clockwise viewed from output side).



## 1-6 GENERAL INFORMATION


---

### Before Servicing

---

#### *Electrical Wires*

A two-color wire is identified first by the primary color and then the stripe color. Unless instructed otherwise, electrical wires must be connected to those of the same color.





Model Identification

KX250-N1 Left Side View



KX250-N1 Right Side View





# 1-8 GENERAL INFORMATION

## General Specifications

Items	KX250-N1
<b>Dimensions:</b> Overall length Overall width Overall height Wheelbase Road clearance Seat height Dry mass Curb mass:           Front Rear Fuel tank capacity	2 170 mm (85.43 in.) 840 mm (33.1 in.) 1 270 mm (50 in.) 1 475 mm (8.07 in.) 340 mm (13.4 in.) 960 mm (37.8 in.) 92.5 kg (204 lb) 49.9 kg (110 lb) 52.6 kg (116 lb) 7.5 L (2.0 US gal)
<b>Performance</b> Minimum turning radius	—
<b>Engine:</b> Type Cooling system Bore and stroke Displacement Compression ratio Maximum horsepower Maximum torque Carburetion system Starting system Ignition system Timing advance Ignition timing Spark plug Valve timing Inlet                    Open Close Duration Exhaust               Open Close Duration Lubrication system Engine oil: Type Viscosity Capacity	4-stroke, single cylinder, DOHC 4 valve Liquid-cooled 77.0 × 53.6 mm (3.03 × 2.11 in.) 249 mL (15.2 cu in.) 12.6 : 1 31.6 kW (43.0 PS) @11 000 r/min (rpm) 28.7 N·m (2.93 kgf·m, 6.45 in·lb) @ 8 500 r/min (rpm) Carburetor, KEIHIN FCR37 Primary kick Digital AC-CDI BTDC 8° @ 2 000 r/min (rpm) NGK CR8EB or NGK CR9EB BTDC 49° ABDC 63° 292° BBDC 69° ATDC 49° 298° Forced lubrication (semi-dry sump) API SH or SJ with JASO MA SAE 10W-40 1.5 L (1.6 USqt)
<b>Drive Train:</b> Primary reduction system: Type Reduction ratio Clutch type	Gear <a href="http://manualsmagnamaniac.com">http://manualsmagnamaniac.com</a> 3.350 (67/20) Wet, multi disc

**General Specifications**

Items	KX250-N1
<b>Transmission:</b> Type Gear ratios:        1st 2nd 3rd 4th 5th  Final drive system: Type Reduction ratio Overall drive ratio	5-speed, constant mesh, return shift  2.142 (30/14) 1.785 (25/14) 1.444 (26/18) 1.200 (24/20) 1.052 (20/19)  Chain drive 3.692 (48/13) 13.020 @ Top gear
<b>Frame:</b> Type Steering angle Caster (rake angle) Trail Front tire:            Size Make/Type Rear tire:            Size Make/Type Front suspension:    Type Wheel travel Rear suspension:    Type Wheel travel Brake type:            Front and Rear Effective disc diameter: Front (effect. dia.) Rear (effect. dia.)	Tubular, semi-double cradle 42° to either side 26.5° 110 mm (4.33 in.) 80/100-21 51M BRIDGESTONE M601 (EU, M201) Tube type 100/90-19 57M BRIDGESTONE M602 (EU, M202) Tube type Telescopic fork (up side down) 300 mm (11.8 in.) Swingarm (New Uni-trak) 310 mm (12.2 in.) Single disc 225 mm (8.86 in.) 215 mm (8.46 in.)

EU: European Model

Specifications are subject to change without notice, and may not apply to every country.

# 1-10 GENERAL INFORMATION

## Unit Conversion Table

### Prefixes for Units:

Prefix	Symbol	Power
mega	M	× 1 000 000
kilo	k	× 1 000
centi	c	× 0.01
milli	m	× 0.001
micro	μ	× 0.000001

### Units of Mass:

kg	×	2.205	=	lb
g	×	0.03527	=	oz


### Units of Volume:

L	×	0.2642	=	gal (US)
L	×	0.2200	=	gal (imp)
L	×	1.057	=	qt (US)
L	×	0.8799	=	qt (imp)
L	×	2.113	=	pint (US)
L	×	1.816	=	pint (imp)
mL	×	0.03381	=	oz (US)
mL	×	0.02816	=	oz (imp)
mL	×	0.06102	=	cu in

### Units of Force:

N	×	0.1020	=	kgf
N	×	0.2248	=	lb
kgf	×	9.807	=	N
kgf	×	2.205	=	lb

### Units of Temperature:



### Units of Length:

km	×	0.6214	=	mile
m	×	3.281	=	ft
mm	×	0.03937	=	in

### Units of Torque:

N·m	×	0.1020	=	kgf·m
N·m	×	0.7376	=	ft·lb
N·m	×	8.851	=	in·lb
kgf·m	×	9.807	=	N·m
kgf·m	×	7.233	=	ft·lb
kgf·m	×	86.80	=	in·lb

### Units of Pressure:

kPa	×	0.01020	=	kgf/cm <sup>2</sup>
kPa	×	0.1450	=	psi
kPa	×	0.7501	=	cm Hg
kgf/cm <sup>2</sup>	×	98.07	=	kPa
kgf/cm <sup>2</sup>	×	14.22	=	psi
cm Hg	×	1.333	=	kPa

### Units of Speed:

km/h	×	0.6214	=	mph
------	---	--------	---	-----

### Units of Power:

kW	×	1.360	=	PS
kW	×	1.341	=	HP
PS	×	0.7355	=	kW
PS	×	0.9863	=	HP

# Periodic Maintenance

## Table of Contents

Periodic Maintenance Chart .....	2-2	Tires Inspection.....	2-29
Torque and Locking Agent.....	2-4	Spoke Tightness Inspection .....	2-29
Specifications .....	2-8	Rim Runout Inspection.....	2-30
Special Tools .....	2-10	Wheel Bearing Inspection .....	2-30
Periodic Maintenance Procedures....	2-11	Final Drive.....	2-31
Fuel System.....	2-11	Drive Chain Wear Inspection .....	2-31
Fuel Hose and Connection		Drive Chain Lubrication.....	2-31
Inspection.....	2-11	Sprocket Wear Inspection.....	2-32
Throttle Grip Free Play Inspection	2-11	Rear Sprocket Warp Inspection ...	2-32
Throttle Grip Free Play		Brakes.....	2-33
Adjustment .....	2-11	Brake Lever and Pedal	
Hot Start Lever Free Play		Adjustment .....	2-33
Inspection.....	2-12	Brake Fluid Level Inspection.....	2-34
Idle Speed Inspection .....	2-12	Brake Fluid Change .....	2-35
Idle Speed Adjustment.....	2-13	Brake Pad Wear Inspection .....	2-37
Air Cleaner Element Cleaning and		Brake Master Cylinder Cup and	
Inspection.....	2-13	Dust Seal Replacement .....	2-38
Cooling System.....	2-15	Caliper Piston Seal and Dust Seal	
Coolant Level Inspection.....	2-15	Replacement.....	2-39
Coolant Deterioration Inspection..	2-16	Brake Hose and Connection	
Radiator Hoses and Connections		Check.....	2-42
Inspection.....	2-16	Brake Hose Replacement.....	2-42
Engine Top End .....	2-17	Suspension.....	2-44
Valve Clearance Inspection .....	2-17	Front Fork Inspection .....	2-44
Valve Clearance Adjustment.....	2-17	Front Fork Oil Change (each fork	
Cylinder Head Warp Inspection ...	2-19	leg) .....	2-44
Cylinder Wear Inspection.....	2-20	Rear Shock Absorber Oil Change	2-46
Piston/Cylinder Clearance .....	2-20	Swingarm and Uni-Trak Linkage	
Piston, Piston Ring and Piston		Inspection.....	2-51
Pin Replacement.....	2-20	Swingarm and Uni-Track Linkage	
Exhaust System .....	2-21	Pivot Lubricate .....	2-51
Silencer Packing Change.....	2-21	Steering .....	2-52
Engine Right Side.....	2-22	Steering Inspection .....	2-52
Clutch Adjustment.....	2-22	Steering Adjustment .....	2-52
Friction and Steel Plates		Stem Bearing Lubrication.....	2-54
Inspection.....	2-23	Frame .....	2-54
Engine Lubrication System .....	2-23	Frame Inspection .....	2-54
Engine Oil Change.....	2-23	Electrical System .....	2-54
Oil Filter Change .....	2-24	Spark Plug Cleaning and	
Oil Screen Cleaning.....	2-26	Inspection.....	2-54
Breather Hose Inspection .....	2-26	Cable Inspection.....	2-55
Crankshaft/Transmission .....	2-26	Lubrication .....	2-55
Crankshaft Inspection.....	2-26	Nut, Bolt, and Fastener Tightness	
Wheel/Tires.....	2-28	Inspection.....	2-57
Air Pressure		Tightness Inspection .....	2-57
Inspection/Adjustment.....	2-28		