BOOM REPAIR GUIDANC

FOR

KOBELCO CRANI

Kobelco Crane 3 Boom Repair Guidance

Full download: http://manualplace.com/download/kobelco-crane_3-boom-repair-guidance/

A. GENERAL

welder. whenever We recommended that certified KOBE thenever possible.

Contact your local KOBELCO Dealer 1 ö STEEL welders arrange for Q. മ service boom repairs 앜 Ø

repair This r of BOOM s sections when o as a guide to welders ö are not available. <u>a</u> <u>a</u> proper

IMPORTANT

REPAIRS MADE BY OTHER THAN A CERTIFIED KOBE STEEL WELDER ARE THE RESPONSIBILITIES OF THE PERSON PERFORMING THE REPAIR. KOBE STEEL ASSUMES NO RELIABILITY FOR ANY CLAIMS RESULTING FROM FAILURES TRACEABLE TO SUCH REPAIRS.

inserts, These instructions pertain and tower crane () n to repair of Luffing) secti sections. laced bases, Boom tips

Instructions apply to tubular code booms.

BOOM MATERIALS

Ġ.

and size. The booms To insure are made of various high quality materials. that replacement material is of the proper strength It should be obtained from authorized KOBELCO dealers.

Bulk lacing material may be by giving the part number of along with the machine model obtained from any the boom section to and serial number. be repaired, KOBELCO dealer

Individually coped laciness dealer by giving the part n repaired, identifying the ph be replaced on boom drawings a the machine model and serial n laciness can physical lo ys available number of the hard be obtained from any of the boom section. I location of the lac ble from KOBELCO, alor any KOBELCO laciness to be