

# Shop Manual

BULLDOZER

**D275AX-5E0**

SERIAL NUMBERS 30001 and up

**ecot3**

**KOMATSU**

---

# **BULLDOZER**

## **D275AX-5E0**

**Machine model      Serial number**

**D275AX-5E0              30001 and up**

---

## **00 Index and foreword**

### **Index**

---

Composition of shop manual .....	2
Table of contents .....	4

## Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Note 1: Always keep the latest version of this manual in accordance with this list and utilize accordingly.

The marks shown to the right of Form No. denote the following:

○: New issue (to be filed additionally) ●: Revision (to be replaced for each Form No.)

Note 2: This shop manual can be supplied for each Form No.

Note 3: To file this shop manual in the special binder for management, handle it as follows:

- Place a divider on the top of each section in the file after matching the Tub No. with No. indicated next to each Section Name shown in the table below:
- File overview and other materials in sections in the order shown below and utilize them accordingly.

Section Title	Form Number
Shop Manual, contents binder, binder label and tabs	SEN00919-07
00 Index and foreword	SEN00920-07
Index	SEN00921-07 ●
Foreword and general information	SEN00922-04
01 Specification	SEN00923-00
Specification and technical data	SEN00924-00
10 Structure, function and maintenance standard	SEN00925-03
Engine and cooling system	SEN00926-00
Power train, Part 1	SEN00927-01
Power train, Part 2	SEN00928-00
Undercarriage and frame	SEN00929-01
Hydraulic system, Part 1	SEN00930-00
Hydraulic system, Part 2	SEN00931-00
Hydraulic system, Part 3	SEN00932-00
Work equipment	SEN00933-01
Cab and its attachments	SEN00934-00
Electrical system	SEN00935-02
20 Standard value table	SEN00936-02
Standard service value table	SEN01413-02 ●
30 Testing and adjusting	SEN00937-02
Testing and adjusting, Part 1	SEN01414-02 ●
Testing and adjusting, Part 2	SEN01415-02 ●
Testing and adjusting, Part 3	SEN01416-01
Testing and adjusting, Part 4	SEN01417-02 ●
40 Troubleshooting	SEN00938-02
Failure code table and fuse locations	SEN01767-02 ●
General information on troubleshooting	SEN01768-02 ●
Troubleshooting by failure and error codes, Part 1	SEN01655-01
Troubleshooting by failure and error codes, Part 2	SEN01656-02 ●
Troubleshooting by failure and error codes, Part 3	SEN01657-01

---

Troubleshooting by failure and error codes, Part 4	SEN01658-01 ●
Troubleshooting by failure and error codes, Part 5	SEN01659-00
Troubleshooting by failure and error codes, Part 6	SEN01878-01
Troubleshooting of electrical system (E-mode)	SEN01646-01
Troubleshooting of hydraulic and mechanical system (H-mode)	SEN01647-00
Troubleshooting of engine (S-mode)	SEN01648-02 ●
50 Disassembly and assembly	SEN00939-02
General information on disassembly and assembly	SEN02340-02 ●
Engine and cooling system	SEN02341-02 ●
Engine	SEN02342-01
Power train, Part 1	SEN02343-00
Power train, Part 2	SEN02344-01 ●
Undercarriage and frame, Part 1	SEN02345-02 ●
Undercarriage and frame, Part 2	SEN02346-01 ●
Hydraulic system	SEN02347-00
Work equipment	SEN02348-01
Cab and its attachments	SEN02349-01
Electrical system	SEN02350-01
90 Diagrams and drawings	SEN00940-02
Hydraulic diagrams and drawings	SEN00941-00
Electrical diagrams and drawings	SEN00942-02

## Table of contents

00 Index and foreword	
Index	SEN00921-07
Composition of shop manual .....	2
Table of contents .....	4
Foreword and general information	SEN00922-04
Safety notice .....	2
How to read the shop manual .....	7
Explanation of terms for maintenance standard .....	9
Handling of electric equipment and hydraulic component .....	11
Handling of connectors newly used for engines .....	20
How to read electric wire code .....	23
Precautions when carrying out operation .....	26
Method of disassembling and connecting push-pull type coupler .....	29
Standard tightening torque table .....	32
Conversion table .....	36
01 Specification	
Specification and technical data	SEN00924-00
Specification and technical data .....	2
Specefication dimension drawings .....	2
Specifications .....	3
Weight table .....	9
Table of fuel, coolant and lubricants .....	11
10 Structure, function and maintenance standard	
Engine and cooling system	SEN00926-00
Engine and cooling system .....	2
Engine mount .....	2
Cooling system .....	4
Cooling fan pump .....	6
Cooling fan motor .....	14
Power train, Part 1	SEN00927-01
Power train skeleton .....	2
HSS system .....	4
Overall drawing of power train unit .....	6
Power train hydraulic piping drawing .....	8
Transmission control .....	9
Steering, brake control .....	10
Damper, universal joint .....	12
Torque converter, PTO .....	14
Transmission .....	28
Tranmission ECMV .....	40
Main relief valve and torque convertor relief valve .....	46
Torque converter valve .....	50
Lubrication relief valve .....	58
Power train, Part 2	SEN00928-00
Power train, Part 2 .....	3
Bevel gear shaft, HSS, brake .....	3
Brake valve .....	16
Brake ECMV .....	17
Parking brake valve .....	23
Sudden brake prevention valve .....	24
Final drive .....	25

Sprocket.....	30
Undercarriage and frame	SEN00929-01
Track frame .....	2
Recoil spring .....	4
Idler .....	6
Track roller .....	8
Track roller bogie.....	10
Carrier roller .....	12
Track shoe.....	14
Main frame .....	18
Suspension .....	20
Hydraulic system, Part 1	SEN00930-00
Hydraulic system, Part 1 .....	2
Work equipment hydraulic piping diagram .....	2
PPC control piping diagram .....	6
Work equipment control.....	8
Hydraulic tank.....	10
Scavenging pump.....	12
Work equipment pump .....	14
Power train pump, steering lubrication pump .....	30
HSS pump .....	31
HSS motor.....	47
PPC, HSS charge filter .....	56
Hydraulic system, Part 2	SEN00931-00
Hydraulic system, Part 2 .....	2
Control valve.....	2
Self pressure reducing valve .....	31
Hydraulic system, Part 3	SEN00932-00
Hydraulic system, Part 3 .....	2
HSS charge filter bypass .....	2
HSS oil cooler bypass valve .....	4
PPC valve.....	6
PCCS lever.....	18
PPC lock valve .....	21
Work equipment cylinder .....	22
Piston valve .....	25
Quick drop valve.....	26
Pin puller switch.....	27
Pin puller solenoid valve.....	28
Blade control knob.....	30
Pitch, dual tilt solenoid valve .....	31
Accumulator.....	32
Work equipment	SEN00933-01
Cylinder stay .....	2
Blade .....	4
Ripper.....	10
Cab and its attachments	SEN00934-00
Cab and its attachments.....	2
Cab mount.....	2
Cab .....	3
Air conditioner.....	5
Electrical system	SEN00935-02
Engine control system.....	2
CRI engine control system .....	12
Monitor system.....	14
Machine monitor.....	16

Mode selection system .....	30
Sensors .....	34
Electrical equipment .....	40
Palm command control system .....	42
KOMTRAX system .....	44
20 Standard value table	
Standard service value table .....	SEN01413-02
Standard value table for engine .....	2
Standard value table for machine .....	3
30 Testing and adjusting	
Testing and adjusting, Part 1 .....	SEN01414-02
Tools for testing, adjusting, and troubleshooting .....	3
Testing engine speed .....	6
Testing intake air pressure (Boost pressure) .....	9
Testing exhaust temperature .....	11
Testing exhaust gas color .....	13
Adjusting valve clearance .....	15
Testing compression pressure .....	17
Testing blow-by pressure .....	19
Testing engine oil pressure .....	20
Testing EGR valve and bypass valve drive oil pressure .....	21
Handling of fuel system devices .....	22
Releasing residual pressure from fuel system .....	22
Testing fuel pressure .....	23
Testing fuel return rate and fuel leakage .....	24
Bleeding air from fuel circuit .....	28
Testing fuel circuit for leakage .....	30
Testing and adjusting alternator belt tension .....	31
Handling controller voltage circuit .....	32
Testing and adjusting air conditioner compressor belt .....	33
Testing fan speed .....	34
Testing fan circuit oil pressure .....	35
Bleeding air from fan pump .....	36
Adjusting fuel control dial and decelerator pedal .....	37
Testing and adjusting, Part 2 .....	SEN01415-02
Testing power train oil pressure .....	3
Testing and adjusting HSS oil pressure .....	12
Adjusting transmission speed sensor .....	17
Bleeding air from HSS pump .....	18
Simple method of testing brake performance .....	18
Adjusting brake pedal and parking brake lever .....	19
Adjusting PCCS lever console position .....	22
Emergency escape method when power train has trouble .....	23
Adjusting clearance of idler .....	26
Inspecting wear of sprocket .....	26
Testing and adjusting track shoe tension .....	27
Testing and adjusting work equipment oil pressure .....	28
Testing control circuit main pressure .....	32
Testing PPC valve output pressure .....	33
Adjusting play of PPC valve .....	35
Testing outlet pressure of ripper pin puller solenoid valve .....	36
Testing parts which cause hydraulic drift of blade and ripper .....	37
Testing internal leakage of work equipment cylinder .....	38
Releasing residual pressure from work equipment cylinder .....	39

Bleeding air from work equipment cylinder .....	39
Adjusting ripper lever position .....	40
Adjusting work equipment lock lever .....	41
Adjusting blade .....	42
Testing and adjusting operator's cab .....	46
Testing and adjusting, Part 3 .....	SEN01416-01
Special functions of machine monitor (EMMS) .....	2
Testing and adjusting, Part 4 .....	SEN01417-02
Adjustment method when controller has been replaced .....	2
Method of starting use of KOMTRAX terminal .....	4
Indication by KOMTRAX terminal lamps .....	7
Preparation work for troubleshooting for electric system .....	10
Handling of optional devices .....	13
Pm Clinic service .....	14
40 Troubleshooting .....	
Failure code table and fuse locations .....	SEN01767-02
Failure codes table .....	2
Fuse locations .....	10
General information on troubleshooting .....	SEN01768-02
Points to remember when troubleshooting .....	2
Sequence of events in troubleshooting .....	3
Check before troubleshooting .....	4
Classification and procedures for troubleshooting .....	5
Contents of troubleshooting table .....	8
Connection table for connector pin numbers .....	10
T-branch box and T-branch adapter table .....	46
Troubleshooting by failure and error codes, Part 1 .....	SEN01655-01
Failure code [1500L0] Transmission clutch dual engagement .....	3
Failure code [15SAL1] Forward clutch oil pressure 1 .....	4
Failure code [15SALH] Forward clutch oil pressure 2 .....	6
Failure code [15SBL1] Reverse clutch oil pressure 1 .....	8
Failure code [15SBLH] Reverse clutch oil pressure 2 .....	10
Failure code [15SEL1] 1st clutch oil pressure 1 .....	12
Failure code [15SELH] 1st clutch oil pressure 2 .....	13
Failure code [15SFL1] 2nd clutch oil pressure 1 .....	14
Failure code [15SFLH] 2nd clutch oil pressure 2 .....	15
Failure code [15SGL1] 3rd clutch oil pressure 1 .....	16
Failure code [15SGLH] 3rd clutch oil pressure 2 .....	17
Failure code [1800MW] Power train clutch slip .....	18
Failure code [2300NR] Brake thermal load .....	19
Failure code [2301L1] Right steering brake oil pressure 1 .....	20
Failure code [2301LH] Right steering brake oil pressure 2 .....	22
Failure code [2301NR] Right steering brake thermal load .....	24
Failure code [2302L1] Left steering brake oil pressure 1 .....	26
Failure code [2302LH] Left steering brake oil pressure 2 .....	28
Failure code [2302NR] Left steering brake thermal load .....	30
Failure code [6001ZK] Failure code for design .....	30
Failure code [A000NS] Engine overheat .....	31
Failure code [AA10NX] Air cleaner clogging .....	32
Failure code [AB00MA] Battery charge abnormal .....	34
Failure code [B@BAZG] Eng oil press low .....	36
Failure code [B@BAZK] Eng oil level low .....	37
Failure code [B@BCNS] Eng coolant overheat .....	38
Failure code [B@BCZK] Radiator coolant level low .....	38
Failure code [B@BEBF] Water gets mixed with fuel .....	39



Failure code [B@BFZK] Fuel level abnormal reduction .....	39
Failure code [B@CENS] Torque converter oil overheat .....	40
Failure code [B@CHZG] HSS charge oil pressure reduction .....	41
Failure code [B@CHZK] Power train oil level reduction .....	41
Failure code [B@GAZK] Battery electrolyte level reduction .....	42
Failure code [B@HANS] Hyd oil overheat .....	42
Failure code [B@HAZK] Hydraulic oil level reduction .....	43
Troubleshooting by failure and error codes, Part 2 .....	SEN01656-02
Failure code [CA111] EMC critical internal failure .....	4
Failure code [CA115] Eng Ne and Bkup speed sens error .....	6
Failure code [CA122] Chg air press sensor high error .....	8
Failure code [CA123] Chg air press sensor low error .....	10
Failure code [CA131] Throttle sensor high error .....	12
Failure code [CA132] Throttle sensor low error .....	14
Failure code [CA135] Eng oil press sensor high error .....	16
Failure code [CA141] Eng oil press sensor low error .....	18
Failure code [CA144] Coolant temp sens high error .....	20
Failure code [CA145] Coolant temp sens low error .....	22
Failure code [CA153] Chg air temp sensor high error .....	24
Failure code [CA154] Chg air temp sensor low error .....	26
Failure code [CA187] Sens supply 2 volt low error .....	26
Failure code [CA221] Ambient press sens high error .....	28
Failure code [CA222] Ambient press sens low error .....	30
Failure code [CA227] Sens supply 2 volt high error .....	32
Failure code [CA234] Eng overspeed .....	34
Failure code [CA238] Ne speed sens supply volt error .....	36
Failure code [CA263] Fuel temp sensor high error .....	38
Failure code [CA265] Fuel temp sensor low error .....	40
Failure code [CA271] PCV1 short error .....	41
Failure code [CA272] PCV1 open error .....	42
Failure code [CA273] PCV2 short error .....	43
Failure code [CA274] PCV2 open error .....	44
Failure code [CA322] Inj #1 (L#1) open/short error .....	46
Failure code [CA323] Inj #5 (L#5) open/short error .....	48
Failure code [CA324] Inj #3 (L#3) open/short error .....	50
Failure code [CA325] Inj #6 (L#6) open/short error .....	52
Failure code [CA331] Inj #2 (L#2) open/short error .....	54
Failure code [CA332] Inj #4 (L#4) open/short error .....	56
Failure code [CA342] Calibration code incompatibility .....	58
Failure code [CA351] Injectors drive circuit error .....	60
Failure code [CA352] Sens supply 1 volt low error .....	62
Failure code [CA386] Sens supply 1 volt high error .....	64
Failure code [CA441] Battery voltage low error .....	66
Failure code [CA442] Battery voltage high error .....	66
Failure code [CA449] Rail press very high error .....	67
Failure code [CA451] Rail press sensor high error .....	68
Failure code [CA452] Rail press sensor low error .....	70
Failure code [CA553] Rail press high error .....	70
Failure code [CA554] Rail press sensor in range error .....	71
Failure code [CA559] Rail press low error .....	72
Failure code [CA689] Eng Ne speed sensor error .....	76
Troubleshooting by failure and error codes, Part 3 .....	SEN01657-01
Failure code [CA731] Eng Bkup speed sens phase error .....	3
Failure code [CA757] All continuous data lost error .....	3
Failure code [CA778] Eng Bkup speed sensor error .....	4
Failure code [CA1228] EGR valve servo error 1 .....	6
Failure code [CA1625] EGR valve servo error 2 .....	7

Failure code [CA1626] BP valve sol current high error .....	8
Failure code [CA1627] BP valve sol current low error .....	10
Failure code [CA1628] Bypass valve servo error 1 .....	11
Failure code [CA1629] Bypass valve servo error 2 .....	12
Failure code [CA1631] BP valve pos sens high error .....	14
Failure code [CA1632] BP valve pos sens low error .....	16
Failure code [CA1633] KOMNET error .....	18
Failure code [CA1642] EGR inlet press sens low error .....	20
Failure code [CA1653] EGR inlet press sens high error .....	22
Failure code [CA2185] Throt sens sup volt high error .....	24
Failure code [CA2186] Throt sens sup volt low error .....	26
Failure code [CA2249] Rail press very low error .....	26
Failure code [CA2271] EGR valve pos sens high error .....	28
Failure code [CA2272] EGR valve pos sens low error .....	30
Failure code [CA2351] EGR valve sol current high error .....	32
Failure code [CA2352] EGR valve sol current low error .....	34
Failure code [CA2555] Grid htr relay volt low error .....	35
Failure code [CA2556] Grid htr relay volt high error .....	36
Failure code [D110KA] Battery relay holding disconnection .....	38
Failure code [D110KB] Battery relay drive short circuit .....	40
Failure code [D130KA] Neutral safety relay disconnection .....	42
Failure code [D130KB] Neutral safety relay short circuit .....	44
Failure code [D161KA] Back-up alarm relay disconnection .....	46
Failure code [D161KB] Back-up alarm relay short circuit .....	48
Failure code [D190KA] Engine controller ACC signal cut relay .....	50
Failure code [D190KB] Engine controller ACC signal cut relay short .....	52
Failure code [D811KR] KOMTRAX controller CAN defective communication .....	54
Failure code [DAFRKR] Machine monitor CAN communication defective communication .....	56
Troubleshooting by failure and error codes, Part 4 .....	SEN01658-01
Failure code [DAQ0KT] Transmission controller internal abnormality .....	3
Failure code [DAQ1KK] Transmission controller main source voltage reduction .....	4
Failure code [DAQ2KK] Transmission controller load voltage reduction .....	6
Failure code [DAQ5KK] Transmission controller sensor 5 V power source (1) power supply source voltage reduction .....	8
Failure code [DAQ6KK] Transmission controller sensor 24 V power supply source voltage reduction .....	10
Failure code [DAQ7KK] Transmission controller sensor 5 V power supply source (2) power source voltage reduction .....	11
Failure code [DAQ9KQ] Transmission controller type collation (Type select signal inconsistency) .....	12
Failure code [DAQRKR] Transmission controller CAN defective communication (Abnormality in objective component system) .....	14
Failure code [DAQSKR] Transmission controller S-NET defective communication (Abnormality in objective component system) .....	16
Failure code [DB2RKR] Engine controller CAN defective communication .....	18
Failure code [DB30KT] Steering controller abnormality in controller .....	20
Failure code [DB31KK] Steering controller main power supply source voltage reduction .....	22
Failure code [DB32KK] Load power source of steering controller power source voltage drop ...	24
Failure code [DB35KK] Steering controller sensor 5 V power source (1) power source voltage drop .....	26
Failure code [DB36KK] Steering controller sensor 24 V power supply source voltage reduction .....	28
Failure code [DB37KK] Steering controller sensor 5 V power source (2) power source voltage drop .....	30
Failure code [DB39KQ] Steering controller type collation (Type select signal inconsistency) .....	32
Failure code [DB3RKR] Steering controller CAN defective communication (Abnormality in objective component system) .....	34

Failure code [DB3SKR] Steering controller S-NET defective communication (Abnormality in objective component system).....	36
Failure code [DD12KA] Shift up switch disconnection .....	38
Failure code [DD12KB] Shift up switch short circuit .....	40
Failure code [DD13KA] Shift down switch disconnection.....	42
Failure code [DD13KB] Shift down switch short circuit .....	44
Failure code [DD14KA] Parking brake lever switch disconnection.....	46
Failure code [DD14KB] Parking brake lever switch short circuit .....	48
Failure code [DDB9L4] Reverse switch disagreement.....	50
Failure code [DDK3L4] Forward switch disagreement.....	51
Failure code [DDK5KA] Gearshift switch disconnection.....	52
Failure code [DDK5KB] Gearshift switch short circuit .....	53
Failure code [DDN7KA] Blade pitch switch disconnection .....	54
Failure code [DDN7KB] Blade pitch switch short circuit.....	56
Failure code [DDN9KA] Blade tilt switch disconnection .....	58
Failure code [DDN9KB] Blade tilt switch short circuit.....	60
Failure code [DDNBLD] Ripper lift raise oil pressure switch is kept ON for long time.....	62
Failure code [DDNCLD] Ripper lift lower oil pressure switch is kept ON for long time.....	63
Failure code [DDNDLD] Ripper lift tilt-in oil pressure switch is kept ON for long time.....	64
Failure code [DDQ2KA] Parking brake lever switch disconnection.....	66
Failure code [DDQ2KB] Parking brake lever switch short circuit .....	68
Failure code [DDQ2L4] Parking brake lever switch disagreement.....	70
Failure code [DDT5KA] Neutral switch disconnection.....	71
Failure code [DDT5KB] Neutral switch short circuit .....	72
Failure code [DDT5KQ] Lever specification selection (Model selection signal disagreement) ...	73
Failure code [DGS1KX] Hydraulic oil temperature sensor input signal is out of normal range ...	74
Troubleshooting by failure and error codes, Part 5	SEN01659-00
Failure code [DGT1KA] Power train oil temp sensor disconnection.....	4
Failure code [DGT1KX] Power train oil temp sensor out of input signal range .....	6
Failure code [DH21KB] Work equipment pump oil pressure sensor short circuit.....	8
Failure code [DH22KA] Work equipment pump oil pressure sensor disconnection .....	10
Failure code [DH22KB] Work equipment pump oil pressure sensor short circuit.....	12
Failure code [DHH3KA] HSS pump oil pressure sensor A disconnection.....	14
Failure code [DHH3KB] HSS pump oil pressure sensor A short circuit .....	16
Failure code [DHH4KA] HSS pump oil pressure sensor B disconnection.....	18
Failure code [DHH4KB] HSS pump oil pressure sensor B short circuit .....	20
Failure code [DK10KA] Fuel control dial disconnection .....	22
Failure code [DK10KB] Fuel control dial short circuit .....	24
Failure code [DK30KA] Steering potentiometer (1) disconnection .....	26
Failure code [DK30KB] Steering potentiometer (1) short circuit.....	28
Failure code [DK30KX] Steering potentiometer (1) out of input signal range.....	30
Failure code [DK30KZ] Steering potentiometer (1) disconnection or short circuit.....	31
Failure code [DK30L8] Steering potentiometer (1) analog signals do not agree.....	32
Failure code [DK31KA] Steering potentiometer (2) disconnection .....	34
Failure code [DK31KB] Steering potentiometer (2) short circuit.....	36
Failure code [DK40KA] Brake potentiometer disconnection .....	38
Failure code [DK40KB] Brake potentiometer short circuit .....	40
Failure code [DK55KX] Directional potentiometer out of input signal range .....	42
Failure code [DK55KZ] Directional potentiometer disconnection or short circuit .....	43
Failure code [DK55L8] Directional potentiometer analog signals do not agree .....	44
Failure code [DK56KA] F-R potentiometer (1) disconnection .....	46
Failure code [DK56KB] F-R potentiometer (1) short circuit.....	48
Failure code [DK57KA] F-R potentiometer (2) disconnection .....	50
Failure code [DK57KB] F-R potentiometer (2) short circuit.....	52
Failure code [DK60KA] Acceleration sensor disconnection .....	54
Failure code [DK60KB] Acceleration sensor short circuit.....	56
Failure code [DKH1KA] Pitch angle sensor disconnection.....	58
Failure code [DKH1KB] Pitch angle sensor short circuit .....	60

Failure code [DKH1KX] Pitch angle sensor out of input signal range .....	62
Failure code [DLT3KA] Transmission out-speed sensor disconnection .....	64
Failure code [DLT3KB] Transmission out-speed sensor abnormal .....	66
Failure code [DV00KB] Caution buzzer short circuit .....	67
Failure code [DW59KA] Blade dual selector solenoid disconnection .....	68
Failure code [DW59KB] Blade dual selector solenoid short circuit .....	70
Failure code [DW59KY] Blade dual selector solenoid hot short .....	72
Failure code [DW5AKA] Blade pitch selector solenoid disconnection .....	73
Failure code [DW5AKB] Blade pitch selector solenoid short circuit .....	74
Failure code [DW5AKY] Blade pitch selection solenoid hot short circuit .....	76
Troubleshooting by failure and error codes, Part 6 .....	SEN01878-01
Failure code [DW7BKA] Fan rev EPC disconnection .....	3
Failure code [DW7BKB] Fan rev EPC short circuit .....	4
Failure code [DW7BKY] Fan reverse solenoid hot short circuit .....	5
Failure code [DWN1KA] HSS pump solenoid right disconnection .....	6
Failure code [DWN1KB] HSS pump solenoid right short circuit .....	8
Failure code [DWN1KY] HSS pump solenoid right hot short .....	10
Failure code [DWN2KA] HSS pump solenoid left disconnection .....	12
Failure code [DWN2KB] HSS pump solenoid left short circuit .....	14
Failure code [DWN2KY] HSS pump solenoid left short circuit .....	16
Failure code [DWN3KA] Sudden stop prevention solenoid disconnection .....	18
Failure code [DWN3KB] Sudden stop prevention solenoid short circuit .....	20
Failure code [DWN3KY] Sudden stop prevention solenoid hot short circuit .....	22
Failure code [DWN4KA] HSS motor free solenoid disconnection .....	23
Failure code [DWN4KB] HSS motor free solenoid short circuit .....	24
Failure code [DWN5KA] Fan pump solenoid disconnection .....	26
Failure code [DWN5KB] Fan pump solenoid short circuit .....	28
Failure code [DWN5KY] Fan pump solenoid hot short circuit .....	30
Failure code [DXH1KA] Lock-up solenoid disconnection .....	32
Failure code [DXH1KB] Lock-up solenoid short circuit .....	34
Failure code [DXH1KY] Lock-up solenoid hot short .....	36
Failure code [DXH4KA] 1st clutch ECMV disconnection .....	38
Failure code [DXH4KB] 1st clutch ECMV short circuit .....	40
Failure code [DXH4KY] 1st clutch ECMV hot short circuit .....	42
Failure code [DXH5KA] 2nd clutch ECMV disconnection .....	44
Failure code [DXH5KB] 2nd clutch ECMV short circuit .....	46
Failure code [DXH5KY] 2nd clutch ECMV hot short circuit .....	48
Failure code [DXH6KA] 3rd clutch ECMV disconnection .....	50
Failure code [DXH6KB] 3rd clutch ECMV short circuit .....	52
Failure code [DXH6KY] 3rd clutch ECMV hot short circuit .....	54
Failure code [DXH7KA] Reverse clutch ECMV disconnection .....	56
Failure code [DXH7KB] Reverse clutch ECMV short circuit .....	58
Failure code [DXH7KY] R clutch ECMV hot short circuit .....	60
Failure code [DXH8KA] Forward clutch ECMV disconnection .....	62
Failure code [DXH8KB] Forward clutch ECMV short circuit .....	64
Failure code [DXH8KY] F clutch ECMV hot short circuit .....	66
Failure code [DXHBKA] Right brake ECMV disconnection .....	68
Failure code [DXHBKB] Right brake ECMV short circuit .....	70
Failure code [DXHBKY] Right brake ECMV hot short circuit .....	72
Failure code [DXHCKA] Left brake ECMV disconnection .....	74
Failure code [DXHCKB] Left brake ECMV short circuit .....	76
Failure code [DXHCKY] Left brake ECMV hot short circuit .....	78
Troubleshooting of electrical system (E-mode) .....	SEN01646-01
Information in troubleshooting table .....	3
E-1 The engine does not start .....	4
E-2 The preheater does not operate (Manual preheating function) .....	7
E-3 The ripper pin puller cylinder does not operate .....	10

E-4 The machine monitor does not come on at all when the starting switch is turned ON .....	12
E-5 When the starting switch is turned ON, the machine monitor completely remains lighted and does not go out .....	14
E-6 When the starting switch is turned ON, the basic check items flash .....	15
E-7 While the engine is operating, any caution item flashes .....	16
E-8 While the engine is operating, the emergency warning item flashes .....	19
E-9 While the preheater is operating, the preheating pilot lamp does not come on .....	24
E-10 At the selecting time of dual tilt, the dual/single tilt selector lamp does not come on (Dual tilt-mounted machine) .....	26
E-11 At the locking-up of the torque converter, the torque converter lock-up display lamp does not come on .....	26
E-12 The engine coolant temperature gauge does not indicate normally .....	27
E-13 Indication of the power train (torque converter) temperature gauge is abnormal .....	28
E-14 The hydraulic oil temperature gauge does not indicate normally .....	30
E-15 Indication of the fuel gauge is abnormal .....	31
E-16 Indications of gear speed and engine speed are abnormal .....	32
E-17 Indication of the shift mode service meter is abnormal .....	32
E-18 The switch module cannot be operated .....	33
E-19 The warning lamp does not flash or does not go out .....	34
E-20 The alarm buzzer does not sound or does not stop .....	35
E-21 Auto shift down is not possible or is not released .....	36
E-22 Pivot turn is not possible or is not released .....	37
E-23 The alarm buzzer cannot be cancelled .....	38
E-24 The operator mode cannot be operated .....	40
E-25 The service mode cannot be operated .....	42
E-26 The back-up alarm does not sound .....	44
E-27 The night light, the headlamp, the working lamp and the rear lamp on the panel do not come on .....	46
E-28 The air conditioner does not operate .....	52
E-29 KOMTRAX system does not operate normally .....	58
E-30 Fan does not reverse .....	60
E-31 Gear cannot be shifted .....	62
Troubleshooting of hydraulic and mechanical system (H-mode) .....	SEN01647-00
Information in troubleshooting table .....	3
H-1 No travel power (No drawbar pull) .....	4
H-2 Machine does not move (At 2nd or 3rd speed) .....	5
H-3 Machine does not move in any speed range .....	6
H-4 Machine travels only in one direction forward or in reverse .....	7
H-5 When gear is shifted or travel direction is changed, large time lag is made .....	8
H-6 Machine does not turn (Not turned rightward or leftward) .....	9
H-7 Steering speed or power is low .....	10
H-8 Brake does not work .....	11
H-9 Torque converter does not lock-up .....	12
H-10 Overheat of power train oil temperature .....	13
H-11 Abnormal sound around HSS pump or HSS motor .....	14
H-12 All work equipment speeds are slow .....	15
H-13 Work equipment does not move .....	16
H-14 Blade lift speed is slow or lacks power .....	17
H-15 Blade tilt speed is slow or lacks power .....	18
H-16 Ripper lift speed is slow or lacks power .....	19
H-17 Ripper tilt speed is slow or lacks power .....	20
H-18 Excessive hydraulic drift of blade lift .....	21
H-19 Excessive hydraulic drift of blade tilt .....	22
H-20 Excessive hydraulic drift of ripper lift .....	23
H-21 Ripper pin puller cylinder does not work (Giant ripper attachment machine) .....	24
H-22 Blade pitch does not work (Dual tilt attachment machine) .....	25
H-23 Abnormal sound comes out from around work equipment pump .....	26

H-24 Fan speed is abnormal (Sound and/or vibration of fan are/is abnormally large or engine overheats) .....	27
Troubleshooting of engine (S-mode) .....	SEN01648-02
Method of using troubleshooting chart .....	3
S-1 Starting performance of engine is poor .....	6
S-2 Engine does not start .....	8
S-3 Engine does not pick up smoothly .....	12
S-4 Engine stops during operation .....	13
S-5 Engine does not rotate smoothly .....	14
S-6 Engine lack output (or lacks power) .....	15
S-7 Exhaust gas is black (incomplete combustion) .....	16
S-8 Oil consumption is excessive (or exhaust gas is blue) .....	18
S-9 Oil becomes dirty quickly .....	19
S-10 Fuel consumption is excessive .....	20
S-11 Oil is in coolant (or coolant spurts back or coolant level goes down) .....	21
S-12 Oil pressure drops .....	22
S-13 Oil level rises (Entry of coolant or fuel) .....	24
S-14 Coolant temperature becomes too high (Overheating) .....	26
S-15 Abnormal noise is made .....	27
S-16 Vibration is excessive .....	28
50 Disassembly and assembly .....	
General information on disassembly and assembly .....	SEN02340-02
How to read this manual .....	2
Coating materials list .....	4
Special tool list .....	7
Sketchs of special tools .....	15
Engine and cooling system .....	SEN02341-02
Removal and installation of engine assembly .....	2
Removal and installation of radiator assembly (including hydraulic oil cooler assembly and aftercooler assembly) .....	7
Removal and installation of hydraulic oil cooler assembly .....	11
Removal and installation of aftercooler assembly .....	13
Removal and installation of radiator guard assembly .....	15
Removal and installation of fuel tank assembly .....	20
Removal and installation of engine hood assembly .....	21
Removal and installation of fan drive assembly .....	23
Removal and installation of fan motor assembly .....	25
Engine .....	SEN02342-01
Removal and installation of fuel supply pump assembly .....	2
Removal and installation of common rail .....	6
Removal and installation of cylinder head assembly .....	9
Removal and installation of fuel injector assembly .....	20
Removal and installation of engine front seal .....	24
Removal and installation of engine rear seal .....	28
Power train, Part 1 .....	SEN02343-00
Removal and installation of damper assembly .....	2
Disassembly and assembly of damper assembly .....	5
Removal and installation of power train unit assembly .....	10
Disconnection and connection of power train unit assembly .....	15
Disassembly and assembly of PTO assembly .....	26
Disassembly and assembly of torque converter assembly .....	33
Disassembly and assembly of torqflow transmission assembly .....	43
Power train, Part 2 .....	SEN02344-01
Removal and installation of scavenging pump .....	2
Disassembly and assembly of HSS case assembly .....	3

Removal and installation of final drive assembly.....	23
Disassembly and assembly of final drive assembly .....	25
Undercarriage and frame, Part 1	SEN02345-02
Removal and installation of track frame assembly .....	2
Removal and installation of recoil spring assembly.....	6
Disassembly and assembly of recoil spring assembly .....	10
Removal and installation of idler assembly .....	12
Disassembly and assembly of idler assembly.....	13
Removal and installation of track roller assembly .....	16
Disassembly and assembly of track roller assembly.....	18
Removal and installation of carrier roller assembly.....	21
Disassembly and assembly of carrier roller assembly .....	22
Removal and installation of 1st bogie assembly .....	25
Removal and installation of 2nd, 3rd and 4th bogie assembly .....	31
Disassembly and assembly of bogie assembly .....	37
Undercarriage and frame, Part 2	SEN02346-01
Expanding and installing track shoe assembly.....	2
Whole disassembly and whole assembly of track shoe assembly .....	5
Removal and installation of pivot shaft assembly.....	27
Removal and installation of equalizer bar assembly .....	28
Disassembly and assembly of equalizer bar bushing .....	31
Hydraulic system	SEN02347-00
Removal and installation of HSS pump assembly.....	2
Removal and installation of work equipment and HSS charge pump assembly .....	4
Removal and installation of power train and lubricating oil pump assembly .....	6
Removal and installation of HSS motor assembly .....	8
Removal and installation of fan pump assembly .....	9
Removal and installation of control valve assembly.....	11
Disassembly and assembly of work equipment control valve assembly .....	15
Disassembly and assembly of hydraulic cylinder assembly.....	16
Work equipment	SEN02348-01
Removal and installation of blade assembly .....	2
Disassembly and assembly of ripper assembly .....	4
Cab and its attachments	SEN02349-01
Removal and installation of ROPS guard .....	2
Removal and installation of operator's cab assembly .....	3
Removal and installation of operator's cab glass (Stuck glass).....	5
Removal and installation of floor frame assembly .....	14
Electrical system	SEN02350-01
Removal and installation of transmission controller assembly .....	2
Removal and installation of steering controller assembly .....	3
Removal and installation of engine controller assembly .....	4
Removal and installation of air conditioner unit assembly.....	5
Removal and installation of monitor panel assembly .....	8
90 Diagrams and drawings	
Hydraulic diagrams and drawings	SEN00941-00
Hydraulic diagrams and drawings .....	3
Hydraulic circuit diagram .....	3
Power train hydraulic circuit diagram.....	5
Electrical diagrams and drawings	SEN00942-02
Electrical circuit diagram (1/13).....	3
Electrical circuit diagram (2/13).....	5
Electrical circuit diagram (3/13).....	7
Electrical circuit diagram (4/13).....	9

---

Electrical circuit diagram (5/13).....	11
Electrical circuit diagram (6/13).....	13
Electrical circuit diagram (7/13).....	15
Electrical circuit diagram (8/13).....	17
Electrical circuit diagram (9/13).....	19
Electrical circuit diagram (10/13).....	21
Electrical circuit diagram (11/13).....	23
Electrical circuit diagram (12/13).....	25
Electrical circuit diagram (13/13).....	27
Electrical circuit diagram for inside cab .....	29
Air conditioner unit electrical circuit diagram.....	31
Connectors table and arrangement drawing .....	33



D275AX-5E0 Bulldozer

Form No. SEN00921-07

---

© 2009 KOMATSU  
All Rights Reserved  
Printed in Japan 04-09 (02)

---

# BULLDOZER

## D275AX-5E0

<b>Machine model</b>	<b>Serial number</b>
D275AX-5E0	30001 and up

---

## 00 Index and foreword

### Foreword and general information

---


Safety notice .....	2
How to read the shop manual .....	7
Explanation of terms for maintenance standard .....	9
Handling of electric equipment and hydraulic component .....	11
Handling of connectors newly used for engines .....	20
How to read electric wire code .....	23
Precautions when carrying out operation .....	26
Method of disassembling and connecting push-pull type coupler .....	29
Standard tightening torque table .....	32
Conversion table .....	36

## Safety notice


(Rev. 2008/08)

### Important safety notice

Proper service and repair are extremely important for safe machine operation. The service and repair techniques recommended by Komatsu and described in this manual are both effective and safe. Some of these techniques require the use of tools specially designed by Komatsu for the specific purpose.

To prevent injury to workers, the symbol  is used to mark safety precautions in this manual. The cautions accompanying these symbols should always be followed carefully. If any dangerous situation arises or may possibly arise, first consider safety, and take the necessary actions to deal with the situation.

### 1. General precautions

 **Mistakes in operation are extremely dangerous. Read the Operation and Maintenance Manual carefully before operating the machine. In addition, read this manual and understand its contents before starting the work.**

- 1) Before carrying out any greasing or repairs, read all the safety labels stuck to the machine. For the locations of the safety labels and detailed explanation of precautions, see the Operation and Maintenance Manual.
- 2) Decide a place in the repair workshop to keep tools and removed parts. Always keep the tools and parts in their correct places. Always keep the work area clean and make sure that there is no dirt, water, or oil on the floor. Smoke only in the areas provided for smoking. Never smoke while working.
- 3) When carrying out any operation, always wear safety shoes and helmet. Do not wear loose work clothes, or clothes with buttons missing.
  - Always wear safety glasses when hitting parts with a hammer.
  - Always wear safety glasses when grinding parts with a grinder, etc.
- 4) When carrying out any operation with 2 or more workers, always agree on the operating procedure before starting. Always inform your fellow workers before starting any step of the operation. Before starting work, hang UNDER REPAIR warning signs in the operator's compartment.
- 5) Only qualified workers must carry out work and operation which require license or qualification.
- 6) Keep all tools in good condition, learn the correct way to use them, and use the proper ones of them. Before starting work, thoroughly check the tools, machine, forklift, service car, etc.
- 7) If welding repairs are needed, always have a trained and experienced welder carry out the work. When carrying out welding work, always wear welding gloves, apron, shielding goggles, cap and other clothes suited for welding work.
- 8) Before starting work, warm up your body thoroughly to start work under good condition.
- 9) Avoid continuing work for long hours and take rests at proper intervals to keep your body in good condition. Take rests in specified safe places.

### Safety points

1	Good arrangement
2	Correct work clothes
3	Following work standard
4	Making and checking signs
5	Prohibition of operation and handling by unlicensed workers
6	Safety check before starting work
7	Wearing protective goggles (for cleaning or grinding work)
8	Wearing shielding goggles and protectors (for welding work)
9	Good physical condition and preparation
10	Precautions against work which you are not used to or you are used to too much

## 2. Preparations for work

- 1) Before adding oil or making any repairs, park the machine on a hard and level ground, and apply the parking brake and block the wheels or tracks to prevent the machine from moving.
- 2) Before starting work, lower the work equipment (blade, ripper, bucket, etc.) to the ground. If this is not possible, insert the lock pin or use blocks to prevent the work equipment from falling. In addition, be sure to lock all the control levers and hang warning signs on them.
- 3) When disassembling or assembling, support the machine with blocks, jacks, or stands before starting work.
- 4) Remove all mud and oil from the steps or other places used to get on and off the machine. Always use the handrails, ladders or steps when getting on or off the machine. Never jump on or off the machine. If it is impossible to use the handrails, ladders or steps, use a stand to provide safe footing.

## 3. Precautions during work

- 1) Before disconnecting or removing components of the oil, water, or air circuits, first release the pressure completely from the circuit. When removing the oil filler cap, a drain plug, or an oil pressure pickup plug, loosen it slowly to prevent the oil from spurting out.
- 2) The coolant and oil in the circuits are hot when the engine is stopped, so be careful not to get scalded. Wait for the oil and coolant to cool before carrying out any work on the oil or water circuits.
- 3) Before starting work, stop the engine. When working on or around a rotating part, in particular, stop the engine. When checking the machine without stopping the engine (measuring oil pressure, revolving speed, temperature, etc.), take extreme care not to get rolled or caught in rotating parts or moving parts.
- 4) Before starting work, remove the leads from the battery. Always remove the lead from the negative (-) terminal first.
- 5) When raising a heavy component (heavier than 25 kg), use a hoist or crane. Before starting work, check that the slings (wire ropes, chains, and hooks) are free from damage. Always use slings which have ample capacity and install them to proper places. Operate the hoist or crane slowly to prevent the component from hitting any other part. Do not work with any part still raised by the hoist or crane.

- 6) When removing a cover which is under internal pressure or under pressure from a spring, always leave 2 bolts in diagonal positions. Loosen those bolts gradually and alternately to release the pressure, and then remove the cover.
- 7) When removing components, be careful not to break or damage the electrical wiring. Damaged wiring may cause electrical fires.
- 8) When removing piping, stop the fuel or oil from spilling out. If any fuel or oil drips onto the floor, wipe it up immediately. Fuel or oil on the floor can cause you to slip and can even start fires.
- 9) As a general rule, do not use gasoline to wash parts. Do not use it to clean electrical parts, in particular.
- 10) Be sure to assemble all parts again in their original places. Replace any damaged parts and parts which must not be reused with new parts. When installing hoses and wires, be sure that they will not be damaged by contact with other parts when the machine is operated.
- 11) When installing high pressure hoses, make sure that they are not twisted. Damaged tubes are dangerous, so be extremely careful when installing tubes for high pressure circuits. In addition, check that connecting parts are correctly installed.
- 12) When assembling or installing parts, always tighten them to the specified torques. When installing protective parts such as guards, or parts which vibrate violently or rotate at high speed, be particularly careful to check that they are installed correctly.
- 13) When aligning 2 holes, never insert your fingers or hand. Be careful not to get your fingers caught in a hole.
- 14) When measuring hydraulic pressure, check that the measuring tools are correctly assembled.
- 15) Take care when removing or installing the tracks of track-type machines. When removing the track, the track separates suddenly, so never let anyone stand at either end of the track.
- 16) If the engine is operated for a long time in a place which is not ventilated well, you may suffer from gas poisoning. Accordingly, open the windows and doors to ventilate well.