

# **Operation & Maintenance Manual**

**UEAM003201**

# **PW160-7K**

## **WHEELED EXCAVATOR**

**SERIAL NUMBER**

**PW160-7K - K40001 and up**



### **WARNING**

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept inside the cab for reference and periodically reviewed by all personnel who will come into contact with the machine.

**KOMATSU**



# **FOREWORD**

## FOREWORD

This manual provides rules and guidelines which will help you use this machine safely and effectively. Keep this manual handy and have all personnel read it periodically. If this manual has been lost or has become dirty and can not be read, request a replacement manual from Komatsu or your Komatsu distributor.

If you sell the machine, be sure to give this manual to the new owners.

Continuing improvements in the design of this machine can lead to changes in detail which may not be reflected in this manual. Consult Komatsu or your Komatsu distributor for the latest available information for your machine or for questions regarding information in this manual.

### **⚠ WARNING**

- This operation & maintenance manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you require.
  - This machine complies with EC directive (89/392/EEC). Machines complying with this directive display the CE mark
  - Improper operation and maintenance of this machine can be hazardous and could result in serious injury or death.
  - Operators and maintenance personnel should read this manual thoroughly before beginning operation or maintenance.
  - Some actions involved in operation and maintenance of the machine can cause a serious accident, if they are not done in a manner described in this manual.
  - The procedures and precautions given in this manual apply only to intended uses of the machine. If you use your machine for any unintended uses that are not specifically prohibited, you must be sure that it is safe for you and others. In no event should you or others engage in prohibited uses or actions as described in this manual.
  - Komatsu delivers machines that comply with all applicable regulations and standards of the country to which it has been shipped. If this machine has been purchased in another country or purchased from someone in another country, it may lack certain safety devices and specifications that are necessary for use in your country. If there is any question about whether your product complies with the applicable standards and regulations of your country, consult Komatsu or your Komatsu distributor before operating the machine.
  - The description of safety is given, see "SAFETY INFORMATION (5)" and in "SAFETY" from page 19.
-

# SAFETY INFORMATION

## SAFETY MESSAGES

Most accidents are caused by the failure to follow fundamental safety rules for the operation and maintenance of machines.

To avoid accidents, read, understand and follow all precautions and warnings in this manual and on the machine before performing operation and maintenance.

To identify hazards on the machine pictorial decals are used (see POSITION FOR ATTACHING SAFETY LABELS).

### **RED WARNING TRIANGLE** - This is used on safety

labels where there is a high probability of serious injury or death if the hazard is not avoided. These safety messages or labels usually describe precautions that must be taken to avoid the hazard. Failure to avoid this hazard may also result in serious damage to the machine.

### **ORANGE WARNING TRIANGLE** - This is used on

safety labels where there is a potentially dangerous situation which could result in serious injury or death if the hazard is not avoided. These safety messages or labels usually describe precautions that must be taken to avoid the hazard. Failure to avoid this hazard may also result in serious damage of the machine

### **YELLOW SAFETY TRIANGLE** - This is used on

safety labels for hazards which could result in minor or moderate injury if the hazard is not avoided. This word might also be used for a hazard where the only result could be damage to the machine.

**NOTICE** - This word is used for precautions that must be taken to avoid actions which could shorten the life of the machine.

Safety precautions are described in SAFETY from page 19.

Komatsu cannot predict every circumstance that might involve a potential hazard in operation and maintenance. Therefore the safety message in this manual and on the machine may not include all possible safety precautions. If any procedures or actions not specifically recommended or allowed in this manual are used, you must be sure that you and others can do such procedures and actions safely and without damaging the machine. If you are unsure about the safety of some procedures, contact Komatsu or your Komatsu distributor.

## NOISE

- Sound pressure level at the operator's station, measured according to ISO6396 (Dynamic test method, simulated working cycle).



- Sound power level emitted. This is the guaranteed value as specified in the European directive 2000/14/EC



## VIBRATION

- The weighted root mean square acceleration value to which the operator's arms are subjected does not exceed  $2.5 \text{ m/s}^2$
- The weighted root mean square acceleration value to which the operator's body is subjected was measured at  $0.64 \text{ m/s}^2$

These results were obtained by accelerometers during trench digging.

## **EMERGENCY STEERING**

This machine is equipped with an emergency steering system and complies to ISO 5010 (BSEN 12643). In the advent of failure of the source of power for the steering system (engine failure) whilst travelling, the machine can be steered allowing the machine to be safely stopped.

In such a case, the effort required at the steering wheel and the number of turns to steer the machine will increase. To confirm function of emergency steering system, raise the front wheels off the ground (using the work equipment) and with the engine off, turn the steering wheel and check movement of the wheels.

## **EMERGENCY BRAKING**

This machine is equipped with an emergency braking system and complies to ISO 3450. In the advent of failure of the source of power for the braking system (engine failure) whilst travelling, the brakes can be actuated from stored energy in the accumulators to bring the machine safely to a stop.

In such a case, seven brake applications can be made before exhausting the energy in the accumulators. In the advent of service brake failure, the park brake can be used as an emergency brake to bring the machine to a stop.

# INTRODUCTION

## INTENDED USE

This Komatsu HYDRAULIC EXCAVATOR is designed to be used mainly for the following work:

- Digging
- Smoothing work
- Ditching work
- Loading work

**See the section see "WORK POSSIBLE USING HYDRAULIC EXCAVATOR (186)" for further details**

## FEATURES

- This Komatsu HYDRAULIC EXCAVATOR is equipped with various controls based on an advanced electronics system.
- The monitor panel greatly facilitates daily maintenance and self-diagnosis.
- Working mode & travel speed are selectable.
- Digging and lifting force can be increased by light-touch control. (For details, see operation section.)
- Adjustable wrist control levers make operations smooth and easy.
- Fresh filtered air conditioner assures comfortable operation.
- Low noise level and smart urban style design and colouring.
- Superb operation performance provided by powerful engine and high-performance hydraulic pump.
- Low fuel consumption controlled by an electronic control system provides an environment-friendly machine.
- Sophisticated drive train provides fast and smooth travelling on the highway and off road.

## BREAKING IN YOUR NEW MACHINE

Your Komatsu machine has been thoroughly adjusted and tested before shipment.

However, operating the machine under severe conditions at the beginning can adversely affect the performance and shorten the machine life.

Be sure to break in the machine for the initial 100 hours (as indicated by the hour meter.)

During breaking in:

- Idle the engine for 5 minutes after starting it up.
- Avoid operation with heavy loads or at high speeds.
- Sudden starting or acceleration, unnecessarily abrupt braking and sharp turning should be avoided except in cases of emergency.

Additionally for the first 20 hours

- Avoid operating engine for prolonged periods at constant speed (including idle.)
- Avoid high speed travelling for periods of more than 5 minutes.

Pay particular attention to oil pressure and temperature indicators & check coolant and oil levels frequently during breaking in.

The precautions given in this manual for operating, maintenance, and safety procedures are only those that apply when this product is used for the specified purpose. If the machine is used for a purpose that is not listed in this manual, Komatsu cannot bear any responsibility for safety. All consideration of safety in such operations is the responsibility of the user.

Operations that are prohibited in this manual must never be carried out under any circumstances.

# LOCATIONS OF PLATES, TABLE TO ENTER SERIAL NO. AND DISTRIBUTOR


## MACHINE SERIAL NO. PLATE POSITION

On the front left of the undercarriage



## ENGINE SERIAL NO. PLATE POSITION

On the gear case front corner.



## TABLE TO ENTER SERIAL NO. AND DISTRIBUTOR

Machine serial No.:

Engine Serial No.:

Product Identification Number.

Manufacturer's name: Komatsu UK Ltd.

Address

Durham Road  
Birtley  
Chester-Le-Street  
County Durham DH32QX  
United Kingdom


Distributor

Address


Phone

## MACHINE SERIAL PLATES


### STANDARD SERIAL PLATE



### GERMANY SERIAL PLATE



### ITALIAN SERIAL PLATE





---

# CONTENTS

<b>FOREWORD.....</b>	<b>3</b>
<b>FOREWORD .....</b>	<b>4</b>
<b>SAFETY INFORMATION .....</b>	<b>5</b>
SAFETY MESSAGES .....	5
NOISE .....	6
VIBRATION .....	6
EMERGENCY STEERING .....	7
<b>INTRODUCTION .....</b>	<b>8</b>
INTENDED USE .....	8
FEATURES .....	8
BREAKING IN YOUR NEW MACHINE .....	9
<b>LOCATIONS OF PLATES, TABLE TO ENTER SERIAL NO. AND DISTRIBUTOR .....</b>	<b>10</b>
MACHINE SERIAL NO. PLATE POSITION .....	10
ENGINE SERIAL NO. PLATE POSITION .....	10
TABLE TO ENTER SERIAL NO. AND DISTRIBUTOR .....	10
MACHINE SERIAL PLATES .....	11
<b>SAFETY.....</b>	<b>19</b>
<b>GENERAL PRECAUTIONS .....</b>	<b>20</b>
<b>PRECAUTION DURING OPERATION .....</b>	<b>27</b>
BEFORE STARTING ENGINE .....	27
OPERATING MACHINE .....	28
TRANSPORTATION .....	35
BATTERY .....	36
TOWING .....	37
BUCKET WITH HOOK OR BUCKET LINK WITH LIFTING EYE .....	38
<b>PRECAUTIONS FOR MAINTENANCE .....</b>	<b>42</b>
BEFORE CARRYING OUT MAINTENANCE .....	42
DURING MAINTENANCE .....	45
<b>POSITION FOR ATTACHING SAFETY LABELS .....</b>	<b>48</b>
POSITION FOR ATTACHING SAFETY LABELS .....	48
<b>LIFTING CAPACITY CHART PW160-7K .....</b>	<b>56</b>
ONE PIECE BOOM Lift capacity tables .....	56
TWO PIECE BOOM Lift capacity tables .....	62
ROTATING ARM capacity tables .....	68
OVERLOAD CAUTION .....	70

---

<b>OPERATION.....</b>	<b>71</b>
<b>GENERAL VIEW .....</b>	<b>72</b>
GENERAL VIEW OF MACHINE .....	72
GENERAL VIEW OF CONTROLS AND GAUGES .....	73
<b>EXPLANATION OF COMPONENTS .....</b>	<b>74</b>
MACHINE MONITOR .....	74
BASIC CHECK ITEMS .....	77
<b>SWITCHES .....</b>	<b>106</b>
<b>CONTROL LEVERS, PEDALS .....</b>	<b>114</b>
FRONT WINDOW .....	119
EMERGENCY EXIT FROM OPERATOR'S CAB .....	123
DOOR LOCK .....	124
CAP, COVER WITH LOCK .....	125
FUSE .....	126
LUGGAGE TRAY .....	127
ASHTRAY .....	127
CUP HOLDER .....	127
HOT AND COOL BOX .....	127
CAB RADIO .....	128
POWER PICK-UP PORT .....	128
HANDLING AIR CONDITIONER .....	129
FUSIBLE LINK .....	142
CONTROLLER .....	142
TOOL BOX (CHASSIS) .....	143
REFUELING PUMP .....	143
WARNING LAMPS .....	145
HANDLING ACCUMULATORS .....	146
<b>OPERATION .....</b>	<b>147</b>
CHECK BEFORE STARTING ENGINE .....	147
<b>OPERATIONS AND CHECKS BEFORE STARTING ENGINE .....</b>	<b>158</b>
STARTING ENGINE .....	160
MOVING MACHINE OFF .....	169
STEERING .....	172
TRAVELLING ON PUBLIC HIGHWAY .....	173
STOPPING & PARKING .....	174
SWINGING (Slewing the upper carriage) .....	176
OPERATION OF WORK EQUIPMENT .....	177
WORKING MODE SELECTION .....	180
PROHIBITIONS FOR OPERATION .....	181
PRECAUTIONS FOR OPERATION .....	182
PRECAUTIONS WHEN TRAVELLING UP OR DOWN HILLS .....	184
HOW TO ESCAPE FROM MUD .....	185
WORK POSSIBLE USING HYDRAULIC EXCAVATOR .....	186

---

REPLACEMENT AND INVERSION OF BUCKET .....	187
STOPPING ENGINE .....	189
CHECK AFTER FINISHING WORK .....	189
<b>CHECK AFTER STOPPING ENGINE .....</b>	<b>190</b>
LOCKING .....	190
OVERLOAD WARNING DEVICE .....	190
HANDLING THE WHEELS .....	190
<b>TRANSPORTATION .....</b>	<b>195</b>
LOADING, UNLOADING WORK .....	195
PRECAUTIONS FOR LOADING .....	197
PRECAUTIONS FOR TRANSPORTATION .....	200
TRAVELLING POSTURE .....	202
<b>COLD WEATHER OPERATION .....</b>	<b>203</b>
PRECAUTIONS FOR LOW TEMPERATURE .....	203
PRECAUTIONS AFTER COMPLETION OF WORK .....	205
AFTER COLD WEATHER .....	205
<b>LONG-TERM STORAGE .....</b>	<b>206</b>
BEFORE STORAGE .....	206
DURING STORAGE .....	206
AFTER STORAGE .....	207
STARTING MACHINE AFTER LONG-TERM STORAGE .....	207
<b>TROUBLESHOOTING .....</b>	<b>208</b>
PHENOMENA THAT ARE NOT FAILURES .....	208
METHOD OF TOWING MACHINE .....	209
PRECAUTIONS ON PARTICULAR JOBSITE .....	209
DISCHARGED BATTERY .....	210
OTHER TROUBLE .....	214
<b>MAINTENANCE .....</b>	<b>219</b>
<b>GUIDES TO MAINTENANCE .....</b>	<b>220</b>
<b>OUTLINE OF SERVICE .....</b>	<b>223</b>
OUTLINE OF OIL, FUEL, COOLANT .....	223
OUTLINE OF ELECTRIC SYSTEM .....	226
OUTLINE OF HYDRAULIC SYSTEM .....	227
<b>WEAR PARTS LIST .....</b>	<b>229</b>
<b>USE FUEL, COOLANT AND LUBRICANTS ACCORDING TO AMBIENT TEMPERATURE .....</b>	<b>230</b>
PROPER SELECTION OF FUEL, COOLANT AND LUBRICANTS .....	230

---

<b>USE FUEL, COOLANT AND LUBRICANTS ACCORDING TO AMBIENT TEMPERATURE CONT.</b>	<b>232</b>
<b>STANDARD TIGHTENING TORQUES FOR BOLTS AND NUTS</b>	<b>234</b>
INTRODUCTION OF NECESSARY TOOLS	234
<b>TIGHTENING TORQUE SPECIFICATIONS</b>	<b>235</b>
TIGHTENING TORQUE LIST	235
<b>PERIODIC REPLACEMENT OF SAFETY CRITICAL PARTS</b>	<b>236</b>
SAFETY CRITICAL PARTS	237
<b>MAINTENANCE SCHEDULE CHART</b>	<b>238</b>
KEY TO LUBRICATION POINTS	242
<b>SERVICE PROCEDURE</b>	<b>244</b>
INITIAL 250 HOURS SERVICE	244
WHEN REQUIRED	245
CHECKING COOLANT LEVEL	253
CHECK AND TIGHTEN WHEEL NUTS	256
CHECK ELECTRICAL INTAKE AIR HEATER	256
CHECK ALTERNATOR	256
REPLACE BUCKET SIDE CUTTERS	257
REPLACE BUCKET TEETH	258
ADJUST BUCKET CLEARANCE	262
CHECK WINDOW WASHER FLUID LEVEL, ADD FLUID	263
CHECK AND ADJUST AIR CONDITIONER	264
CHECK BEFORE STARTING	265
CHECK COOLANT LEVEL, ADD WATER	265
EVERY 50 HOURS	270
EVERY 100 HOURS SERVICE	270
EVERY 250 HOURS MAINTENANCE	276
EVERY 500 HOURS SERVICE	282
EVERY 1000 HOURS SERVICE	290
EVERY 2000 HOURS SERVICE	296
EVERY 4000 HOURS SERVICE	297
EVERY 5000 HOURS SERVICE	298
<b>SPECIFICATIONS</b>	<b>301</b>
<b>SPECIFICATIONS</b>	<b>302</b>
1 - PIECE BOOM	303
2 - PIECE BOOM	304
WORKING RANGE: ONE PIECE BOOM	305
WORKING RANGE: TWO PIECE BOOM	306
WORKING RANGE: ROTATING ARM	307

---

<b>OPTIONS, ATTACHMENTS .....</b>	<b>309</b>
<b>GENERAL PRECAUTIONS .....</b>	<b>310</b>
PRECAUTIONS RELATED TO SAFETY .....	310
<b>PRECAUTIONS WHEN INSTALLING ATTACHMENTS .....</b>	<b>311</b>
<b>HANDLING BUCKET WITH HOOK .....</b>	<b>313</b>
CHECKING FOR DAMAGE TO BUCKET WITH HOOK .....	313
PROHIBITED OPERATIONS .....	313
PRECAUTIONS DURING OPERATIONS .....	313
<b>MACHINES READY FOR ATTACHMENTS .....</b>	<b>314</b>
GENERAL LOCATIONS .....	314
HANDLING THE CLAMSHELL BUCKET .....	316
OPERATION .....	318
METHOD FOR RELEASING PRESSURE IN CONTROL CIRCUIT OF MACHINES EQUIPPED WITH ACCUMULATOR .....	321
LONG-TERM STORAGE .....	321
<b>INTRODUCTION OF ATTACHMENTS AND EXTENDING MACHINE SERVICE LIFE .....</b>	<b>322</b>
HYDRAULIC BREAKER .....	322
POWER RIPPER .....	325
FORK GRAB .....	326
GRAPPLE BUCKET .....	327
SCRAP GRAPPLE .....	328
CRUSHER & SMASHER .....	330
HYDRAULIC PILE DRIVER .....	331
HYDRAULIC EXCAVATOR WITH MULTIPURPOSE CRANE .....	332
<b>ROTATING ARM .....</b>	<b>337</b>
GENERAL LOCATION AND SPECIFICATIONS .....	337
GENERAL VIEW OF CONTROLS .....	339
TRAVELLING POSTURE .....	341
MAINTENANCE .....	343



# SAFETY

## **WARNING**

**Read and follow all safety precautions. Failure to do so may result in serious injury or death.**

---

This safety section also contains precautions for optional equipment and attachments.

**⚠ WARNING:** For reasons of safety, always follow these safety precautions.

## GENERAL PRECAUTIONS

### SAFETY RULES


- ONLY trained and authorised personnel can operate and maintain the machine.
- Follow all safety rules, precautions and instructions when operating or performing maintenance on the machine.
- When working with another operator or a person on work site traffic duty, be sure all personnel understand all hand signals that are to be used.

### SAFETY FEATURES

- Be sure all guards and covers are in their proper position. Have guards and covers repaired if damaged.
- Use safety features such as safety lock lever at all times.
- NEVER remove any safety features. ALWAYS keep them in good operating condition.
- Always wear safety belt when operating machine.
- Improper use of safety features could result in serious bodily injury or death.

### CLOTHING AND PERSONAL PROTECTIVE ITEMS

- Avoid loose clothing, jewellery, and loose long hair. They can catch on controls or in moving parts and cause serious injury or death. Also, do not wear oily clothes because they are flammable.
- Wear a hard hat, safety glasses, safety shoes, mask or gloves when operating or maintaining the machine. Always wear safety goggles, hard hat and heavy gloves if your job involves scattering metal chips or minute materials, this is so particularly when driving pins with a hammer and when cleaning the air cleaner element with compressed air.  
Check also that there is no one near the machine.



**Driving in pins, see "REPLACEMENT AND INVERSION OF BUCKET (187)"**

**Cleaning of air cleaner element, see "WHEN REQUIRED (245)" in service procedure.**

### UNAUTHORISED MODIFICATION

- Any modification made without authorisation from Komatsu can create hazards.
- Before making a modification, consult your Komatsu distributor. Komatsu will not be responsible for any injury or damage caused by any unauthorised modification.