

SHOP MANUAL KOMATSU WA450-2 WHEEL LOADER

MACHINE MODEL	SERIAL NUMBERS
WA450-2	A25001 and up

This material is proprietary to Komatsu Dresser Company and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu Dresser Company.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or add improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, periodic revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.

DEC 90

Copyright 1990 Komatsu Dresser Company

PRODUCT PUBLICATIONS INFORMATION

VARIOUS PRODUCT PARTS & SERVICE PUBLICATIONS ARE AVAILABLE TO ALL **KOMATSU** CONSTRUCTION EQUIPMENT OWNERS, INCLUDING OPERATION & MAINTENANCE MANUALS, PARTS BOOKS AND SHOP MANUALS.

SPECIAL PUBLICATIONS SUCH AS SERVICE TOOL, AIR CONDITIONING, AND TURBOCHARGER SHOP MANUALS ARE ALSO AVAILABLE AS WELL AS SELECTED OPERATION & MAINTENANCE AND SHOP MANUALS IN FOREIGN LANGUAGES.

THE PUBLICATIONS LISTED BELOW ARE AVAILABLE FOR THIS PARTICULAR MACHINE(S).

DESCRIPTION	FORM NUMBER
PARTS BOOK - PAPER:	
Engine and Chassis	BEPBW21021
PARTS BOOK - MICROFICHE:	
Engine and Chassis	BEPMW21021
OPERATION & MAINTENANCE MANUAL:	
Chassis	SEAM0421KD200
Engine	3810492-00
SHOP MANUAL:	
Chassis	CEBMW21020
Engine:	
Shop Manual	3379347
Alternative Repair Manual	3810310
Trouble Shooting & Repair	3810246
SAFETY MANUAL	1085 883 R3

PARTS AND SERVICE PUBLICATIONS CAN ONLY BE ACQUIRED BY AUTHORIZED KOMATSU DISTRIBUTORS, USING THE KDC PARTS INVENTORY PROCESSING SYSTEM (PIPS).

IF THE PIPS SYSTEM IS NOT AVAILABLE AT THE DISTRIBUTOR LOCATION, THEN THE FOLLOWING REQUISITION FOR LITERATURE FORM CAN BE USED: FORM KDC-EPS-05, SHOWN ON THE REVERSE SIDE OF THIS PAGE.

CONTENTS

No. of page

10 ENGINE

12 TESTING AND ADJUSTING	12-1
13 DISASSEMBLY AND ASSEMBLY	13-1
14 MAINTENANCE STANDARD	14-1

20 POWER TRAIN

21 STRUCTURE AND FUNCTION	21-1
22 TESTING AND ADJUSTING	22-1
23 DISASSEMBLY AND ASSEMBLY	23-1
24 MAINTENANCE STANDARD	24-1

40 STEERING SYSTEM

41 STRUCTURE AND FUNCTION	41-1
42 TESTING AND ADJUSTING	42-1
43 DISASSEMBLY AND ASSEMBLY	43-1
44 MAINTENANCE STANDARD	44-1

50 BRAKE AND AIR SYSTEM

51 STRUCTURE AND FUNCTION	51-1
52 TESTING AND ADJUSTING	52-1
53 DISASSEMBLY AND ASSEMBLY	53-1
54 MAINTENANCE STANDARD	54-1

60 WORK EQUIPMENT SYSTEM

61 STRUCTURE AND FUNCTION	61-1
62 TESTING AND ADJUSTING	62-1
63 DISASSEMBLY AND ASSEMBLY	63-1
64 MAINTENANCE STANDARD	64-1

80 ELECTRIC AND ELECTRONIC SYSTEM

81 STRUCTURE AND FUNCTION	81-1
82 TESTING AND ADJUSTING	82-1
83 DISASSEMBLY AND ASSEMBLY	83-1

90 OTHERS

91 LOGGING SPECIFICATIONS	91-1
93 DISASSEMBLY AND ASSEMBLY	93-1
97 GEAR PUMP	97-1
99 METRIC CONVERSION TABLE	99-1



WARNING! IMPORTANT SAFETY NOTICE

Proper service and repair is extremely important for the safe operation of your machine. The service and repair techniques recommended and described in this manual are both effective and safe methods of operation. Some of these operations require the use of tools specially designed for the purpose.

To prevent injury to workers, the symbol shown is used to mark safety precautions in this manual. The cautions accompanying these symbols should always be followed carefully. If any dangerous situation arises or may possibly arise, first consider safety, and take the necessary actions to deal with the situation.



SAFETY

GENERAL PRECAUTIONS

Mistakes in operation are extremely dangerous. Read the Operation and Maintenance Manual carefully BEFORE operating the machine.

1. Before carrying out any greasing or repairs, read all the precautions given on the decals which are fixed to the machine.
2. When carrying out any operation, always wear safety shoes and helmet. Do not wear loose work clothes, or clothes with buttons missing.
-Always wear safety glasses when hitting parts with a hammer.
-Always wear safety glasses when grinding parts with a grinder, etc.
3. If welding repairs are needed, always have a trained, experienced welder carry out the work. When carrying out welding work, always wear welding gloves, apron, glasses, cap and other clothes suited for welding work.
4. When carrying out any operation with two or more workers, always agree on the operating procedure before starting. Always inform your fellow workers before starting any step of the operation. Before starting work, hang UNDER REPAIR signs on the controls in the operator's compartment.
5. Keep all tools in good condition and learn the correct way to use them.
6. Decide a place in the repair workshop to keep tools and removed parts. Always keep the tools and parts in their correct places. Always keep the work area clean and make sure that there is no dirt or oil on the floor.

Smoke only in the areas provided for smoking. Never smoke while working.

PREPARATIONS FOR WORK

7. Before adding oil or making repairs, park the machine on hard, level ground, and block the wheels or tracks to prevent the machine from moving.
8. Before starting work, lower blade, ripper, bucket or any other work equipment to the ground. If this is not possible, insert the safety pin or use blocks to prevent the work equipment from falling. In addition, be sure to lock all the control levers and hang warning signs on them.
9. When disassembling or assembling, support the machine with blocks, jacks or stands before starting work.
10. Remove all mud and oil from the steps or other places used to get on and off the machine. Always use the handrails, ladders or steps when getting on or off the machine. Never jump on or off the machine. If it is impossible to use the handrails, ladders or steps, use a stand to provide safe footing.

PRECAUTIONS DURING WORK

11. When removing the oil filler cap, drain plug or hydraulic pressure measuring plugs, loosen them slowly to prevent the oil from spurting out. Before disconnecting or removing components of the oil, water or air circuits, first remove the pressure completely from the circuit.

SAFETY

12. The water and oil in the circuits are hot when the engine is stopped, so be careful not to get burned. Wait for the oil and water to cool before carrying out any work on the oil or water circuits.

13. Before starting work, remove the leads from the battery. Always remove the lead from the negative (-) terminal first.

14. When raising heavy components, use a hoist or crane.

Check that the wire rope, chains and hooks are free from damage.

Always use lifting equipment which has ample capacity.

Install the lifting equipment at the correct places. Use a hoist or crane and operate slowly to prevent the component from hitting any other part. Do not work with any part still raised by the hoist or crane.

15. When removing covers which are under internal pressure or under pressure from a spring, always leave two bolts in position on opposite sides. Slowly release the pressure, then slowly loosen the bolts to remove.

16. When removing components, be careful not to break or damage the wiring. Damaged wiring may cause electrical fires.

17. When removing piping, stop the fuel or oil from spilling out. If any fuel or oil drips on to the floor, wipe it up immediately. Fuel or oil on the floor can cause you to slip, or can even start fires.

18. As a general rule, do not use gasoline to wash parts. In particular, use only the minimum of gasoline when washing electrical parts.

19. Be sure to assemble all parts again in their original places.

Replace any damaged part with new parts.

- When installing hoses and wires, be sure that they will not be damaged by contact with other parts when the machine is being operated.

20. When installing high pressure hoses, make sure that they are not twisted. Damaged tubes are dangerous, so be extremely careful when installing tubes for high pressure circuits. Also check that connecting parts are correctly installed.

21. When assembling or installing parts, always use the specified tightening torques. When installing protective parts such as guards, or parts which vibrate violently or rotate at high speed, be particularly careful to check that they are installed correctly.

22. When aligning two holes, never insert your fingers or hand. Be careful not to get your fingers caught in a hole.

23. When measuring hydraulic pressure, check that the measuring tool is correctly assembled before taking any measurements.

24. Take care when removing or installing the tracks of track-type machines.

When removing the track, the track separates suddenly, so never let anyone stand at either end of the track.

FOREWORD

This shop manual has been prepared as an aid to improve the quality of repairs by giving the serviceman an accurate understanding of the product and by showing him the correct way to perform repairs and make judgements. Make sure you understand the contents of this manual and use it to full effect at every opportunity.

This shop manual mainly contains the necessary technical information for operations performed in a service workshop.

For ease of understanding, the manual is divided into chapters for each main group of components; these chapters are further divided into the following sections.

STRUCTURE AND FUNCTION

This section explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting.

TESTING AND ADJUSTING

This section explains checks to be made before and after performing repairs, as well as adjustments to be made at completion of the checks and repairs. Troubleshooting charts correlating "Problems" to "Causes" are also included in this section.

DISASSEMBLY AND ASSEMBLY

This section explains the order to be followed when removing, installing, disassembling or assembling each component, as well as precautions to be taken for these operations.

MAINTENANCE STANDARD

This section gives the judgement standards when inspecting disassembled parts.

NOTICE

The specifications contained in this shop manual are subject to change at any time and without any advance notice. Contact your distributor for the latest information.

HOW TO READ THE SHOP MANUAL

VOLUMES

Shop manuals are issued as a guide to carrying out repairs. They are divided as follows:

Chassis volume: Issued for every machine model
Engine volume: Issued for every engine series

These various volumes are designed to avoid duplication the same information. Therefore to deal with all repairs for any model, it is necessary that chassis and engine volumes are ready.


DISTRIBUTION AND UPDATING

Any additions, amendments or other changes will be sent to your distributors. Get the most up-to-date information before you start any work.


FILING METHOD

1. See the page number on the bottom of the page. File the pages in correct order.
2. Following examples show how to read the page number:

Example 1 (Chassis volume):



Example 2 (Engine volume):



3. Additional pages: Additional pages are indicated by a hyphen (-) and numbered after the page number.

File as in the example.
 Example:

21-4		12-203
21-4-1	Added pages	12-203-1
21-4-2		12-203-2
21-5		12-204

REVISED EDITION MARK ([1] [2] [3])

When a manual is revised, an edition mark is recorded on the bottom outside corner of the pages.

REVISIONS





Revised pages are shown at the LIST OF REVISED PAGES on the between the title page and SAFETY page.

SYMBOLS

So that the shop manual can be of ample practical use, important places for safety and quality are marked with the following symbols.

Symbol	Item	Remarks
	Safety	Special safety precautions are necessary when performing the work.
		Extra special safety precautions are necessary when performing the work because it is under internal pressure.
★	Caution	Special technical precautions or other precautions for preserving standards are necessary when performing the work.
	Weight	Weight of parts or systems. Caution necessary when selecting hoisting wire or when working posture is important, etc.


HOW TO READ THE SHOP MANUAL

Symbol	Item	Remarks
	Torque	Places that require special attention for tightening the torque during assembly.
	Coat	Places to be coated with adhesives and lubricants etc.
	oil water	Places where oil, water or fuel must be added, and the capacity.
	Drain	Places where oil or water must be drained, and quantity to be drained.



HOISTING INSTRUCTIONS



Heavy parts (25 kg or more) must be lifted with a hoist etc. In the **Disassembly and Assembly** section, every part weighing 25 kg or more is indicated clearly with the symbol 

1. If a part cannot be smoothly removed from the machine by hoisting, the following checks should be made:

- Check for removal of all bolts fastening the part to the relative parts.
- Check for existence of another part causing interface with the part to be removed.

2. Wire ropes

1) Use adequate ropes depending on the weight of parts to be hoisted, referring to the table below:

Wire ropes
(Standard "Z" or "S" twist ropes without galvanizing)


Rope diameter (mm)	Allowable load (tons)
10	1.0
11.2	1.4
12.5	1.6
14	2.2
16	2.8
18	3.6
20	4.4
22.4	5.6
30	10.0
40	18.0
50	28.0
60	40.0

The allowable load value is estimated to be one-sixth or one-seventh of the breaking strength of the rope used.

2) Sling wire ropes from the middle portion of the hook.

Slinging near the edge of the hook may cause

the rope to slip off the hook during hoisting, and a serious accident can result. Hooks have maximum strength at the middle portion.



FS0064

3) Do not sling a heavy load with one rope alone, but sling with two or more ropes symmetrically wound on to the load.




Slinging with one rope may cause turning of the load during hoisting, untwisting of the rope, or slipping of the rope from its original winding position on the load, which can result in a dangerous accident.

4) Do not sling a heavy load with ropes forming a wide hanging angle from the hook.

When hoisting a load with two or more ropes, the force subjected to each rope will increase with the hanging angles. The table below shows the variation of allowable load (kg) when hoisting is made with two ropes, each of which is allowed to sling up to 1000 kg vertically, at various hanging angles.

When two ropes sling a load vertically, up to 2000 kg of total weight can be suspended. This weight becomes 1000 kg when two ropes make a 120° hanging angle. On the other hand, two ropes are subject to an excessive force as large as 4000 kg if they sling a 2000 kg load at a lifting angle of 150°.



FS0065



STANDARD TIGHTENING TORQUE

STANDARD TIGHTENING TORQUE



1. STANDARD TIGHTENING TORQUE OF BOLTS AND NUTS.

The following charts give the standard tightening torques of bolts and nuts. Exceptions are given in sections of "Disassembly and Assembly".

Thread diameter of bolt (mm)	Width across flat (mm)		
		kgm	Nm
6	10	1.35±0.15	13.2±1.4
8	13	3.2±0.3	31.4±2.9
10	17	6.7±0.7	65.7±6.8
12	19	11.5±1.0	112±9.8
14	22	18.0±2.0	177±19
16	24	28.5±3	279±29
18	27	39±4	383±39
20	30	56±6	549±58
22	32	76±8	745±78
24	36	94.5±10	927±98
27	41	135±15	1320±140
30	46	175±20	1720±190
33	50	225±25	2210±240
36	55	280±30	2750±290
39	60	335±35	3280±340

This torque table does not apply to the bolts with which nylon packings or other non-ferrous metal washers are to be used, or which require tightening to otherwise specified torque.

★ Nm (newton meter): 1Nm ≈ 0.1 kgm

STANDARD TIGHTENING TORQUE




2. TIGHTENING TORQUE OF SPLIT FLANGE BOLTS

Use these torques for split flange bolts.

Thread diameter of bolt (mm)	Width across flats (mm)	Tightening torque	
		kgm	Nm
10	14	6.7±0.7	65.7±6.8
12	17	11.5±1	112±9.8
16	22	28.5±3	279±29

3. TIGHTENING TORQUE FOR NUTS OF FLARED

Use these torques for nut part of flared.



FS0068

Thread diameter of nut part (mm)	Width across flats of nut part (mm)	Tightening torque	
		kgm	Nm
14	19	2.5±0.5	24.5±4.9
18	24	5±2	49±19.6
22	27	8±2	78.5±19.6
24	32	14±3	137.3±29.4
30	36	18±3	176.5±29.4
33	41	20±5	196.1±49
36	46	25±5	245.2±49
42	55	30±5	294.2±49



COATING MATERIALS

The recommended coating materials prescribed in the shop manuals are listed below.

Nomenclature	Code	Applications
Adhesives	LT-1A	Used to apply rubber pads, rubber gaskets, and cork plugs.
	LT-1B	Used to apply resin, rubber, metallic and non-metallic parts when a fast, strong seal is needed.
	LT-2 ^o	Preventing bolts, nuts, and plugs from loosening and leaking oil.
	LT-3	Provides an airtight, electrically insulating seal. Used for aluminum surfaces.
Liquid gasket	LG-1	Used with gaskets and packings to increase sealing effect.
	LG-3	Heat-resistant gasket for precombustion chambers and exhaust piping.
	LG-4	Used by itself on mounting surfaces on the final drive and transmission cases. (Thickness after tightening: 0.07 - 0.08 mm).
	LG-5	Used by itself to seal grease fittings, tapered screw fittings and tapered screw fittings in hydraulic circuits of less than 50 mm in diameter.
Antifriction compound (Lubricant including molybdenum disulfide)	LM-P	Applied to bearings and taper shafts to facilitate press-fitting and to prevent sticking, burning or rusting.
Grease (Lithium grease)	G2-LI	Applied to bearings, sliding parts and oils seals for lubrication, rust prevention and facilitation of assembling work.
Vaseline	---	Used for protecting battery electrode terminals from corrosion.

•LT-2 is also called **LOCTITE** in the shop manuals.

ELECTRIC WIRE CODE

In the wiring diagrams, various colors and symbols are employed to indicate the thickness of wires. This wire code table will help you understand WIRING DIAGRAMS.

Example: 05WB indicates a cable having a nominal number 05 and white coating with black stripe.

CLASSIFICATION BY THICKNESS

Nominal number	Copper wire			Cable O.D. (mm)	Current rating (A)	Applicable circuit
	Number strands	Dia. of strands (mm)	Cross section (mm ²)			
0.85 (01)*	11	0.32	0.88	2.4	12	Starting, lighting, signal etc.
2 (02)*	26	0.32	2.09	3.1	20	Lighting, signal etc.
5 (05)*	65	0.32	5.23	4.6	37	Charging and signal
15	84	0.45	13.36	7.0	59	Starting (Glow plug)
40	85	0.80	42.73	11.4	135	Starting
60	127	0.80	63.84	13.6	178	Starting
100	217	0.80	109.1	17.6	230	Starting

* Old numbers

ELECTRIC WIRE CODE

CLASSIFICATION BY COLOR AND CODE

Priority	Classification	Circuits	Starting	Charging	Lighting	Signal	Instru- ment	Other
1	Primary	Code	B	W	R	G	Y	L
		Color	Black	White	Red	Green	Yellow	Blue
2	Auxiliary	Code	BW	WR	RW	GW	YR	LW
		Color	Black & White	White & Red	Red & White	Green & White	Yellow & Red	Blue & White
3		Code	BY	WB	RB	GR	YB	LR
		Color	Black & Yellow	White & Black	Red & Black	Green & Red	Yellow & Black	Blue & Red
4		Code	BR	WL	RY	GY	YG	LY
		Color	Black & Red	White & Blue	Red & Yellow	Green & Yellow	Yellow & Green	Blue & Yellow
5		Code	--	WY	RG	GB	YL	LB
		Color	--	White & Yellow	Red & Green	Green & Black	Yellow & Blue	Blue & Black
6		Code	--	WG	RL	GL	YW	
		Color	--	White & Green	Red & Blue	Green & Blue	Yellow & White	

WEIGHT TABLE



This weight table is a guide for use when transporting or handling components.

Unit: kg

Engine assembly	1,045
Radiator assembly	165
Torque converter assembly	195
Transmission assembly	770
Damper	65
Upper drive shaft	15
Center drive shaft	30
Front drive shaft	45
Rear drive shaft	30
Front axle assembly	1,492
Rear axle assembly	1,535
Front differential assembly	255
Rear differential assembly	235
Planetary carrier assembly (1 piece)	90
Planetary hub assembly (1 piece)	60
Axle pivot (Rear axle)	105
Wheel (1 piece)	215
Tire (1 piece)	335
Steering valve	25
Steering cylinder (1 piece)	38
Brake (1 piece)	128
Hydraulic tank	314
Hydraulic pump	20
Switch • PPC pump	13
Steering pump	13
PPC valve	3.5
Main control valve	90
Lift cylinder (1 piece)	195
Dump cylinder	220
Engine hood	81
Front frame	1,749
Rear frame	1,423
Bucket link	80
Tilt lever	440
Lift arm (with bushing)	1,375
Bucket (with teeth)	1,840
Counterweight	1,550
Fuel tank	265
Battery (1 piece)	47
Operator's seat	40
Floor frame	99

TABLE OF QUANTITIES

FUEL, COOLANT AND LUBRICANTS

PROPER SELECTION OF FUEL, COOLANT AND LUBRICANTS

Reservoir	Kind of Fluid	Ambient Temperature									Capacity	
		-32	-4	14	32	50	68	86	104	122°F	Specified	Refill
		-30	-20	-10	0	10	20	30	40	50°C		
Engine oil pan	Engine oil (See NOTE 1 and 2)	<p style="text-align: center;">← SAE 20W-40, 20W-50 →</p> <p style="text-align: center;">← SAE 15W-40 →</p> <p style="text-align: center;">← SAE 10W-30 →</p> <p style="text-align: center;">← SAE 5W-20, 5W-30 → (See NOTE (1-1))</p>									40	32
Transmission case (1)	Engine oil (See NOTE (3))	← SAE 10W →									61	59
Hydraulic system (2)		← SAE 10W →									230	148
Axle (Front and rear) (3)		See NOTE (4)									each 65	each 65
Fuel tank	Diesel fuel	See NOTE (5)									383	--
Cooling system	Coolant	See NOTE (6)									55	--

- (1) Includes torque converter, transfer and cooler
- (2) Includes brake system
- (3) Includes differential and planetary gear case

ASTM: American Society of Testing and Material
 SAE: Society of Automotive Engineers
 API: American Petroleum Institute

Specified capacity: Total amount of oil including oil for components and oil in piping.
 Refill capacity: Amount of oil needed to refill system during normal inspection and maintenance.

NOTE

(1) The use of quality engine lubricating oils combined with appropriate oil drain and filter change intervals is a critical factor in maintaining engine performance and durability.

Cummins Engine Company, Inc. recommends the use of a high quality SAE 15W-40 heavy duty engine oil (such as Cummins Premium Blue) which meets the American Petroleum Institute (API)

TABLE OF QUANTITIES

performance classification CE.

- * CC/CD or CD/SF engine oils can be used in areas where CE oil is not yet available.

A sulfated ash limit of 1.0 mass percent is suggested for optimum valve and piston deposit and oil consumption control. The sulfated ash **must not exceed 1.85 mass percent.**

For further details and discussion of engine lubricating oils Cummins engines, refer to Bulletin No. 3810340, Cummins Engine Oil Recommendations.

The API service symbols are shown in the accompanying illustration. The upper half of the symbol displays the appropriate oil categories; the lower half may contain words to describe oil energy conserving features. The center section identifies the SAE oil viscosity grade.

- * Alternate Oil Grades

SAE10W -20°C to 10°C [-4°F to 50°F]
 SAE30W 4°C and above [39°F and above]
 SAE20W -10°C to 25°C [14°F to 77°F]
 SAE40W 10°C and above [50°F and above]

- * The use of low viscosity oils, such as 10W or 10W-30, can be used to aid in starting the engine and in providing sufficient oil flow at ambient temperatures below -5°C [23°F]. Continuous use of low viscosity oils can decrease engine life due to wear.

- (1-1) These oils are available commercially with better low temperature properties. Consult your supplier.

- (2) If an engine is operated in ambient temperatures consistently below -23°C [-10°F] and there are no provisions to keep the engine warm when it is not in operation, use a synthetic CE/SF engine oil with adequate low temperature properties such as 5W-20 or 5W-30.

The oil supplier **must** be responsible for meeting the performance service specifications.

- * The use of a synthetic base oil does not justify extended oil change intervals. Extended oil change intervals can decrease engine life due to factors such as corrosion, deposits, and wear.

Special "break-in"; engine lubricating oils are not recommended for new or rebuilt Cummins engines. Use the same type oil during the "break-in" as that which is used in normal operation.

- * A sulfated ash limit of 1.85 percent has been placed on all engine lubricating oils recommended for use in Cummins engines. Higher ash oils can cause

valve and/or piston damage and lead to excessive oil consumption.

Additional information regarding lubricating oil availability throughout the world is available in the E.M.A. Lubricating Oils Data Book for Heavy Duty Automotive and Industrial Engines. The data book may be ordered from the Engine Manufacturers Association, One Illinois Center, 111 East Wacker Drive, Chicago, IL U.S.A. 60601. The telephone number is: (312) 644-6610.

- (3) Use API classification CD as engine oil and if API classification CC, reduce the engine oil change interval to half.
- (4) For axle oil, use only recommended oil as follows.

SHELL:	DONAX TT OT TD
CALTEX:	RPM TRACTOR HYDRAULIC FLUID
CHEVRON:	TRACTOR HYDRAULIC FLUID
TEXACO:	TDH OIL
MOBIL:	MOBIL AND SUPER UNIVERSAL

- * It is possible to substitute engine oil CLASS-CD SAE30 for axle oil. If noise comes from the brake, it is no problem of durability.

- (5) Cummins recommends the use of ASTM No. 2D fuel. The use of No. 2 diesel fuel will result in optimum engine performance. At operating temperatures below 0°C [32°F], acceptable performance can be obtained by using blends of No. 2 D and No. 1 D. the use of lighter fuels can reduce fuel economy.

The viscosity of the fuel **must** be kept above 1.3 Cst to provide adequate fuel system lubrication.

For a more detailed description of fuel properties, refer to Fuel For Cummins Engines, Bulletin No. 3379001.



WARNING! Do not mix gasoline or alcohol with diesel fuel. This mixture can cause an explosion.

- (6) Heavy duty diesel engines require a balanced coolant mixture of water, antifreeze, and supplemental coolant additives (supplemental coolant additive recommendations are included in the Section). Drain and replace the mixture every 2 years, 6,000 hours of operation, whichever occurs first.

- DCA4 is recommended for use in all Cummins engines.
- In climates where the temperature is above

TABLE OF QUANTITIES

-37°C [-34°F], use a coolant mixture that contains 50 percent antifreeze. **Antifreeze is essential in any climate.** It broadens the operating temperature range by lowering the coolant freezing point and by raising its boiling point. Do **not** use more than 50 percent antifreeze in the mixture unless additional freeze protection is required. **Never** use more than 68 percent antifreeze under any condition.

- Use low silicate antifreeze which meets Engineering Standard GM 6038-M or which contains no more than 0.1 percent anhydrous alkali metasilicate and meets either Engineering Standard 1828-M or GM 1899-M which are performance specifications.
- Use soft water in the coolant mixture. Contaminants in hard water neutralize the corrosion inhibitor components. Water **must not** exceed 300 ppm hardness or contain more than 100 ppm chloride or sulfate.
- Maintain supplemental coolant additive levels at 1 unit DCA4 per 3.8 liters [1 U.S. gallon] of coolant.