

SHOP MANUAL



PW95-1

HYDRAULIC EXCAVATOR

SERIAL NUMBER

0000007 and up

KOMATSU

CONTENTS

	No. of page
10 STRUCTURE AND FUNCTION	10-1
20 TESTING AND ADJUSTING.....	20-1
30 DISASSEMBLY AND ASSEMBLY.....	30-1
40 MAINTENANCE STANDARD	40-1

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to table below.

Mark	Indication	Action required
○	Page to be newly	Add
●	Page to be replaced	Replace
()	Page to be delete	Discard

Pages having no marks are those previously revised or made additions.



LIST OF REVISED PAGES

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
	00-1			10-26			20-1			20-41			20-81	
	00-2			10-27			20-2			20-42			20-82	
	00-2-1			10-28			20-3			20-43			20-83	
	00-2-2			10-29			20-4			20-44			20-84	
	00-3			10-30			20-5			20-45			20-85	
	00-4			10-31			20-6			20-46			20-86	
	00-5			10-32			20-7			20-47			20-87	
	00-6			10-33			20-8			20-48			20-88	
	00-7			10-34			20-9			20-49			20-89	
	00-8			10-35			20-10			20-50			20-90	
	00-9			10-36			20-11			20-51			20-91	
	00-10			10-37			20-12			20-52			20-92	
	00-11			10-38			20-13			20-53			20-93	
	00-12			10-39			20-14			20-54			20-94	
				10-40			20-15			20-55			20-95	
	10-1			10-41			20-16			20-56			20-96	
	10-2			10-42			20-17			20-57			20-97	
	10-3			10-43			20-18			20-58			20-98	
	10-4			10-44			20-19			20-59			20-99	
	10-5			10-45			20-20			20-60			20-100	
	10-6			10-46			20-21			20-61			20-101	
	10-7			10-47			20-22			20-62			20-102	
	10-8			10-48			20-23			20-63			20-103	
	10-9			10-49			20-24			20-64			20-104	
	10-10			10-50			20-25			20-65			20-105	
	10-11			10-51			20-26			20-66			20-106	
	10-12			10-52			20-27			20-67			20-107	
	10-13			10-53			20-28			20-68			20-108	
	10-14			10-54			20-29			20-69			20-109	
	10-15			10-55			20-30			20-70			20-110	
	10-16			10-56			20-31			20-71			20-111	
	10-17			10-57			20-32			20-72			20-112	
	10-18			10-59			20-33			20-73			20-113	
	10-19			10-61			20-34			20-74			20-114	
	10-20			10-63			20-35			20-75			20-115	
	10-21			10-65			20-36			20-76			20-116	
	10-22			10-67			20-37			20-77			20-117	
	10-23			10-69			20-38			20-78			20-118	
	10-24			10-71			20-39			20-79			20-119	
	10-25						20-40			20-80			20-120	

Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision	Mark	Page	Time of revision
	20-121			30-47			30-103			30-159				
	20-122			30-48			30-104			30-160				
	20-123			30-49			30-105			30-161				
	20-124			30-50			30-106			30-162				
	20-125			30-51			30-107			30-163				
	20-126			30-52			30-108			30-164				
	20-127			30-53			30-109			30-165				
	20-128			30-54			30-110			30-166				
	20-129			30-55			30-111			30-167				
				30-56			30-112			30-168				
	30-1			30-57			30-113			30-169				
	30-2			30-58			30-114			30-170				
	30-3			30-59			30-115			30-171				
	30-4			30-60			30-116			30-172				
	30-5			30-61			30-117			30-173				
	30-6			30-62			30-118			30-174				
	30-7			30-63			30-119			30-175				
	30-8			30-64			30-120			30-176				
	30-9			30-65			30-121			30-177				
	30-10			30-66			30-122			30-178				
	30-11			30-67			30-123			30-179				
	30-12			30-68			30-124							
	30-13			30-69			30-125			40-1				
	30-14			30-70			30-126			40-3				
	30-15			30-71			30-127			40-4				
	30-16			30-72			30-128			40-5				
	30-17			30-73			30-129			40-6				
	30-18			30-74			30-130			40-7				
	30-19			30-75			30-131			40-8				
	30-20			30-76			30-132			40-9				
	30-21			30-77			30-133			40-10				
	30-22			30-78			30-134			40-11				
	30-23			30-79			30-135			40-12				
	30-24			30-80			30-136			40-13				
	30-25			30-81			30-137			40-14				
	30-26			30-82			30-138			40-15				
	30-27			30-83			30-139			40-16				
	30-28			30-84			30-140			40-17				
	30-29			30-85			30-141			40-18				
	30-30			30-86			30-142			40-19				
	30-31			30-87			30-143			40-20				
	30-32			30-88			30-144			40-21				
	30-33			30-89			30-145			40-22				
	30-34			30-90			30-146			40-23				
	30-35			30-91			30-147			40-24				
	30-36			30-92			30-148			40-25				
	30-37			30-93			30-149			40-26				
	30-38			30-94			30-150			40-27				
	30-39			30-95			30-151			40-28				
	30-40			30-96			30-152			40-29				
	30-41			30-97			30-153			40-30				
	30-42			30-98			30-154			40-31				
	30-43			30-99			30-155			40-32				
	30-44			30-100			30-156			40-33				
	30-45			30-101			30-157							
	30-46			30-102			30-158							

IMPORTANT SAFETY NOTICE

Proper service and repair is extremely important for the safe operation of your machine. The service and repair techniques recommended by FKI and describe in this manual are both effective and safe methods of operation. Some of these operations require the use of tools specially designed by FKI for the purpose.

To prevent injury to workers, the symbols  and  are used to mark safety precautions in this manual. The cautions accompanying these symbols should always be carefully followed. If any danger arises or may possibly arise, first consider safety, and take necessary steps to face.

SAFETY

GENERAL PRECAUTIONS

Mistakes in operation extremely dangerous. Read all the Operation and Maintenance Manual carefully **BEFORE** operating the machine.

1. Before carrying out any greasing or repairs, read all the precautions written on the decals which are stuck on the machine.
2. When carrying out any operation, always wear safety shoes and helmet. Do not wear loose work clothes, or clothes with buttons missing.
 - Always wear safety glasses when hitting parts with a hammer.
 - Always wear safety glasses when grinding parts with a grinder, etc.
3. If welding repairs are needed, always have a trained, experienced welder carry out the work. When carrying out welding work, always wear welding gloves, apron, glasses, cap and other clothes suited for welding work.
4. When carrying out any operation with two or more workers, always agree on the operating procedure before starting. Always inform your fellow workers before starting any step of the operation. Before starting work, hang **UNDER REPAIR** signs on the controls in the operator's compartment.
5. Keep all tools in good condition and learn the correct way to use them.
6. Decide a place in the repair workshop to keep tools and removed parts. Always keep the tools and parts in their correct places. Always keep the work area clean and make sure that there is no dirt or oil on the floor. Smoke only in the areas provided for smoking. Never smoke while working.

PREPARATIONS FOR WORK

7. Before adding or making any repairs, park the machine on hard, level ground, and block the wheels to prevent the machine from moving.
8. Before starting work, lower ourigger, bucket or any other work equipment to the ground. If this is not possible, use blocks to prevent the work equipment from falling down. In addition, be sure to lock all the control levers and hang warning sign on them.
9. When disassembling or assembling, support the machine with blocks, jacks or stands before starting work.
10. Remove all mud and oil from the steps or other places used to get on and off the machine. Always use the handrails, ladders or steps when getting on or off the machine. Never jump on or off the machine. If it is impossible to use the handrails, ladders or steps, use a stand to provide safe footing.

PRECAUTIONS DURING WORK

11. When removing the oil filler cap, drain plug or hydraulic pressure measuring plugs, loosen them slowly to prevent the oil from spurting out. Before disconnecting or removing components of the hydraulic circuit and engine cooling circuit, first remove the pressure completely from the circuit.
12. The water and oil in the circuits are not hot when the engine is stopped, so be careful not to get burned. Wait for the oil water to cool before carrying out any work on the cooling water circuits.

13. Before starting work, remove the leads from the battery. Always remove the lead from the negative (-) terminal first.
14. When raising heavy components, use a hoist or crane. Check that the wire rope, chains and hooks are free from damage.
Always use lifting equipment which has ample capacity. Install the lifting equipment at the correct places.
Use a hoist or crane and operate slowly to prevent the component from hitting any other part.
Do not work with any part still raised by the hoist or crane.
15. When removing covers which are under internal pressure or under pressure from a spring, always leave two bolts in position on opposite sides. Slowly release the pressure, then slowly loosen the bolts to remove.
16. When removing components, be careful not to break or damage the wiring.
Damage wiring may cause electrical fires.
17. When removing piping, stop the fuel or oil from spilling out. If any fuel or oil drips on to the floor, wipe it up immediately.
Fuel or oil on the floor can cause you to slip, or can even start fires.
18. As a general rule, do not use gasoline to wash parts. In particular, use only the minimum of gasoline when washing electrical parts.
19. Be sure to assemble all parts again in their original places. Replace any damage parts with new parts.
 - When installing hoses and wires, be sure that they will not be damaged by contact with other parts when the machine is being operated.
20. When installing high pressure hoses, make sure that they are not twisted. Damaged tubes are dangerous, so be extremely careful when installing tubes for high pressure circuits. Also, check that connecting parts are correctly tightened.
21. When assembling or installing parts, always use specified tightening torques.
When installing the parts which vibrate violently or rotate at high speed, be particularly careful to check that they are correctly installed.
22. When aligning two holes, never insert your fingers or hand.
23. When measuring hydraulic pressure, check that the measuring tool is correctly assembled before taking any measurement.
24. Take care when removing or installing tracks of in particular rubber tracks. When removing the track, the track separates suddenly, so never let anyone stand at either end of the wheel.

FOREWORD

This shop manual has been prepared as an aid to improve the quality of repairs by giving the operator an accurate understanding of the product and by showing him the correct way to perform repairs and make judgements. Make sure you understand the contents of this manual and use it to full effect at every opportunity.

This shop manual mainly contains the necessary technical information for operations performed in a service workshop.

The manual is divided into chapters on each main group of components; these chapters are further divided into the following sections.

STRUCTURE AND FUNCTION

This section explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting.

TESTING AND ADJUSTING

This section explains checks to be made before and after performing repairs, as well as adjustments to be made at completion of the checks and repairs.

Troubleshooting charts correlating «Problems» to «Causes» are also included in this section.

DISASSEMBLY AND ASSEMBLY

This section explains the order to be followed when removing, installing, disassembling or assembling each component, as well as precautions to be taken for these operations.

MAINTENANCE STANDARD

This section gives the judgement standards when inspecting disassembled parts.

NOTICE

The specifications contained in this shop manual are subject to change at any time and without any notice.

Contact your FKI distributor for the latest information.

HOW TO READ THE SHOP MANUAL

VOLUMES

Shop manual are issued as a guide to carry out repairs. These various volumes are designed to avoid duplicating the same information.

DISTRIBUTION AND UPDATING

Any additions, amendments or other changes will be sent to FKI distributors. Get the most up-to-date information before you start any work.

FILING METHOD

1. See the page number on the bottom of the page. File the pages in correct order.
2. Following examples show you how to read the page number.

Example

10 - 3

Numero dell'articolo (10. Struttura e funzionamento)

Numero di pagina progressivo per ogni articolo

3. Additional pages: additional pages are indicated by a hyphen (-) and number after the page number.

File as in the example.

Example:

10-4

10-4-1

10-4-2] Added pages

10-5

REVISED EDITION MARK

(① ② ③)









When a manual is revised, an edition mark is recorded on the bottom outside corner of the pages.

REVISIONS


Revised pages are shown on the LIST OF REVISED PAGES between the title page and SAFETY page.

SYMBOLS

In order to make the shop manual greatly helpful, important points about safety and quality are marked with the following symbols.

Symbol	Item	Remarks
	Safety	Special safety precautions are necessary when performing the work.
		Extra special safety precautions are necessary when performing the work because it is under internal pressure.
	Caution	Special technical precautions or other precautions for preserving standards are necessary when performing the work.
	Weight	Weight of parts or systems. Caution necessary when selecting hoisting wire, or when working posture is important, etc.
	Tightening torque	Parts that require special attention for the tightening torque during assembly.
	Coat	Parts to be coated with adhesives and lubricants etc.
	Oil, water	Places where oil, water or fuel must be added, and their quantity.
	Drain	Places where oil or water must be drained, and quantity to be drained.

HOISTING INSTRUCTIONS



⚠ Heavy parts (25 kg or more) must be lifted with a hoist etc. In the **Disassembly and Assembly** section, every part weighing 25 kg or more is clearly indicated with the symbol kg

1. If a part cannot be smoothly removed from the machine by hoisting, the following checks should be made:
 - Check for removal of all bolts fastening the part to the relative parts.
 - Check for any part causing interference with the part to be removed.

2. Wire ropes


- 1) Use adequate ropes depending on the weight of parts to be hoisted, referring to the table below:

WIRE ROPES (Standard «S» or «Z» twist ropes without galvanizing)	
Rope diameter (mm)	Allowable load (tons)
10	1.0
11.2	1.4
12.5	1.6
14	2.2
16	2.8
18	3.6
20	4.4
22.4	5.6
30	10.0
40	18.0
50	28.0
60	40.0

The allowable load value is estimated to be one-sixth or one-seventh of the breaking strength of the rope used.

- 2) Sling wire ropes from the middle portion of the hook. Slinging near the edge of the hook may cause the rope to slip off the hook during hoist-

ing, and a serious accident can result. Hooks have maximum strenght at the middle portion.



- 3) Do not sling a heavy load with one rope alone, but sling with two or more ropes symmetrically wound on to the load.

⚠ Slinging with one rope may cause turning of the load during hoisting, untwisting of the rope, or slipping of the rope from its original winding position on the load, which can cause dangerous accidents.

- 4) Do not sling a heavy load with ropes forming a wide hanging angle from the hook.


When hoisting a load with two or more ropes, the force subjected to each rope will increase with the hanging angles.

The table below shows the variation of allowable load (kg) when hoisting is made with two ropes, each of which is allowed to sling up to 1000 kg vertically, at various hanging angles.

When two ropes sling a load vertically, up to 2000 kg of total weight can be suspended.

This weight becomes 1000 kg when two ropes make a 120° hanging angle.

On the other hand, two ropes are subjected to an excessive force as large as 4000 kg if they sling a 2000 kg load at a lifting angle of 150°.





STANDARD TIGHTENING TORQUE



STANDARD TIGHTENING TORQUE

The following charts give the standard tightening torques of bolts and nuts. Exceptions are given in sections of «Dis-assembly and Assembly».


1. STANDARD TIGHTENING TORQUE OF BOLTS AND NUT

Thread diameter of bolts (mm)	Pitch of bolts (mm)	Width across flat (mm)		8.8		10.9	
				kgm	Nm	kgm	Nm
6	1	10	5	0.96±0.1	9.5±1	1.3±0.15	13.5±1.5
8	1.25	13	6	2.3±0.2	23±2	3.2±0.3	32.2±3.5
10	1.5	17	8	4.6±0.5	45±4.9	6.5±0.6	63±6.5
12	1.75	19	10	7.8±0.8	77±8	11±1	108±11
14	2	22	12	12.5±1	122±13	17.5±2	172±18
16	2	24	14	19.5±2	191±21	27±3	268±29
18	2.5	27	14	27±3	262±28	37±4	366±36
20	2.5	30	17	38±4	372±40	53±6	524±57
22	2.5	32	17	52±6	511±57	73±8	719±80
24	3	36	19	66±7	644±70	92±10	905±98
27	3	41	19	96±10	945±100	135±15	1329±140
30	3.5	46	22	131±14	1287±140	184±20	1810±190
33	3.5	50	24	177±20	1740±200	250±27	2455±270
36	4	55	27	230±25	2250±250	320±35	3150±350
39	4	60	—	295±33	2900±330	410±45	4050±450

This torque table does not apply to bolts or nuts which have to fasten nylon or other parts non-ferrous metal washer.

★ Nm (Newton meter): 1 Nm = 0.102 kgm

STANDARD TIGHTENING TORQUE



2. TIGHTENING TORQUE FOR NUTS OF FLARED

Use these torques for nut part of flared.

Thread diameter of nut part (mm)	Width across flats of nut part (mm)	TIGHTENING TORQUE	
		kgm	Nm
1/2" - 20	17	2.6±0.5	25.5±4.9
9/16" - 18	17	4±0.5	39.2±4.9
3/4" - 16	22	6.7±2	65.7±19.6
7/8" - 14	27	8±2	78.5±19.6
1.1/16" - 12	32	9.7±3	95.15±29.4
1.5/16" - 12	38	17±3	166.7±29.4
1.5/8" - 12	50	20±5	196.2±49
22	27	8±2	78.5±19.6
33	41	20±5	196.2±49



COATING MATERIALS

The recommended coating materials prescribed in FKI Shop Manuals are listed below:

Nomenclature	Code	Applications
Adhesives	ASL800010	Used to apply rubber pads, rubber gaskets and cork plugs.
	ASL800020	Used to apply resin, rubber, metallic and non-metallc parts when a fast, strong seal is needed.
	Loctite 222	Used for low resistance locking of screws, check nuts and adjustment nuts.
	Loctite 242	To prevent the loosening of bolts, nuts and plugs and the leakage of oil. Used for medium resistance locking of screws and nuts of every type, and for locking keys and bearings.
	Loctite 262	Used for high resistant of threaded parts that can be removed with normal tools.
	Loctite 270	Used for high resistant locking and for sealing threaded parts, bolts and stud bolts.
	Loctite 542	Used for sealing the union threads for hydraulic tubes.
	Loctite 573	Used for sealing rather exact plane surfaces when the option of possible future dismantling is required.
	Loctite 601	Used for high resistant locking of mechanical components that can be removed only after heating
Gasket sealant	ASL800060	Used by itself to seal grease fittings, tapered screw fittings and tapered screw fittings in hydraulic circuits of less than 50 mm in diameter.
	ASL800070	Used by itself on mounting surface on the final drive and transmission cases. (Thickness after tightening :0.07-0.08 mm).
Antifriction compound (Lubricant including Molybdenum disulfide)	ASL800040	Applied to bearings and taper shaft to facilitate press-fitting and to prevent sticking, burning or rusting.
Grease (Lithium grease)	ASL800050	Applied to bearings, sliding parts and oil seals for lubrication, rust prevention and facilitation of assembling work.
Vaseline	-	Used for protecting battery electrode terminals from corrosion.

ELECTRIC WIRE CODE

In the wiring diagrams, various colors and symbols are employed to indicate the thickness of wires.

This wire code table will help you understand WIRING DIAGRAMS.

Example: R -N 1.5 indicates a cable having a nominal number 1.5 and red coating with black stripe.

CLASSIFICATION BY THICKNESS

Nominal number	Copper wire			Cable O.D. (mm)	Current rating (A)	Applicable circuit
	Number strands	ø of strands (mm)	Cross section (mm ²)			
0.35	11	0.20	0.35	1.55	3.5	Proximity sensor
0.5	16	0.20	0.50	2.40	6	Instrument
0.8	11	0.30	0.78	2.80	8	Instrument - transmitter
1	14	0.30	0.99	2.80	11	Lighting - signal etc.
1.5	21	0.30	1.48	3.35	14	Working light - solenoid valve etc.
2.5	35	0.30	2.47	3.80	20	Control panel - Ignition switch etc.
4	56	0.30	3.95	4.60	28	Alternator - preheating etc.
6	84	0.30	5.93	5.20	37	Starter motor fuses
50	399	0.40	50.11	14	160	Ground - starter motor

CLASSIFICATION BY COLOUR AND CODE

Code	Primary	Auxiliary									
	A	A-B	A/B	A-G	A/G	A-N	A/N	A-R	A/R	A-V	A/V
Colour	Light blue	Light blue-White		Light blue-Yellow		Light blue-Black		Light blue-Red		Light blue-Green	
Code	B	B-G	B/G	B-L	B/L	B-N	B/N	B-R	B/R	---	---
Colour	White	White-Yellow		White-Blue		White-Black		White-Red		---	
Code	C	C-B	C/B	C-N	C/N	C-V	C/V	---	---	---	---
Colour	Orange	Orange-White		Orange-Black		Orange-Green		---		---	
Code	G	G-N	G/N	G-R	G/R	G-V	G/V	---	---	---	---
Colour	Yellow	Yellow-Black		Yellow-Red		Yellow-Green		---		---	
Code	H	H-G	H/G	H-N	H/N	H-R	H/R	---	---	---	---
Colour	Gray	Gray-Yellow		Gray-Black		Gray-Red		---		---	
Code	L	L-G	L/G	L-N	L/N	L-R	L/R	---	---	---	---
Colour	Blue	Blue-Yellow		Blue-Black		Blue-Red		---		---	
Code	M	M-B	M/B	M-N	M/N	---	---	---	---	---	---
Colour	Brown	Brown-White		Brown-Black		---		---		---	
Code	N	---	---	---	---	---	---	---	---	---	---
Colour	Black	---		---		---		---		---	
Code	R	R-N	R/N	R-V	R/V	---	---	---	---	---	---
Colour	Red	Red-Black		Red-Green		---		---		---	
Code	S	S-G	S/G	S-N	S/N	---	---	---	---	---	---
Colour	Pink	Pink-Yellow		Pink-Black		---		---		---	
Code	V	V-B	V/B	V-N	V/N	V-R	V/R	---	---	---	---
Colour	Green	Green-White		Green-Black		Green-Red		---		---	
Code	Z	Z-B	Z/B	Z-G	Z/G	Z-N	Z/N	---	---	---	---
Colour	Violet	Violet-White		Violet-Yellow		Violet-Black		---		---	


COMPOSITION OF THE COLOURS

The coloration of two-colour wires is indicated by the composition of the symbols listed.

Example: G-V = Yellow-Green with longitudinal colouring.

G/V = Yellow-Green with transversal colouring.

WEIGHT TABLE

 This weight table is a guide for use when transporting or handling components.

Unit: kg

Machine model	PW95-1
From serial no.	0000007
Engine assembly	492
Radiator - exchanger	41
Hydraulic tank (without hydraulic oil)	76
Fuel tank (without fuel)	104
Revolving frame	1092
Counter weight	1150
Swing circle	130
Swing machinery assembly	65
Main hydraulic pump	60
Auxiliary pump	16.5
Operator's cab	250
Operator's seat	32
Operator's seat support	9
Platform	55
Control valve	60
Track frame assembly	860
Front axle	403
Rear axle	410
Transmission assembly	72
Wheel assembly	79
Center swivel joint	97
Axle locking cylinder cylinder	30.5
Swing bracket	36
Engine hood (movable)	60
Engine hood (fixed)	83
Control valve hood	16
Boom	358
1 st boom	272
2 nd boom	195
Arm (L = 1850)	156
Arm (L = 1600)	134
Outrigger	76
Bracket	29
Outrigger support	140
Blade	192

TABLE OF OIL AND COOLANT QUANTITIES

RESERVOIR	KIND OF FLUID	AMBIENT TEMPERATURE						CAPACITY (ℓ)	
		-20	-10	0	10	20	30°C	Specified	Refill
Lubricating oil sump Engine oil filter	OIL ● API CD-SG ● MIL-L-2104 E ● CCMC D4-G4	SAE 10W						11.5	11.5
		SAE 20W-20							
		SAE 30							
		SAE 40							
Hydraulic system		SAE 10W						148	82
Front axle: ● differential ● planetary (each) Rear axle: ● differential ● planetary (each)	OIL ● UTTO FLUID							7.8	7.8
		SAE 10W						0.9	0.9
								7.8	7.8
		SAE 10W						0.9	0.9
Transmission	OIL ● API GL5 ● MIL-L-2105 D							1.9	1.9
Swing machinery		SAE 80W/90						4	4
Fuel tank	DIESEL FUEL	*						140	---
		ASTM D975 N. 2							
Cooling system	WATER + ANTI-FREEZE							20	---
	WATER							20	---
	PERMANENT LIQUID	SAE 10W						20	---

* ASTM D975 N. 1

ASTM: America Society of Testing and Materials

SAE: Society of Automotive Engineers

API: American Petroleum Institute

MIL: USA Military Specification

CCMC: Common Market Constructors Committe

Specified capacity: Total amount of oil including oil for components and oil in piping.

Refill capacity: Amount of oil needed to refill system during normal inspection and maintenance.

NOTE:

- (1) When fuel sulphur content is less than 0.5%, change oil in the oil pan every periodic maintenance hours described in operation and maintenance manual.
Change oil according to the following table if fuel sulphur content is above 0.5%.

Fuel sulphur content	Oil change interval in engine oil pan
0.5 to 1.0%	1/2 of regular interval
Above 1.0%	1/4 of regular interval

- (2) When starting the engine is weathers temperature below 0°C, be sure to use engine oil SAE 10W, SAE 20W-20, even if weather temperature goes up to 10°C day time.
- (3) Use classification CD as engine oil, if use classification CC, reduce the engine oil change interval to half.
- (4) Use original products, which have characteristics specifically formulated and approved for the engine, the hydraulic circuit of equipment and for reductions.


GROUP

10

10 STRUCTURE AND FUNCTION

P.T.O.	10- 2	Servocontrol feed unit	10-40
Power train	10- 3	R.H. PPC valve.....	10-42
Transmission	10- 4	L.H. PPC valve	10-43
Front axle - differential.....	10- 6	Accumulators	10-44
Rear axle - differential	10- 7	Swing motor braking circuit selector valve.....	10-45
Planetary.....	10- 8	Travel PPC valve.....	10-46
Axles	10- 9	2 nd boom PPC valve	10-47
Parking brake and cylinder.....	10-10	Boom swing PPC valve.....	10-48
Steering system	10-12	Outrigger and blade PPC valve.....	10-49
Steering unit.....	10-16	Outrigger and blade safety valve	10-50
Swing circle.....	10-17	Brake pump.....	10-51
Swing machinery.....	10-18	Axle locking valve	10-52
Check valve and oil cooler safety by-pass.....	10-19	Solenoid valves.....	10-53
Hydraulic circuit diagram.....	10-20	Electrical circuit diagrams:	
Main hydraulic pump	10-21	1 - Starting and engine line.....	10-59
Pump drive	10-22	2 - Beams, direction indicator horn and fan line	10-61
Summation horsepower control.....	10-23	3 - Column steering switch, R.H. dashboard switch, mechanical travel speed change relay and rotary and cutting shovel switch line	10-63
3 circuit control valve	10-26	4 - Mode System, relief servocontrol and L.H. dashboard switch line	10-65
Mode-System	10-28	5 - Steering emergency switch steering selection switch and upper slip ring collector line	10-67
Auxiliary pump	10-29	6 - Track frame solenoid valve and steering relay box line	10-69
Priority valve.....	10-30	7 - Main box and track frame relay box disposition	10-71
Control valve (valve)	10-31		
Control valve (ports)	10-32		
Swing motor	10-34		
Swing motor relief valve.....	10-35		
Center swivel joint	10-36		
Travel motor	10-37		
Displacement automatic control high pressure related.....	10-38		
Travel motor brake valves.....	10-39		

P.T.O.



D0400002

- | | |
|---------------------|-----------------|
| 1. Connecting plate | 10. Screw |
| 2. Crown wheel | 11. Flywheel |
| 3. Flywheel housing | 12. Washer |
| 4. Centering ring | 13. Screw |
| 5. Screw | 14. Nut |
| 6. Screw | 15. Loose piece |
| 7. Screw | |
| 8. Hub | |
| 9. Pump plate | |