

Document ID

Order number:%&) \$% ()
Issued: 2014-10
Version: 07
Author: LBH / Technical Documentation Department

Product ID

Manufacturer: Liebherr-Werk Bischofshofen GmbH
Valid for: L 580-1170

Conformity: 

Contact Liebherr-Werk Bischofshofen GmbH
Dr. Hans Liebherr-Straße 4
Bischofshofen - A – 5500

Notes for the user

This service handbook is designed for trained specialists of the Liebherr organisation and their dealers.

This service handbook contains special knowledge for repairing Liebherr construction machines. Basic specialist knowledge on electronics, hydraulics, mechanics and engine technology is not contained in this service handbook. Therefore specialized training and qualifications are necessary. Liebherr recommends participation in the Liebherr training program for construction machines.

In this service handbook you will find information on:


- Special tools
- Technical data
- Maintenance intervals and maintenance tasks
- Testing and adjustment tasks
- Structure and function descriptions
- Removal and installation tasks
- Circuit diagrams, hydraulic plans and technical drawings

You will find information on controls and operation in the operating instructions. Information on spare parts are in the spare parts catalogue. Please observe the local accident prevention laws.

This document may only be duplicated, even in part, with the permission of Liebherr.



Technical changes are reserved.


Warning symbols

	This is the warning symbol. It warns you of potential injuries. To prevent injury or death, carry out all the measures identified by this warning symbol.
---	---

The warning symbol always appears together with the signal words

DANGER
WARNING
CAUTION

	DANGER	Indicates a hazardous situation that will immediately lead to serious or fatal injury if it is not avoided.
	WARNING	Indicates a hazardous situation that may lead to serious or fatal injury if it is not avoided.

	CAUTION	Indicates a hazardous situation that may lead to minor or moderate injury if it is not avoided.
	ATTENTION	Indicates a hazardous situation that may lead to damage if it is not avoided.

Structure of warnings

Warnings in this document are structured as follows:







WARNING

Here you will find information about the type and source of danger. Here you will be informed about possible consequences of not paying attention to the warning.

▶ Here you will be called on to take measures to avoid the dangerous situation.

Other designations

Symbol	Meaning
	Note Indicates useful tips and information.
	This symbol means: Carry out a task.
	This symbol means: Requirements must be fulfilled.
	This symbol means: Results of a task.
-	This symbol indicates a list.

Symbols

Contents

010	Introduction	010-1
010.1	Safety instructions	010-3
010.1.1	General safety instructions	010-3
010.1.2	Instructions on preventing crushing injuries and burns	010-4
010.1.3	Instructions on preventing fires and explosions	010-4
010.1.4	Safety instructions for start-up	010-5
010.1.5	Safety precautions during start-up	010-5
010.1.6	Instructions for safe working	010-6
010.1.7	Safety instructions for driving on slopes	010-7
010.1.8	Parking safely	010-7
010.1.9	Transporting the machine safely	010-7
010.1.10	Towing the machine safely	010-8
010.1.11	Measures for ensuring safe maintenance	010-8
010.1.12	Safety instructions for maintenance work on machines with hydro accumulators	010-11
010.1.13	Safety instructions for welding work on the machine	010-11
010.1.14	Instructions for working safely on the working attachment	010-11
010.1.15	Safety instructions for transporting the machine by crane	010-12
010.1.16	Safe maintenance of hydraulic hoses and hose lines	010-12
010.1.17	Roll-over protection structure (ROPS) and falling object protection structure (FOPS)	010-13
010.1.17.1	Preventing accidents	010-13
010.1.17.2	Preventing injuries	010-13
010.1.18	Attachments and accessories	010-14
010.1.19	Protection against vibrations	010-14
010.1.20	See and be seen	010-15
010.1.20.1	Field of view	010-15
010.1.20.2	Measures before and during operation	010-15
010.2	Special tools for maintenance and repair work	010-16
010.2.1	Special tools in general	010-16

010.2.2	Special tools for Liebherr diesel engines	010-17
010.2.3	Special tools for steering cylinders	010-18
010.2.4	Special tools for the electrical system	010-18
010.2.5	Special tools for the transmission	010-19
010.2.6	Special tools for front axle MT-L II	010-19
010.2.7	Special tools for rear axle MT-L II	010-19
010.2.8	Special tools for the air conditioning system	010-20
010.2.9	Special tools for cab glazing	010-20
010.2.10	Special tools for the central lubrication system (Liebherr)	010-20
010.2.11	Special tools for the central lubrication system (Groeneveld)	010-21
010.3	Standards and regulations	010-22
010.3.1	Prestressing forces and tightening torques for bolts with metric standard and fine threads	010-22
010.3.2	Assembly instructions for the piston and piston nut of the hydraulic cylinder (WN 4121)	010-26
010.3.2.1	Range of application and purpose	010-26
010.3.2.2	Requirements and description	010-26
010.3.2.3	Amendments	010-31
010.3.2.4	Other applicable documents	010-31
010.3.2.5	Maximum permissible adapter operating pressure	010-36
010.4	Preservation guidelines	010-37
010.4.1	General information	010-37
010.4.2	Putting the machine out of service – unknown duration	010-37
010.4.3	Putting the machine out of service	010-38
010.4.3.1	Out of service for up to 2 months	010-38
010.4.3.2	Out of service for up to 12 months	010-39
010.4.3.3	Out of service for longer than 12 months	010-40
010.4.4	Putting back into service	010-40
010.4.4.1	After being out of service for 2 months	010-40
010.4.4.2	After being out of service for 12 months	010-41
010.4.4.3	After being out of service for longer than 12 months	010-41
020	Technical data	020-1
020.1	Overall machine	020-5
020.1.1	Complete machine with bucket (Z lift arms) <i>L580-1170/26443-;</i>	020-5

020.1.2	Complete machine with bucket (industrial lift arms) <i>L580-1170/26443-;</i>	020-7
020.2	Drive group	020-9
020.2.1	Diesel engine <i>L580-1170/26443-;</i>	020-9
020.2.2	Diesel particulate filter temperature sensors <i>L580-1170/26443-;</i>	020-10
020.2.3	Fuel tank <i>L580-1170/26443-;</i>	020-11
020.2.4	Fuel pre-filter (separator filter) <i>L580-1170/26443-;</i>	020-11
020.2.5	Fuel fine filter <i>L580-1170/26443-;</i>	020-11
020.2.6	Air filter vacuum switch <i>L580-1170/26443-;</i>	020-11
020.2.7	Clutch <i>L580-1170/26443-;</i>	020-11
020.2.8	Splitter box <i>L580-1170/26443-;</i>	020-12
020.3	Cooling system	020-13
020.3.1	Fan gear pump <i>L580-1170/26443-;</i>	020-13
020.3.2	Fan gear motor <i>L580-1170/26443-;</i>	020-13
020.4	Working hydraulics	020-14
020.4.1	Working hydraulics pump <i>L580-1170/26443-;</i>	020-14
020.4.2	Control valve block <i>L580-1170/26443-;</i>	020-14
020.4.3	Pilot control unit <i>L580-1170/26443-;</i>	020-15
020.4.4	Pilot control solenoid valve <i>L580-1170/26443-;</i>	020-15
020.4.5	Pilot control hydro accumulator <i>L580-1170/26443-26442;</i>	020-15
020.4.6	Float position pressure switch <i>L580-1170/26443-;</i>	020-15
020.4.7	Stabilisation module <i>L580-1170/26443-;</i>	020-16
020.4.8	Ride control hydro accumulator <i>L580-1170/26443-;</i>	020-16
020.4.9	Z kinematics and industrial lift arms lift cylinder <i>L580-1170/26443-;</i>	020-16

020.4.10	Z kinematics tilt cylinder <i>L580-1170/26443-;</i>	020-17
020.5	Travel hydraulics	020-18
020.5.1	Variable displacement pump <i>L580-1170/23166-;</i>	020-18
020.5.2	Variable displacement motor 1 <i>L580-1170/26443-;</i>	020-18
020.5.3	Variable displacement motor 2 <i>L580-1170/26443-;</i>	020-19
020.5.4	Variable displacement motor scavenging gear pump <i>L580-1170/26443-;</i>	020-19
020.6	Hydraulic components	020-20
020.6.1	Filter unit <i>L580-1170/26443-;</i>	020-20
020.6.2	Breather filter <i>L580-1170/26443-;</i>	020-20
020.7	Steering system	020-21
020.7.1	Steering pump <i>L580-1170/26443-;</i>	020-21
020.7.2	Servostat <i>L580-1170/26443-;</i>	020-21
020.7.3	Steering cylinder <i>L580-1170/26443-;</i>	020-21
020.7.4	Steering damper hydro accumulator <i>L580-1170/26443-;</i>	020-22
020.7.5	Emergency steering pump <i>L580-1170/26443-;</i>	020-22
020.7.6	Emergency steering pressure switch <i>L580-1170/26443-;</i>	020-22
020.7.7	Emergency steering check pressure switch <i>L580-1170/26443-;</i>	020-22
020.8	Brake system	020-23
020.8.1	Brake system gear pump <i>L580-1170/26443-;</i>	020-23
020.8.2	Compact brake valve <i>L580-1170/26443-;</i>	020-23
020.8.3	Service brake hydro accumulator <i>L580-1170/26443-;</i>	020-23
020.8.4	Brake light pressure switch <i>L580-1170/26443-;</i>	020-23
020.8.5	Accumulator charge pressure switch <i>L580-1170/26443-;</i>	020-24
020.8.6	Parking brake hydro accumulator <i>L580-1170/26443-;</i>	020-24

020.8.7	Overspeed protection solenoid valve <i>L580-1170/26443-;</i>	020-24
020.9	Electrical system	020-25
020.9.1	Central control unit (Master 4) <i>L580-1170/26443-;</i>	020-25
020.9.2	Input module <i>L580-1170/26443-;</i>	020-25
020.9.3	Output module <i>L580-1170/26443-;</i>	020-25
020.9.4	Battery <i>L580-1170/26443-;</i>	020-26
020.9.5	Reversing camera <i>L580-1170/26443-;</i>	020-26
020.10	Transmission	020-27
020.10.1	Transmission <i>L580-1170/26443-;</i>	020-27
020.10.2	Gear shifting solenoid valves <i>L580-1170/26443-;</i>	020-27
020.10.3	Speed sensors <i>L580-1170/26443-;</i>	020-27
020.10.4	Transmission gear pump <i>L580-1170/26443-;</i>	020-28
020.11	Axles and cardan shafts	020-29
020.11.1	Front axle <i>L580-1170/26443-;</i>	020-29
020.11.2	Rear axle <i>L580-1170/26443-;</i>	020-29
020.11.3	Rear cardan shaft <i>L580-1170/26443-;</i>	020-30
020.12	Steel components of the basic machine	020-31
020.12.1	Ballast weight <i>L580-1170/26443-;</i>	020-31
020.13	Working attachment	020-32
020.13.1	Lift arms with Z kinematics <i>L580-1170/26443-;</i>	020-32
020.14	Cab, heating and air conditioning	020-33
020.14.1	Heating, air conditioning <i>L580-1170/26443-;</i>	020-33
020.14.2.1	Air conditioning	020-33
020.14.3.1	Air conditioning compressor	020-33
020.14.4	Condenser <i>L580-1170/26443-;</i>	020-33

020.14.5	Dryer <i>L580-1170/26443-;</i>	020-34
020.14.6	Air conditioning pressure switch <i>L580-1170/26443-;</i>	020-34
020.14.7	Anti-icing temperature sensor <i>L580-1170/26443-;</i>	020-34
020.15	Lubrication system	020-36
020.15.1	Central lubrication system (Liebherr) <i>L580-1170/26443-;</i>	020-36
020.15.1.1	Central lubrication pump	020-36
020.15.1.2	Progressive distributor	020-36
030	Maintenance	030-1
030.1	Maintenance and inspection schedule	030-9
030.2	Filling quantities and lubrication chart	030-13
030.2.1	Recommended lubricants <i>L580-1170/26443-;</i>	030-13
030.2.2	Recommended operating fluids <i>L580-1170/26443-;</i>	030-14
030.3	Lubricants and fuels	030-15
030.3.1	General information on changing lubricants and fuels	030-15
030.3.2	Converting the hydraulic system from mineral oils to environmentally harmless hydraulic fluids	030-15
030.3.3	Diesel fuels <i>L580-1170/26443-;</i>	030-16
030.3.3.1	Specification	030-16
030.3.3.2	Sulphur content of the diesel fuel, lubricity	030-16
030.3.3.3	Diesel fuel at low temperatures (winter operation)	030-16
030.3.3.4	Flow improvers at low temperatures	030-17
030.3.4	Lubricating oils for diesel engines <i>L580-1170/26443-;</i>	030-17
030.3.4.1	Lubricating oil quality	030-17
030.3.4.2	Lubricating oil viscosity	030-17
030.3.4.3	Complicating factors affect the oil change	030-18
030.3.5	Coolants for diesel engines <i>L580-1170/26443-;</i>	030-19
030.3.5.1	General recommendations	030-19
030.3.5.2	Water (fresh water)	030-19
030.3.5.3	Coolant mixing ratio	030-19

	030.3.5.4	Permissible antifreeze and corrosion inhibitors	030-20
	030.3.5.5	Corrosion inhibitors without antifreeze	030-20
030.3.6	Hydraulic oil <i>L580-1170/26443-;</i>		030-21
	030.3.6.1	Liebherr hydraulic oil	030-21
	030.3.6.2	Using engine oil as hydraulic oil	030-21
	030.3.6.3	Warming up	030-22
	030.3.6.4	Biodegradable hydraulic oils	030-22
	030.3.6.5	Changing the oil, analysing the oil, changing filters	030-23
030.3.7	Lubricating oils for splitter boxes <i>L580-1170/26443-;</i>		030-24
030.3.8	Lubricating oils for transmissions <i>L580-1170/26443-;</i>		030-25
030.3.9	Lubricating oils for axles <i>L580-1170/26443-;</i>		030-26
030.3.10	Lubrication grease and other lubricants <i>L580-1170/26443-;</i>		030-27
	030.3.10.1	Minimum quality requirements	030-27
	030.3.10.2	Liebherr lubrication grease	030-27
030.4	Maintenance tasks		030-29
030.4.1	Safety precautions <i>L580-1170/26443-;</i>		030-29
030.4.2	Preparatory tasks for maintenance		030-30
	030.4.2.1	Maintenance positions <i>L580-1170/26443-;</i>	030-30
	030.4.2.2	Opening the service accesses <i>L580-1170/26443-;</i>	030-31
	030.4.2.3	Turning off the battery main switch <i>L580-1170/26443-;</i>	030-34
030.4.3	Overall machine		030-34
	030.4.3.1	Checking the machine for external damage <i>L580-1170/26443-;</i>	030-34
	030.4.3.2	Removing loose parts, dirt, ice and snow from the machine <i>L580-1170/26443-;</i>	030-34
	030.4.3.3	Cleaning the machine <i>L580-1170/26443-;</i>	030-35
	030.4.3.4	Shutting down the machine for a lengthy period <i>L580-1170;</i>	030-36
	030.4.3.5	Checking the machine for leaks <i>L580-1170/26443-;</i>	030-37

030.4.3.6	Making sure the bolted connections are tight <i>L580-1170/26443-;</i>	030-37
030.4.3.7	Corrosion protection on machines that work with salt and artificial fertilisers and exchanging VCI capsules <i>L580-1170/26443-;</i>	030-37
030.4.3.8	Oil analyses <i>L580-1170/26443-;</i>	030-37
030.4.4	Drive group	030-44
030.4.4.1	Checking the engine oil level <i>L580-1170/26443-;</i>	030-44
030.4.4.2	Changing the engine oil <i>L580-1170/26443-;</i>	030-45
030.4.4.3	Changing the engine oil filter <i>L580-1170/26443-;</i>	030-45
030.4.4.4	Checking the V-ribbed belt on the engine <i>L580-1170/26443-;</i>	030-46
030.4.4.5	Changing the V-ribbed belt on the engine <i>L580-1170/26443-;</i>	030-47
030.4.4.6	Checking the mounting and sensor cable connections of the engine control units <i>L580-1170/26443-;</i>	030-48
030.4.4.7	Checking the engine valve clearance <i>L580-1170/26443-;</i>	030-49
030.4.4.8	Changing the engine oil separator filter insert <i>L580-1170/26443-;</i>	030-53
030.4.4.9	Checking the engine heating flange <i>L580-1170/26443-;</i>	030-54
030.4.4.10	Changing the engine heating flange <i>L580-1170/26443-;</i>	030-54
030.4.4.11	Draining off condensate and sediment from the fuel tank <i>L580-1170/26443-;</i>	030-55
030.4.4.12	Draining off condensate from the Separ fuel pre-filter <i>L580-1170/26443-;</i>	030-56
030.4.4.13	Changing the Separ fuel pre-filter insert <i>L580-1170/26443-;</i>	030-57
030.4.4.14	Changing the fuel fine filter <i>L580-1170/26443-;</i>	030-58
030.4.4.15	Bleeding the fuel system <i>L580-1170/26443-;</i>	030-59
030.4.4.16	Cleaning the air filter service cover and dust discharge valve <i>L580-1170/26443-;</i>	030-61
030.4.4.17	Checking the air suction system for leaks and tight fitting <i>L580-1170/26443-;</i>	030-62

030.4.4.18	Changing the air filter main element <i>L580-1170/26443-;</i>	030-63
030.4.4.19	Changing the air filter safety element <i>L580-1170/26443-;</i>	030-64
030.4.4.20	Checking the oil level in the splitter box <i>L580-1170/26443-;</i>	030-64
030.4.4.21	Changing the splitter box oil <i>L580-1170/26443-;</i>	030-65
030.4.4.22	Checking the exhaust system for leaks and tight fitting <i>L580-1170/26443-;</i>	030-66
030.4.4.23	Cleaning or changing the diesel particulate filter <i>L580-1170/26443-;</i>	030-67
030.4.5	Cooling system	030-71
030.4.5.1	Checking the coolant antifreeze and corrosion inhibitor concentration <i>L580-1170/26443-;</i>	030-71
030.4.5.2	Cleaning the cooling system <i>L580-1170/26443-;</i>	030-75
030.4.5.3	Changing the coolant <i>L580-1170/26443-;</i>	030-76
030.4.6	Working hydraulics	030-78
030.4.6.1	Checking the oil level in the hydraulic tank <i>L580-1170/26443-;</i>	030-78
030.4.6.2	Checking and cleaning the magnetic rod on the hydraulic tank <i>L580-1170/26443-;</i>	030-79
030.4.6.3	Draining off condensate and sediment from the hydraulic tank <i>L580-1170/26443-;</i>	030-80
030.4.6.4	Changing the hydraulic tank return suction filter <i>L580-1170/26443-;</i>	030-81
030.4.6.5	Changing the hydraulic tank breather filter <i>L580-1170/26443-;</i>	030-82
030.4.6.6	Hydraulic tank - changing the oil in the hydraulic system <i>L580-1170/26443-;</i>	030-83
030.4.6.7	Lubricating the solenoids, universal joints and tappets on the pilot control unit <i>L580-1170/26443-;</i>	030-84
030.4.7	Travel hydraulics	030-85
030.4.7.1	Checking wear on the travel pump swivel plate bearing <i>L580-1170/26443-;</i>	030-85
030.4.8	Steering system	030-87

030.4.8.1	Testing the steering <i>L580-1170/26443-;</i>	030-87
030.4.8.2	Lubricating the bearing points on the steering cylinders <i>L580-1170/26443-;</i>	030-87
030.4.9	Brake system	030-88
030.4.9.1	Testing the service brake and parking brake <i>L580-1170/26443-;</i>	030-88
030.4.9.2	Checking the service brake discs for wear <i>L580-1170/26443-;</i>	030-89
030.4.9.3	Checking the gap and wear on the parking brake linings <i>L580-1170/26443-;</i>	030-91
030.4.10	Electrical system	030-93
030.4.10.1	Checking the lights <i>L580-1170/26443-;</i>	030-93
030.4.10.2	Checking the batteries, fluid level and terminals <i>L580-1170/26443-;</i>	030-94
030.4.10.3	Changing the travel direction rocker switch and cap (optional) on the control lever <i>L580-1170/26443-;</i>	030-96
030.4.11	Transmission	030-98
030.4.11.1	Checking the transmission oil level <i>L580-1170/26443-;</i>	030-98
030.4.11.2	Changing the transmission oil <i>L580-1170/26443-;</i>	030-99
030.4.11.3	Changing the transmission oil filter <i>L580-1170/26443-;</i>	030-100
030.4.12	Axles and cardan shafts	030-101
030.4.12.1	Checking the axle oil levels <i>L580-1170/26443-;</i>	030-101
030.4.12.2	Changing the axle oil <i>L580-1170/26443-;</i>	030-101
030.4.12.3	Checking the cardan shafts <i>L580-1170/26443-;</i>	030-103
030.4.12.4	Checking the tyre pressure <i>L580-1170/26443-;</i>	030-103
030.4.12.5	Checking the wheel tightness <i>L580-1170/26443-35541;</i>	030-104
030.4.12.6	Checking the wheel tightness <i>L580-1170/35542-;</i>	030-104
030.4.13	Steel components of the basic machine	030-105

030.4.13.1	Lubricating the articulated bearing and the rear oscillating bedding <i>L580-1170/26443-;</i>	030-105
030.4.13.2	Covering - lubricating locks and hinges <i>L580-1170/26443-;</i>	030-106
030.4.13.3	Greasing the rear section cover lower hinges <i>L580-1170/26443-;</i>	030-106
030.4.14	Working attachment	030-107
030.4.14.1	Lubricating the lift arms and attachment <i>L580-1170/26443-;</i>	030-107
030.4.14.2	Checking the bucket bearing seals and the bearing bushings on the lift arms <i>L580-1170/26443-;</i>	030-108
030.4.14.3	Checking the lift arm bucket stops <i>L580-1170/26443-;</i>	030-110
030.4.14.4	Lubricating and testing the quick-change device <i>L580-1170/26443-;</i>	030-111
030.4.15	Cab, heating and air conditioning	030-112
030.4.15.1	Lubricating the elongated hole on the accelerator pedal and checking the bearing <i>L580-1170/26443-;</i>	030-112
030.4.15.2	Cleaning the fresh and recirculated air filters <i>L580-1170/26443-;</i>	030-113
030.4.15.3	Changing the fresh and recirculated air filters <i>L580-1170/26443-;</i>	030-115
030.4.15.4	Checking the condition and function of the safety belt <i>L580-1170/26443-;</i>	030-116
030.4.15.5	Checking and topping up the windscreen washer reservoir <i>L580-1170/26443-;</i>	030-116
030.4.15.6	Lubricating the cab door hinges <i>L580-1170/26443-;</i>	030-117
030.4.15.7	Checking the rubber seals on the driver's cab <i>L580-1170/26443-;</i>	030-117
030.4.15.8	Testing the air conditioning unit <i>L580-1170/26443-;</i>	030-117
030.4.16	Lubrication system	030-119
030.4.16.1	Checking the lubrication system grease reservoir level <i>L580-1170/26443-;</i>	030-119
030.4.16.2	Checking the pipes, hoses and lubrication points of the lubrication system <i>L580-1170/26443-;</i>	030-119

	030.4.16.3	Checking whether metered quantities are adequate at the bearing points (grease collars) of the lubrication system <i>L580-1170/26443-;</i>	030-120
030.5	Testing and adjustment checklist <i>L580-1170/26443-;</i>		030-121
030.6	Testing and adjustment tasks		030-124
	030.6.1	Safety precautions <i>L580-1170/26443-;</i>	030-124
	030.6.2	Overall machine	030-125
	030.6.2.1	Preparatory tasks for testing and adjustment <i>L580-1170/26443-;</i>	030-125
	030.6.2.2	Bringing the machine up to operating temperature <i>L580-1170/26443-;</i>	030-126
	030.6.3	Drive group	030-127
	030.6.3.1	Calibrating the pedals <i>L580-1170/26443-;</i>	030-127
	030.6.3.2	Checking the engine speed <i>L580-1170/26443-;</i>	030-127
	030.6.3.3	Performing a service regeneration on the diesel particulate filter <i>L580-1170/26443-;</i>	030-128
	030.6.4	Cooling system	030-130
	030.6.4.1	Checking the fan motor and fan control proportional pressure relief valve <i>L580-1170/26443-;</i>	030-130
	030.6.5	Working hydraulics	030-131
	030.6.5.1	Checking the flow regulator of the working hydraulics pump <i>L580-1170/26443-;</i>	030-131
	030.6.5.2	Checking the power regulator of the working hydraulics pump <i>L580-1170/26443-;</i>	030-132
	030.6.5.3	Checking the secondary pressure relief valves on the control valve block <i>L580-1170/26443-;</i>	030-133
	030.6.5.4	Checking the primary pressure relief valve on the control valve block <i>L580-1170/26443-;</i>	030-134
	030.6.5.5	Checking the LS pressure cut-off on the control valve block <i>L580-1170/26443-;</i>	030-135
	030.6.5.6	Checking the cut-off valve in the stabilisation module <i>L580-1170/26443-;</i>	030-135

030.6.5.7	Depressurising the ride control and the hydro accumulators <i>L580-1170/26443-;</i>	030-136
030.6.5.8	Checking the nitrogen filling of the ride control hydro accumulators <i>L580-1170/26443-;</i>	030-137
030.6.5.9	Testing the control valve block for leakages <i>L580-1170/26443-;</i>	030-138
030.6.6	Travel hydraulics	030-141
030.6.6.1	Checking the replenishing pressure of the variable displacement pump <i>L580-1170/26443-;</i>	030-141
030.6.6.2	Checking the pressure relief valves of the variable displacement pump <i>L580-1170/26443-;</i>	030-141
030.6.6.3	Checking the pressure cut-off of the variable displacement pump <i>L580-1170/26443-;</i>	030-143
030.6.6.4	Checking the high pressure sensor <i>L580-1170/26443-;</i>	030-143
030.6.6.5	Automatic block curve calibration <i>L580-1170/26443-;</i>	030-144
030.6.6.6	Calibrating the variable displacement motors <i>L580-1170/26443-;</i>	030-145
030.6.6.7	Checking the nitrogen filling of the hydro accumulator for feeding the travel hydraulics <i>L580-1170/26443-;</i>	030-147
030.6.6.8	Engine output <i>L580-1170/26443-;</i>	030-147
030.6.7	Steering system	030-149
030.6.7.1	Checking the pressure cut-off of the steering system <i>L580-1170/26443-;</i>	030-149
030.6.8	Brake system	030-149
030.6.8.1	Checking the cut-in and cut-off pressure of the compact brake valve <i>L580-1170/26443-;</i>	030-149
030.6.8.2	Checking the brake pressure at the axles <i>L580-1170/26443-;</i>	030-150
030.6.8.3	Checking the capacity of the brake accumulators <i>L580-1170/26443-;</i>	030-151
030.6.8.4	Checking the accumulator charge pressure <i>L580-1170/26443-;</i>	030-152
030.6.8.5	Checking the brake light pressure switch and brake lights <i>L580-1170/26443-;</i>	030-152
030.6.9	Electrical system	030-153

030.6.9.1	Setting the IP addresses of the central control unit (Master4) <i>L580-1170/26443-;</i>	030-153
030.6.9.2	Central control unit (Master4) - Performing a reset <i>L580-1170/26443-;</i>	030-156
030.6.9.3	Testing the CAN line <i>L580-1170/26443-;</i>	030-157
030.6.9.4	Addressing the CAN module and checking the system information <i>L580-1170/26443-;</i>	030-161
030.6.10	Transmission	030-165
030.6.10.1	Control valve block shift pressure <i>L580-1170/26443-;</i>	030-165
030.6.10.2	Nitrogen filling of transmission hydro accumulator <i>L580-1170/26443-;</i>	030-165
030.6.11	Cab, heating and air conditioning	030-167
030.6.11.1	Checking the pressure and temperature conditions of the air conditioning unit <i>L580-1170/26443-;</i>	030-167
030.6.11.2	Calibrating the display unit <i>L580-1170/26443-;</i>	030-168
030.6.11.3	Formatting the display unit and reinstalling the software <i>L580-1170/26443-;</i>	030-169
030.6.12	Options	030-171
030.6.12.1	LiDAT on the machine - Checking connecting link <i>L580-1170/26443-;</i>	030-171
040	Drive group	040-1
040.1	Engine	040-2
040.1.1	Diesel engine overview <i>L580-1170/26443-;</i>	040-2
040.1.2	Electrical components on the engine <i>L580-1170/26443-;</i>	040-6
040.1.3	Speed sensor for crankshaft <i>L580-1170/26443-;</i>	040-7
040.1.4	Camshaft speed sensor <i>L580-1170/26443-;</i>	040-8
040.1.5	Fuel system	040-9
040.1.5.1	Overview of the fuel system <i>L580-1170/26443-;</i>	040-10
040.1.5.2	Fuel level sensor <i>L580-1170/26443-;</i>	040-11
040.1.6	Air filter system	040-11

	040.1.6.1	Air filter <i>L580-1170/26443-;</i>	040-12
	040.1.6.2	Vacuum switch <i>L580-1170/26443-;</i>	040-13
	040.1.7	Exhaust system	040-13
	040.1.7.1	Overview of the diesel particulate filter <i>L580-1170/26443-;</i>	040-14
	040.1.7.2	Diesel oxidation catalyst (DOC) <i>L580-1170/26443-;</i>	040-19
	040.1.7.3	Diesel particulate filter module <i>L580-1170/26443-;</i>	040-20
	040.1.7.4	Removing and installing the diesel particulate filter <i>L580-1170/26443-;</i>	040-20
	040.2	Coupling <i>L580-1170/26443-;</i>	040-27
	040.3	Splitter box <i>L580-1170/26443-;</i>	040-29
050	Cooling system		050-1
	050.1	Overview of the cooling system <i>L580-1170/26443-;</i>	050-2
	050.2	Hydraulic control unit	050-3
	050.2.1	Overview of the hydraulics cooling system <i>L580-1170/26443-;</i>	050-3
	050.2.2	Fan gear pump <i>L580-1170/26443-;</i>	050-5
	050.2.3	Fan gear motor <i>L580-1170/26443-;</i>	050-7
	050.3	Electronic control unit	050-11
	050.3.1	Electric fan speed control <i>L580-1170/26443-;</i>	050-11
	050.3.2	Hydraulic oil temperature sensor <i>L580-1170/26443-;</i>	050-13
060	Working hydraulics		060-1
	060.1	Working hydraulics - Overview <i>L580-1170/26443-;</i>	060-3
	060.2	Working hydraulics pump <i>L580-1170/26443-;</i>	060-10
	060.3	Control valve block <i>L580-1170/26443-;</i>	060-18
	060.4	Pilot control	060-24

060.4.1	Overview of the pilot control unit <i>L580-1170/26443-;</i>	060-24
060.4.2	Pilot control unit <i>L580-1170/26443-;</i>	060-28
060.4.3	Pilot control solenoid valve <i>L580-1170/26443-;</i>	060-33
060.4.4	Pilot control hydro accumulator <i>L580-1170/26443-;</i>	060-34
060.4.5	Float position pressure switch <i>L580-1170/26443-;</i>	060-35
060.5	Ride control	060-37
060.5.1	Ride control overview <i>L580-1170/26443-;</i>	060-37
060.5.2	Stabilisation module <i>L580-1170/26443-;</i>	060-43
060.5.3	Hydro accumulator unit <i>L580-1170/26443-;</i>	060-47
060.6	Working hydraulics cylinder	060-49
060.6.1	Hydraulic cylinders for Z kinematics	060-49
060.6.1.1	Z kinematics lift cylinder <i>L580-1170/26443-;</i>	060-49
060.6.1.2	Z kinematics tilt cylinder <i>L580-1170/26443-;</i>	060-50
060.6.2	Hydraulic cylinders for industrial lift arms	060-51
060.6.2.1	Lift cylinder for industrial lift arms <i>L580-1170/26443-;</i>	060-51
060.6.2.2	Industrial lift arms tilt cylinder <i>L580-1170/26443-;</i>	060-52
070	Travel hydraulics	070-1
070.1	Travel hydraulics overview <i>L580-1170/26443-;</i>	070-2
070.2	Variable displacement pump <i>L580-1170/26443-;</i>	070-12
070.3	Travel motors	070-23
070.3.1	Overview of the variable displacement motors <i>L580-1170/26443-;</i>	070-23
070.3.2	Variable displacement motor <i>L580-1170/26443-;</i>	070-26
080	Hydraulic components	080-1
080.1	Hydraulic tank	080-2