

Service Training

Linde electric lift truck E 20/25/30 with shunt drive and LLC, series **336 -02**
336 804 4601.0600

TABLE OF CONTENTS

6	Electrical system	1
6.1	Control system for LDC traction drive unit	1
6.1.1	Operating principle	2
6.1.1.1	Components of the electrical system	4
6.1.1.2	Control current fuses	5
6.1.1.3	Position of the plugs in the truck	6
6.1.2	Power units	8
6.1.2.1	Power unit A1	9
6.1.2.2	Power unit 1A1	11
6.1.3	Main current unit	12
6.1.3.1	Switching on and charging the intermediate circuit capacitors	12
6.1.3.2	Discharging the intermediate circuit capacitors	13
6.1.3.3	Forward direction of travel	14
6.1.3.4	Backward direction of travel	14
6.1.3.5	Freewheel circuit	15
6.1.3.6	Regenerative braking	15
6.1.4	Control circuit	16
6.1.4.1	Drive electronics 1A2	16
6.1.4.2	Power supply	21
6.1.4.3	Main contactor K1	21
6.1.4.4	Release signal	21
6.1.4.5	Accelerator	21
6.1.4.6	Direction of travel switch, single pedal operation	23
6.1.4.7	Monitoring the rpm speed of the traction motors	23
6.1.4.8	Curve signal	24
6.1.4.9	Emergency stop microswitch	24
6.1.4.10	Temperature signal for the traction motors	24
6.1.4.11	Handbrake switch	25
6.1.4.12	Brake pedal switch	25
6.1.4.13	Discharge relay K2	25
6.1.4.14	Fans	25
6.1.4.15	Switch-controlled speed reduction	25

6.1.4.16	Truck encoding	25
6.1.5	LCD Diagnosis (Linde Digital Control)	26
6.1.5.1	Window 1 - Truck status information	30
6.1.5.2	Window 2 - Information and fault messages	31
6.1.5.3	Window 3 - Stored fault messages	50
6.1.5.4	Window 31 - Acknowledge fault messages	50
6.1.5.5	Window 32 - Delete fault messages	51
6.1.5.6	Window 4 - Switch inputs	52
6.1.5.7	Window 5 - Switch outputs	53
6.1.5.8	Window 6 - Analog signals not related to the motors	53
6.1.5.9	Windows 61 and 62 - Analog signals related to the drive motors	54
6.1.5.10	Window 63 - Temperature signal for the power modules	54
6.1.5.11	Window 7 - Setting general parameters for the truck	55
6.1.5.12	Window 71 - Standard setting for the parameters in window 7	56
6.1.5.13	Window 72 - Adjustment of special truck parameters	56
6.1.5.14	Window 73 - Standard setting for the parameters in window 7 and 72	57
6.1.5.15	Window 74 - Display of UPA designs	57
6.1.5.16	Window 8 - Programming of the neutral pedal setting	58
6.1.5.17	Window 81 - Programming of the steering end stops	59
6.2	LLC Control unit for the working and steering hydraulics	60
6.2.1	Control circuit	62
6.2.1.1	Voltage supply	62
6.2.1.2	Release signal	62
6.2.1.3	Joysticks	62
6.2.1.4	Activation of the solenoid valves	63
6.2.1.5	Speed sensor 2B8	64
6.2.1.6	Monitoring the motor temperature and the battery charge level	64
6.2.1.7	Monitoring of the temperature in the power unit	65
6.2.1.8	General monitoring of the power unit	65
6.2.2	LLC Diagnostic System (Linde Load Control)	66
6.2.2.1	Window 1 - Status information	71
6.2.2.2	Window 2 - Current informations and fault messages	71
6.2.2.3	Window 3 - Stored fault messages	85
6.2.2.4	Window 31 - Acknowledge fault messages in memory	85
6.2.2.5	Window 32 - Delete fault messages in memory	86
6.2.2.6	Window 4 - Switch inputs	87
6.2.2.7	Window 5 - Switch outputs	88

6.2.2.8	Window 6 - Analog signals	89
6.2.2.9	Window 61-64 - Joystick signals	90
6.2.2.10	Window 7 - Setting parameters for auxiliary hydraulics	91
6.2.2.11	Window 71 - Standard setting for the parameters in window 7	91
6.2.2.12	Window 72 - Setting special parameters for the working hydraulic	92
6.2.2.13	Window 73 - Standard setting for the parameters in window 7 and 72	92
6.2.2.14	Window 8 - General alignment for the joystick	93
6.2.2.15	Window 81 - Joystick alignment for auxiliary hydraulic	93
6.2.2.16	Window 82 - Making the hydraulic system pressureless	94
6.2.2.17	Window 82 - Pumpmotor cutout	95
6.3	Circuit diagram	96
6.4	Additional function	99
6.4.1	Brake light activation	99
6.4.2	Warning light activation	99
6.4.3	Flashing pilot light activation	99
6.4.4	Activation of the operatin hours counter while driving and when the pump motor is functioning	100
6.5	AMP-Saab Plug connector	101
6.6	Diagnostic LDC Software Version 3.0	109
6.6.1	Window 1 Status Information	109
6.6.2	Window 2 Current Information and Error Messages	109
6.6.3	Window 3 Error Memory	109
6.6.4	Window 31 Error Memory Operating Error	109
6.6.5	Window 32 Acknowledging the Error Memory	109
6.6.6	Window 33 Clearing the Error Memory	109
6.6.7	Window 4 Inputs	109
6.6.8	Window 4 outputs	110
6.6.9	Window 6 Analog Signals not related to Motor	110
6.6.10	Window 61 and 62 Analog Values related to Traction Motor	110
6.6.11	Window 63 Temperature Signals of Power Supplies	111
6.6.12	Window 7 Setting the General Truck Parameters	111
6.6.13	Window 71 Standard Setting of Window 7 Parameters	112
6.6.14	Window 72 Setting Special Truck Parameters	112
6.6.15	Window 73 Standard Setting of Window 7 and 72 Parameters	113
6.6.16	Window 74 Display of UPA Versions	113
6.6.17	Window 8 Programming the Accelerator	113
6.6.18	Window 81 Programming the Steering Stops	113

6.7	LIC Diagnostic Software Version 1.10	114
6.7.1	Window 1 Status Information	114
6.7.2	Window 2 Current Information and Error Messages	114
6.7.3	Window 3 Error Memory	114
6.7.4	Window 31 Error Memory Operating Error	114
6.7.5	Window 32 Acknowledging the Error Memory	114
6.7.6	Window 33 Clearing the Error Memory	115
6.7.7	Window 4 Inputs	115
6.7.8	Window 5 Outputs	115
6.7.9	window 6 Analog signals	115
6.7.10	Window 61-64 Joystick Signals	115
6.7.11	Window 7 Setting the Auxiliary Hydraulics Parameters	116
6.7.12	Window 71 Standard Setting of Window 7 Parameters	116
6.7.13	Window 72 Setting of Special Working Hydraulics Parameters	116
6.7.14	Window 73 Standard Setting of Window 72 Parameters	116
6.7.15	Window 74 Setting Switch-controlled Speed Reduction	117
6.7.16	Window 75 Standard Setting of Window 74 Parameters	117
6.7.17	Window 76 Setting the Switch-controlled Speed Reduction	117
6.7.18	Window 77 Standard setting of window 76 ParameterS	118
6.7.19	window 78 setting the discharge indicator Function	118
6.7.20	Window 79 Standard Setting of Window 78 Parameters	118
6.6.21	Window 8 General Joystick Calibration	118
6.6.22	Window 81 Auxiliary Hydraulics Joystick Calibration	118
6.6.23	Window 82 Making the Hydraulic System Pressureless	118
6.6.24	Window 83 Pump Motor Shutoff	118
7	Working hydraulics	1
7.1	Valve block	2
7.1.1	Single auxiliary hydraulics	2
7.1.2	Double auxiliary hydraulics	3
7.2	Maintenance and emergency functions of working hydraulics	4
7.2.1	Tilting the mast manually	4
7.2.2	Lowering the fork carriage manually	4
7.2.3	Making the hydraulic system pressureless	4
7.3	Hydraulic circuit diagram	6
7.4	Fine filter	8

Service Training

Table of content

Page 5

9	Optional Equipment	1
9.1	Console for Optional Equipment	2
9.2	Voltage Converter	3
9.3	Fuses	5
9.4	Wiring Diagram for Optional Equipment	6



Table of content

Page 6


Service Training

6 ELECTRICAL SYSTEM


6.1 CONTROL SYSTEM FOR LDC TRACTION DRIVE UNIT

The use of shunt motors as drive motors offers the following advantages:

- Change of direction possible without direction of travel contactors
- Active current operation without contactors
- Simple optional weakening of field without additional components
- Improved cornering ability
- Improved temperature monitoring in the power unit
- Stable speed maintained with different loads



In the shunt motor, the field winding is not connected in series with the armature winding. The field winding is controlled via its own power unit. According to the polarity and the flow of the current in the field winding, the rpm speed and the direction of rotation of the motor can be controlled. The direction of the current in the armature winding always remains the same (with the exception of the braking operation).




6.1.1 OPERATING PRINCIPLE

The shunt control operates with a clock (or cycle) frequency of 16 kHz. Since the activation of the direction of travel is controlled via the exciter field, no contactors are required for the direction of travel. In the electrical system, there are two power units which drive the three motors. In the power unit A1, the main current unit for the left traction motor and the pump motor is integrated. The power unit 1A1 includes the main current unit for the right traction motor.

The system is activated via the drive electronics 1A2. A closing (switch-on) contactor K1 is added for the complete electrical system; this contactor is activated after the key switch has been switched on.

To control the motor speed, the armature voltage is controlled according to the operation of the accelerator, via the bottom transistor and the exciter field. This occurs in proportion to the travel speed and the motor current.


When accelerating, the armature voltage and the exciter voltage are increased. After reaching about 8 km/h, the exciter current is kept constant so that there is a constant current of approx. 33 A in the exciter field. The voltage at the armature winding continues to increase, until at about 14 km/h the full battery voltage is applied at the armature winding. After reaching about 10 km/h, the exciter current is simultaneously reduced until at a speed of approximately 16 km/h, there is an exciter current of 9 A. With a high torque load and low speed, a field current in the shaded area of the graph is possible.



Service Training

When the truck is stationary, the exciter coil receives an alternating current, in order to prevent a residual magnetism in the exciter winding. If the truck started to move, a residual magnetism would cause a further acceleration of the traction motors. The alternating current is produced by the rapidly alternating switching on of the field transistor bridge.

6.1.1.1 COMPONENTS OF THE ELECTRICAL SYSTEM




Main current fuse F1
Main current fuse F2

250A Traction motor 1M1
355A Traction motor 1M2, pump motor 2M1

6.1.1.2 CONTROL CURRENT FUSES

1	6F1	10A	Discharge indicator
2	1F2	10A	Control current fuse in front of the key switch
3	4F3	5A	Horn
4	1F4	5A	Fan
5	1F5	5A	Composite instrument, traction control and pump control unit
6	1F6	5A	Charging circuit
7	F7	5A	Charging circuit
8	F8	5A	Charging circuit




NOTE: Only use original Linde replacement fuses with high voltage design.



6.1.1.3 POSITIONS OF THE CONNECTORS IN THE E25/30 TRUCK

X1	Connector connector, 42 pin	connecting connector, main/end cable loom	in the counterweight, electric installation on left
X2	Connector connector, 10 pin	connecting connector, main/end cable loom	in the counterweight, electric installation on left
X3	Connector connector, 2 pin	microswitch, S2, emergency off	in the counterweight, electric installation underneath the LLC
X4	Connector connector, 2 pin	connector connector, contactor coil K1	in the counterweight, electric installation on left
X5	Connector connector, 2 pin	connector connector, feed contact switch 3S1, steering	on the steering control valve
X7	Connector connector, 4 pin	connector connector, steering potentiometer 3B1	in the counterweight, electric installation underneath the LLC
X8	Connector connector, 6 pin	connector connector, voltage transformer U1	in the counterweight, electric installation on the left
X9	Connector connector, 3 pin	connector connector, overhead guard switch S4	driver's overhead guard, behind steering column covering
X10	Battery connector		in the counterweight, electric installation on the right
X11	Connector connector, 29 pin	connector connector, drive electronics, power unit A1	in the counterweight, electric installation on the left
X12	Connector connector, 6 pin	connector connector, charge/discharge circuit	in the counterweight, electric installation on left
X31	Battery negative point	central battery negative point, conductor rail	conductor rail between power units A1 and 1A1
1X1	Connector connector, 4 pin	connector connector, rpm speed sensor 1B1	fastening plate on right traction motor
1X2	Connector connector, 4 pin	diagnostic connector, drive electronics	behind switch covering to the left of the steering column
1X3	Connector connector, 4 pin	connector connector, rpm speed sensor 1B2	fastening plate on the left traction motor
1X4	Connector connector, 3 pin	connector connector, hand brake switch 1S4	above control valve, working hydraulics
1X5	Connector connector, 3 pin	connector connector, brake pedal switch 1S5	underneath bottom plate, driver's overhead guard
1X6	Connector connector, 2 pin	connector connector, seat switch S3	at the back, on the right, on the driver's seat
1X7	Connector connector, 4 pin	connector connector, right traction motor 1M1	fastening plate on the right traction motor
1X8	Connector connector, 4 pin	connector connector, left traction motor 1M2	fastening plate on the left traction motor
1X10	Connector connector, 4 pin	connector connector, accelerator 1A4	underneath bottom plate, driver's overhead guard
1X11	Connector connector, 42 pin	connector connector, drive electronics 1A2	in the counterweight, electric installation in the middle
1X12	Connector connector, 42 pin	connector connector, drive electronics 1A2	in the counterweight, electric installation in the middle
1X13	Connector connector, 16 pin	connector connector, power section 1A1	in the counterweight, electric installation on the right
2X1	Connector connector, 42 pin	connector connector LLC 2A1	in the counterweight, electric installation on the right
2X2	Connector connector, 4 pin	connector connector, rpm speed sensor 2B8	on the fastening plate, pump motor
2X3	Connector connector, 6 pin	connector connector, joystick 2B1	underneath the joystick arm rest
2X4	Connector connector, 6 pin	connector connector, joystick 2B2	underneath the joystick arm rest
2X5	Connector connector, 4 pin	diagnostic connector LLC	behind switch covering to the left of the steering column
2X6	Connector connector, 4 pin	connector connector, pump motor 2M1	on the fastening plate, pump motor
4X1	Connector connector, 2 pin	connector connector, horn switch 4S1	behind switch cover on the right of the steering column
5X13	Connector connector, 3 pin	connector connector, flashing pilot indicator	behind switch cover on the right of the steering column
6X1	Connector connector, 4 pin	diagnostic connector, composite instrument	behind switch cover on the left of the steering column
6X9	Connector connector, 36 pin	connector connector, composite instrument 6P2	to the right of the steering column on the composite instrument
9X7	Connector connector, 4 pin	connector connector, power supply SA	at the back on the right, underneath driver's overhead guard
9X8	Connector connector, 6 pin	connector connector, single pedal direction switch 1S13	behind switch cover to the right of the steering column
9X10	Connector connector, 2 pin	connector connector, ventilator 9M1	at fan for traction and pump motor
9X11	Connector connector, 2 pin	connector connector, ventilator 9M2	in counterweight, electrical system on the left
9X12	Connector connector, 2 pin	connector connector, ventilator 9M3	in wheel box on left



E01 / Chapter 1
336 804 4601.0600

33606-73

6.1.2 POWER UNITS

The truck has two separate power units. The power unit 1A1 contains the power transistors for the armature winding and field winding of the right traction motor 1M1. The power unit A1 contains the power transistors for the armature winding and field winding of the left traction motor 1M2, and the power transistor for the pump motor 2M1. The power units have a connecting connector linking them to the control unit. The main current connections of the power transistors are connected to the outside via stud bolts. The motor leads are connected to the stud bolts.

The power units contain the actual current indicators which monitor the armature current of the relevant motor. Heat sensors are fitted near the power transistors, and these sensors monitor the temperature of the transistors. If the transistor temperature rises above 70°C, this will produce a continuous reduction of the armature current of the traction motors. At a temperature of 80 °C, the armature current is reduced to 50% and the truck only travels at creep speed. The temperature and the related reduction in power or cut-out is monitored by the drive electronics.

The intermediate circuit capacitors are located under the covering. The capacitors are required to act as buffers for the battery. In principle, the intermediate circuit capacitors shift the battery directly the motors, and thereby compensate for the inductivity of the electric leads.

The complete activation logic for the transistors and monitoring system is integrated with the power unit. This means that the power unit monitors itself, and in the event of a fault, it sends a signal (separately for the traction motor and the pump motor) to the traction control or pump control unit. The signal (approval from the power unit) can be monitored in window (6).

Assembly of the power units:

- Remove any dust and foreign bodies from the power module's fastening surface in the area of the dissipator.
- With a spatula, apply a **very thin** layer of thermal conducting paste WP12 to the power module's fastening surface to reduce the thermal contact resistance (heat transmission resistance) between the power module and counterweight.
- Correctly position the power module.
- Tighten the hexagon socket screws M10 x 35. Tightening torque 49 Nm.
- Fit the connectors.


NOTE:



The hexagon socket screws, M10 x 35, are to be tightened with the correct tightening torque to ensure the correct positioning of the power module.

After 30 min, retighten the opposite hexagon socket screws as the heat dissipating compound can still change during this time.

6.1.2.1 POWER UNIT A1



Main circuit connections


- 1 Negative connection for the power unit (source for the power transistors)
- 2 Positive connection for the power unit
- 3 Drain connection for the power transistor for pump motor D2
- 4 Field winding connection E1 for the left traction motor
- 5 Armature connection A2 for the left traction motor
- 6 Field winding connection E2 for the left traction motor
- 7 Armature connection A1 for the left traction motor

Connector allocation X11

- 1 PWM transistor signal for pump motor 2M1
- 2 0 V for PWM signal from transistor for pump motor 2M1
- 3 Not allocated
- 4 Not allocated
- 5 Not allocated
- 6 Actual current indicator signal for traction motor 1M2
- 7 0V for actual current transmitter 1M2
- 8 Not allocated
- 9 Not allocated
- 10 Not allocated
- 11 Internal battery voltage
- 12 PWM transistor signal for armature at top of traction motor 1M2

- 13 0V for PWM transistors signal for traction motor 1M2
- 14 Voltage of armature at top of traction motor 1M2
- 15 Voltage of armature at bottom of traction motor 1M2
- 16 Chip temperature 1M2
- 17 Heat sensor for chip temperature 2M1
- 18 Not allocated
- 19 0V for heat sensor for chip temperature 2M1
- 20 PWM transistor signal for armature at bottom of traction motor 1M2
- 21 PWM transistor signal for field S9/S12 of traction motor 1M2
- 22 PWM transistor signal for field S11/S10 of traction motor 1M2
- 23 Not allocated
- 24 Not allocated
- 25 Fault signal for power unit 1M2
- 26 Fault signal for power unit 2M1
- 27 Not allocated
- 28 +24V power supply from voltage transformer
- 29 Negative power supply from voltage transformer

6.1.2.2 POWER UNIT 1A1



Main circuit connections

- 1 Negative connection for the power unit (source for the power transistors)
- 2 Positive connection for the power unit
- 8 Armature connection A1 for the right traction motor
- 9 Field winding connection E2 for the right traction motor
- 10 Armature connection A2 for the right traction motor
- 11 Field winding connection E1 for the drive traction motor

Connector allocation 1X13

- 1 PWM transistor signal for armature at top of traction motor 1M1
- 2 PWM transistor signal for armature at bottom of traction motor 1M1
- 3 0V for heat sensor for chip temperature and actual current indicator 1M1
- 4 Actual current indicator signal for traction motor 1M1
- 5 Voltage of armature at bottom of traction motor 1M1
- 6 Fault signal for power unit 1M1
- 7 Not allocated
- 8 Internal battery voltage
- 9 PWM transistor signal for field S5/S8 of traction motor 1M1
- 10 PWM transistor signal for field S7/S6 of traction motor 1M1
- 11 0V for PWM transistors signal for traction motor 1M1
- 12 Not allocated
- 13 Voltage of armature at top of traction motor 1M1
- 14 Chip temperature 1M1
- 15 +24V power supply from voltage transformer
- 16 Negative power supply from voltage transformer




6.1.3 MAIN CURRENT UNIT

6.1.3.1 SWITCHING ON AND CHARGING THE INTERMEDIATE CIRCUIT CAPACITORS

The intermediate circuit capacitors are located in the two power units. In order to prevent a very strong charging current flowing across the contactor contacts when the main contactor K1 is switched on, the capacitors are pre-charged before the contacts of K1 are closed.

This pre-charging is carried out via a charging circuit or via the relays K2 and K3. The charging circuit with the charging and discharging resistors is located in an aluminium housing in the counterweight, together with the electrical system. When the key switch is turned on, the relay K3 is activated via the voltage transformer U1. The relay K2 is directly activated by the drive electronics 1A2. As soon as the two relays are activated, the capacitors in the power units can charge up via the charging resistors 1R1 and R1.

Only when the intermediate circuit capacitors are charged (this is detected via the connection to 1X11:11 and 1X11:1 of the drive electronics) can the activation of the main contactor K1 take place. After that relay K2 is switched off again, since the capacitors are now receiving their charging voltage via the contacts of the main current contactor K1.



3350206-30