


Mazda 323 4-WHEEL DRIVE

Workshop Manual Supplement



- JMZ BG8262 00
- JMZ BG8362 00
- JMZ BG82F2 00
- JMZ BG83F2 00
- JMZ BG83H2 00
- JMO BG10P1 00

12/89 1229-10-89L

mazda

Europe, Australia

Mazda 323 4-Wheel Drive Workshop Manual Supplement

FOREWORD

This is a supplement to the workshop manual(s) shown below. This supplement describes service procedures of new or modified mechanical and/or electrical systems. For service procedures and important safety notices not contained in this supplement, please refer to the previous workshop manual.

Workshop Manual:
Form No.1203-10-89F (Vol.1) Europe
1204-10-89F (Vol.1) Australia
1206-10-89F (Vol.2)

All information in this supplement was the latest available at the time of printing, all alterations related to modifications will be notified by Service Bulletin.

**Mazda Motor Corporation
HIROSHIMA, JAPAN**

APPLICATION:

This manual is applicable to vehicles beginning with the Vehicle Identification Numbers (VIN) shown on the following page.

CONTENTS

Title	Section	
	Current	New
General Information	G	GI
Pre-Delivery Inspection and Scheduled Maintenance	0	A
Engine	1	B1
		B2
		B3
Lubrication System	2	D
Cooling System	3	E
Fuel and Emission Control System	4	F1
		F2
		F3
		F4
		F5
Engine Electrical System	5	G
Clutch	6	H
Manual Transaxle	7	J1
		J2
		J3
Automatic Transaxle	7	K1
		K2
		K3
Propeller Shaft	8	L
Front and Rear Axles	9	M
Steering System	10	N
Braking System	11	P
Wheels and Tires	12	Q
Suspension	13	R
Body	14	S
Body Electrical System	15	T
Heater and Air Conditioner System	16	U
Technical Data	30	TD
Special Tools	40	ST
Parts Index	—	PI
Wiring Diagram	50	Z

This manual explains only the sections marked with shadows ()

VEHICLE IDENTIFICATION NUMBERS (VIN)

Europe

JMZ BG8262 00 100001 ~
JMZ BG8362 00 100001 ~
JMZ BG82F2 00 100001 ~
JMZ BG83F2 00 100001 ~
JMZ BG83H2 00 100001 ~

Australia

JM0 BG10P1 00 100001 ~

GENERAL INFORMATION

IMPORTANT INFORMATION	GI- 2
BASIC ASSUMPTIONS	GI- 2
SAFETY RISK	GI- 2
POSSIBLE LOSS OF WARRANTY	GI- 2
WARNING ON LUBRICANTS AND GREASES	GI- 2
HOW TO USE THIS MANUAL	GI- 3
PREPARATION	GI- 3
REPAIR PROCEDURE	GI- 3
SYMBOLS	GI- 4
NOTES, CAUTIONS, AND WARNINGS	GI- 4
FUNDAMENTAL PROCEDURES	GI- 4
PROTECTION OF THE VEHICLE	GI- 4
A WORD ABOUT SAFETY	GI- 5
PREPARATION OF TOOLS AND MEASURING EQUIPMENT	GI- 5
SPECIAL TOOLS	GI- 5
REMOVAL OF PARTS	GI- 5
DISASSEMBLY	GI- 5
REASSEMBLY	GI- 6
ADJUSTMENTS	GI- 7
RUBBER PARTS AND TUBING	GI- 7
JACK AND SAFETY STAND POSITIONS	GI- 8
VEHICLE LIFT (2-SUPPORT TYPE) POSITIONS	GI- 8
TOWING	GI- 9
IDENTIFICATION NUMBER LOCATIONS	GI-10
UNITS	GI-10
ABBREVIATIONS	GI-10
CAUTION	GI-11
INSTALLATION OF A MOBILE TWO-WAY RADIO SYSTEM	GI-11
REMOVAL OF IGNITION KEY ON AUTOMATIC TRANSAXLE MODEL	GI-11
ELECTRICAL TROUBLESHOOTING TOOLS	GI-12
CAUTION WITH ELECTRICAL PARTS	GI-13

IMPORTANT INFORMATION**BASIC ASSUMPTIONS**

This workshop manual assumes that you have certain special tools that are necessary for the safe and efficient performance of service operations on Mazda vehicles and that you know how to use them properly. It also assumes that you are familiar with automobile systems and basic service and repair procedures. You should not attempt to use this manual unless these assumptions are correct and you understand the consequences described below.

SAFETY RISK

This manual contains certain notes, warnings, and other precautionary information that you should carefully read and follow to reduce the risk of personal injury to yourself or others and the risk of improper service that may damage the vehicle or render it unsafe. If there is no such information in regard to any specific service method, this does not mean there is no possibility that personal safety or vehicle safety will be jeopardized by the use of incorrect methods or tools.

POSSIBLE LOSS OF WARRANTY

The manufacturer's warranty on Mazda vehicles and engines can be voided if improper service or repairs are performed by persons other than those at an Authorized Mazda Dealer.

WARNING ON LUBRICANTS AND GREASES

Avoid all prolonged and repeated contact with mineral oils, especially used oils. Used oils contaminated during service (e.g., engine sump oils) are more irritating and more likely to cause serious effects, including skin cancer, in the event of gross and prolonged skin contact.

Wash skin thoroughly after work involving oil.

Protective hand cleaners may be of value provided they can be removed from the skin with water. Do not use gasoline, paraffin, or other solvents to remove oil from the skin.

Lubricants and greases may be slightly irritating to the eyes.

Repeated or prolonged skin contact should be avoided by wearing protective clothing if necessary. Particular care should be taken with used oils and greases containing lead. Do not allow work clothing to be contaminated with oil. Dry clean or launder such clothing at regular intervals.

9MUGIX-002

HOW TO USE THIS MANUAL

HOW TO USE THIS MANUAL

PREPARATION


PREPARATION points out the needed **Special Service Tool (SST)** for the service operation that it proceeds. Gather all necessary **SST** before beginning work.


Example:

MANUAL STEERING

PREPARATION

SST

49 0118 850C		For removal of tie-rod end	49
Puller, ball joint		in-	bo-


SST NUMBER	SST ILLUSTRATION	USAGE
49 0118 850C		For removal of tie-rod end
Puller, ball joint		

03UGIX-006

REPAIR PROCEDURE

1. Most repair operations begin with an overview illustration. It identifies the components, shows how the parts fit together, and visual parts inspections. If a damaged or worn part is found, repair or replace it as necessary.
2. Expendable parts, tightening torques, and symbols for oil, grease, and sealant are shown in the overview illustration.
3. Pages related to service procedures are shown under the illustration. Refer to this information when servicing the related part.

Example:



SHOWS EXPENDABLE PARTS

SHOWS APPLICATION POINT OF OIL, ETC.

SHOWS TIGHTENING TORQUE SPECIFICATION *2

SHOWS TIGHTENING TORQUE UNIT

SHOWS VISUAL INSPECTION INFORMATION

SHOWS RELATED PAGE FOR SERVICE

<p>1. Bolt</p> <p>2. Lock plate</p> <p>3. Bearing cup</p> <p>4. Adjusting screw</p> <p>5. Bearing outer race</p> <p>6. Locknut</p> <p>7. Washer</p> <p>8. Companion flange</p> <p>9. REPLACE</p> <p>10. REPAIR</p> <p>11. OIL</p> <p>12. GREASE</p> <p>13. SEALANT</p> <p>14. INSPECT FOR WEAR OR DAMAGE</p> <p>15. TIGHTENING TORQUE</p> <p>16. TIGHTENING TORQUE UNIT</p> <p>17. SELECTIVE</p> <p>18. DRIVE PINION</p> <p>19. SPACER</p> <p>20. BEARING INNER RACE</p> <p>21. ADJUSTING SCREW</p> <p>22. LOCK PLATE</p> <p>23. LOCKNUT</p> <p>24. WASHER</p> <p>25. COMPANION FLANGE</p> <p>26. BEARING OUTER RACE</p> <p>27. BEARING INNER RACE</p> <p>28. BEARING OUTER RACE</p> <p>29. BEARING INNER RACE</p> <p>30. BEARING OUTER RACE</p> <p>31. BEARING INNER RACE</p> <p>32. BEARING OUTER RACE</p> <p>33. BEARING INNER RACE</p> <p>34. BEARING OUTER RACE</p> <p>35. BEARING INNER RACE</p> <p>36. BEARING OUTER RACE</p> <p>37. BEARING INNER RACE</p> <p>38. BEARING OUTER RACE</p> <p>39. BEARING INNER RACE</p> <p>40. BEARING OUTER RACE</p> <p>41. BEARING INNER RACE</p> <p>42. BEARING OUTER RACE</p> <p>43. BEARING INNER RACE</p> <p>44. BEARING OUTER RACE</p> <p>45. BEARING INNER RACE</p> <p>46. BEARING OUTER RACE</p> <p>47. BEARING INNER RACE</p> <p>48. BEARING OUTER RACE</p> <p>49. BEARING INNER RACE</p> <p>50. BEARING OUTER RACE</p> <p>51. BEARING INNER RACE</p> <p>52. BEARING OUTER RACE</p> <p>53. BEARING INNER RACE</p> <p>54. BEARING OUTER RACE</p> <p>55. BEARING INNER RACE</p> <p>56. BEARING OUTER RACE</p> <p>57. BEARING INNER RACE</p> <p>58. BEARING OUTER RACE</p> <p>59. BEARING INNER RACE</p> <p>60. BEARING OUTER RACE</p> <p>61. BEARING INNER RACE</p> <p>62. BEARING OUTER RACE</p> <p>63. BEARING INNER RACE</p> <p>64. BEARING OUTER RACE</p> <p>65. BEARING INNER RACE</p> <p>66. BEARING OUTER RACE</p> <p>67. BEARING INNER RACE</p> <p>68. BEARING OUTER RACE</p> <p>69. BEARING INNER RACE</p> <p>70. BEARING OUTER RACE</p> <p>71. BEARING INNER RACE</p> <p>72. BEARING OUTER RACE</p> <p>73. BEARING INNER RACE</p> <p>74. BEARING OUTER RACE</p> <p>75. BEARING INNER RACE</p> <p>76. BEARING OUTER RACE</p> <p>77. BEARING INNER RACE</p> <p>78. BEARING OUTER RACE</p> <p>79. BEARING INNER RACE</p> <p>80. BEARING OUTER RACE</p> <p>81. BEARING INNER RACE</p> <p>82. BEARING OUTER RACE</p> <p>83. BEARING INNER RACE</p> <p>84. BEARING OUTER RACE</p> <p>85. BEARING INNER RACE</p> <p>86. BEARING OUTER RACE</p> <p>87. BEARING INNER RACE</p> <p>88. BEARING OUTER RACE</p> <p>89. BEARING INNER RACE</p> <p>90. BEARING OUTER RACE</p> <p>91. BEARING INNER RACE</p> <p>92. BEARING OUTER RACE</p> <p>93. BEARING INNER RACE</p> <p>94. BEARING OUTER RACE</p> <p>95. BEARING INNER RACE</p> <p>96. BEARING OUTER RACE</p> <p>97. BEARING INNER RACE</p> <p>98. BEARING OUTER RACE</p> <p>99. BEARING INNER RACE</p> <p>100. BEARING OUTER RACE</p>	<p>16. Bearing inner race</p> <p>Removal page M-22</p> <p>Inspect for damage or rough rotation</p> <p>Installation page M-24</p> <p>17. Spacer</p> <p>18. Drive pinion</p> <p>Removal page M-21</p> <p>Inspect splines and teeth for wear or damage</p> <p>Adjustment of height page M-22</p> <p>Adjustment of height page M-24</p>
---	---







9MUGIX-034

*1: The numbering (ex. ①) shows service procedure.

*2: Units shown in N·m (m·kg, ft·lb) unless otherwise specified.

SYMBOLS

There are six symbols indicating oil, grease, and sealant. These symbols show the points of applying such materials during service.

Symbol	Meaning	Kind
	Apply oil	New engine oil or gear oil as appropriate
	Apply brake fluid	Only brake fluid
	Apply automatic transmission fluid	Only ATF
	Apply grease	Appropriate grease
	Apply sealant	Appropriate sealant
	Apply petroleum jelly	Appropriate petroleum jelly

05UGIX-005


Note

- When special oil or grease is needed, this is shown in the illustration.

NOTES, CAUTIONS, AND WARNINGS

As you read through the procedures, you will come across NOTES, CAUTIONS, and WARNINGS. Each one is there for a specific purpose. **NOTES** give you **added information** that will help you to complete a particular procedure. **CAUTIONS** are given to prevent you from making an error that could **damage the vehicle**. **WARNINGS** remind you to be especially careful in those areas where carelessness can cause **personal injury**. The following list contains some general WARNINGS you should follow when you work on a vehicle.

9MUGIX-036




9MUGIX-037

FUNDAMENTAL PROCEDURES

PROTECTION OF THE VEHICLE

Always be sure to cover fenders, seats, and floor areas before starting work.




9MUGIX-003

A WORD ABOUT SAFETY

The following precautions must be followed when jacking up the vehicle.

1. Block the wheels.
2. Use only the specified jacking positions.
3. Support the vehicle with safety stands.


Start the engine only after making certain the engine compartment is clear of tools and people.



9MUGIX-038

PREPARATION OF TOOLS AND MEASURING EQUIPMENT


Be sure that all necessary tools and measuring equipment are available before starting any work.



47U0GX-005

SPECIAL TOOLS


Use special tools when they are required.



47U0GX-006

REMOVAL OF PARTS


While correcting a problem, try also to determine its cause. Begin work only after first learning which parts and subassemblies must be removed and disassembled for replacement or repair.



9MUGIX-039

DISASSEMBLY


If the disassembly procedure is complex, requiring many parts to be disassembled, all parts should be disassembled in a way that will not affect their performance or external appearance and identified so that reassembly can be performed easily and efficiently.



9MUGIX-040

1. Inspection of parts

When removed, each part should be carefully inspected for malfunctioning, deformation, damage, and other problems.




9MUGIX-041

2. Arrangement of parts

All disassembled parts should be carefully arranged for re-assembly.


Be sure to separate or otherwise identify the parts to be replaced from those that will be reused.



47U0GX-010

3. Cleaning parts for reuse

All parts to be reused should be carefully and thoroughly cleaned in the appropriate method.



9MUGIX-004

REASSEMBLY


Standard values, such as torques and certain adjustments, must be strictly observed in the reassembly of all parts. Refer to STANDARD BOLT AND NUT TIGHTENING TORQUE in Section TD for tightening torques not mentioned in the main text.

If removed, these parts should be replaced with new ones:


- | | |
|----------------|-----------------|
| 1. Oil seals | 2. Gaskets |
| 3. O-rings | 4. Lock washers |
| 5. Cotter pins | 6. Nylon nuts |

Depending on location:

1. Sealant should be applied to gaskets.
2. Oil should be applied to the moving components of parts.
3. Specified oil or grease should be applied at the prescribed locations (such as oil seals) before reassembly.




9MUGIX-042



67U0GX-002

ADJUSTMENTS

Use suitable gauges and/or testers when making adjustments.



9MUGIX-005

RUBBER PARTS AND TUBING

Prevent gasoline or oil from getting on rubber parts or tubing.


GI JACK AND SAFETY STAND POSITIONS/VEHICLE LIFT (2-SUPPORT TYPE) POSITIONS

JACK AND SAFETY STAND POSITIONS

FRONT END

Jack position:


At the front crossmember



03UGIX-007

Safety stand positions:

On both sides of the body frame




03UGIX-008

REAR END

Jack position:

At the center of the rear crossmember (2WD)


At the rear differential (4WD)



03UGIX-801

Safety stand positions:

On both sides of the body frame




03UGIX-010

VEHICLE LIFT (2-SUPPORT TYPE) POSITIONS

FRONT END

Frame

Side sills




9MUGIX-010

REAR END

Frame

Side sills



9MUGIX-011

TOWING

TOWING

Proper towing equipment is necessary to prevent damage to the vehicle.

Laws and regulations applicable to vehicles in tow must always be observed.


As a general rule, towed vehicles should be pulled with the driving wheels off the ground. If excessive damage or other conditions prevent towing the vehicle with the driving wheels off the ground, use wheel dollies.

With either automatic or manual transaxle:


1. Set the ignition switch in the ACC position;
2. Place the selector lever or shift lever in N (Neutral);
3. Release the parking brake.

Caution


- Do not tow the vehicle backward with driving wheels on the ground. This may cause internal damage to the transaxles.
- Do not use the hook loops under the front and rear of the vehicle for towing purposes. These hook loops are designed ONLY for transport tie-down. If tie-down hook loops are used for towing, the front/rear bumper will be damaged.




03UGIX-002



TIE-DOWN HOOKS — FRONT




TIE-DOWN HOOKS — REAR




IDENTIFICATION NUMBER LOCATIONS


VEHICLE IDENTIFICATION NUMBER (VIN)



AUTOMATIC TRANSAXLE MODEL AND NUMBER



ENGINE MODEL AND NUMBER



9MUGIX-015

UNITS

N·m (m·kg or cm·kg, ft·lb or in·lb).....	Torque
rpm.....	Revolutions per minute
A.....	Ampere(s)
V.....	Volt(s)
Ω.....	Ohm(s) (resistance)
kPa (kg/cm ² , psi).....	Pressure (usually positive)
mmHg (inHg).....	Pressure (usually negative)
W.....	Watt
liters (US qt, Imp qt)....	Volume
mm (in).....	Length

89U0GX-006

ABBREVIATIONS

ABDC.....	After bottom dead center
A/C.....	Air conditioner
ACC.....	Accessories
ATX.....	Automatic transaxle
ATDC.....	After top dead center
ATF.....	Automatic transmission fluid
BAC.....	Bypass air control
BBDC.....	Before bottom dead center
BTDC.....	Before top dead center
CPU.....	Central processing unit

EC-AT.....	Electronically-controlled automatic transmission
ECU.....	Engine control unit
EGI.....	Electronic gasoline injection
E/L.....	Electrical load
EX.....	Exhaust
IC.....	Integrated circuit
IGN.....	Ignition
IN.....	Intake
INT.....	Intermittent
ISC.....	Idle speed control
LH.....	Left hand
M.....	Motor
MIL.....	Malfunction indicator lamp
MTX.....	Manual transaxle
OD.....	Overdrive
OFF.....	Switch off
ON.....	Switch on
PCV.....	Positive crankcase ventilation
PRC.....	Pressure regulator control
P/S.....	Power steering
P/W.....	Power window
RH.....	Right hand
SST.....	Special service tool
ST.....	Start
SW.....	Switch
TDC.....	Top dead center
4WD.....	4-wheel drive

03UGIX-802


CAUTION

INSTALLATION OF MOBILE TWO-WAY RADIO SYSTEM


If a mobile two-way radio system is installed improperly or if a high-powered type is used, the EGI system and other systems may be affected.

When the vehicle is to be equipped with a mobile two-way radio, observe the following precautions:

1. Install the antenna at the farthest point from control units.
2. Install the antenna feeder as far as possible from the control unit harnesses (**at least 30 cm [11.8 in]**).
3. Ensure that the antenna and feeder are properly adjusted.
4. Do not install a high-powered mobile two-way radio system.




05UGIX-013




03UGIX-005

REMOVAL OF IGNITION KEY ON AUTOMATIC TRANSAXLE MODEL


The selector lever must be in P (PARK) to turn the ignition key to the OFF position. If the switch seems to be off but the key cannot be removed, the switch may still be in the ACC position, or the selector lever may not be in P (PARK). Shift the selector lever to P (PARK), and turn the ignition key to the LOCK position. The key should now be free for removal.




9MUGIX-019




9MUGIX-020



9MUGIX-021



05UGIX-021



9MUGIX-045

ELECTRICAL TROUBLESHOOTING TOOLS

Test Light

The test light, as shown in the figure, uses a 12V bulb. The two lead wires should be connected to probes. The test light is used for simple voltage checks and for checking for short circuits.

Caution

- When checking the control unit, never use a bulb over 3.4W.

Jumper Wire

The jumper wire is used for testing by shorting across switch terminals and ground connections.

Caution

- Do not connect a jumper wire from the power source line to a body ground; this may cause burning or other damage to harnesses or electronic components.

Voltmeter

The DC voltmeter is used to measure of circuit voltage. A voltmeter with a range of 15V or more is used by connecting the positive (+) probe (red lead wire) to the point where voltage is to be measured and the negative (-) probe (black lead wire) to a body ground.

Diagnosis Connector

Insert the probe into the service hole when connecting a jumper wire to the diagnosis connector.

Caution

- Do not insert the jumper wire probe into the diagnosis connector terminal, which may damage the terminal.

Ohmmeter

The ohmmeter is used to measure the resistance between two points in a circuit and also to check for continuity and diagnosis of short circuits.

Caution


- Do not attempt to connect the ohmmeter to any circuit to which voltage is applied; this may burn or otherwise damage the ohmmeter.

CAUTION

CAUTION WITH ELECTRICAL PARTS

Battery Cable

Before disconnecting connectors or replacing electrical parts, disconnect the negative battery cable.




9MUGIX-022

Connectors


Removal of connector

Never pull on the wiring harness when disconnecting connectors.



9MUGIX-023


Connectors can be removed by pressing or pulling the lock lever as shown.



9MUGIX-024

Locking of connector


When locking connectors, make sure to listen for a click that will indicate they are securely locked.




9MUGIX-025

Inspection


1. When a tester is used to check for continuity or to measure voltage, insert the tester probe from the wire harness side.




03UGIX-011





05UGIX-028



9MUGIX-027



9MUGIX-026



9MUGIX-030

2. Check the terminals of waterproof connectors from the connector side, as they cannot be accessed from the wire harness side.

Caution

- Use fine wire to prevent damage to the terminal.
- Do not damage the terminal when inserting the tester lead.

Terminals Inspection

Pull lightly on individual wires to check that they are secured in the terminal.

Replacement of terminals

Use the appropriate tools to remove the terminal as shown. When installing the terminal, be sure to insert it until it locks securely.

< Female >

Insert a thin piece of metal from the terminal side of the connector, and then, with the terminal locking tab pressed down, pull the terminal out from the connector.


< Male >

Same as the female type.


Sensors, Switches, and Relays

Handle sensors, switches, and relays carefully. Do not drop them or strike them against other parts.


CAUTION



9MUGIX-031



9MUGIX-032



9MUGIX-029

Fuse Replacement


1. When replacing a fuse, be sure to replace it with one of specified capacity.
If a fuse again fails after it has been replaced, the circuit probably has a short circuit and the wiring should be checked.
2. Be sure the negative battery terminal is disconnected before replacing a main fuse (80A).
3. When replacing a pullout fuse, use the fuse puller supplied in the fuse box cover.

Wiring Harness

Wiring color codes

Two-color wires are indicated by a two-color code symbol. The first letter indicates the base color of the wire and the second the color of the stripe.

CODE	COLOR	CODE	COLOR
B	Black	O	Orange
BR	Brown	P	Pink
G	Green	R	Red
GY	Gray	V	Violet
L	Blue	W	White
LB	Light Blue	Y	Yellow
LG	Light Green	—	—



PRE-DELIVERY INSPECTION AND SCHEDULED MAINTENANCE SERVICES

PRE-DELIVERY INSPECTION TABLE	A- 2
SCHEDULED MAINTENANCE SERVICES (Australia)	A- 3
SCHEDULED MAINTENANCE SERVICES (Europe)	A- 5

93G0AX-701