#### Mazda Rx 7 Front And Rear Axles Shop Repair Manual

Full download: http://manualplace.com/download/mazda-rx-7-front-and-rear-axles-shop-repair-manual/

This file is available for free download at <u>http://www.iluvmyrx7.com</u>

This file was not scanned to deprive Mazda of any money - it was scanned due to the rareness of the original manuals and the overwhelming need of the RX-7 owner to have this information so that they can accurately troubleshoot problems. Perhaps if Mazda's dealerships could support the Rotary Engine it wouldn't be so necessary for the owners to do so.



Many thanks to Anh Diep for scanning this file.

This is the cut pages sample. Download all 42 page(s) at: ManualPlace.com

# FRONT AND REAR AXLES

ì

3

Ì


· •

	. М		2
OUTLINE	. M	_	3
SPECIFICATIONS			
TROUBLESHOOTING GUIDE	. М	_	3
FRONT AXLE	. М	-	4
PREPARATION	. М		4
WHEEL HUB / STEERING KNUCKLE	. М	-	4
REAR AXLE	. M	-	9
PREPARATION	. M		9
WHEEL HUB	. М	-	9
DRIVE SHAFT	. М	-1	4
PREPARATION	. M	1	4
DRIVE SHAFT (TRIPOD JOINT)	. M	-1	4
DIFFERENTIAL	. M	-2	2
PREPARATION			
DIFFERENTIAL OIL	. M	-2	3
OIL SEAL			
DIFFERENTIAL (TORQUE SENSING LSD)	. M	-2	7
	37U0M	X-0	01

Μ

## M

## INDEX



37U0MX-002

à

1. Front axle			
Preinspection	page	M	4
Removal / Inspection /	. 🗸		
Installation	page	М-	5
Disassembly / Inspection /			
Assembly	page	M	7
2. Rear axle			
Preinspection	page	M	9
Removal / Inspection /			
Installation	page	M-1	0
Disassembly / Inspection /	_		
Assembly	page	M-1	2
	•		

war compo ana na pravo mor

З.	Drive	shaft

.

υ.	Drive share		
	Preinspection	page	M14
	Removal / Installation	bage	M-15
	Overhaull	page	M18
4.	Differential		
	Differential oil	page	M23
	Oil seal	page	M–24
	Removal / Installation	page	M27
	Disassemebly / Inspection	page	M-30
	Assembly	page	M-34

- Manager and and the second

#### Mazda Rx 7 Front And Rear Axles Shop Repair Manual

Full download: http://manualplace.com/download/mazda-rx-7-front-and-rear-axles-shop-repair-manual/

## TROUBLESHOOTING GUIDE

### OUTLINE

)

#### SPECIFICATION

Engine / Trans		/ Transmission	13B		
item				MT	AT
Front as	cie	······			
Bearing type				Unitized angular ball bearing	
Rear ax					
Bearing	type			Unitized angular ball bearing	
Drive st	haft				
Туре				Constant v	elocity joint
Length (	(between cente	rs of joints)	mm {in}	484.2	{19.06}
Diamete	r		mm {in}	29.0 {1.14}	
Differen	ti <b>al</b>				
Туре				Torque sensing LSD	
Reductio	on gear			Hypoid gear	
Different	tial gear			Worm gear	
Reductio	on ratio			4.100	3.909
Number	of tooth	Ring gear		41	43
Number	Un teetri	Drive pinion gear		10	11
Ring gea	ar size		mm {in}	204.2 (8.038)	
	Grade mm {in}		mm {in}	API service GL-4 or 5	
Oil	Vincenity			Above- 18°C (0°F): SAE 90	
01	Viscosity			Below- 18°C	(0°F): SAE 80
	Capacity	L	{US at, Imp at}	1.30 {1.3	38, 1.14}

## TROUBLESHOOTING GUIDE

) -

Problem Possible Cause		Action	Page
Front axle			
Steering wheel vibration	Worn or damaged wheel bearing	Replace	M- 5
Pulls or one-sided braking	Worn or damaged wheel bearing	Replace	M- 5
Rear axle			
Abnormal noise Worn or damaged wheel bearing Replace Bent drive shaft Replace			M-12 M-15 M-15
Differential			
Abnormal noise	Insufficient differential oil Incorrect differential oil Worn or damaged side bearing Worn or damaged ring gear Worn or damaged drive pinion bearing Worn or damaged gear in LSD assembly Worn side gear spline Improperly adjusted drive pinion gear preload Improperly adjusted ring gear backlash Poor contact of ring gear teeth	Add oil Replace Replace Replace Replace gear case Replace Adjust Adjust Adjust	M-23 M-23 M-30 M-30 M-30 M-30 M-30 M-38 M-39 M-41
Heat bildup	Insufficient differential oil Add oil Insufficient drive pinion gear backlash Adjust Excessive bearing preload Adjust		M-23 M-39 M-38
Oil leakage	Dil leskage Excessive differential oil Remove oil Worn or damaged oil seal Replace Loose differential carrier Tighten or repair		M–23 M–24 M–30
No differential operation	Misassembled or damageo	Repair or replace	M-30

Μ

### This is the cut pages sample. Download all 42 page(s) at: ManualPlace.com