


DaimlerChrysler

Engine control with MR-PLD



ECU

Manual

Environment protection



DaimlerChrysler professes itself to an integrated environmental protection, which sets at the causes and on the environment into the business decisions includes all effects of the production processes and the product. Goals are the economical employment of resources and careful handling the natural bases of life, whose preservation serves humans and nature.

Printed in Germany changes of technical details of the controllers and engines opposite the data and illustrations of the available manual are reserved.

Reproduction, duplication or translation, also in part, are not permitted without written permission.

Editorship conclusion:
Customer service Powertrain Business unit PBE/MSS Responsible for contents: PBE/DEE



Printed on free from chlorine bleached paper

Document name: **PRODUKT DOCUMENTATION MR-PLD**

Project: DC - MR-PLD

Usage: Generally accessible

Validity: ECU versions C3 to D21

Pages: 150

File name: Product documentation MR-PLD_1.1.pdf

	name	dep.	fon	date	sign
processed	Scheuer, K.	PBE/DEE	52469	02.07.03	
checked					
waned					
responsible	Scheuer, K.	PBE/DEE	52469		

DAIMLERCHRYSLER Business division PowerSystems / Engines ALL RIGHTS RESERVATIONS - property of the DaimlerChrysler AG -	Product documentation engine elektronik MR-PLD	02. July 2003
Version 1.1	DaimlerChrysler Order-No.:	
This document is in copyright matters protected. Each utilization outside of the close borders of the copyright law is inadmissible without agreement of the DaimlerChrysler AG.		

LIST OF VERSIONS

version	date	processed	remark / description
1.1	05.02.03	Scheuer, K.	pre version (draft)

CHANGING US CONDITIONS

version	date	processed	modification
1.1	02.07.03	Scheuer, K.	assimilation to German version 1.1

<p style="text-align: center;">DAIMLERCHRYSLER</p> <p style="text-align: center;">Business division</p> <p style="text-align: center;">PowerSystems / Engines</p> <p style="text-align: center;">ALL RIGHTS RESERVATIONS - property of the DaimlerChrysler AG -</p>	<p style="text-align: center;">Product documentation</p> <p style="text-align: center;">engine elektronik</p> <p style="text-align: center;">MR-PLD</p>	<p style="text-align: center;">02. July 2003</p>
<p style="text-align: center;">Version 1.1</p>	<p style="text-align: center;">DaimlerChrysler Order-No.:</p>	
<p>This document is in copyright matters protected. Each utilization outside of the close borders of the copyright law is inadmissible without agreement of the DaimlerChrysler AG.</p>		

List of abbreviations	10
1. Safety	11
1.1. Symbols	11
1.2. General information	11
1.3. Use for the intended purpose	12
1.4. Personnel requirements	12
1.5. Conversions and modifications to the MR-PLD	12
1.6. Installation	12
1.7. Organizational measures.....	12
1.8. Safety precautions for engines with electronic control units	13
1.9. DaimlerChrysler original parts	14
1.10. Safety and backup running programm.....	14
2. General governor architecture.....	15
2.1. Standard model of engine control (MR-PLD) and vehicle electronics (FRE)	15
2.2. Features of the governor and interface module	16
2.2.1. VCU (ADM2) as FRE (vehicle electronics).....	16
2.2.2. ADM as FRE (vehicle electronics).....	17
3. MR-PLD engine control (pump-line-nozzle)	18
3.1. Brief description of the Diesel engine control unit PLD-MR	18
3.2. Control unit - operating principle	18
3.2.1. Overview of the telligent engine system BR 500	19
3.2.2. Overview of the telligent engine system BR 900	20
3.2.3. Control unit block diagram.....	21
3.2.4. PLD control unit as engine control (MR-PLD)	22
3.3. Functional description	23
3.3.1. Configuration.....	23
3.3.2. Flexibility of the concept.....	23
3.3.3. Control unit description of engine electronics MR-PLD	24
3.3.3.1. Safeguard /redundancy.....	24
3.3.3.2. Description of the inputs	24
3.3.3.3. Description of the outputs	24
3.3.4. Compound network between MR-PLD <=> FRE	25
3.3.4.1. Communication	25
3.3.5. MR-PLD <=> FRE interface functions	26
3.3.5.1. Idle-speed control / speed control / maximum engine speed limitation	26
3.3.6. Shutoff or throttling of the engine through the FRE (vehicle electronics).....	27
3.3.7. Engine start and stop	28
3.3.7.1. Starter control (conditions).....	28
3.3.7.2. Starter protection.....	29
3.3.7.3. Start by the driver	29
3.3.7.4. CAN start	30
3.3.7.5. Starter reset bridge	30
3.3.7.6. Starter driver.....	31
3.3.7.7. Start through the FRE (vehicle control electronics) via CAN	32
3.3.7.8. Starting procedure	32
3.3.7.9. Service start button at the engine block	32
3.3.7.10. Service stop button at the engine block.....	32
3.3.7.11. Engine cranking via the service start and stop button	33
3.3.7.12. Rev up to maximum speed via service start button.....	33

3.3.7.13. Engine stop.....	33
3.3.8. Plausibility check terminal 50	34
3.3.9. Calculation of injection delivery angle and start of injection.....	35
3.3.10. Controls (PID governor)	36
3.3.11. Operating modes	37
3.3.11.1. PTO speed control	37
3.3.11.2. Controlled operation (normal operation).....	37
3.3.11.3. Immobilizer.....	37
3.3.12. Tow starting of the engine.....	37
3.3.13. Emergency syndrome.....	37
3.4. Mechanical description.....	38
3.4.1. Mechanical layout of PLD engine electronics	38
3.4.2. Complete version PLD engine electronics	38
3.4.2.1 Fuel cooling	39
3.4.2.2 MR-PLD Control Unit.....	39
3.4.2.2.1.MR-PLD - version assignment table.....	41
3.4.3. Technical data	41
3.4.4. General testing conditions	41
3.5. Electrical description	42
3.5.1. System interface diagram	42
3.5.1.1. Interface diagram.....	42
3.5.1.2. Socket pin designation MR-PLD control unit (D2.1)/according to pin assignment .	43
3.5.1.3. Pin assignment of MR-PLD control unit (D2.1); function oriented/alphabetical	46
3.5.1.4. Voltage supply of control unit MR-PLD (D2.1)	50
 3.5.2.	xx
 3.5.2.1.	xx
 3.5.2.2.	xx
 3.5.2.3.	xx
3.5.3. Sensor system of the PLD engine control unit (MR-PLD).....	51
3.5.3.1. Control unit internal sensors	51
3.5.3.2. Control unit external sensors.....	51
3.5.3.3. Active sensors	51
3.5.3.4. Passive sensors	52
3.5.3.5. Temperature sensors	52
3.5.3.6. Passive oil pressure	53
3.5.3.7. Oil level	54
3.5.3.8. Camshaft / crankshaft position (inductive).....	55
3.5.3.9. Booster speed 1 / 2.....	55
3.5.3.10. Fan speed.....	56
3.5.4. Digital inputs.....	57
3.5.4.1. Ignition (Terminal 15).....	57
3.5.4.2. Terminal 50	57
3.5.4.3. Service button start/stop	58
3.5.4.4. Oil separator.....	59
3.5.5. Proportional valve control.....	60
3.5.5.1. Functional assignment of proportional valves/hardware status D2.1	61
3.5.5.2. Principle block diagram proportional valve control /hardware status D2.1.....	62
3.5.5.3. Functional assignment of the proportional valves/hardware status C3..C6	63
3.5.5.4. Principle block diagram proportional valve control/hardware status C3..C6.....	64
3.5.6. Starter control through the MR-PLD	65
3.5.6.1. Main path (self-locking)	65
3.5.6.2. Auxiliary path (self conducting).....	65
3.5.6.3. Principle block diagram starter control	66
3.5.6.4. Starter relay.....	66
3.5.6.5. Principle block diagram of safety concept of JE-starter	67
3.5.7. Serial communication interfaces	68

3.5.7.1. CAN data bus (2-wire-interface, standard: ISO 11992)	68
3.5.7.2. Diagnostic line (standard: ISO 9141)	69
3.5.7.3. Classification of the injector valves	69
3.6. Configuration possibilities of the MR-PLD	70
3.6.1. Fan type.....	70
3.6.1.1. General connection	70
3.6.1.2. Pin assignment of the proportional valve-power stages (PV/Prop) for fan control.	70
3.6.1.2.1. Type 0/Linning-clutch (on highway/two-stage)	70
3.6.1.2.2. Type 1/Linning-clutch (off highway/two-stage)	70
3.6.1.2.2.1. Configuration / fan switch-on threshold (type 1)	70
3.6.1.2.3. Type 2 /electrically controlled Viscous-fan	72
3.6.1.2.4. Type 3 /Hydrostatic Fan	73
3.6.1.2.5. Type 4/Horton-clutch	74
3.6.1.2.6. Type 5/one Hydrostatic-fan.....	75
3.6.1.2.7. Type 6/two Hydrostatic-fans.....	76
3.6.2. Starter control	77
3.6.2.1. JE-starter	77
3.6.2.2. KB-starter.....	78
3.6.2.2.1. KB-starter with starter solenoid relay (2 A)	78
3.6.2.2.2. KB-starter without Starter Solenoid Relay (2 A)	79
3.6.3. Oil pans	80
4. Diagnosis	81
4.1. Measured values	81
4.1.1. Analogue measured values	81
4.1.2. Binary measured values	83
4.2. Serial diagnosis interfaces	86
4.2.1. Diagnostic line	86
4.2.1.1. Fault memory	86
4.2.1.2. Operating modes	86
4.2.2. CAN data bus systems.....	87
4.2.2.1. Engine-CAN (ISO 11992)	87
4.2.2.2. Vehicle CAN	87
4.2.3. SAE J1587/SAE J1708 (USA- and partly NAFTA-market).....	88
4.2.4. Configuration of diagnostic interface.....	88
4.2.4.1. MB-truck / Brazil.....	89
4.2.4.2. Europe (ADM / not MB-trucks)	90
4.2.4.3. Europe (ADM2 / not MB-Trucks).....	91
4.2.4.4. USA- and partly NAFTA-market	92
4.2.5. Diagnosis interface/software description	93
4.2.5.1. Fault memory structure	93
4.2.5.2. Ground switching.....	93
4.3. Diagnosis unit & application.....	94
4.3.1. minidiag2	94
4.3.1.1. Display/delete fault code memory	94
4.3.1.2. Testing routines.....	97
4.3.1.2.1. Voltmeter function.....	97
4.3.1.2.2. Cylinder cutoff.....	98
4.3.1.2.3. Compression check.....	99
4.3.1.2.4. Idle speed balance (hot engine!).....	100
4.3.1.2.5. Impact delay time	101
4.3.1.2.6.....	xx
4.3.1.2.7.....	xx
4.3.1.3. Calibration	102

4.3.1.3.1.	Single parameters	102
4.3.1.3.2.	Data set calibration	104
4.3.1.3.3.	Save modified parameter set.....	105
4.3.1.3.4.	Convert modified parameter set.....	106
4.3.1.4.	Program protection	107
4.3.2.	Stardiagnose	107
4.3.3.	ServiceLink.....	108
4.4.	Diagnosis routines	109
4.4.1.	Detailed testing routines.....	109
4.5.	Backup	110
4.5.1.	System backup capability	110
4.5.1.1.	Microprocessor 1-backup.....	110
4.5.1.1.1.	Crankshaft backup.....	110
4.5.1.1.2.	Camshaft backup	110
4.5.1.1.3.	CAN-backup (definition)	110
4.5.1.1.4.	CAN-backup, mode 0 (standard-backup)	111
4.5.1.1.5.	CAN-backup, mode 1	112
4.5.1.1.6.	CAN-backup, mode 2.....	112
4.5.1.1.7.	CAN data-area check	112
4.5.1.1.8.	Nominal engine speed CAN-backup	112
4.5.1.1.8.1.	Nominal engine speed CAN-backup mode 0.....	112
4.5.1.1.8.2.	Nominal engine speed CAN-backup mode 1	113
4.5.1.2.	Microprocessor 2-backup.....	113
4.5.2.	Backup functions	114
4.5.2.1.	Ambient pressure sensor.....	114
4.5.2.2.	Boost pressure control.....	114
4.5.3.	Sensor-replacement values	114
4.5.3.1.	Plausibility limits and sensor replacement values	114
4.5.4.	Diagnosis of sensor and backup functions	115
4.5.4.1.	Temperature and presure sensors.....	115
4.5.4.2.	Crankshaft sensor	115
4.5.4.3.	Camshaft sensor (cylinder 1 recognition).....	116
4.5.5.	Diagnosis of actuators	117
4.5.5.1.	MR-PLD injector-/magnetic valves (MV).....	117
4.5.5.2.	MR-PLD proportional valves.....	118
4.5.5.3.	Starter control.....	118
4.6.	Fault codes & repair instructions.....	119
4.6.1.	Fault codes	119
4.6.1.1.	Fault priority 0	119
4.6.1.2.	Fault priority 1	119
4.6.1.3.	Fault priority 2	119
4.6.2.	Fault path	120
4.6.3.	Fault type	122
4.6.4.	Fault codes und repair instructions, high priority	124
4.6.5.	Fault codes und repair instructions, mean priority.....	125
4.6.6.	Fault codes und repair instructions, minor priority.....	134
 4.6.7.	xx
 4.6.8.	xx
4.7.	Special measurements	138
4.7.1.	General information	138
4.7.2.	Actuators.....	138
4.7.2.1.	Solenoid valves: Current modulation curve of the injector valve control/type 1..	138
4.7.2.2.	Solenoid valves: Current modulation curve of the injector valve control/ type 2..	140
 4.7.2.3.	xx
 4.7.3.	xx

5. Parameters (minidiag2)..... 142

5.1. MR-PLD Diagnosis version 3 to 5 (up-/download)..... 142

5.2. MR-PLD Diagnosis from version 6 (single parameters)..... 146

A listing follows in the project "MR-PLD" used abbreviations.

Abbreviation	Meaning	Abbreviation	Meaning
ABS	Anti-lock Braking System	LRR	Engine-Smoothness Control
ADR / PTO	PTO speed control / Power Take-off	LK	Slight Vehicle Class (MB-NFZ)
		LS	Low Speed (CAN)
ATG / AT	Automated Transmission	MB	Mercedes Benz
AVD	Compression check	MBR	Engine Brake
BGR	Limitations	MR-PLD	Engine control (Pump-Line-Nozzle System)
BK	exhaust flap		
BR	Engine Type Series (e. g. BR900)		
CAN	Controller Area Network	MS / MTS	Engine protection
		MV	Magnetic Valve
EGR	Exhaust Gas Recirculation	MZA	Mechanical Additional Boost
EMV	Electro-Magnetical-Impulse	n.d.	not difined
EOL	End Of Line		
EZA	Individual cylinder adaption	NFZ	Commercial Vehicle
FB	Start Of Injection	NW	Camshaft
FDOK	Vehicle Documentation System	OM	Oel Engine
FLA	Flame Start Unit	OT / TDC	Top Dead Centre
		PFA	Particle Filter System
FRE	Vehicle control (e. g. VCU, ADM, ADM2, UCV, FR/FMR)	PID	Parameter Identifier
FRT	Free Running Telegramm		
FSP		PV / Prop	Proportional Valve
FW	Injection Delivery Angle	PWM	Pulse Width Modulated
GMA	Basic Moment Adaption	SEG	Segment
HB	High Byte	SG / Stg. / ECU	Electronical Control Unit
		s.n.v.	signal not available
HW	HardWare	SK	Heavy Vehicle Class (MB-NFZ)
ID	IDentifier	STG / MA	Manual Transmission
IES	Intigrated Electronic System	SW	SoftWare
INS / ICU3	Dashboard	TN	(CAN) Attendant
IMO	Industrial Engine (Off-Highway)	TPC	TransPonderCode
KD	Decompression Valve	UT	Bottom Dead Centre
		VTG	Variable Geometry Turbo
		WS	Service System
		WSP	Immobilizer
K-Line	Communication Line (serial)	ZYL / CYL	Cylinder
KW	Crankshaft		
LB	Low Byte		
LL / LLR	Idle / Idle Control		