

ELECTRICAL SYSTEM**SECTION EL****CONTENTS**

PRECAUTIONS	4	GI
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER".....	4	MA
Wiring Diagrams and Trouble Diagnosis.....	4	EM
PREPARATION	5	LC
Special Service Tools	5	EC
HARNESS CONNECTOR.....	6	FE
Description	6	CL
STANDARDIZED RELAY.....	8	MT
Description	8	AT
POWER SUPPLY ROUTING.....	10	TF
Circuit Diagram	10	PD
Wiring Diagram - POWER -	12	AX
Inspection.....	17	SU
GROUND.....	18	BR
Ground Distribution.....	18	ST
COMBINATION SWITCH	32	RS
Check.....	32	BT
Replacement.....	33	HA
STEERING SWITCH.....	34	SC
Check.....	34	EL
HEADLAMP (FOR USA).....	35	IDX
System Description.....	35	
Wiring Diagram - H/LAMP -	36	
Trouble Diagnoses.....	37	
Bulb Replacement	38	
Aiming Adjustment.....	38	
HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -	40	
System Description (For Canada).....	40	
Circuit Diagram	42	
Wiring Diagram - DTRL -	43	
Trouble Diagnoses.....	46	
Bulb Replacement	47	
Aiming Adjustment.....	47	
PARKING, LICENSE AND TAIL LAMPS	48	
Wiring Diagram - TAIL/L -	48	
STOP LAMP	49	
Wiring Diagram - STOP/L -	49	
BACK-UP LAMP.....	50	
Wiring Diagram - BACK/L -	50	
FRONT FOG LAMP	51	
System Description.....	51	
Wiring Diagram - F/FOG -	52	
Aiming Adjustment.....	53	
Removal and Installation	54	
Bulb and Lens Replacement	54	
TURN SIGNAL AND HAZARD WARNING LAMPS	55	
System Description.....	55	
Wiring Diagram - TURN -	57	
Trouble Diagnoses.....	59	
Electrical Components Inspection	60	
ILLUMINATION.....	61	
System Description.....	61	
Wiring Diagram - ILL -	62	
INTERIOR ROOM LAMP	64	
Component Parts and Harness Connector		
Location	64	
System Description.....	65	
Wiring Diagram - ROOM/L -	68	
Trouble Diagnosis.....	72	
METERS AND GAUGES	74	
Component Parts and Harness Connector		
Location	74	
System Description.....	75	
Combination Meter	77	
Wiring Diagram - METER -	79	
Meter/Gauge Operation and Odo/Trip Meter		
Segment Check in Diagnosis Mode	80	
Trouble Diagnoses.....	81	
Electrical Components Inspection	87	
COMPASS AND THERMOMETER	89	
System Description.....	89	
Wiring Diagram - COMPAS -	90	
Trouble Diagnoses.....	92	
Calibration Procedure for Compass	93	
WARNING LAMPS	94	
Circuit Diagram	94	

CONTENTS (Cont'd)

Wiring Diagram - WARN -	95	Trouble Diagnoses.....	184
Electrical Components Inspection	103	POWER DOOR LOCK	186
WARNING CHIME	104	Component Parts and Harness Connector	
Component Parts and Harness Connector		Location	186
Location	104	System Description.....	187
System Description.....	105	Circuit Diagram.....	189
Wiring Diagram - CHIME -	107	Wiring Diagram - D/LOCK -.....	190
Trouble Diagnoses.....	109	Trouble Diagnoses.....	193
FRONT WIPER AND WASHER	118	REMOTE KEYLESS ENTRY SYSTEM	200
System Description.....	118	Component Parts and Harness Connector	
Wiring Diagram - WIPER -	120	Location	200
Removal and Installation	122	System Description.....	201
Washer Nozzle Adjustment	123	Wiring Diagram - KEYLES -	204
Washer Tube Layout	123	Trouble Diagnoses.....	206
HORN	124	ID Code Entry Procedure	215
Wiring Diagram - HORN -	124	Keyfob Battery Replacement.....	216
CIGARETTE LIGHTER	125	VEHICLE SECURITY (THEFT WARNING) SYSTEM	217
Wiring Diagram - CIGAR -	125	Component Parts and Harness Connector	
REAR WINDOW DEFOGGER	126	Location	217
Component Parts and Harness Connector		System Description.....	219
Location	126	Circuit Diagram.....	222
System Description.....	127	Wiring Diagram - VEHSEC -	223
Wiring Diagram - DEF -	129	Trouble Diagnoses.....	226
Trouble Diagnoses.....	131	SMART ENTRANCE CONTROL UNIT	240
Electrical Components Inspection	135	Description	240
Filament Check.....	136	Circuit Diagram	241
Filament Repair	137	Smart Entrance Control Unit Inspection Table	243
AUDIO	138	ELECTRICAL UNITS LOCATION	245
System Description.....	138	Engine Compartment.....	245
Schematic - With Audio Amplifier	140	Passenger Compartment.....	246
Wiring Diagram - AUDIO -	141	HARNESS LAYOUT	248
Trouble Diagnoses.....	149	How to Read Harness Layout	248
Inspection.....	150	Outline.....	249
AUDIO ANTENNA	153	Main Harness (KA24DE Models)	250
Location of Antenna.....	153	Main Harness (VG33E and VG33ER Models)	252
Fixed Antenna Rod Replacement.....	153	Engine Room Harness (KA24DE Models)	254
DOOR MIRROR	154	Engine Room Harness (VG33E and VG33ER Models)	257
Wiring Diagram - MIRROR -	154	Engine Control Harness (KA24DE Models)	260
AUTOMATIC SPEED CONTROL DEVICE (ASCD)	155	Engine No. 2 Harness (KA24DE Models)	262
Component Parts and Harness Connector		Engine Control Harness (VG33E Models)	263
Location	155	Engine Control Harness (VG33ER Models)	265
System Description.....	157	Engine No. 2 Harness (VG33E and VG33ER Models)	267
Circuit Diagram	159	Chassis and Tail Harness (KA24DE Models)	268
Wiring Diagram - ASCD -	160	Chassis and Tail Harness (VG33E and VG33ER Models)	269
Fail-safe System.....	163	Room Lamp Harness	270
Trouble Diagnoses.....	164	Front Door Harness	271
Electrical Component Inspection	172	Rear Door Harness	273
ASCD Wire Adjustment	174	BULB SPECIFICATIONS	275
POWER WINDOW	176		
System Description.....	176		
Circuit Diagram	179		
Wiring Diagram - WINDOW -	180		

CONTENTS (Cont'd)

Headlamp.....	275	Interior Lamp.....	275	GI
Exterior Lamp	275	WIRING DIAGRAM CODES (CELL CODES).....276		
				MA
				EM
				LC
				EC
				FE
				CL
				MT
				AT
				TF
				PD
				AX
				SU
				BR
				ST
				RS
				BT
				HA
				SC
				EL

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

NEEL0001

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER" used along with a seat belt, help to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and in the instrument panel on the passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness, and spiral cable.

The vehicle (except Crew Cab model) is equipped with a passenger air bag deactivation switch. Because no rear seat exists where a rear-facing child restraint can be placed, the switch is designed to turn off the passenger air bag so that a rear-facing child restraint can be used in the front passenger seat. The switch is located in the center of the instrument panel, near the ashtray. When the switch is turned to the ON position, the passenger air bag is enabled and could inflate in a frontal collision. When the switch is turned to the OFF position, the passenger air bag is disabled and will not inflate in a frontal collision. A passenger air bag OFF indicator on the instrument panel lights up when the passenger air bag is switched OFF. The driver air bag always remains enabled and is not affected by the passenger air bag deactivation switch.

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow harness connectors.
- The vehicle (except Crew Cab model) is equipped with a passenger air bag deactivation switch which can be operated by the customer. When the passenger air bag is switched OFF, the passenger air bag is disabled and will not inflate in a frontal collision. When the passenger air bag is switched ON, the passenger air bag is enabled and could inflate in a frontal collision. After SRS maintenance or repair, make sure the passenger air bag deactivation switch is in the same position (ON or OFF) as when the vehicle arrived for service.

Wiring Diagrams and Trouble Diagnosis

NEEL0002

When you read wiring diagrams, refer to the following:

- **GI-11**, "HOW TO READ WIRING DIAGRAMS"
- "POWER SUPPLY ROUTING" for power distribution circuit, EL-10

When you perform trouble diagnosis, refer to the following:

- **GI-34**, "How to Follow Test Groups in Trouble Diagnoses"
- **GI-23**, "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT"

Check for any Service bulletins before servicing the vehicle.


PREPARATION

Special Service Tools

Special Service Tools

=NEEL0234

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
(J-43241) Remote keyless entry tester	 <p>Used to test keyfobs</p> <p>LEL946A</p>

*: Special tool or commercial equivalent

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

HARNESS CONNECTOR

Description

Description

HARNESS CONNECTOR (TAB-LOCKING TYPE)

NEEL0003

NEEL0003S01


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the illustration below.

Refer to EL-7 for description of the slide-locking type connector.

CAUTION:

Do not pull the harness when disconnecting the connector.

[Example]



SEL769D

HARNESS CONNECTOR

Description (Cont'd)

HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

=NEEL0003S02


- A new style slide-locking connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the illustration below.

CAUTION:

Do not pull the harness or wires when disconnecting the connector.

Be careful not to damage the connector support bracket when disconnecting the connector.

Waterproof type




① Firmly grasp shell of connector housing at A.

② Push slider until connector pops or snaps apart.

③ Disconnect harness connector.

Non-waterproof type



① Firmly grasp shell of connector housing at A.

② Pull back on the slider while pulling apart male and female halves of connector.

③ Disconnect harness connector.

AEL299C

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

STANDARDIZED RELAY


Description

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.

NEEL0004
NEEL0004S01




SEL881H

TYPE OF STANDARDIZED RELAYS

NEEL0004S02

















1M	1 Make	2M	2 Make
1T	1 Transfer	1M-1B	1 Make 1 Break



SEL882H

STANDARDIZED RELAY

Description (Cont'd)

Type	Outer view	Circuit	Connector symbol and connector	Case color
1T				BLACK
				
2M				BROWN
1M•1B				GRAY
1M				BLUE
				

The arrangement of terminal numbers on the actual relays may differ from those shown above.

GEL264

EL

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC


POWER SUPPLY ROUTING

Circuit Diagram

Circuit Diagram

NOTE: For detailed ground distribution information, refer to "GROUND DISTRIBUTION", EL-18.

NEEL0005



WEL091B

Next page
B


Next page
C

POWER SUPPLY ROUTING

Circuit Diagram (Cont'd)

Preceding page

Preceding page



- (2D) : 2 door models
- (4D) : 4 door models
- (DL) : With power door locks
- (N) : For Canada
- (A) : With A/T
- (AK) : With AT and KA24DE engine
- (XK) : Except with KA24DE

POWER SUPPLY ROUTING

Wiring Diagram — POWER —

Wiring Diagram — POWER —



BATTERY POWER SUPPLY — IGNITION SW. IN ANY POSITION

NOTE:

For detailed ground distribution information, refer to "GROUND DISTRIBUTION", EL-18.

NEEL0006

NEEL0006S01



WEL093B

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-02

 : With fog lamps

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT



HA

SC

WEL840A

EL

IDX



POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)


ACCESSORY POWER SUPPLY — IGNITION SW. IN ACC OR ON

=NEEL0006S02

NOTE:

For detailed ground distribution information, refer to "GROUND DISTRIBUTION", EL-18.

EL-POWER-03



B i1 ST
 R AC i2
 W

Refer to the following.					
(M26, M27, E50, E52)					
1	6	11	16	21	25
2	7	12	17	22	26
3	8	13	18	23	27
4	9	14	19	24	
5	10	15	20		28

-FUSE BLOCK - JUNCTION BOX (J/B)

WEL841A

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)


IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START

=NEEL0006S03

NOTE:

For detailed ground distribution information, refer to "GROUND DISTRIBUTION", EL-18.

EL-POWER-04



Refer to the following.



M26	M27	E49	E50	E52
1	6	11	16	21 25
2	7	12	17	22 26
3	8	13	18	23 27
4	9	14	19	24
5	10	15	20	28

-FUSE BLOCK - JUNCTION BOX (J/B)

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-05



B i1 ST
R AC 12 E48
W

Refer to the following.


M26	, M27	, M31	, E49		
E50	, E52				
1	6	11	16	21	25
2	7	12	17	22	26
3	8	13	18	23	27
4	9	14	19	24	
5	10	15	20		28

-FUSE BLOCK - JUNCTION
BOX (J/B)

WEL843A

POWER SUPPLY ROUTING

Inspection



Inspection

FUSE

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.

NEEL0007


GI

MA

EM

LC

NEEL0007S01



FUSIBLE LINK

A melted fusible link can be detected either by visual inspection or by feeling with fingertip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.

NEEL0007S02

EC

FE

CL


MT

AT

TF

PD

AX



CIRCUIT BREAKER

For example, when current is 30A, the circuit is broken within 8 to 20 seconds.

Circuit breakers are used in the following systems:

- Power windows
- Power door locks
- Remote keyless entry.

NEEL0007S03

SU

BR

ST

RS

BT

HA

SC

EL

IDX

GROUND


Ground Distribution

Ground Distribution MAIN HARNESS

NEEL0171

NEEL0171S01

Body ground





WEL844A

GROUND

Ground Distribution (Cont'd)

Body ground



Body
ground

CONNECTOR NUMBER	CONNECT TO
(M23)	ABS control unit (Terminal No. 11) (With 2-wheel ABS)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT


HA

SC

LEL795

EL

IDX

GROUND*Ground Distribution (Cont'd)***Body ground**

CONNECTOR NUMBER	CONNECT TO
(M38)	Combination meter (high beam indicator) (Terminal No.10)
(M39)	Combination meter (Terminal No. 33) • Air bag warning lamp • Fuel gauge • Speedometer • Water temperature gauge • Tachometer
(M45)	Combination flasher unit
(M52)	Cigarette lighter socket
(M54)	Power socket
(M57)	Fan switch (Terminal No. 6)
(M95)	Air control (Terminal No. 8) (with A/C)
(M111)	Smart entrance control unit (Terminal No. 43)
(M128)	ASCD relay (Terminal No. 2)
(M129)	Overdrive cancel relay (Terminal No. 2) (with KA engine and A/T) (if equipped)
(M129)	Overdrive cancel relay (Terminal No. 5) (with KA engine and A/T) (if equipped)
(M132)	Audio amplifier (Terminal No. 4)
(M132)	Audio amplifier (Terminal No. 11)
(M136)	Cargo lamp switch (Terminal No. 5)
(F29)	ECM (Terminal No. 66)

WEL846A