

# QUICK REFERENCE CHART : Q45

# 1991

## ENGINE TUNE-UP DATA

Engine model	VH45DE		
Firing order	1-8-7-3-6-5-4-2		
Idle speed	rpm	A/T (in "N" position)	650±50
Ignition timing	(B.T.D.C. at idle speed) 15°±2°		
CO% at idle	Idle mixture screw is preset and sealed at factory.		
Drive belt deflection (Cold)	mm (in)	Used belt deflection	
		Limit	Deflection after adjustment
Alternator		14 (0.55)	9 - 10 (0.35 - 0.39)
Air conditioner compressor		12 (0.47)	8.5 - 9.5 (0.335 - 0.374)
Power steering oil pump	Without SUPER HICAS or FULL-ACTIVE SUSPENSION	14 (0.55)	9 - 10 (0.35 - 0.39)
	With SUPER HICAS or FULL-ACTIVE SUSPENSION	13 (0.51)	7 - 8 (0.28 - 0.31)
Applied pushing force	N (kg, lb)	98 (10, 22)	
Radiator cap relief pressure	kPa (kg/cm <sup>2</sup> , psi)	78 - 98 (0.8 - 1.0, 11 - 14)	
Cooling system leakage testing pressure	kPa (kg/cm <sup>2</sup> , psi)	157 (1.6, 23)	
Compression pressure	Standard	1,275 (13.0, 185)/300	
	Minimum	981 (10.0, 142)/300	
Spark plug	Type (Standard)	PFR6B-11	

## REAR WHEEL ALIGNMENT (Unladen)

		Without full-active suspension	With full-active suspension
Camber	degree	-1°35' to -0°35'	-2°00' to -1°00'
Total toe-in	mm (in)	0 - 4 (0 - 0.16)	
	degree	0' - 22'	

## BRAKE

Unit: mm (in)

Front brake	
Pad wear limit	2.0 (0.079)
Rotor repair limit	26.0 (1.024)
Rear brake	
Pad wear limit	2.0 (0.079)
Rotor repair limit	8.0 (0.315)
Pedal free height	184 - 194 (7.24 - 7.64)
Pedal depressed height*	105 - 115 (4.13 - 4.53)

\* Under force of 490 N (50 kg, 110 lb) with engine running

## FRONT WHEEL ALIGNMENT (Unladen\*)

		Without full-active suspension	With full-active suspension
Camber	degree	-1°35' to -0°05'	-1°40' to -0°10'
Caster	degree	5°45' - 7°15'	6°10' - 7°40'
Kingpin inclination	degree	12°00' - 13°30'	12°10' - 13°40'
Total toe-in	mm (in)	0 - 2 (0 - 0.08)	
	degree	0' - 10'	
Wheel turning angle (Full turn)	degree	35°30' - 39°30'	
	Inside	35° - 39°	
Outside	32°		

\* Fuel, radiator coolant and engine oil full.  
Spare tire, jack, hand tools and mats in designated positions.

## REFILL CAPACITIES

Unit	Liter	US measure	
Fuel tank	85	22-1/2 gal	
Coolant (With reservoir tank)	10.3	10-7/8 qt	
Engine	With oil filter	6.0	6-3/8 qt
	Without oil filter	5.6	5-7/8 qt
Transmission	A/T	10.2	10-3/4 qt
Differential carrier		1.5	3-1/8 pt
Power steering system	With SUPER HICAS	2.2	2-3/8 qt
	Without SUPER HICAS	1.2	1-1/4 qt
Full-active suspension system		5.7	6 qt
Air conditioning system	Compressor oil	0.236	8.0 fl oz
	Refrigerant	1.10 - 1.20 kg	2.43 - 2.65 lb

## QUICK REFERENCE INDEX

GENERAL INFORMATION _____	<b>GI</b>
MAINTENANCE _____	<b>MA</b>
ENGINE MECHANICAL _____	<b>EM</b>
ENGINE LUBRICATION & COOLING SYSTEMS —	<b>LC</b>
ENGINE FUEL & EMISSION CONTROL SYSTEM —	<b>EF &amp; EC</b>
ACCELERATOR CONTROL, FUEL & _____ EXHAUST SYSTEMS	<b>FE</b>
AUTOMATIC TRANSMISSION _____	<b>AT</b>
PROPELLER SHAFT & DIFFERENTIAL CARRIER —	<b>PD</b>
FRONT AXLE & FRONT SUSPENSION _____	<b>FA</b>
REAR AXLE & REAR SUSPENSION _____	<b>RA</b>
BRAKE SYSTEM _____	<b>BR</b>
STEERING SYSTEM _____	<b>ST</b>
BODY _____	<b>BF</b>
HEATER & AIR CONDITIONER _____	<b>HA</b>
ELECTRICAL SYSTEM _____	<b>EL</b>



I N F I N I T I ®

Q45

MODEL G50 SERIES



I N F I N I T I ®

© 1989 NISSAN MOTOR CO., LTD. Printed in Japan

Not to be reproduced in whole or in part without the prior written permission of Nissan Motor Company Ltd., Tokyo, Japan.

# FOREWORD

---

This manual contains maintenance and repair procedures for the 1991 INFINITI Q45.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

---

## IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately.

Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by INFINITI must first completely satisfy himself that neither his safety nor the vehicle's safety will be jeopardized by the service method selected.



I N F I N I T I <sup>®</sup>



NISSAN MOTOR CO., LTD.

Overseas Service Department

Tokyo, Japan

# GENERAL INFORMATION



<b>SECTION</b>	<b>GI</b>
----------------	-----------

## CONTENTS

PRECAUTIONS .....	GI- 2
HOW TO USE THIS MANUAL .....	GI- 6
HOW TO READ WIRING DIAGRAMS .....	GI- 8
HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES .....	GI-13
CONSULT CHECKING SYSTEM .....	GI-17
IDENTIFICATION INFORMATION .....	GI-19
LIFTING POINTS AND TOW TRUCK TOWING .....	GI-23
TIGHTENING TORQUE OF STANDARD BOLTS .....	GI-26

## PRECAUTIONS

Observe the following precautions to ensure safe and proper servicing. These precautions are not described in each individual section.



### Precautions for Supplemental Restraint System “AIR BAG”

The Supplemental Restraint System “Air Bag” helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag (located in the center of the steering wheel), sensors, a control unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **BF** section of this Service Manual.

#### WARNING:


- To avoid rendering the SRS inoperative, which could lead to personal injury or death in the event of a severe frontal collision, all maintenance must be performed by an authorized INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS “Air Bag”.

### Precautions for “FULL-ACTIVE SUSPENSION”

1. Do not disconnect battery terminals or remove fuses for approximately 2 minutes after stopping the engine. Doing so may change vehicle height.
2. Before raising the vehicle using a jack, wait at least 2 minutes after stopping the engine.
3. Do not get under the vehicle when it is raised with only a jack and do not start the engine.
4. Before working under the vehicle, raise the four wheels off the ground and properly support the vehicle using rigid racks.





### General Precautions

1. Do not operate the engine for an extended period of time without proper exhaust ventilation. Keep the work area well ventilated and free of any inflammable materials. Special care should be taken when handling any inflammable or poisonous materials, such as gasoline, refrigerant gas, etc. When working in a pit or other enclosed area, be sure to properly ventilate the area before working with hazardous materials. Do not smoke while working on the vehicle.



## PRECAUTIONS

### General Precautions (Cont'd)




2. Before jacking up the vehicle, apply wheel chocks or other tire blocks to the wheels to prevent the vehicle from moving. After jacking up the vehicle, support the vehicle weight with safety stands at the points designated for proper lifting and towing before working on the vehicle. These operations should be done on a level surface.
3. When removing a heavy component such as the engine or transaxle/transmission, be careful not to lose your balance and drop them. Also, do not allow them to strike adjacent parts, especially the brake tubes and master cylinder.
4. Before starting repairs which do not require battery power, always turn off the ignition switch, then disconnect the ground cable from the battery to prevent accidental short circuit.
5. To prevent serious burns, avoid contact with hot metal parts such as the radiator, exhaust manifold, tail pipe and muffler. Do not remove the radiator cap when the engine is hot.
6. Before servicing the vehicle, protect fenders, upholstery and carpeting with appropriate covers. Take caution that keys, buckles or buttons on your person do not scratch the paint.

## PRECAUTIONS


### General Precautions (Cont'd)

7. Clean all disassembled parts in the designated liquid or solvent prior to inspection or assembly.
8. Replace oil seals, gaskets, packings, O-rings, locking washers, cotter pins, self-locking nuts, etc. with new ones.
9. Replace inner and outer races of tapered roller bearings and needle bearings as a set.
10. Arrange the disassembled parts in accordance with their assembled locations and sequence.
11. Do not touch the terminals of electrical components which use microcomputers (such as electronic control units). Static electricity may damage internal electronic components.
12. After disconnecting vacuum or air hoses, attach a tag to indicate the proper connection.
13. Use only the lubricants specified in MA section.
14. Use approved bonding agent, sealants or their equivalents when required.
15. Use tools and recommended special tools where specified for safe and efficient service repairs.
16. When repairing the fuel, oil, water, vacuum or exhaust systems, check all affected lines for leaks.
17. Dispose of drained oil or the solvent used for cleaning parts in an appropriate manner.



### Precautions for E.F.I. or E.C.C.S. Engine

1. Before connecting or disconnecting E.F.I. or E.C.C.S. harness connector to or from any E.F.I. or E.C.C.S. control unit, be sure to turn the ignition switch to the "OFF" position and disconnect the negative battery terminal. Otherwise, there may be damage to control unit.
2. Before disconnecting pressurized fuel line from fuel pump to injectors, be sure to release fuel pressure to eliminate danger.
3. Be careful not to jar components such as control unit and air flow meter.



### Precautions for Catalyst

If a large amount of unburned fuel flows into the converter, the converter temperature will be excessively high. To prevent this, follow the procedure below:

1. Use unleaded gasoline only. Leaded gasoline will seriously damage the catalytic converter.
2. When checking for ignition spark or measuring engine compression, make tests quickly and only when necessary.
3. Do not run engine when the fuel tank level is low, otherwise the engine may misfire causing damage to the converter.
4. Do not place the vehicle on inflammable material. Keep inflammable material off the exhaust pipe.

## PRECAUTIONS

---

### Precautions for Fuel

To maintain engine and exhaust system durability and performance, UNLEADED PREMIUM gasoline with an octane rating of at least 91 AKI (Research octane number 96) must be used.

If premium unleaded gasoline is not available, REGULAR UNLEADED gasoline with an octane rating of 87 AKI (Research octane number 91) may be used temporarily, but only under the following conditions:


- The fuel tank should be filled only partially with unleaded regular gasoline, and filled up with premium unleaded gasoline as soon as possible.
- Full throttle driving and abrupt acceleration should be avoided.

**Use UNLEADED fuel only. Under no circumstances should leaded gasoline be used. Lead gasoline will damage the catalytic converter and increase dangerous emissions from the vehicle exhaust.**



## HOW TO USE THIS MANUAL









1. **A QUICK REFERENCE INDEX**, a black tab (e.g. **BR**) is provided on the first page. You can quickly find the first page of each section by mating it to the section's black tab.
2. **THE CONTENTS** are listed on the first page of each section.
3. **THE TITLE** is indicated on the upper portion of each page and shows the part or system.
4. **THE PAGE NUMBER** of each section consists of two letters which designate the particular section and a number (e.g. "BR-5").
5. **THE LARGE ILLUSTRATIONS** are exploded views (See below.) and contain tightening torques, lubrication points and other information necessary to perform repairs. The illustrations should be used in reference to service matters only. When ordering parts, refer to the appropriate **PARTS CATALOG**.



6. **THE SMALL ILLUSTRATIONS** show the important steps such as inspection, use of special tools, knacks of work and hidden or tricky steps which are not shown in the previous large illustrations. Assembly, inspection and adjustment procedures for complicated units such as the automatic transaxle or transmission, etc. are presented in a step-by-step format where necessary.

## HOW TO USE THIS MANUAL

7. The following **SYMBOLS AND ABBREVIATIONS** are used:

	: Tightening torque	S.D.S.	: Service Data and Specifications
	: Should be lubricated with grease. Unless otherwise indicated, use recommended multi-purpose grease.	SAE	: Society of Automotive Engineers Inc.
	: Should be lubricated with oil.	L.H., R.H.	: Left-Hand, Right-Hand
	: Sealing point	FR, RR	: Front, Rear
	: Checking point	A/T	: Automatic Transaxle/Transmission
	: Always replace after every disassembly.	Tool	: Special Service Tools
	: Apply petroleum jelly.	A.T.F.	: Automatic Transmission Fluid
	: Apply A.T.F.	D <sub>1</sub>	: Drive range 1st gear
★	: Select with proper thickness.	D <sub>2</sub>	: Drive range 2nd gear
☆	: Adjustment is required.	D <sub>3</sub>	: Drive range 3rd gear
P/S	: Power steering	D <sub>4</sub>	: Drive range 4th gear
		O.D.	: Overdrive
		2 <sub>2</sub>	: 2nd range 2nd gear
		2 <sub>1</sub>	: 2nd range 1st gear
		1 <sub>2</sub>	: 1st range 2nd gear
		1 <sub>1</sub>	: 1st range 1st gear
		3 <sub>3</sub>	: 3rd range 3rd gear
		3 <sub>2</sub>	: 3rd range 2nd gear
		3 <sub>1</sub>	: 3rd range 1st gear

8. The **UNITS** given in this manual are primarily expressed as SI UNITS (International System of Unit), and alternately expressed in the metric system and in the yard/pound system.

“Example”

**Tightening torque:**


**59 - 78 N·m (6.0 - 8.0 kg·m, 43 - 58 ft·lb)**

9. **TROUBLE DIAGNOSES** are included in sections dealing with complicated components.
10. **SERVICE DATA AND SPECIFICATIONS** are contained at the end of each section for quick reference of data.
11. The captions **WARNING** and **CAUTION** warn you of steps that must be followed to prevent personal injury and/or damage to some part of the vehicle.
- **WARNING** indicates the possibility of personal injury if instructions are not followed.
  - **CAUTION** indicates the possibility of component damage if instructions are not followed.
  - **BOLD TYPED STATEMENTS** except **WARNING** and **CAUTION** give you helpful information.

# HOW TO READ WIRING DIAGRAMS


## WIRING DIAGRAM

Symbols used in WIRING DIAGRAM are shown below:



SGI543


# HOW TO READ WIRING DIAGRAMS



## SWITCH POSITIONS


Wiring diagram switches are shown with the vehicle in the following condition.

- Ignition switch "OFF".
- Doors, hood and trunk lid/back door closed.
- Pedals are not depressed and parking brake is released.



## CONNECTOR SYMBOLS

- All connector symbols in wiring diagrams are shown from the terminal side.




- Male and female terminals  
Connector guides for male terminals are shown in black and female terminals in white in wiring diagrams.

# HOW TO READ WIRING DIAGRAMS

## MULTIPLE SWITCH

The continuity of the multiple switch is identified in the switch chart in wiring diagrams.

### Example



WIPER SWITCH

	OFF	INT	LO	HI	WASH
1					○
2				○	
③	○	○	●		
4	○	○	●		
5			○		
⑥	○		●	○	○

Continuity circuit of wiper switch

SWITCH POSITION	CONTINUITY CIRCUIT
OFF	3 - 4
INT	3 - 4, 5 - 6
LO	3 - 6
HI	2 - 6
WASH	1 - 6

Example: Wiper switch in LO position


Continuity circuit: Red wire - (A) terminal - (③) terminal - Wiper switch (● - ●):  
LO) - (⑥) terminal - (F) terminal - Black wire

SGI365

# HOW TO READ WIRING DIAGRAMS

## SUPER MULTIPLE JUNCTION (S.M.J.)

- The "S.M.J." indicated in wiring diagrams is shown in a simplified form. The terminal arrangement should therefore be referred to in the foldout at the end of the Service Manual.
- The foldout should be spread to read the entire wiring diagram.




# HOW TO READ WIRING DIAGRAMS

## SPLICE LOCATION

- "GM25", "M130" etc., which are shown in the wiring diagram, refer to wiring harness splice points. These points are located in shaded areas "GM25", "M130", etc. in illustrations under the title "SPLICE LOCATION".
- Wiring harness splice points are subject to change without prior notice.


### Example



SEL192Q

# HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES

## Example



## NOTICE

The flow chart indicates work procedures required to diagnose problems effectively. Observe the following instructions before diagnosing.


- 1) Use the flow chart after locating probable causes of a problem following the "Preliminary Check" or the "Symptom Chart".
- 2) After repairs, re-check that the problem has been completely eliminated.
- 3) Refer to Component Parts Location and Harness Layout for the Systems described in each section for identification/location of components and harness connectors.
- 4) Refer to the Circuit Diagram for Quick Pinpoint Check. If you must perform circuit continuity between harness connectors more detail, such as in case of sub-harness is used, refer to Wiring Diagram and Harness Layout in EL section for identification of harness connectors.
- 5) When checking circuit continuity, ignition switch should be "OFF".
- 6) Before checking voltage at connectors, check battery voltage.
- 7) After accomplishing the Diagnostic Procedures and Electrical Components Inspection, make sure that all harness connectors are reconnected as they were.



## HOW TO FOLLOW THIS FLOW CHART

### 1 Work and diagnostic procedure

Start to diagnose a problem using procedures indicated in enclosed blocks, as shown in the following example.



### 2 Measurement results

Required results are indicated in bold type in the corresponding block, as shown below:

These have the following meanings:

**Battery voltage** → 11 - 14V or approximately 12V

**Voltage: Approximately 0V** → Less than 1V

### 3 Cross reference of work symbols in the text and illustrations

Illustrations are provided as visual aids for work procedures. For example, symbol **A** indicated in the left upper portion of each illustration corresponds with the symbol in the flow chart for easy identification. More precisely, the procedure under the "CHECK POWER SUPPLY" outlined previously is indicated by an illustration **A**.


### 4 Symbols used in illustrations

Symbols included in illustrations refer to measurements or procedures. Before diagnosing a problem, familiarize yourself with each symbol.


# HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES

## Example

### View from terminal side



Connector symbol




Single line


Direction mark



### View from harness side



Connector symbol



Double lines

Direction mark



SGI364

## Direction mark

A direction mark is shown to clarify the side of connector (terminal side or harness side).

Direction marks are mainly used in the illustrations indicating terminal inspection.



: View from terminal side ... T.S.

- All connector symbols shown from the terminal side are enclosed by a single line.


































: View from harness side ... H.S.


- All connector symbols shown from the harness side are enclosed by a double line.

# HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES

## Key to symbols signifying measurements or procedures

Symbol	Symbol explanation	Symbol	Symbol explanation
	Check after disconnecting the connector to be measured.		Current should be measured with an ammeter.
	Check after connecting the connector to be measured.		Procedure with CONSULT
	Insert key into ignition switch.		Procedure without CONSULT
	Remove key from ignition switch.		A/C switch is "OFF".
	Turn ignition switch to "OFF" position.		A/C switch is "ON".
	Turn ignition switch to "ON" position.		Fan switch is "ON". (At any position except for "OFF" position)
	Turn ignition switch to "START" position.		Fan switch is "OFF".
	Turn ignition switch from "OFF" to "ACC" position.		Apply battery voltage directly to components.
	Turn ignition switch from "ACC" to "OFF" position.		Drive vehicle.
	Turn ignition switch from "OFF" to "ON" position.		Disconnect battery negative cable.
	Turn ignition switch from "ON" to "OFF" position.		Depress brake pedal.
	Do not start engine, or check with engine stopped.		Release brake pedal.
	Start engine, or check with engine running.		Depress accelerator pedal.
	Apply parking brake.		Release accelerator pedal.
	Release parking brake.	<p>Pin terminal check for S.M.J. type E.C.U., A/T control unit, full-active suspension control unit and TCS control unit connectors.</p> <p><b>For details regarding the terminal arrangement, refer to the foldout page.</b></p> 	
	Check after engine is warmed up sufficiently.		
	Voltage should be measured with a voltmeter.		
	Circuit resistance should be measured with an ohmmeter.		

**Outside View**



SGI619

**System Application**

System	System						
	E.C.C.S.	A/T	Air bag	HICAS	ASCD	*AUTO D/P	ACTIV SUS
Diagnostic mode							
Work support	×	—	—	—	—	—	×
Self-diagnostic results	×	×	×	×	×	×	×
Data monitor	×	×	—	×	×	×	×
Active test	×	—	—	×	—	—	×
E.C.U. part number	×	×	—	×	—	—	×
Function test	×	—	—	—	—	—	—

×: Applicable

\*AUTO D/P: Automatic drive positioner system