

## ENGINE CONTROL SYSTEM

SECTION **EC**

## CONTENTS

<b>PRECAUTIONS AND PREPARATION</b> .....	2	<b>TROUBLE DIAGNOSIS — Basic Inspection</b> .....	60
<b>ENGINE AND EMISSION CONTROL OVERALL SYSTEM</b> .....	6	Basic Inspection.....	60
Circuit Diagram.....	6	<b>TROUBLE DIAGNOSIS — General Description</b> .....	63
System Diagram.....	7	Diagnostic Trouble Code (DTC) Chart.....	63
ECCS Component Parts Location.....	8	Fail-Safe Chart.....	78
Vacuum Hose Drawing.....	10	Symptom Matrix Chart (For New CT/CS).....	79
System Chart.....	11	CONSULT Reference Value in Data Monitor Mode.....	81
<b>ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION</b> .....	12	Major Sensor Reference Graph in Data Monitor Mode.....	83
Multiport Fuel Injection (MFI) System.....	12	ECM Terminals and Reference Value.....	85
Distributor Ignition (DI) System.....	14	<b>TROUBLE DIAGNOSIS FOR POWER SUPPLY</b> .....	91
Air Conditioning Cut Control.....	15	Main Power Supply and Ground Circuit.....	91
Fuel Cut Control (at no load & high engine speed).....	16	<b>TROUBLE DIAGNOSIS FOR DTC P0100</b> .....	94
<b>EVAPORATIVE EMISSION SYSTEM</b> .....	17	Mass Air Flow Sensor (MAFS) (DTC: 0102).....	94
<b>POSITIVE CRANKCASE VENTILATION</b> .....	21	<b>TROUBLE DIAGNOSIS FOR DTC P0105</b> .....	99
<b>BASIC SERVICE PROCEDURE</b> .....	22	Absolute Pressure Sensor (DTC: 0803).....	99
Fuel Pressure Release.....	22	<b>TROUBLE DIAGNOSIS FOR DTC P0110</b> .....	105
Fuel Pressure Check.....	22	Intake Air Temperature Sensor (DTC: 0401).....	105
Injector Removal and Installation.....	23	<b>TROUBLE DIAGNOSIS FOR DTC P0115</b> .....	110
Fast Idle Inspection and Adjustment.....	24	Engine Coolant Temperature Sensor (ECTS) (DTC: 0103).....	110
Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment.....	25	<b>TROUBLE DIAGNOSIS FOR DTC P0120</b> .....	114
<b>ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION</b> .....	31	Throttle Position Sensor (DTC: 0403).....	114
Introduction.....	31	<b>TROUBLE DIAGNOSIS FOR DTC P0125</b> .....	119
Two Trip Detection Logic.....	31	Engine Coolant Temperature (ECT) Sensor (DTC: 0908).....	119
Diagnostic Trouble Code (DTC).....	31	<b>TROUBLE DIAGNOSIS FOR DTC P0130</b> .....	124
Freeze Frame Data.....	32	Front Heated Oxygen Sensor (Front HO2S) (DTC: 0303).....	124
Malfunction Indicator Lamp (MIL).....	33	<b>TROUBLE DIAGNOSIS FOR DTC P0130</b> .....	129
OBD System Operation Chart.....	36	Closed Loop Control (DTC: 0307).....	129
CONSULT.....	41	<b>TROUBLE DIAGNOSIS FOR DTC P0135</b> .....	130
Generic Scan Tool (GST).....	54	Front Heated Oxygen Sensor Heater (DTC: 0901).....	130
<b>TROUBLE DIAGNOSIS — Introduction</b> .....	56	<b>TROUBLE DIAGNOSIS FOR DTC P0136</b> .....	133
Introduction.....	56	Rear Heated Oxygen Sensor (Rear HO2S) (DTC: 0707).....	133
Diagnostic Worksheet.....	57	<b>TROUBLE DIAGNOSIS FOR DTC P0141</b> .....	138
<b>TROUBLE DIAGNOSIS — Work Flow</b> .....	58	Rear Heated Oxygen Sensor Heater (DTC: 0902).....	138
Work Flow.....	58		
Description for Work Flow.....	59		

# CONTENTS (Cont'd.)

<b>TROUBLE DIAGNOSIS FOR DTC P0171</b> .....142	<b>TROUBLE DIAGNOSIS FOR DTC P0705</b> .....220	GI
Fuel Injection System Function (Lean side)	Park/Neutral Position Switch (DTC: 1003).....220	MA
(DTC: 0115).....142	<b>TROUBLE DIAGNOSIS FOR DTC P1105</b> .....224	EM
<b>TROUBLE DIAGNOSIS FOR DTC P0172</b> .....147	Manifold Absolute Pressure (MAP)/Barometric	LC
Fuel Injection System Function (Rich side) (DTC:	Pressure (BARO) Switch Solenoid Valve (DTC:	EC
0114).....147	1302).....224	FE
<b>TROUBLE DIAGNOSIS FOR DTC P0180</b> .....151	<b>TROUBLE DIAGNOSIS FOR DTC P1130</b> .....230	CL
Tank Fuel Temperature Sensor (DTC: 0402).....151	Swirl Control Valve Control Solenoid Valve (DTC:	MT
<b>TROUBLE DIAGNOSIS FOR DTC P0300 - P0304</b> ....154	1004).....230	AT
No. 4 - 1 Cylinder Misfire, Multiple Cylinder	<b>TROUBLE DIAGNOSIS FOR DTC P1165</b> .....238	TF
Misfire (DTC: 0701 - 0605).....154	Swirl Control Valve Control Vacuum Check	PD
<b>TROUBLE DIAGNOSIS FOR DTC P0335</b> .....158	Switch (DTC: 0112).....238	FA
Crankshaft Position Sensor (CKPS) (OBD) (DTC:	<b>TROUBLE DIAGNOSIS FOR DTC P1320</b> .....242	RA
0802).....158	Ignition Signal (DTC: 0201).....242	BR
<b>TROUBLE DIAGNOSIS FOR DTC P0340</b> .....162	<b>TROUBLE DIAGNOSIS FOR DTC P1336</b> .....247	ST
Camshaft Position Sensor (CMPS) (DTC: 0101)....162	Crankshaft Position Sensor (CKPS) (OBD)	RS
<b>TROUBLE DIAGNOSIS FOR DTC P0400</b> .....166	(COG) (DTC: 0905).....247	BT
EGR Function (DTC: 0302).....166	<b>TROUBLE DIAGNOSIS FOR DTC P1400</b> .....251	HA
<b>TROUBLE DIAGNOSIS FOR DTC P0402</b> .....174	EGRC-Solenoid Valve (DTC: 1005).....251	EL
EGRC-BPT Valve Function (DTC: 0306).....174	<b>TROUBLE DIAGNOSIS FOR DTC P1401</b> .....254	IDX
<b>TROUBLE DIAGNOSIS FOR DTC P0420</b> .....176	EGR Temperature Sensor (DTC: 0305).....254	
Three Way Catalyst Function (DTC: 0702).....176	<b>TROUBLE DIAGNOSIS FOR DTC P1441</b> .....259	
<b>TROUBLE DIAGNOSIS FOR DTC P0440</b> .....179	Vacuum Cut Valve Bypass Valve (DTC: 0801).....259	
Evaporative Emission (EVAP) Control System	<b>TROUBLE DIAGNOSIS FOR DTC P1445</b> .....264	
(Small Leak) (DTC: 0705).....179	Evaporative Emission (EVAP) Canister Purge	
<b>TROUBLE DIAGNOSIS FOR DTC P0443</b> .....189	Volume Control Valve (DTC: 1008).....264	
Evaporative Emission (EVAP) Canister Purge	<b>TROUBLE DIAGNOSIS FOR DTC P1447</b> .....271	
Control Valve/Solenoid Valve (DTC: 0807).....189	Evaporative Emission (EVAP) Control System	
<b>TROUBLE DIAGNOSIS FOR DTC P0446</b> .....197	Purge Flow Monitoring (DTC: 0111).....271	
Evaporative Emission (EVAP) Canister Vent	<b>TROUBLE DIAGNOSIS FOR DTC P1550</b> .....278	
Control Valve (DTC: 0903).....197	Torque Converter Clutch Solenoid Valve (DTC:	
<b>TROUBLE DIAGNOSIS FOR DTC P0450</b> .....202	0904).....278	
Evaporative Emission (EVAP) Control System	<b>TROUBLE DIAGNOSIS FOR NON-DETECTABLE</b>	
Pressure Sensor (DTC: 0704).....202	<b>ITEMS</b> .....280	
<b>TROUBLE DIAGNOSIS FOR DTC P0500</b> .....206	Injector.....280	
Vehicle Speed Sensor (VSS) (DTC: 0104).....206	Start Signal.....283	
<b>TROUBLE DIAGNOSIS FOR DTC P0505</b> .....210	Fuel Pump.....285	
Idle Air Control Valve (IACV) — Auxiliary Air	Power Steering Oil Pressure Switch.....289	
Control (AAC) Valve (DTC: 0205).....210	IACV-FICD Solenoid Valve.....292	
<b>TROUBLE DIAGNOSIS FOR DTC P0510</b> .....214	MIL & Data Link Connectors.....296	
Closed Throttle Position Switch (DTC: 0203).....214	<b>TROUBLE DIAGNOSIS — Index</b> .....297	
<b>TROUBLE DIAGNOSIS FOR DTC P0605</b> .....218	Alphabetical & P No. Index for DTC.....297	
Engine Control Module (ECM)-ECCS Control	<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....299	
Module (DTC: 0301).....218	General Specifications.....299	
	Inspection and Adjustment.....299	

## When you read wiring diagrams:


- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".

# PRECAUTIONS AND PREPARATION

## Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
(J36471-A) Front heated oxygen sensor wrench	 Loosening or tightening front heated oxygen sensor  NT379

## Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag module (located in the center of the steering wheel), a diagnosis sensor unit, warning lamp, wiring harness, crash zone sensor (4WD models) and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

### WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.

## Precautions for On Board Diagnostic (OBD) System of Engine

The ECM (ECCS control module) has an on-board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

### CAUTION:


- Be sure to turn the ignition switch "OFF" and disconnect the negative battery terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MIL to light up due to the short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to the malfunction of the EGR system or fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM before returning the vehicle to the customer.

# PRECAUTIONS AND PREPARATION

## Engine Fuel & Emission Control System


### FUEL PUMP

- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.



### BATTERY

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.



### ECM


- Do not disassemble ECCS control module (ECM).
- Do not turn diagnosis mode selector forcibly.
- If a battery terminal is disconnected, the memory will return to the ECM value.  
The ECCS will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

### WHEN STARTING

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.

### WIRELESS EQUIPMENT

- When installing CB ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on its installation location.
  - 1) Keep the antenna as far away as possible from the electronic control units.
  - 2) Keep the antenna feeder line more than 20 cm (7.9 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
  - 3) Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
  - 4) Be sure to ground the radio to vehicle body.



### ECCS PARTS HANDLING






- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble IACV-AAC valve.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor.

### ECCS HARNESS HANDLING

- Securely connect ECCS harness connectors.  
A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep ECCS harness at least 10 cm (3.9 in) away from adjacent harnesses, to prevent an ECCS system malfunction due to receiving external noise.
- Keep ECM parts and harnesses dry.
- Before removing parts, turn off ignition switch and then disconnect battery ground cable.

GI  
MA  
EM  
LC  
EC  
PE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

## PRECAUTIONS AND PREPARATION




### Precautions

- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.
- When connecting ECM harness connector, tighten securing bolt until the gap between orange indicators disappears.
  - ☞: 3 - 5 N·m (0.3 - 0.5 kg·m, 26 - 43 in·lb)
- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).  
Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.
- Before replacing ECM, perform ECM Terminals and Reference Value inspection and make sure ECM functions properly. Refer to EC-85.
- After performing each TROUBLE DIAGNOSIS, perform "OVERALL FUNCTION CHECK" or "DTC (Diagnostic Trouble Code) CONFIRMATION PROCEDURE". The DTC should not be displayed in the "DTC CONFIRMATION PROCEDURE" if the repair is completed. The "OVERALL FUNCTION CHECK" should be a good result if the repair is completed.

## PRECAUTIONS AND PREPARATION

### Precautions (Cont'd)

- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL


IDX

# ENGINE AND EMISSION CONTROL OVERALL SYSTEM

## Circuit Diagram



System Diagram





- \*1: Ignition coil, power transistor and camshaft position sensor: built into distributor
- \*2: EVAP shut valve
- \*3: Vacuum cut valve bypass valve
- \*4: EVAP control system pressure sensor
- \*5: EVAP canister purge volume control valve
- \*6: EVAP canister purge control valve
- \*7: Crankshaft position sensor (OBD)

GI  
MA  
EM  
LC  
**EC**  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX








# ENGINE AND EMISSION CONTROL OVERALL SYSTEM

## ECCS Component Parts Location



# ENGINE AND EMISSION CONTROL OVERALL SYSTEM


## ECCS Component Parts Location (Cont'd)



GI  
MA  
EM  
LC  
**EC**  
FE  
CL  
MT  
AT  
TF  
PD  
FA  
RA  
BR  
ST  
RS  
BT  
HA  
EL  
IDX

# ENGINE AND EMISSION CONTROL OVERALL SYSTEM

## Vacuum Hose Drawing




Refer to "System Diagram", EC-7 for vacuum control system.

AEC146A

# ENGINE AND EMISSION CONTROL OVERALL SYSTEM

## System Chart




\*1: These sensors are not directly used to control the engine system. They are used only for the on board diagnosis.

\*2: This sensor is not used to control the engine system under normal conditions.

\*3: This switch will operate in place of the throttle position sensor to control EVAP parts if the sensor malfunctions.

## Multiport Fuel Injection (MFI) System

### INPUT/OUTPUT SIGNAL LINE



### BASIC MULTIPOINT FUEL INJECTION SYSTEM

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and air intake) from both the camshaft position sensor and the mass air flow sensor.

### VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION


In addition, the amount of fuel injection is compensated for to improve engine performance under various operating conditions as listed below.

(Fuel increase)

- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- High-load, high-speed operation

(Fuel decrease)

- During deceleration
- During high engine speed operation



## Multiport Fuel Injection (MFI) System (Cont'd) MIXTURE RATIO FEEDBACK CONTROL

The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The three way catalyst can then better reduce CO, HC and NOx emissions. This system uses a front heated oxygen sensor in the exhaust manifold to monitor if the engine is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about front heated oxygen sensor, refer to page EC-124. This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition. Rear heated oxygen sensor is located downstream of the three way catalyst. Even if the switching characteristics of the front heated oxygen sensor shift, the air-fuel ratio is controlled to stoichiometric by the signal from the rear heated oxygen sensor.

## OPEN LOOP CONTROL

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Engine idling
- Malfunction of front heated oxygen sensor or its circuit
- Insufficient activation of front heated oxygen sensor at low engine coolant temperature
- High-engine coolant temperature
- During warm-up
- After shifting from "N" to "D"
- When starting the engine

## MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from the front heated oxygen sensor. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both Manufacturing differences (i.e. mass air flow sensor hot wire) and characteristic changes during operation (i.e. injector clogging) directly affect mixture ratio.

Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short-term fuel trim and long-term fuel trim.

"Short-term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from the front heated oxygen sensor indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

"Long-term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the short-term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.

# ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION


## Multiport Fuel Injection (MFI) System (Cont'd)

### FUEL INJECTION TIMING

Two types of systems are used.

#### Sequential multiport fuel injection system

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.




#### Simultaneous multiport fuel injection system

Fuel is injected simultaneously into all four cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The four injectors will then receive the signals two times for each engine cycle.

This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.




### FUEL SHUT-OFF

Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high speeds.

## Distributor Ignition (DI) System

### INPUT/OUTPUT SIGNAL LINE



# ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

## Distributor Ignition (DI) System (Cont'd)

### SYSTEM DESCRIPTION

The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine.

The ignition timing data is stored in the ECM. This data forms the map shown.


The ECM detects information such as the injection pulse width and camshaft position sensor signal. Responding to this information, ignition signals are transmitted to the power transistor.

e.g. N: 1,800 rpm, Tp: 1.50 msec

A °BTDC


During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- When swirl control valve operates.
- Hot engine operation
- During acceleration



## Air Conditioning Cut Control

### INPUT/OUTPUT SIGNAL LINE



### SYSTEM DESCRIPTION

This system improves engine operation when the air conditioner is used.


Under the following conditions, the air conditioner is turned off.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- When the engine coolant temperature becomes excessively high.



## Fuel Cut Control (at no load & high engine speed)

### INPUT/OUTPUT SIGNAL LINE



If the engine speed is above 3,500 rpm with no load (for example, in neutral and engine speed over 3,500 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed.


Fuel cut will operate until the engine speed reaches 1,500 rpm, then fuel cut is cancelled.

**NOTE:**

**This function is different than deceleration control listed under multiport fuel injection on EC-12.**

# EVAPORATIVE EMISSION SYSTEM

## Description



The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister.

The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating.

The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating.

EVAP canister purge volume control valve is controlled by engine control module. When the engine operates, the flow rate of vapor purged by EVAP canister purge volume control valve is proportionally regulated as the air flow increases.

EVAP canister purge control valve shuts off the vapor purge line during decelerating and idling, and under normal operating conditions the valve is usually open.


EVAP shut valve shuts off the vapor charge line when fuel is being supplied to the fuel tank.

## Inspection

### EVAP CANISTER

Check EVAP canister as follows:

1. Pinch the fresh air vent hose.
2. Blow air in port (A) and check that it flows freely out of port (B).






## EVAPORATIVE EMISSION SYSTEM

### Inspection (Cont'd)

#### TIGHTENING TORQUE

Tighten EVAP canister as shown in the figure.



#### FUEL TANK VACUUM RELIEF VALVE

1. Wipe clean valve housing.
2. Suck air through the cap. A slight resistance accompanied by valve clicks indicates that valve A is in good mechanical condition. Note also that, by further sucking air, the resistance should disappear with valve clicks.
3. Blow air on fuel tank side and ensure that continuity of air passage exists through valve B.
4. If valve is clogged or if no resistance is felt, replace cap as an assembly.

#### CAUTION:

**Use only a genuine fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.**

#### EVAPORATIVE EMISSION (EVAP) SHUT VALVE

- When pushing down the shutter inside the fuel filler opening, the EVAP shut valve is closed.
  - When releasing the shutter, the valve is open.
1. Blow air from one side of the EVAP shut valve tube (a) or (b) and check that there is air flow.
  2. Insert suitable steel tube as shown in the figure.
  3. Blow air from one side of the EVAP shut valve tube (a) or (b) and check that there is no air flow.

#### EVAP CANISTER PURGE CONTROL VALVE

Refer to EC-189.

#### VACUUM CUT VALVE

Refer to EC-263.

#### EVAPORATIVE EMISSION (EVAP) CANISTER PURGE VOLUME CONTROL VALVE

Refer to EC-264.


#### EVAPORATIVE EMISSION (EVAP) CANISTER PURGE CONTROL SOLENOID VALVE

Refer to EC-189.

#### TANK FUEL TEMPERATURE SENSOR

Refer to EC-151.

### Evaporative Emission Line Drawing



- GI
- MA
- EM
- LC
- EC**
- FE
- CL
- MT
- AT
- TF
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL
- IDX