

2004



NISSAN

TERRANO II model R20 series supplement



SERVICE MANUAL

GENERAL INFORMATION

GI

SECTION GI

CONTENTS

PRECAUTIONS	2	IDENTIFICATION INFORMATION.....	18
Precautions for E.F.I. or E.C.C.S. Engine	3	Model Variation	18
Precautions for Catalyst	4	Identification Number.....	20
Precautions for Turbocharger	4	Dimensions	22
Precautions for Fuel	4	Wheel and Tires.....	22
Engine Oils	5		
HOW TO USE THIS MANUAL	7	LIFTING POINTS AND TOW TRUCK TOWING.....	23
HOW TO READ WIRING DIAGRAMS	9	Garage Jack and Safety Stand	23
HOW TO FOLLOW FLOW CHART IN		Screw Jack	23
TROUBLE DIAGNOSES	12	4-pole Lift	24
CONSULT CHECKING SYSTEM	16	Tow Truck Towing	24
Lithium Battery Replacement	16		
Function and System Application	17	TIGHTENING TORQUE OF STANDARD BOLTS	26
Checking Equipment.....	17		

<SUPPLEMENT-I>

MODIFICATIONS	1002
PRECAUTIONS	1003
Precautions for NATS V2.0.....	1003
CONSULT CHECKING SYSTEM	1004
Function and System Application	1004
Lithium Battery Replacement	1004
Checking Equipment.....	1004

IDENTIFICATION INFORMATION.....	1005
Model Variation	1005
Wheel and Tires.....	1007
SAE J1930 TERMINOLOGY LIST	1008

<SUPPLEMENT-II>

MODIFICATIONS	2002
PRECAUTIONS	2003
Supplemental Restraint System (SRS) "AIR BAG"	2003
Precautions for NATS V2.0 (For Diesel)	2003

CONTENTS (Cont'd)

<SUPPLEMENT-III>

MODIFICATIONS	3002
CONSULT CHECKING SYSTEM	3003
Function and System Application	3003
Checking Equipment.....	3003

IDENTIFICATION INFORMATION	3004
Model Variation	3004
Identification Number.....	3006
Dimensions	3008
Wheel and Tires.....	3008

<SUPPLEMENT-IV> (For Africa and Gulf Countries)

MODIFICATIONS	4002
IDENTIFICATION INFORMATION	4003
Model Variation	4003
Identification Number.....	4004

Dimensions	4005
Wheel and Tires.....	4005

<SUPPLEMENT-V> (For Australia)

MODIFICATIONS	5002
PRECAUTIONS	5003
Precautions for Fuel	5003

IDENTIFICATION INFORMATION	5004
Model Variation	5004
Identification Number.....	5005

<SUPPLEMENT-VI> (For Europe and Australia)

MODIFICATIONS	6002
PRECAUTIONS	6003
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" (Dual Air Bag System)	6003

IDENTIFICATION INFORMATION	6004
Model Variation	6004
Identification Number.....	6006

<SUPPLEMENT-VII> (For Europe)

MODIFICATIONS	7002
IDENTIFICATION INFORMATION	7003
Model Variation	7003

LIFTING POINTS AND TOW TRUCK TOWING	7006
Tow Truck Towing	7006

<SUPPLEMENT-VIII> (For Africa and Gulf Countries)

MODIFICATIONS	8002
IDENTIFICATION INFORMATION	8003
Model Variation	8003

Identification Number.....	8005
Dimensions	8006
Wheel and Tires.....	8006

<SUPPLEMENT-IX> (For Europe, Africa and Gulf Countries)

MODIFICATIONS	9002
CONSULT CHECKING SYSTEM	9003
General	9003
Function and System Application	9003
Nickel Metal Hydride Battery Replacement.....	9003
Checking Equipment.....	9004

IDENTIFICATION INFORMATION	9005
Model Variation	9005
Identification Number.....	9007
Dimensions	9009
Wheel and Tires.....	9009

<SUPPLEMENT-X> (For Gulf Countries)

MODIFICATIONS	10002
Checking Equipment.....	10003

IDENTIFICATION INFORMATION	10004
Model Variation	10004

CONTENTS (Cont'd)

<SUPPLEMENT-XI> (For Europe)

MODIFICATIONS	11002
IDENTIFICATION INFORMATION	11003
Model Variation	11003

<SUPPLEMENT-XII> (For Africa, Gulf Countries and Central & South America)

MODIFICATIONS	12002	Identification Number.....	12004
IDENTIFICATION INFORMATION	12003	Dimensions	12005
Model Variation	12003		

<SUPPLEMENT-XIII> (For Africa, Gulf Countries and Russia)

MODIFICATIONS	13002	Model Variation	13003
IDENTIFICATION INFORMATION	13003	Identification Number.....	13004

GENERAL INFORMATION

GI

SECTION GI

CONTENTS

MODIFICATIONS	13002
IDENTIFICATION INFORMATION	13003
Model Variation	13003
Identification Number.....	13004

MODIFICATIONS

OUTLINE OF MODIFICATIONS

Applied from:

- **For Africa and Russia: VSK★B★R20★0550000**
- **For Gulf Countries: VSKBR4★C★★A550000**

★: Any of the possibilities. See Vehicle Identification Number arrangement.

Electrical

- Wiring diagrams have been changed.

Seat belts


- The center seat belt on the 2nd seat has been changed from two-point type to three-point type.

IDENTIFICATION INFORMATION

Model Variation


Body	Grade	Engine	Transmission	Africa (LHD)	Africa (RHD)	GCC	Russia
H/T	Luxury	KA24E	FS5W71C	—	—	KBFNLVF-EKD	—
	Sport	KA24E		—	—	KBFNLUF-EKD	—
Wagon	Luxury	KA24E	FS5W71C	TBFULVF-LYD	TBFURVF-LYD	TBFULVF-EKD	TBFULVF-ESD
	Sport	KA24E		TBFULUF-LYD	TBFURUF-LYD	TBFULUF-EKD	TBFULUF-ESD

Prefix and suffix designations:



IDENTIFICATION INFORMATION

Identification Number




EGI013

VEHICLE IDENTIFICATION NUMBER (Chassis number)

Prefix and suffix designations:

For Africa and Russia:




IDENTIFICATION INFORMATION

Identification Number (Cont'd)

Prefix and suffix designations:

For Gulf Countries:



MAINTENANCE

SECTION MA

MA

CONTENTS

<COMBINED EDITION>

PRE-DELIVERY INSPECTION ITEMS	3
GENERAL MAINTENANCE	4
PERIODIC MAINTENANCE	5
RECOMMENDED FLUIDS AND LUBRICANTS	8
Fluids and Lubricants	8
SAE Viscosity Number.....	9
ENGINE MAINTENANCE KA24E	10
Checking Drive Belts	10
Changing Engine Coolant.....	11
Checking Cooling system	12
Checking Fuel Lines	13
Changing Fuel Filter	13
Changing Air Cleaner Filter (Viscous paper type)	13
Changing Engine Oil.....	14
Changing Oil Filter.....	15
Checking and Changing Spark Plugs	15
Checking Ignition Wires.....	16
Checking Positive Crankcase Ventilation (P.C.V.) System.....	16
Changing Positive Crankcase Ventilation (P.C.V.) Filter.....	17
Checking Vacuum Hoses and Connections	17
Checking Vapor Lines.....	17
Checking Exhaust Gas Recirculation (E.G.R.) Control System	17
Checking Exhaust Gas Sensor	18
ENGINE MAINTENANCE TD27T	19
Retightening Manifold Bolts and Nuts	19
Adjusting Intake and Exhaust Valve Clearance	19
Drive Belt Inspection.....	20
Changing Engine Oil.....	20
Changing Oil Filter.....	21
Changing Engine Coolant.....	21
Checking Cooling System	22
Checking and Replacing Fuel Filter and Draining Water	23
Replacing Air Cleaner Filter (Viscous paper type)	24
Checking Injection Nozzle	24
Checking Idle Speed	25
CHASSIS AND BODY MAINTENANCE	28
Checking Exhaust System.....	28
Checking Clutch Operation.....	28
Checking Clutch Fluid Level and Leaks.....	28
Checking Clutch System	28
Checking M/T Oil	28
Changing M/T Oil.....	29
Checking Water Entry	29
Checking Transfer Oil	29
Changing Transfer Oil	30
Checking Propeller Shaft	30
Checking Differential Gear Oil	30
Changing Differential Gear Oil	31
Checking Front Wheel Bearing Grease	31
Repacking Front Wheel Bearing Grease	31
Checking Free-running Hub Grease	32
Checking Brake Fluid Level and Leaks.....	32
Checking Brake System	32
Checking Brake Booster, Vacuum Hoses, Connections and Check Valve	32
Checking Disc Brake	32
Checking Drum Brake	33
Checking Foot Brake Pedal Operation.....	34
Checking Parking Brake	34
Changing Brake Fluid	34
Balancing Wheels	35
Tire Rotation	35
Checking Steering Gear and Linkage	35
Checking Fluid Level and Leaks (Power steering)	35

CONTENTS (Cont'd)

Greasing Steering Linkage	36
Body	37
Checking Body Corrosion	39

SERVICE DATA AND SPECIFICATIONS (S.D.S.)	40
Engine Maintenance	40
Chassis and Body Maintenance	41

<SUPPLEMENT-I>

PERIODIC MAINTENANCE	1002
RECOMMENDED FLUIDS AND LUBRICANTS	1004
Fluids and Lubricants	1004
ENGINE MAINTENANCE TD27T	1005
Cleaning and Replacing Air Cleaner Filter (Dry paper type).....	1005

SERVICE DATA AND SPECIFICATIONS (SDS)	1006
Engine Maintenance	1006

<SUPPLEMENT-II>

PERIODIC MAINTENANCE	2002
-----------------------------------	-------------

<SUPPLEMENT-III>

PRE-DELIVERY INSPECTION ITEMS	3002
PERIODIC MAINTENANCE (For Europe)	3003
PERIODIC MAINTENANCE (Except for Europe)	3007
RECOMMENDED FLUIDS AND LUBRICANTS	3011
Fluids and Lubricants.....	3011
SAE Viscosity Number.....	3012
ENGINE MAINTENANCE TD27Ti	3013
Adjusting Intake and Exhaust Valve	
Clearance.....	3013
Changing Engine Oil.....	3013
Checking and Replacing Fuel Filter and Draining Water	3014

Cleaning and Replacing Air Cleaner Filter (Dry paper type).....	3015
Checking Injection Nozzle	3015
CHASSIS AND BODY MAINTENANCE	3016
Checking Clutch Operation.....	3016
Checking Fluid Level and Leaks (Power Steering)	3016
SERVICE DATA AND SPECIFICATIONS (SDS)	3018
Engine Maintenance	3018
Chassis and Body Maintenance	3019

<SUPPLEMENT-IV> (For Africa and Gulf Countries)

PERIODIC MAINTENANCE	4002
RECOMMENDED FLUIDS AND LUBRICANTS	4006
Fluids and Lubricants	4006
SAE Viscosity Number.....	4007
ENGINE MAINTENANCE KA24E	4008
Cleaning and Replacing Air Cleaner Filter (Dry Paper Type)	4008
Checking and Changing Spark Plugs	4008

ENGINE MAINTENANCE TD27T	4009
Cleaning and Replacing Air Cleaner Filter (Dry Paper Type)	4009
CHASSIS AND BODY MAINTENANCE	4010
Checking Clutch Operation.....	4010
SERVICE DATA AND SPECIFICATIONS (SDS)	4011
Engine Maintenance	4011
Chassis and Body Maintenance	4011

<SUPPLEMENT-V> (For Australia)

PERIODIC MAINTENANCE	5002
Engine and Emission Control Maintenance	5002
Chassis and Body Maintenance.....	5003
Maintenance Under Severe Driving Conditions	5004

CONTENTS (Cont'd)

<SUPPLEMENT-VI> (For Europe and Australia)

GENERAL MAINTENANCE (for Europe)	6002
PERIODIC MAINTENANCE (for Europe)	6003
Maintenance Schedule for Petrol Engine	
Models (annual mileage < 30,000 km/year).....	6003
Maintenance Schedule for Petrol Engine	
Models (annual mileage > 30,000 km/year).....	6005
Maintenance Schedule for Diesel Engine	
Models (annual mileage < 30,000 km/year).....	6007
Maintenance Schedule for Diesel Engine	
Models (annual mileage > 30,000 km/year).....	6009
Maintenance Under Severe Driving Conditions	
(annual mileage < 30,000 km/year).....	6011
Maintenance Under Severe Driving Conditions	
(annual mileage > 30,000 km/year).....	6013
RECOMMENDED FLUIDS AND LUBRICANTS	6015
Fluids and Lubricants	6015
SAE Viscosity Number.....	6016

KA24E

ENGINE MAINTENANCE	6017
Changing Engine Coolant.....	6017

<SUPPLEMENT-VII> (For Europe)

GENERAL MAINTENANCE	7002
PERIODIC MAINTENANCE	7003
Maintenance Schedule for Petrol Engine	
Models (annual mileage < 30,000 km/year).....	7003
Maintenance Schedule for Petrol Engine	
Models (annual mileage > 30,000 km/year).....	7005
Maintenance Schedule for Diesel Engine	
Models (annual mileage < 30,000 km/year).....	7007
Maintenance Schedule for Diesel Engine	
Models (annual mileage > 30,000 km/year).....	7009
Maintenance Under Severe Driving Conditions	
(annual mileage < 30,000 km/year).....	7011

TD27Ti	
ENGINE MAINTENANCE	6019
Changing Engine Oil.....	6019
Retightening Manifold Bolts and Nuts	6019
Changing Engine Coolant.....	6019
Cleaning and Replacing Air Cleaner Filter	
(Dry paper type).....	6020
Checking Injection Nozzle	6021
CHASSIS AND BODY MAINTENANCE	6022
Checking Differential Gear Oil.....	6022
Changing Differential Gear Oil.....	6022
Ventilation Air Filter.....	6023
SERVICE DATA AND SPECIFICATIONS (SDS).....	6024
Engine Maintenance	6024
Chassis and Body Maintenance	6024

Maintenance Under Severe Driving Conditions	
(annual mileage > 30,000 km/year).....	7013

RECOMMENDED FLUIDS AND LUBRICANTS	7015
Fluids and Lubricants	7015
CHASSIS AND BODY MAINTENANCE	7016
Checking A/T Fluid	7016
Changing A/T Fluid	7016
SERVICE DATA AND SPECIFICATIONS (SDS).....	7017
Engine Maintenance	7017

<SUPPLEMENT-VIII> (For Africa and Gulf Countries)

RECOMMENDED FLUIDS AND LUBRICANTS	8002
Fluids and Lubricants	8002

KA24E

ENGINE MAINTENANCE	8003
Changing Engine Coolant.....	8003

TD27T	
ENGINE MAINTENANCE	8005
Changing Engine Coolant.....	8005

CHASSIS AND BODY MAINTENANCE	8006
Checking Differential Gear Oil.....	8006
Changing Differential Gear Oil.....	8006
Ventilation Air Filter.....	8006

CONTENTS (Cont'd)

<SUPPLEMENT-IX> (For Europe, Africa and Gulf Countries)

ENGINE MAINTENANCE	9002	CHASSIS AND BODY MAINTENANCE	9003
Changing Engine Oil.....	9002	Checking Drum Brake	9003

<SUPPLEMENT-X> (For Africa and Gulf Countries)

NO CHANGES

<SUPPLEMENT-XI> (For Europe)

NO CHANGES

<SUPPLEMENT-XII> (For Africa, Gulf Countries and Central & South America)

NO CHANGES

<SUPPLEMENT-XIII> (For Africa, Gulf Countries and Russia)

CHASSIS AND BODY MAINTENANCE	13002	Checking Foot Brake Pedal Operation.....	13002
Checking Clutch Operation.....	13002	Body.....	13003
Checking Transfer Oil	13002	SERVICE DATA AND SPECIFICATIONS (SDS)	13004
Changing Transfer Oil.....	13002	Chassis and Body Maintenance.....	13004


MAINTENANCE

SECTION MA

MA

CONTENTS

CHASSIS AND BODY MAINTENANCE	13002
Checking Clutch Operation.....	13002
Checking Transfer Oil	13002
Changing Transfer Oil.....	13002
Checking Foot Brake Pedal Operation.....	13002
Body.....	13003
SERVICE DATA AND SPECIFICATIONS (SDS)	13004
Chassis and Body Maintenance.....	13004



Checking Clutch Operation

Check clutch pedal height, free play and smooth operation.

Pedal height "H":


LHD: 217 - 227 mm (8.54 - 8.94 in)

RHD: 200 - 210 mm (7.87 - 8.27 in)

Pedal free play "A":


1 - 3 mm (0.039 - 0.118 in)

If necessary, adjust clutch pedal height and pedal free play. Refer to Section CL.



Checking Transfer Oil


1. Check transfer for leakage.



2. Check oil level.

Never start engine while checking oil level.

"DEXRON™" type Automatic Transmission Fluid is used for the transfer in the factory. Never add gear oil (API GL-4) to Automatic Transmission Fluid.




Changing Transfer Oil

Oil capacity:

2.3 liters (2 Imp qt)

When changing transfer oil completely, either "DEXRON™" type Automatic Transmission Fluid or gear oil (API GL-4) may be used.

Do not mix Automatic Transmission Fluid and gear oil.



Checking Foot Brake Pedal Operation

Check brake pedal free height, depressed height and for smooth operation.

H: Free height:

RHD: 196 - 206 mm (7.72 - 8.11 in)

LHD: 210 - 220 mm (8.27 - 8.66 in)

D: Depressed height:

Under force of 490 N (50 kg, 110 lb)
with engine running

RHD: 137.7 - 147.7 mm (5.42 - 5.81 in)


LHD: 142.5 - 152.5 mm (5.61 - 6.00 in)

A: Pedal free play

1.0 - 3.0 mm (0.039 - 0.118 in)

Body


CHECKING SEAT BELTS, BUCKLES, RETRACTORS, ANCHORS AND ADJUSTERS



CAUTION:

- After any collision, inspect all seat belt assemblies, including retractors and other attached hardwares (i.e. anchor bolt, guide rail set). Nissan recommends to replace all seat belt assemblies in use during a collision, unless not damaged and properly operating after minor collision. Replace the seat belt assembly if any damage or improper operation were found even if the belt had not been used during a collision.
- Also inspect seat belt assemblies not in use during a collision, and replace if damaged or improperly operating. Front seat belt pre-tensioner should be replaced even if the seat belt are not in use during a frontal collision where the driver and passenger air bags are deployed.
- If any component of seat belt assembly is questionable, do not repair. Replace as seat belt assembly.
- If webbing is cut, frayed, or damaged, replace belt assembly.
- Do not spill drinks, oil etc. on inner lap belt buckle. Never oil tongue and buckle.
- Use a NISSAN genuine seat belt assembly.

43.1 - 54.9 (4.4 - 5.6, 32 - 40)



CAUTION:

When removing the seat belt and seat belt pre-tensioner retractor, be sure to make the seat belt pre-tensioner inoperative. Refer to "SUPPLEMENTAL RESTRAINT SYSTEM (SRS)" –Removal and Installation– Seat belt pre-tensioner in section BF.

N : N·m (kg·m, ft-lb)

YMA021


SERVICE DATA AND SPECIFICATIONS (SDS)

Chassis and Body Maintenance

INSPECTION AND ADJUSTMENT

Front axle and front suspension (Unladen)*1

Applied model	Hardtop	Wagon
Camber	degree	0°38'±30'
Caster	degree	1°45'±30'
Kingpin inclination	degree	8°03'±30'
Total toe-in		
Radial tire	mm (in)	3.8 - 5.8 (0.15 - 0.23)
Front wheel turning angle		
Full turn		
inside		33° - 35°
outside		31° - 33°
Vehicle posture		
Lower arm pivot height (H) mm (in)		49 (1.93)



NFA021

*1: Fuel, radiator coolant and engine oil full.

Spare tire, jack, hand tools and mats in designated positions.

*2: Wheel turning force (at circumference of steering wheel) of 98 to 147 N (10 to 15 kg, 22 to 33 lb) with engine idle.

TIGHTENING TORQUE

Unit	N·m	kg·m	ft·lb
Clutch			
Pedal stopper lock nut KA24E	12 - 15	1.3 - 1.5	9 - 11
Master cylinder push rod lock nut	8 - 11	0.8 - 1.1	5.8 - 8.0
Manual transmission			
Drain and filler plugs FS5W71C	25 - 34	2.5 - 3.5	18 - 25
FS5R30A	25 - 34	2.5 - 3.5	18 - 25
Front axle and front suspension			
Tie-rod lock nut	80 - 100	8.2 - 10.1	59 - 73
Brake system			
Air bleeder valve	7 - 9	0.7 - 0.9	5.1 - 6.5
Wheel and tire			
Wheel nut	118 - 147	12.0 - 15.0	87.0 - 108.4

ENGINE MECHANICAL

SECTION EM

EM

CONTENTS

<COMBINED EDITION>

PRECAUTIONS	2
Parts Requiring Angular Tightening Liquid	2
Gasket Application Procedure	2
PREPARATION	3
KA24E	
OUTER COMPONENT PARTS	8
COMPRESSION PRESSURE.....	9
Measurement of Compression Pressure.....	9
OIL PAN	10
Removal.....	10
Installation	11
TIMING CHAIN	13
Removal.....	13
Inspection.....	15
Installation.....	15
CYLINDER HEAD	18
Removal.....	19
Disassembly.....	21
Inspection.....	21
Assembly	26
Installation.....	28
OIL SEAL REPLACEMENT	32
ENGINE REMOVAL	34
CYLINDER BLOCK	36
Disassembly.....	37
Inspection.....	37
Assembly	44

TD27T

ENGINE COMPONENTS — Outer Parts	47
COMPRESSION PRESSURE.....	49
Measurement of Compression Pressure.....	49
CYLINDER HEAD	50
Removal.....	51
Disassembly.....	52
Inspection.....	53
Assembly	59
Installation	60
OIL SEAL REPLACEMENT	63
TURBOCHARGER.....	65
Removal and Installation	65
Inspection.....	65
ENGINE REMOVAL	67
ENGINE OVERHAUL	69
Disassembly.....	70
Inspection.....	72
Assembly	84

KA24E

SERVICE DATA AND SPECIFICATIONS (S.D.S.).....	89
General Specifications	89
Inspection and Adjustment	90

TD27T

SERVICE DATA AND SPECIFICATIONS (S.D.S.).....	98
General Specifications	98
Inspection and Adjustment	99

CONTENTS (Cont'd)

<SUPPLEMENT-I>

TD27T

ENGINE COMPONENTS — Outer Parts	1002
ENGINE OVERHAUL	1004

<SUPPLEMENT-II>

NO CHANGES

<SUPPLEMENT-III>

PRECAUTIONS	3002
Parts Requiring Angular Tightening Liquid	3002
Gasket Application Procedure	3002
PREPARATION	3003
Special Service Tools.....	3003
Commercial Service Tools	3006

TD27Ti

ENGINE COMPONENTS — Outer Parts	3007
ENGINE COMPONENTS — Internal Parts.....	3009
COMPRESSION PRESSURE.....	3010
Measurement of Compression Pressure.....	3010
CYLINDER HEAD	3011
Removal.....	3012
Disassembly.....	3013
Inspection.....	3014

<SUPPLEMENT-IV> (For Africa and Gulf Countries)

KA24E

OUTER COMPONENTS	4002
CYLINDER HEAD	4003
Inspection.....	4003

Assembly	3020
Installation.....	3021
OIL SEAL REPLACEMENT	3024
TURBOCHARGER.....	3026
Removal and Installation	3026
Inspection.....	3026
ENGINE REMOVAL.....	3030
ENGINE OVERHAUL	3032
Disassembly	3032
Inspection.....	3034
Assembly	3045
SERVICE DATA AND SPECIFICATIONS (SDS).....	3050
General specifications	3050
Inspection and adjustment.....	3051

<SUPPLEMENT-V> (For Australia)

NO CHANGES

<SUPPLEMENT-VI> (For Europe and Australia)

PREPARATION	6002
Special Service Tools.....	6002

TD27Ti

ENGINE COMPONENTS — Outer Parts	6003
--	------

CYLINDER HEAD	6005
Removal.....	6005
TURBOCHARGER.....	6007
Inspection.....	6007

<SUPPLEMENT-VII> (For Europe)

TD27Ti

ENGINE COMPONENTS — Outer Parts	7002
--	------