

B ENGINE

SECTION **EM**

ENGINE MECHANICAL

CONTENTS**KA24DE**

PRECAUTIONS	5	REMOVAL	16	
Precautions for Drain Coolant	5	INSTALLATION	17	
Precautions for Disconnecting Fuel Piping	5	Changing Air Cleaner Element	18	
Precautions for Removal and Disassembly	5	REMOVAL	18	
Precautions for Inspection, Repair and Replacement	5	INSTALLATION	18	
Precautions for Assembly and Installation	5	THROTTLE BODY	19	
Parts Requiring Angular Tightening	5	Removal and Installation	19	
Precautions for Liquid Gasket	6	REMOVAL	19	
REMOVAL OF LIQUID GASKET SEALING	6	INSPECTION AFTER REMOVAL	20	
LIQUID GASKET APPLICATION PROCEDURE	6	INSTALLATION	20	
PREPARATION	7	Disassembly and Assembly	20	
Special Service Tools	7	DISASSEMBLY	20	
Commercial Service Tools	8	ASSEMBLY	20	
NOISE, VIBRATION, AND HARSHNESS (NVH)		INTAKE MANIFOLD	21	
TROUBLESHOOTING	10	Removal and Installation	21	
NVH Troubleshooting —Engine Noise	10	REMOVAL	21	
Use the Chart Below to Help You Find the Cause of the Symptom.	11	INSPECTION AFTER REMOVAL	22	
ENGINE ROOM COVER	12	INSTALLATION	22	
Removal and Installation of Engine Room Right Side	12	EXHAUST MANIFOLD	23	
REMOVAL	12	Removal and Installation	23	
INSTALLTION	12	REMOVAL	23	
Removal and Installation of Engine Room Rear Cover	12	INSPECTION AFTER REMOVAL	24	
REMOVAL	12	INSTALLATION	24	
INSTALLATION	13	INSPECTION AFTER INSTALLATION	24	
DRIVE BELTS	14	OIL PAN AND OIL STRAINER	25	
Checking Drive Belts	14	Removal and Installation	25	
Tension Adjustment	14	REMOVAL	25	
POWER STEERING PUMP BELT	14	INSPECTION AFTER REMOVAL	25	
AIR CONDITIONER COMPRESSOR BELT	14	INSTALLATION	25	
ALTERNATOR AND WATER PUMP BELT	15	INSPECTION AFTER INSTALLATION	26	
Removal and Installation	15	SPARK PLUG (CONVENTIONAL)	27	
REMOVAL	15	Removal and Installation	27	
INSTALLATION	15	REMOVAL	27	
AIR CLEANER AND AIR DUCT	16	INSPECTION AFTER REMOVAL	27	
Removal and Installation	16	INSTALLATION	27	
		FUEL INJECTOR AND FUEL TUBE	28	
		Removal and Installation	28	
		REMOVAL	28	
		INSTALLATION	29	
		INSPECTION AFTER INSTALLATION	29	

ROCKER COVER	30	ING	81
Removal and Installation	30	PISTON TO CYLINDER BORE CLEARANCE ...	82
REMOVAL	30	OUTER DIAMETER OF CRANKSHAFT JOUR-	
INSTALLATION	30	NAL	83
CAMSHAFT	32	OUTER DIAMETER OF CRANKSHAFT PIN ...	83
Removal and Installation	32	OUT-OF-ROUND AND TAPER OF CRANK-	
REMOVAL	32	SHAFT	83
INSTALLATION	34	CRANKSHAFT RUNOUT	83
INSPECTION AFTER REMOVAL	35	OIL CLEARANCE OF CONNECTING ROD	
Valve Clearance	38	BEARING	84
INSPECTION	38	OIL CLEARANCE OF MAIN BEARING	84
ADJUSTMENT	38	CRUSH HEIGHT OF MAIN BEARING	85
SECONDARY TIMING CHAIN	41	OIL JET	85
Removal and Installation	41	OIL JET RELIEF VALVE	85
REMOVAL	41	FLY WHEEL RUNOUT	86
INSPECTION AFTER REMOVAL	44	SERVICE DATA AND SPECIFICATIONS (SDS)	87
INSTALLATION	45	Standard and Limit	87
PRIMARY TIMING CHAIN	49	GENERAL SPECIFICATIONS	87
Removal and Installation	49	DRIVE BELTS	87
REMOVAL	50	INTAKE MANIFOLD AND EXHAUST MANI-	
INSPECTION AFTER REMOVAL	51	FOLD	87
INSTALLATION	51	SPARK PLUG	88
CYLINDER HEAD	55	SECONDARY TIMING CHAIN	88
On-Vehicle Service	55	CYLINDER HEAD	88
CHECKING COMPRESSION PRESSURE	55	VALVE	88
Removal and Installation	56	CAMSHAFT AND CAMSHAFT BEARING	92
REMOVAL AND INSTALLATION	56	CYLINDER BLOCK	92
Disassembly and Assembly	57	PISTON, PISTON RING AND PISTON PIN ...	93
DISASSEMBLY	57	CONNECTING ROD	94
ASSEMBLY	58	CRANKSHAFT	94
INSPECTION AFTER DISASSEMBLY	58	MAIN BEARING	95
ENGINE ASSEMBLY	63	CONNECTING ROD BEARING	95
Removal and Installation	63	FLYWHEEL	96
REMOVAL	64	Tightening Torque	96
INSTALLATION	65		
INSPECTION AFTER INSTALLATION	66		
CYLINDER BLOCK	67		
Disassembly and Assembly	67		
DISASSEMBLY	68		
ASSEMBLY	70		
How to Select Piston and Bearing	74		
DESCRIPTION	74		
HOW TO SELECT PISTON	75		
HOW TO SELECT CONNECTING ROD BEAR-			
ING	75		
HOW TO SELECT MAIN BEARING	76		
Inspection After Disassembly	78		
CRANKSHAFT SIDE CLEARANCE	78		
CONNECTING ROD SIDE CLEARANCE	78		
PISTON AND PISTON PIN CLEARANCE	78		
PISTON RING SIDE CLEARANCE	79		
PISTON RING END GAP	79		
CONNECTING ROD BEND AND TORSION	80		
CONNECTING ROD BEARING (BIG END)	80		
CONNECTING ROD BUSHING OIL CLEAR-			
ANCE (SMALL END)	80		
CYLINDER BLOCK DISTORTION	81		
INNER DIAMETER OF MAIN BEARING HOUS-			

ZD30DD

PRECAUTIONS	98
Precautions for Drain Coolant	98
Precautions for Disconnecting Fuel Piping	98
Precautions for Removal and Disassembly	98
Precautions for Inspection, Repair and Replace-	
ment	98
Precautions for Assembly and Installation	98
Parts Requiring Angular Tightening	98
Precautions for Liquid Gasket	99
REMOVAL OF LIQUID GASKET SEALING	99
LIQUID GASKET APPLICATION PROCEDURE	99
PREPARATION	100
Special Service Tools	100
Commercial Service Tools	102
NOISE, VIBRATION, AND HARSHNESS (NVH)	
TROUBLESHOOTING	103
NVH Troubleshooting —Engine Noise	103
Use the Chart Below to Help You Find the Cause	
of the Symptom.	104
ENGINE ROOM COVER	105
Removal and Installation of Engine Room Right	

Side	105	INJECTION TUBE AND INJECTION NOZZLE	125	
REMOVAL	105	Removal and Installation	125	A
INSTALLATION	105	REMOVAL	125	
Removal and Installation of Engine Room Rear		INSPECTION AFTER REMOVAL	127	
Cover	105	INSTALLATION	127	EM
REMOVAL	105	INSPECTION AFTER INSTALLATION	128	
INSTALLATION	106	ELECTRONIC CONTROL FUEL INJECTION PUMP	129	
DRIVE BELTS	107	Removal and Installation	129	C
Checking Drive Belt	107	REMOVAL	129	
Tension Adjustment	107	INSTALLATION	132	D
Removal and Installation	107	INSPECTION AFTER INSTALLATION	134	
WATER PUMP, ALTERNATOR AND A/C COMPRESSOR BELT	107	ROCKER COVER	135	E
Drive Belt Auto Tensioner	109	Removal and Installation	135	
REMOVAL	109	REMOVAL	135	F
INSPECTION AFTER REMOVAL	109	INSTALLATION	136	
INSTALLATION	109	CAMSHAFT	138	G
Dummy Pulley	109	Removal and Installation	138	
REMOVAL	109	REMOVAL	139	H
INSPECTION AFTER REMOVAL	109	INSPECTION AFTER REMOVAL	139	
INSTALLATION	109	INSTALLATION	141	I
AIR CLEANER AND AIR DUCT	110	Valve Clearance	142	
Removal and Installation	110	INSPECTION	142	J
REMOVAL	110	ADJUSTMENTS	144	
INSTALLATION	111	TIMING CHAIN	147	K
Changing Air Cleaner Element	112	Removal and Installation	147	
REMOVAL	112	REMOVAL	147	L
INSTALLATION	112	INSPECTION AFTER REMOVAL	149	
INTAKE MANIFOLD COLLECTOR AND INTAKE MANIFOLD	113	INSTALLATION	149	M
Removal and Installation	113	TIMING GEAR	151	
REMOVAL	113	Removal and Installation	151	
INSPECTION AFTER REMOVAL	115	REMOVAL	152	
INSTALLATION	115	INSPECTION AFTER REMOVAL	155	
EXHAUST MANIFOLD	117	INSTALLATION	157	
Removal and Installation	117	CYLINDER HEAD	160	
REMOVAL	117	On-Vehicle Service	160	
INSPECTION AFTER REMOVAL	118	CHECKING COMPRESSION PRESSURE	160	
INSTALLATION	118	Removal and Installation	161	
INSPECTION AFTER INSTALLATION	118	REMOVAL	161	
OIL PAN AND OIL STRAINER	119	INSPECTION AFTER REMOVAL	162	
Removal and Installation	119	INSTALLATION	163	
REMOVAL	119	Disassembly and Assembly	166	
INSTALLATION	120	DISASSEMBLY	166	
INSPECTION AFTER INSTALLATION	120	ASSEMBLY	167	
GLOW PLUG	121	INSPECTION AFTER DISASSEMBLY	167	
Removal and Installation	121	ENGINE ASSEMBLY	172	
REMOVAL	121	Removal and Installation	172	
INSTALLATION	122	REMOVAL	172	
VACUUM PUMP	123	INSTALLATION	174	
Removal and Installation	123	INSPECTION AFTER INSTALLATION	175	
REMOVAL	123	CYLINDER BLOCK	176	
INSTALLATION	123	Disassembly and Assembly	176	
INSPECTION AFTER INSTALLATION	123	DISASSEMBLY	177	
		ASSEMBLY	181	
		How to Select Piston	184	
		DESCRIPTION	184	
		SELECTIVE PISTON COMBINATION	184	
		INSPECTION AFTER DISASSEMBLY	185	

SERVICE DATA AND SPECIFICATIONS (SDS) ...	194	CYLINDER BLOCK	199
Standard and Limit	194	PISTON, PISTON RING AND PISTON PIN	200
GENERAL SPECIFICATIONS	194	CONNECTING ROD	201
INTAKE MANIFOLD AND EXHAUST MANI- FOLD	194	CRANKSHAFT	201
DRIVE BELTS	194	AVAILABLE MAIN BEARING	202
CYLINDER HEAD	195	AVAILABLE CONNECTING ROD BEARING	202
VALVE	195	MISCELLANEOUS COMPONENTS	202
CAMSHAFT AND CAMSHAFT BEARING	199	Tightening torque	203

PRECAUTIONS

PFP:00001

Precautions for Drain Coolant

EBS007JS

- Drain coolant when engine is cooled.

Precautions for Disconnecting Fuel Piping

EBS007JT

- Before starting work, make sure no fire or spark producing items are in the work area.
- Release fuel pressure before disassembly.
- After disconnecting pipes, plug openings to stop fuel leakage.

Precautions for Removal and Disassembly

EBS007JU

- When instructed to use special service tools, use the specified tools. Always be careful to work safely, avoid forceful or uninstructed operations.
- Exercise maximum care to avoid damage to mating or sliding surfaces.
- Cover openings of engine system with tape or the equivalent, if necessary, to seal out foreign materials.
- Mark and arrange disassembly parts in an organized way for easy troubleshooting and re-assembly.
- When loosening nuts and bolts, as a basic rule, start with the one furthest outside, then the one diagonally opposite, and so on. If the order of loosening is specified, do exactly as specified.

Precautions for Inspection, Repair and Replacement

EBS007JV

- Before repairing or replacing, thoroughly inspect parts. Inspect new replacement parts in the same way, and replace if necessary.

Precautions for Assembly and Installation

EBS007JW

- Use torque wrench to tighten bolts or nuts.
- When tightening nuts and bolts, as a basic rule, equally tighten in several different steps starting with the ones in center, then ones on inside and outside diagonally in this order. If the order of tightening is specified, do exactly as specified.
- Replace with new gasket, packing, oil seal or O-ring.
- Thoroughly wash, clean, and air-blow each part. Carefully check oil or coolant passages for any restriction and blockage.
- Avoid damaging sliding or mating surfaces. Completely remove foreign materials such as cloth lint or dust. Before assembly, oil sliding surfaces well.
- Release air within route after draining coolant.
- After repairing, start engine and increase engine speed to check coolant, fuel, oil, and exhaust systems for leakage.

Parts Requiring Angular Tightening

EBS007JX

- Use an angle wrench for the final tightening of the following engine parts:
 - Cylinder head bolts
 - Connecting rod cap nuts
- Do not use a torque value for final tightening.
- The torque value for these parts are for a preliminary step.
- Ensure thread and seat surfaces are clean and coated with engine oil.

Precautions for Liquid Gasket REMOVAL OF LIQUID GASKET SEALING

- After removing the mounting bolts and nuts, disconnect and remove the liquid gasket sealing using a seal cutter.


CAUTION:

Be careful not to damage the mating surfaces.

- In areas where the cutter is difficult to use, use a plastic hammer to lightly tap the areas where the liquid gasket is applied.


CAUTION:

If for some unavoidable reason a tool such as a flat-bladed screwdriver is used, be careful not to damage the mating surfaces.




LIQUID GASKET APPLICATION PROCEDURE

1. Using a scraper, remove the old liquid gasket adhering to the gasket application surface and the mating surface.
- Remove the liquid gasket completely from the groove of the gasket application surface, mounting bolts, and bolt holes.
2. Wipe the gasket application surface and the mating surface with white gasoline (lighting and heating use) to remove adhering moisture, grease and foreign materials.
3. Attach the liquid gasket to the tube presser.
Use Genuine Liquid Gasket or equivalent.



4. Apply the gasket without breaks to the specified location with the specified dimensions.
 - If there is a groove for the liquid gasket application, apply the gasket to the groove.
 - As for the bolt holes, normally apply the gasket inside the holes. Occasionally, it should be applied outside the holes. Make sure to read the text of service manual.
 - Within five minutes of gasket application, install the mating component.
 - If the liquid gasket protrudes, wipe it off immediately.
 - Do not retighten after the installation.
 - After 30 minutes or more have passed from the installation, fill the engine oil and coolant.



CAUTION:

If there are specific instructions in the service manual, observe them.

PREPARATION

[KA24DE]

PFP:00002








A

PREPARATION

Special Service Tools

EBS007JZ

EM

Tool number Tool name	Description
KV10111100 Seal cutter	Removing steel oil pan and rear timing chain case  ZZA0013D
KV10117100 Heated oxygen sensor wrench	Loosening or tightening heated oxygen sensors with 22 mm (0.87 in) hexagon nut  ZZA1007D
KV10105800 Timing chain stopper	Removing and installing idler sprocket  ZZA1006D
KV101151S0 Lifter stopper set 1 KV10115120 Lifter stopper 2 KV10115110 Camshaft pliers	Changing valve lifter shims  ZZA0103D
KV10112100 Angle wrench	Tightening bolts for bearing cap, cylinder head, etc.  ZZA0120D
KV10116200 Valve spring compressor KV10111200 Adapter	Disassembling and assembling valve components  ZZA0993D
KV10116100 Valve oil seal puller	Removing valve oil seal  ZZA0015D

C

D

E

F

G

H

I

J

K

L

M








PREPARATION

[KA24DE]

Tool number Tool name	Description
KV10116300 Valve oil seal drift <div data-bbox="587 296 928 449" style="text-align: center;"> <p>NT602</p> </div>	Installing valve oil seal a: 25 mm (0.98 in) dia. b: 14.4 mm (0.567 in) dia. c: 11.8 mm (0.465 in) dia. d: 10 mm (0.39 in) dia. e: 11 mm (0.43 in) f: 9 mm (0.35 in)
ST0501S000 Engine stand assembly <div data-bbox="667 499 906 680" style="text-align: center;"> <p>ZZA0022D</p> </div>	Engine overhaul
KV10105001 Engine attachment <div data-bbox="683 764 849 919" style="text-align: center;"> <p>ZZA1061D</p> </div>	
ST16610001 Pilot bushing puller <div data-bbox="596 968 916 1150" style="text-align: center;"> <p>ZZA0046D</p> </div>	Removing crankshaft pilot bushing (M/T model only)
KV10114700 Main bearing cap remover <div data-bbox="619 1213 906 1381" style="text-align: center;"> <p>ZZA0023D</p> </div>	
EM03470000 Piston ring compressor <div data-bbox="667 1457 890 1625" style="text-align: center;"> <p>S-NT044</p> </div>	Installing piston assembly into cylinder bore
WS39930000 Tube presser <div data-bbox="638 1696 890 1864" style="text-align: center;"> <p>S-NT052</p> </div>	Pressing the tube of liquid gasket

PREPARATION


[KA24DE]

Tool number Tool name	Description	
Quick connector release	 PBIC0198E	Removing fuel tube quick connectors in engine room (Available in SEC. 164 of PARTS CATALOG: Part No. 16441 6N210)
Spark plug wrench	 S-NT047	Removing and installing spark plug
Valve seat cutter set	 S-NT048	Finishing valve seat dimensions
Piston ring expander	 S-NT030	Removing and installing piston ring
Valve guide drift	 S-NT015	Removing and installing valve guide Intake & Exhaust: a: 109.5 mm (0.413 in) dia. b: 6.6 mm (0.260 in) dia.
Valve guide reamer	 S-NT016	1: Reaming valve guide inner hole 2: Reaming hole for oversize valve guide Intake & Exhaust: d1 : 7.0 mm (0.276 in) dia. d2 : 11.175 mm (0.440 in) dia.
Rear oil seal drift	 ZZA0025D	Installing rear oil seal

A
EM
C
D
E
F
G
H
I
J
K
L
M

NVH Troubleshooting —Engine Noise

EBS007K1



PBIC0192E

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

[KA24DE]

Use the Chart Below to Help You Find the Cause of the Symptom.

EBS007K2

1. Locate the area where noise occurs.
2. Confirm the type of noise.
3. Specify the operating condition of engine.
4. Check specified noise source.

If necessary, repair or replace these parts.

Location of noise	Type of noise	Operating condition of engine						Source of noise	Check item	Reference page
		Before warm-up	After warm-up	When starting	When idling	When racing	While driving			
Top of engine Rocker cover Cylinder head	Ticking or clicking	C	A	—	A	B	—	Tappet noise	Valve clearance	EM-38
	Rattle	C	A	—	A	B	C	Camshaft bearing noise	Camshaft journal clearance Camshaft runout	EM-36 EM-35
Crankshaft pulley Cylinder block (Side of engine) Oil pan	Slap or knock	—	A	—	B	B	—	Piston pin noise	Piston and piston pin clearance Connecting rod bushing clearance	EM-80 EM-80
	Slap or rap	A	—	—	B	B	A	Piston slap noise	Piston-to-bore clearance Piston ring side clearance Piston ring end gap Connecting rod bend and torsion	EM-80 EM-79 EM-79 EM-80
	Knock	A	B	C	B	B	B	Connecting rod bearing noise	Connecting rod bushing clearance (Small end) Connecting rod bearing clearance (Big end)	EM-80 EM-80
	Knock	A	B	—	A	B	C	Main bearing noise	Main bearing oil clearance Crankshaft runout	EM-84 EM-83
Front of engine Timing chain cover	Tapping or ticking	A	A	—	B	B	B	Timing chain and chain tensioner noise	Timing chain cracks and wear Timing chain tensioner operation	EM-44 EM-51
Front of engine	Squeaking or fizzing	A	B	—	B	—	C	Other drive belts (Sticking or slipping)	Drive belts deflection	EM-14
	Creaking	A	B	A	B	A	B	Other drive belts (Slipping)	Idler pulley bearing operation	
	Squall Creak	A	B	—	B	A	B	Water pump noise	Water pump operation	CO-21


A: Closely related B: Related C: Sometimes related —: Not related

ENGINE ROOM COVER

PFP:14049

Removal and Installation of Engine Room Right Side

EBS00ALX



- | | | |
|---------------------------------|------------------------|--------------------------------|
| 1. Engine room right side cover | 2. Parking brake lever | 3. Engine room left side cover |
| 4. Parking brake cable | 5. Harness | 6. Harness protector |

REMOVAL

1. Open engine compartment LH cover and secure it.
2. Remove RH seat. Refer to [SE-4, "FRONT SEAT"](#).
3. Partially remove floor carpet.
4. Disconnect harness protector secured together at front right. Disconnect harness connector to move harness routed on top of engine compartment RH cover aside.
5. Move parking brake lever and cable from engine compartment RH cover. Refer to [PB-3, "PARKING BRAKE SYSTEM"](#).
6. Remove mounting bolts, and remove engine compartment RH cover.

CAUTION:

When taking it out of vehicle, do not allow it to interfere with vehicle.

INSTALLTION

- Install in reverse order of removal following instructions below.
1. Temporarily tighten bolt No. 1 shown in the figure.
 2. Tighten bolt No. 2 shown in figure to specified torque.
 3. Tighten other bolts except bolt "A" shown in the figure (bolt No. 1 is included) to specified torque in any given order.
 4. Close engine compartment LH cover.
 5. Tighten bolt "A" shown in the figure to specified torque.

Removal and Installation of Engine Room Rear Cover

EBS00ALY

REMOVAL

1. Move folded seat on engine compartment rear cover side rearward, if applicable.
2. Partially remove floor carpet.
3. Remove mounting bolts, and remove engine compartment rear cover.


ENGINE ROOM COVER

[KA24DE]

INSTALLATION

Following instructions below, install in reverse order of removal.

1. Tighten bolts No. 1 to No. 3 shown in the figure to specified torque in this order.
2. Tighten other bolts to specified torque in any given order.



A
EM
C
D
E
F
G
H
I
J
K
L
M

DRIVE BELTS

PFP:02117


Checking Drive Belts

EBS007K4

WARNING:

Be sure to perform when the engine is stopped.

- Inspection should be done only when engine is cold, or over 30 minutes after engine is stopped.
- Measure belt tension with tension meter (special service tool) at points marked ▼ shown in the figure.
- Measure belt deflection by applying load of 98.1 N {10 kg} to ▼.



Unit: mm (in)

	Deflection adjustment		
	Used belt		New belt
	Limit	After adjustment	
Alternator	11 (0.43)	7 - 8 (0.28 - 0.31)	6 - 7 (0.24 - 0.28)
Air conditioner compressor	13 (0.51)	8 - 10 (0.31 - 0.39)	7 - 8 (0.28 - 0.31)
Power steering oil pump	13 (0.51)	8 - 10 (0.31 - 0.39)	7 - 8 (0.28 - 0.31)
Applied pushing force	98 N (10 kg, 72 lb)		

Tension Adjustment

EBS00AM2


CAUTION:

- When belt is replaced with a new one, tighten it a little stronger than current one to accommodate for insufficient adaptability with pulley grooves.
- When tension of belt being used exceeds "Retightening limit", adjust it to value for "Used belt".
- When installing belt, make sure that it is correctly engaged with pulley groove.
- Keep oil and water away from belt.
- Do not twist or bend belt excessively.

POWER STEERING PUMP BELT


1. Open and fix engine compartment LH cover.
2. Loosen idler pulley lock nut (A) and adjust tension by turning adjusting bolt (B).
 - For specified belt tension, refer to [EM-14, "Checking Drive Belts"](#).
3. Tighten nut (A).

: 25.5 - 32.4 N·m (2.6 - 3.3 kg·m, 19 - 23 ft·lb)



AIR CONDITIONER COMPRESSOR BELT

1. Open and fix engine compartment LH cover (passenger side for RHD models or driver-side for LHD models).
2. Loosen idler pulley lock nut (C) and adjust tension by turning adjusting bolt (D).
 - For specified belt tension, refer to [EM-14, "Checking Drive Belts"](#).
3. Tighten nut (C).

 : 25.5 - 32.4 N·m (2.6 - 3.3 kg·m, 19 - 23 ft·lb)

A

ALTERNATOR AND WATER PUMP BELT

1. Remove front-side under cover.
2. Remove RH seat. Refer to [SE-4, "FRONT SEAT"](#).
3. Remove engine compartment RH cover. Refer to [EM-12, "ENGINE ROOM COVER"](#).
4. Loosen alternator mounting bolt (E) and adjuster lock bolt (F), and adjust tension by turning adjusting nut (G).
 - For specified belt tension, refer to [EM-14, "Checking Drive Belts"](#).
5. Tighten bolts (E), (F) and (G).

EM

C

D

 : 45.1 - 59.8 N·m (4.6 - 6.1 kg·m, 34 - 44 ft·lb) for E bolt

 : 15.7 - 20.6 N·m (1.6 - 2.1 kg·m, 12 - 15 ft·lb) for F bolt

E

 : 6.5 - 7.6 N·m (0.67 - 0.77 kg·m, 58 - 67 in·lb) for G bolt

Removal and Installation

EBS007K6

REMOVAL

- Loosen each belt while referring to "Adjustment", and remove them one by one starting from the one in front.

F

G

INSTALLATION

1. Install belts to pulley in reverse order of removal.
2. Adjust belt tension.

H

CAUTION:

- **When checking belt tension immediately after installation, first, adjust to specified value. Then, after turning crankshaft more than two turns, re-adjust to specified value to avoid variation in deflection between pulleys.**
 - **Tighten idler pulley lock nut by hand and measure tension without looseness.**
3. Tighten each adjusting bolt and nut to the specified torque.
 4. Make sure that tension of each belt is within the standard.

I

J

K

L

M



AIR CLEANER AND AIR DUCT

[KA24DE]

7. For correct installation, make matching marks on each connection.
8. Remove from engine side after separating the system with the following procedure.
 - a. Remove PCV hose (A).
 - b. Remove air duct (B).
 - c. Separate air hose (C) and resonator (D).
 - d. Remove resonator (E).
 - e. Remove air hose (C).
 - f. Remove resonator (D).
 - g. Remove mass air flow sensor (F).

CAUTION:


- Handle with care, avoiding any shocks.
 - Do not disassemble it.
 - Do not touch sensor part.
- h. After removing mud flap of front RH wheel, remove resonator (G).
 - i. When removing following parts, remove EVAP canister, and set it aside.
 - j. Remove resonator (H).
 - k. Remove air cleaner case (I).
9. When removing components inside vehicle on right-hand, remove them with the following procedure.
 - a. Remove components up to air cleaner case (I), referring to step 8.
 - b. Remove intake grille from outside of vehicle.
 - c. Remove kicking plate on RH side, and lift up panel under RH side seat belt anchor.
 - d. Lift up air duct (J) from vehicle opening, and separate it from air duct (K).
 - e. Pull and remove air duct (K).
 - f. Remove air duct (J) from mounting hole of air duct (K).



INSTALLATION

Install in reverse order of removal, paying attention to points below.


- After aligning matching marks marked when removing, install each connection, and firmly tighten clamps.
- Install dust drain valve so that its opening is along circumference.



Changing Air Cleaner Element REMOVAL

NOTE:

- Mark "*" in the figure shows part of lift arm.
 - For replacement of air cleaner element, it is not necessary to lift up vehicle.
1. Remove brake pipe protector under vehicle, behind front RH wheel.
 2. Remove 3 clips, and the cover at the bottom of air cleaner case.
 3. Remove wing nut, dust pan under air cleaner case, and then air cleaner element.



INSTALLATION


Install in the reverse order of removal.

THROTTLE BODY

Removal and Installation

EBS008X7

SEC. 163•211




KBIA0823E

- | | | |
|-----------------|------------------------------------|--------------|
| 1 Bracket | 2 Throttle position sensor harness | 3 Water hose |
| 4 Throttle body | 5 Bracket | 6 Water hose |
| 7 Gasket | 8 Intake manifold | |

REMOVAL

1. Remove RH seat. Refer to [SE-4, "FRONT SEAT"](#).
2. Remove engine compartment RH cover. Refer to [EM-12, "ENGINE ROOM COVER"](#).
3. Remove air duct on throttle body. Refer to [EM-16, "AIR CLEANER AND AIR DUCT"](#).
4. Disconnect accelerator cable, and set it aside.
5. Disconnect harness connector.
6. Disconnect water hose.
 - After disconnection, plug the hose to prevent coolant leaks.
7. Loosen mounting bolts in reverse order shown in the figure, and remove throttle body.



PBIC0424E

THROTTLE BODY

[KA24DE]

INSPECTION AFTER REMOVAL

- If idle is rough when engine is cold or warmed up, check and adjust the fast idle cam (FIC). Refer to [EC-28, "Fast Idle Cam \(FIC\) Inspection and Adjustment"](#) .


INSTALLATION

Install in reverse order of removal, paying attention to points below.

- For throttle body, tighten mounting bolts in two steps in the numerical order shown in the figure.
- For adjustment of accelerator cable, refer to [ACC-3, "ACCELERATOR CONTROL SYSTEM \(KA24DE\)"](#) .


 **1st step : 8.8 - 10.8 N·m (0.9 - 1.1 kg·m, 78 - 95 in·lb)**

 **2nd step : 17.7 - 21.6 N·m (1.8 - 2.2 kg·m, 13 - 15 ft·lb)**



Disassembly and Assembly

EBS008X8



- | | | |
|-----------------|----------------------------|----------------------------|
| 1 Throttle body | 2 Throttle position sensor | 3 IACV-FICD solenoid valve |
| 4 Washer | 5 Spring | 6 plunger |
| 7 Gasket | 8 IACV-AAC valve | |

DISASSEMBLY

Disassemble referring to the component illustration.

ASSEMBLY

Assemble in reverse order of disassembly, paying attention to points below.

- Insert throttle position sensor into throttle body, with connectors positioned as shown in the figure. Then rotate it in the direction shown by arrow and temporarily tighten mounting screws.
- While they are turned in direction shown by arrow, circumference of sensor hits projection. Avoid hitting projection by giving slight space, and insert projection into inside of mounting screw long hole. (It is temporarily held in place by counter-action of spring.)
- After adjustment on vehicle, tighten mounting screws.
For adjusting procedure, refer to [EC-45, "Basic Inspection"](#) .

