

Perkins 2300 Series

Model 2306C-E14

WORKSHOP MANUAL

6 cylinder turbocharged diesel engines for industrial applications

Publication TSD3455E, Issue 1

© Proprietary information of Perkins Engines Company Limited, all rights reserved.

The information is correct at the time of print.

Published in September 2002 by Technical Publications,

Perkins Engines Company Limited, Shrewsbury SY1 3NX, England

Chapters

- 1 General information**
- 2 Specifications**
- 3 Cylinder head assembly**
- 4 Piston and connecting rod assemblies**
- 5 Crankshaft assembly**
- 6 Gear case and drive assembly**
- 7 Crankcase and cylinder liners**
- 8 Engine timing and electronic controls**
- 9 Aspiration system**
- 10 Lubrication system**
- 11 Fuel system**
- 12 Cooling system**
- 13 Flywheel and housing**
- 14 Electrical equipment**
- 15 Auxiliary equipment**
- 16 Special tools**

The pages which follow contain a detailed table of contents

Contents

1 General information

Introduction	1
Safety precautions	2
Viton seals	4
Welding	4
Environmental protection	4
Engine views	5
Engine identification	6
Engine lift equipment	6

2 Specifications

Basic engine data - 2306 engine	7
Basic engine data - 2806 engine	7
Rocker assemblies	8
Valves	9
Valve guides	10
Valve springs	10
Valve seat inserts	11

Cylinder head	12
Camshaft and bearings	12
Pistons and connecting rods - 2306 engine	13
Pistons and connecting rods - 2806 engine	14
Crankshaft, main bearings and flywheel	15
Crankshaft damper	15
Crankcase and cylinder liners	16
Lubricating oil pump	18
Coolant pump	19
Recommended torque figures	20

3 Cylinder head assembly

General information	27
Rocker cover	
Operation 3-1 To remove and to fit	28
Rocker lever and rocker shaft assemblies	
Operation 3-2 To remove and to fit	29
Operation 3-3 To dismantle and to assemble	30
Operation 3-4 How to check/adjust the tappet clearances	32
Cylinder head assembly	
Operation 3-5 To remove and to fit	35
Valve springs	
Operation 3-6 To remove and to fit	39
Valves	
Operation 3-7 To remove and to fit	41
Valve seals	
Operation 3-8 To renew	42
Valve guides	
Operation 3-9 To remove and to fit	43
Camshaft	

Operation 3-10 To remove and to fit	45
Operation 3-11 How to set the backlash for the camshaft gear	50

Electronic injector units

Operation 3-12 To remove and to fit	51
Operation 3-13 To check and to adjust	53

Injector sleeves

Operation 3-14 To remove and to fit	54
---	----

4 Pistons and connecting rod assemblies

General information	57
--------------------------------------	----

Pistons and connecting rod assemblies

Operation 4-1 To remove and to fit	58
Operation 4-2 To dismantle and assemble	60

Piston cooling jets

Operation 4-3 To remove and to fit	62
--	----

5 Crankshaft assembly

General information	63
--------------------------------------	----

Crankshaft

Operation 5-1 To remove and to fit	64
--	----

Crankshaft front seal and wear sleeve

Operation 5-2 To renew	66
----------------------------------	----

Crankshaft rear seal and wear sleeve

Operation 5-3 To renew	68
----------------------------------	----

Crankshaft vibration damper

Operation 5-4 To remove and to fit	70
--	----

6 Gear case and drive assembly

General information	73
--------------------------------------	----

Gear case cover

Operation 6-1 To remove and to fit	74
--	----

Timing gears

Operation 6-2 To remove and to fit	75
Operation 6-3 How to check the position of the timing gears	78

Gear case

Operation 6-4 To remove and to fit	79
--	----

7 Crankcase and cylinder liners

General information	81
----------------------------------	----

Front engine support

Operation 7-1 To remove and to fit	82
--	----

Cylinder liners

Operation 7-2 To remove and to fit	83
Operation 7-3 To check and to adjust the protrusion of the cylinder liners	84

8 Engine timing and electronic controls

General information	87
----------------------------------	----

Electronic control module

Operation 8-1 To remove and to fit	88
--	----

Engine timing

Operation 8-2 To check	89
------------------------------	----

9 Aspiration system

General information	91
----------------------------------	----

Exhaust manifold

Operation 9-1 To remove and to fit	92
--	----

Turbocharger

Operation 9-2 To remove and to fit	93
Operation 9-3 To dismantle and to assemble	94

10 Lubrication system

General information	95
Oil filter and oil filter header	
Operation 10-1 To remove and to fit	96
Oil filter header	
Operation 10-2 To dismantle and to assemble	98
Sump	
Operation 10-3 To remove and to fit	99
Oil pump	
Operation 10-4 To remove and to fit	101
Operation 10-5 To dismantle and to assemble	102

11 Fuel system

General information	103
Fuel priming pump	
Operation 11-1 To remove and to fit	104
Fuel transfer pump	
Operation 11-2 To remove and to fit	105
Operation 11-3 To test	106
Drive for the fuel transfer pump	
Operation 11-4 To remove and to fit	107
Fuel filter header	
Operation 11-5 To remove and to fit	108
Low pressure fuel system	
Operation 11-6 How to eliminate air from the fuel system	109

12 Cooling system

General information	111
Cooling system	
Operation 12-1 To inspect	112
Operation 12-2 Leakage test	113

Coolant filler cap

Operation 12-3 To test 114

Radiator

Operation 12-4 To remove and to fit 115

Fan

Operation 12-5 To remove and to fit 116

Fan drive assembly

Operation 12-6 To remove and to fit 117

Fan drive belts

Operation 12-7 To check and to adjust the tension 118

Operation 12-8 To renew 119

Engine oil cooler

Operation 12-9 To remove and to fit 120

Thermostats and thermostat housing

Operation 12-10 To remove and to fit 121

Operation 12-11 To test the thermostats 123

Coolant temperature sensor

Operation 12-12 To test 124

Coolant pump

Operation 12-13 To remove and to fit 125

Operation 12-14 To dismantle and to assemble 126

Operation 12-15 To test the pressure of the coolant pump 128

13 Flywheel and housing

General information 129

Flywheel

Operation 13-1 To remove and to fit 130

Flywheel housing

Operation 13-2 To remove and to fit 131

14 Electrical equipment

General information 133

Starter motor

Operation 14-1 To remove and to fit 134

Alternator

Operation 14-2 To remove and to fit 135

Operation 14-3 To check and to adjust the tension of the alternator belt 136

Operation 14-4 To renew the alternator belt 137

15 Auxiliary equipment

General information 139

Oil sample valve 139

16 Special tools

List of special tools 141

