

Perkins New 1000 Series

Models AJ to AS and YG to YK

WORKSHOP MANUAL

4 and 6 cylinder diesel engines for industrial and agricultural applications

Publication TPD 1350E, Issue 4.

© Proprietary information of Perkins Engines Company Limited, all rights reserved.

The information is correct at the time of print.

Published in December 2001 by Technical Publications.

This publication is written in
Perkins Approved Clear English



Chapters

- 1 General information**
- 2 Specifications**
- 3 Cylinder head assembly**
- 4 Piston and connecting rod assemblies**
- 5 Crankshaft assembly**
- 6 Timing case and drive assembly**
- 7 Cylinder block assembly**
- 8 Engine timing**
- 9 Aspiration system**
- 10 Lubrication system**
- 11 Fuel system**
- 12 Cooling system**
- 13 Flywheel and housing**
- 14 Electrical equipment**
- 15 Auxiliary equipment**
- 16 Special tools**

The following pages contain a detailed table of contents

Contents

1 General information

Introduction	1
Engine views	2
Engine identification	3
Safety precautions	5
Viton seals	6
Engine lift equipment	7
POWERPART recommended consumable products	8

2 Specifications

Basic engine data	11
Data and dimensions	12
Thread sealant	35
Standard torque tensions	36
Specific torque tensions	37
Compression test data	40

3 Cylinder head assembly

General description	41
Rocker cover	
Operation 3-1 To remove	42
Operation 3-2 To fit	43
Rocker assembly	
Operation 3-3 To remove and to fit	44
Operation 3-4 To dismantle and to assemble	45
Operation 3-5 To inspect and to correct	45
Valve tip clearances	
Operation 3-6 To check and to adjust (four cylinder engines)	46
Operation 3-7 To check and to adjust (six cylinder engines)	47
Valve springs	
Operation 3-8 To change the valve springs (with cylinder head fitted)	48
Manifolds	
Operation 3-9 To remove and to fit an intake manifold	50
Operation 3-10 To remove and to fit an exhaust manifold (one-piece)	52
Operation 3-11 To remove and to fit an exhaust manifold (three-piece)	54
Cylinder head assembly	
Operation 3-12 To remove	56
Operation 3-13 To fit (engine types AJ to AQ and YG to YK)	58
Operation 3-14 To fit (engine types AR and AS)	61
Valves and valve springs	
Operation 3-15 To remove	64
Operation 3-16 To fit	65
Operation 3-17 To inspect and to correct	66
Valve guides	
Operation 3-18 To inspect	67
Operation 3-19 To remove	68
Operation 3-20 To fit	69
Cylinder head	
Operation 3-21 To inspect and to correct	70
Operation 3-22 To correct a valve seat with a valve seat cutter	71
Operation 3-23 To fit valve seat inserts	73

4 Piston and connecting rod assemblies

General description	75
Big end bearing	
Operation 4-1 To remove	77
Operation 4-2 To fit	78
Operation 4-3 To inspect	78
Piston and connecting rod	
Operation 4-4 To remove	79
Operation 4-5 To fit	80
Operation 4-6 To check the piston height above the cylinder block	82
Piston rings	
Operation 4-7 To remove	83
Operation 4-8 To fit	84
Piston and connecting rod assembly	
Operation 4-9 To dismantle	85
Operation 4-10 To assemble	86
Operation 4-11 To check the length of a connecting rod	87
Piston and piston rings	
Operation 4-12 To inspect	88
Connecting rod	
Operation 4-13 To inspect	89
Partially finished small end bush	
Operation 4-14 To remove and to fit	90
Piston cooling jets	
Operation 4-15 To remove and to fit	91
Operation 4-16 To check the jet alignment	92

5 Crankshaft assembly

General description	93
Crankshaft pulley	
Operation 5-1 To remove and to fit (four cylinder engines)	95

Crankshaft pulley and damper

Operation 5-2 To remove (six cylinder engines)	96
Operation 5-3 To fit (six cylinder engines)	97
Operation 5-4 To inspect	98

Rear oil seal assembly 99

Operation 5-5 To remove and to fit (one-piece assembly)	99
Operation 5-6 To remove and to fit (two-piece assembly)	102
Operation 5-7 To renew the rear end oil seal (two-piece assembly)	103
Operation 5-8 To remove and to fit a wear sleeve	104

Thrust washers

Operation 5-9 To check crankshaft end-float	105
Operation 5-10 To remove	106
Operation 5-11 To fit	107

Main bearings

Operation 5-12 To remove (with the crankshaft in position)	108
Operation 5-13 To fit	109
Operation 5-14 To inspect	109

Crankshaft

Operation 5-15 To remove	110
Operation 5-16 To fit	111
Operation 5-17 To inspect	113

Balancer unit

Operation 5-18 To remove and to fit	114
Operation 5-19 To dismantle	115
Operation 5-20 To assemble	117
Operation 5-21 To inspect	120
Operation 5-22 To remove and to fit the needle roller bearings for the drive shaft	121
Operation 5-23 To remove and to fit the bushes for the balance weights	122

6 Timing case and drive assembly**General description** 123**Timing case cover**

Operation 6-1 To remove	124
Operation 6-2 To fit	125

Front oil seal

Operation 6-3 To remove	127
Operation 6-4 To fit	128
Operation 6-5 To remove and to fit a wear sleeve	130

Idler gear and hub	
Operation 6-6 To remove	131
Operation 6-7 To fit	133
Idler gear and hub for the compressor	
Operation 6-8 To remove	135
Operation 6-9 To fit	136
Fuel pump gear	137
Operation 6-10 To remove	137
Operation 6-11 To fit	139
Camshaft gear	
Operation 6-12 To remove and to fit	141
Crankshaft gear	
Operation 6-13 To remove and to fit	142
Timing case	
Operation 6-14 To remove	143
Operation 6-15 To fit	144
Camshaft and tappets	
Operation 6-16 To remove	146
Operation 6-17 To fit	147
7 Cylinder block assembly	
General description	149
Cylinder block	
Operation 7-1 To dismantle	150
Operation 7-2 To assemble	151
Operation 7-3 To inspect	152
Operation 7-4 To remove and to fit a new type 'D' plug to the tappet chamber	153
Cylinder liner	
Operation 7-5 To inspect	155
Operation 7-6 To remove	156
Operation 7-7 To fit a service liner	158
Operation 7-8 To fit a partially finished liner	161
Cylinder bore, engine types AR and AS	
Operation 7-9 To inspect	164

8 Engine timing

General description	165
----------------------------------	-----

Engine timing

Operation 8-1 To set number 1 piston to TDC on the compression stroke	167
Operation 8-2 Another method to set number 1 piston to TDC	168
Operation 8-3 To check the valve timing	169
Operation 8-4 To check the timing of the fuel injection pump	170

9 Aspiration system

General description	171
----------------------------------	-----

Turbocharger

Operation 9-1 To remove	173
Operation 9-2 To fit	174
Operation 9-3 To clean the impeller and the compressor casing	176
Operation 9-4 To remove and to fit the actuator assembly of the waste-gate unit	177
Operation 9-5 To check and adjust the operation of the waste-gate	178

Turbocharger faults	179
----------------------------------	-----

List of possible causes	180
--------------------------------------	-----

Open engine breather	181
-----------------------------------	-----

Operation 9-6 To clean and to renew	181
Operation 9-7 To Inspect	183

Closed engine breather	184
-------------------------------------	-----

Operation 9-8 To renew the breather valve assembly	185
--	-----

10 Lubrication system

General description - four cylinder engine lubrication system	187
--	-----

General description - Six cylinder engine lubrication system	188
---	-----

Filter canister

Operation 10-1 To renew	191
-------------------------------	-----

Filter head

Operation 10-2 To remove and to fit	192
---	-----

Sump

Operation 10-3 To remove and to fit	193
---	-----

Oil strainer and suction pipe	
Operation 10-4 To remove and to fit	194
Operation 10-5 To inspect and to correct	195
Lubricating oil pump	196
Operation 10-6 To remove	196
Operation 10-7 To fit	197
Operation 10-8 To inspect	198
Lubricating oil pump idler gear shaft	199
Operation 10-9 To remove (six cylinder engines)	199
Operation 10-10 To fit (six cylinder engines)	201
Operation 10-11 To remove and to fit (four cylinder engines)	202
Relief valve	
Operation 10-12 To remove and to fit	203
Operation 10-13 To dismantle and to assemble	204
Operation 10-14 To inspect	204
Flexible oil pipes	205
Operation 10-15 To remove	205
Operation 10-16 To fit	206
Operation 10-17 To Inspect	207

11 Fuel system

General description	209
Cold start advance unit	212
Typical fuel system	215
Fuel filters	216
Fuel filter element	
Operation 11-1 To renew - separate element type	217
Operation 11-2 To renew - canister type	218
Operation 11-3 To renew - quick release canister type	219
Atomisers	220
Operation 11-4 To remove	221
Operation 11-5 To fit	222

Fuel lift pump

Operation 11-6 To remove and to fit	224
Operation 11-7 To dismantle	225
Operation 11-8 To assemble	226
Operation 11-9 To test	227
Bosch fuel injection pump	228
Operation 11-10 To remove	230
Operation 11-11 To fit	232
Operation 11-12 To adjust	234
Lucas/Delphi DP 200 Series fuel injection pump	235
Operation 11-13 To remove	237
Operation 11-14 To fit	239
Operation 11-15 To adjust	242
Operation 11-16 Electrical shut off solenoid (ESOS)	243
Stanadyne fuel injection pump	245
Operation 11-17 To remove	248
Operation 11-18 To fit	249
Operation 11-19 To adjust	251
Air in the fuel system	254
Operation 11-20 To eliminate air from the fuel system	254

12 Cooling system

General description	257
Thermostats	
Operation 12-1 To remove	258
Operation 12-2 To fit	259
Operation 12-3 To test	260
Coolant pump - early gear driven pumps	261
Operation 12-4 To remove	261
Operation 12-5 To fit	262
Operation 12-6 To dismantle	263
Operation 12-7 To assemble	264
Operation 12-8 To remove and to fit a pressed steel cover (early coolant pumps)	267
Coolant pump - latest gear driven pumps	268
Operation 12-9 To remove	268
Operation 12-10 To fit	269
Operation 12-11 To dismantle	270
Operation 12-12 To assemble	273

New 1000 Series

Coolant pump - belt driven	277
Operation 12-13 To remove	277
Operation 12-14 To fit	279
Operation 12-15 To remove high position pump	281
Operation 12-16 To fit high position pump	283
Operation 12-17 To dismantle	285
Operation 12-18 To assemble	286
Fan	
Operation 12-19 To remove and to fit	289
Fan drive (engines with gear driven coolant pumps)	
Operation 12-20 To remove and to fit	290
Lubricating oil cooler	
Operation 12-21 To remove (four cylinder turbocharged engines)	291
Operation 12-22 To fit (four cylinder turbocharged engines)	292
Operation 12-23 To dismantle and to assemble (four cylinder engines)	293
Operation 12-24 To remove (six cylinder turbocharged engines)	294
Operation 12-25 To fit (six cylinder turbocharged engines)	296
Operation 12-26 To dismantle and to assemble (six cylinder engines)	298
Operation 12-27 To remove and to fit (canister type)	300
Operation 12-28 To remove and to fit cooler bypass valve	300
Intercoolers	301
Horizontally mounted intercooler	
Operation 12-29 To remove	302
Operation 12-30 To fit	304
Vertically mounted intercooler	
Operation 12-31 To remove	306
Operation 12-32 To fit	307
Operation 12-33 To clean and to inspect	309
13 Flywheel and housing	
General description	311
Flywheel	
Operation 13-1 To remove and to fit	311
Ring gear	
Operation 13-2 To remove and to fit	312
Flywheel housing	
Operation 13-3 To remove and to fit	313

14 Electrical equipment

Alternators	315
Operation 14-1 To check the drive belts	316
Operation 14-2 To adjust drive belt tension	317
Operation 14-3 To remove and to fit the drive belts	318
Operation 14-4 To remove and to fit the alternator	319
Operation 14-5 To maintain	319
Operation 14-6 Fault diagnosis	320
Starter motors	322
Operation 14-7 To remove and to fit	323
Operation 14-8 To maintain the brush gear and the commutator	324
Operation 14-9 To test on the engine	324
Operation 14-10 Fault diagnosis	325
Starting aids	326
Operation 14-11 To remove and to fit a fuelled starting aid	326
Operation 14-12 To remove and to fit a twin-fuelled starting aid	327
Operation 14-13 To check the fuelled starting aid	328
Operation 14-14 To remove and to fit a port heater	328

15 Auxiliary equipment

Bendix Compressor

Operation 15-1 To remove	330
Operation 15-2 To fit	331

Knorr-Bremse compressor

Operation 15-3 To remove	333
Operation 15-4 To fit	334
Operation 15-5 To remove the reed valves	336
Operation 15-6 To fit the reed valves	337
Operation 15-7 To remove the top unloader valve	338
Operation 15-8 To fit the top unloader valve	339
Operation 15-9 To remove the crankshaft / connecting rod / piston / piston rings	340
Operation 15-10 To fit the crankshaft / connecting rod / piston / piston rings	341

Power steering pump

Operation 15-11 To remove and to fit	343
--	-----

Adaptor for a hydraulic pump or a steering pump with a splined drive

Operation 15-12 To remove and to fit	344
Operation 15-13 To dismantle	345
Operation 15-14 To assemble	346

Exhauster

Operation 15-15 To remove and to fit 347

16 Special tools

List of special tools 350

This page is intentionally blank

1

General information

Introduction

This Workshop Manual has been written to provide assistance in the service and overhaul of Perkins New 1000 Series engines. For overhaul procedures the assumption is made that the engine is removed from the application. The engine conforms with USA (EPA/CARB) stage 1 and EEC stage 1 emissions legislation for agricultural and industrial applications.

Most of the general information which is included in the relevant User's Handbook has not been repeated in this workshop manual and the two publications should be used together.

Where the information applies only to certain engine types, this is indicated in the text.

The details of some operations will be different according to the type of fuel injection pump which is fitted. The specific pump type used can be found by reference to the manufacturer's identification plate on the pump body. Generally, the type of pump fitted is as shown below.

- Lucas/Delphi - DP200 Series
- Bosch - EPVE
- Stanadyne - DB4.

When reference is made to the "left" or "right" side of the engine, this is as seen from the flywheel end of the engine.

Special tools have been made available, for a list of these, see Chapter 16, Special tools. Reference to the relevant special tools is also made at the beginning of each operation, where relevant.

POWERPART recommended consumable products are listed on page 8. Reference to the relevant consumable products is also made at the beginning of each operation, where relevant.

Data and dimensions are included in Chapter 2, Specifications.


Read and remember the "Safety precautions" on page 5. They are given for your protection and must be used at all times.

Danger is indicated in the text by two methods:


Warning! *This indicates that there is a possible danger to the person.*

Caution: *This indicates that there is a possible danger to the engine.*

Note: Is used where the information is important, but there is not a danger.

Engine views

A0378N



A0379

Engine identification

The Perkins New 1000 Series engines have been designed for industrial and agricultural applications. There are both four and six cylinder engines, each of which will have three basic engine types, naturally aspirated, turbocharged and turbocharged with an intercooler.

In this workshop manual, the different engine types are indicated by their code letters. These are the first two letters of the engine number as indicated below:

AJ	Four cylinder, naturally aspirated
AK	Four cylinder, turbocharged
AM	Four cylinder, turbocharged and intercooled
AP	Four cylinder, naturally aspirated, belt driven coolant pump
AQ	Four cylinder, turbocharged, belt driven coolant pump
AR	Four cylinder, naturally aspirated, 103 mm cylinder bore
AS	Four cylinder, naturally aspirated, belt driven coolant pump, 103 mm cylinder bore
YG	Six cylinder, naturally aspirated
YH	Six cylinder, turbocharged
YJ	Six cylinder, charge cooled, air to air
YK	Six cylinder, turbocharged and intercooled

The correct identification of the engine is by the full engine number.

The engine number is stamped on a label which is fastened to the left side (A2) of the cylinder block. An example of an engine number is:


AK80920*U510256B*

The components of the engine number are as follows:

AK80920*U510256B*

AK	Model code number
80920	Build list number
U	Built in the UK
510256	Engine serial number
B	Year of manufacture

Continued



Date letters for engines start from the 1st of January each year. To comply with the new emissions legislation that engines built before 1st April 1999 can be clearly identified from those built after this date, a new letter has been used from the 1st of April 1999. The date letters used are as follows:

From the 1st of January 1999 to the 31st of March 1999 the date letter is E.

From the 1st of April 1999 to the 31st of January 1999 the date letter is F.

If you need parts, service or information for your engine, you must give the complete engine number to your Perkins distributor. If there is a number in the area of the label marked TPL No, then this number must also be given to your Perkins distributor.

Other identification labels fitted to the engine include:


An emissions legislation label (A3) fitted to the side of the cylinder block.

A label (A1) with the fuel injection pump part numbers.

If a short engine has been fitted in service two engine serial numbers and a TPL number are stamped on the engine serial number pad (B3).

Examples of the serial numbers are shown in (B).

If parts for the short engine are needed in service, use the serial number (B4). If parts which were moved from the original engine to the short engine are needed, use the serial number (B1) and the TPL number (B2).



Safety precautions

These safety precautions are important. You must refer also to the local regulations in the country of use. Some items only refer to specific applications.

- Only use these engines in the type of application for which they have been designed.
- Do not change the specification of the engine.
- Do not smoke when you put fuel in the tank.
- Clean away fuel which has been spilt. Material which has been contaminated by fuel must be moved to a safe place.
- Do not put fuel in the tank while the engine runs (unless it is absolutely necessary).
- Do not clean, add lubricating oil, or adjust the engine while it runs (unless you have had the correct training; even then extreme care must be used to prevent injury).
- Do not make adjustments that you do not understand.
- Ensure that the engine does not run in a location where it can cause a concentration of toxic emissions.
- Other persons must be kept at a safe distance while the engine or auxiliary equipment is in operation.
- Do not permit loose clothing or long hair near moving parts.
- Keep away from moving parts during engine operation.

Warning! *Some moving parts cannot be seen clearly while the engine runs.*

- Do not operate the engine if a safety guard has been removed.
- Do not remove the filler cap or any component of the cooling system while the engine is hot and while the coolant is under pressure, because dangerous hot coolant can be discharged.
- Do not allow sparks or fire near the batteries (especially when the batteries are on charge) because the gases from the electrolyte are highly flammable. The battery fluid is dangerous to the skin and especially to the eyes.
- Disconnect the battery terminals before a repair is made to the electrical system.
- Only one person must control the engine.
- Ensure that the engine is operated only from the control panel or from the operators position.
- If your skin comes into contact with high-pressure fuel, obtain medical assistance immediately.
- Diesel fuel and lubricating oil (especially used lubricating oil) can damage the skin of certain persons. Protect your hands with gloves or a special solution to protect the skin.
- Do not wear clothing which is contaminated by lubricating oil. Do not put material which is contaminated with oil into the pockets of clothing.
- Discard used lubricating oil in a safe place to prevent contamination.
- Ensure that the control lever of the transmission drive is in the "out-of-drive" position before the engine is started.
- Use extreme care if emergency repairs must be made in adverse conditions.
- The combustible material of some components of the engine (for example certain seals) can become extremely dangerous if it is burned. Never allow this burnt material to come into contact with the skin or with the eyes, see "Viton seals" on page 6 for safety precautions.
- Read and use the instructions relevant to lift equipment, see "Engine lift equipment" on page 7.

Continued

- Always use a safety cage to protect the operator when a component is to be pressure tested in a container of water. Fit safety wires to secure the plugs which seal the hose connections of a component which is to be pressure tested.
- Do not allow compressed air to contact your skin. If compressed air enters your skin, obtain medical help immediately.
- Turbochargers operate at high speed and at high temperatures. Keep fingers, tools and items away from the inlet and outlet ports of the turbocharger and prevent contact with hot surfaces.
- Do not clean an engine while it runs. If cold cleaning fluids are applied to a hot engine, certain components on the engine may be damaged.
- Fit only genuine Perkins parts.

Viton seals

Some seals used in engines and in components fitted to engines are made of Viton.

Viton is used by many manufacturers and is a safe material under normal conditions of operation.

If Viton is burned, a product of this burnt material is an acid which is extremely dangerous. Never allow this burnt material to come into contact with the skin or with the eyes.

If it is necessary to come into contact with components which have been burnt, ensure that the precautions which follow are used:

- Ensure that the components have cooled
- Use neoprene gloves and discard the gloves safely after use
- Wash the area with calcium hydroxide solution and then with clean water
- Disposal of components and gloves which are contaminated must be in accordance with local regulations.

If there is contamination of the skin or eyes, wash the affected area with a continuous supply of clean water or with calcium hydroxide solution for 15-60 minutes. Obtain immediate medical attention.