

Volvo S40 V40 2004 Wiring Diagram

Full download: <http://manualplace.com/download/volvo-s40-v40-2004-wiring-diagram/>

Frame contained PDF file, click [here](#) to view

- [Cars with SRS](#)
- [Table of contents 1:2, 2:2](#)
- [Abbreviation](#)
- [How to use the wiring diagram 1:2, 2:2](#)
- [Electrical distribution 1:2, 2:2](#)
- Fuses
 - [Engine compartment 11A/1-8](#)
 - [Engine compartment 11A/9-11](#)
 - [Engine compartment 11A/12-17](#)
 - [Engine compartment 11A/18-23](#)
 - [Engine compartment 11A/24-31](#)
 - [Passenger compartment 11B/1-6](#)
 - [Passenger compartment 11B/7-10](#)
 - [Passenger compartment 11B/11-14](#)
 - [Accessories 11C, 11/3](#)
- Relays
 - [Engine compartment 1-9, misc](#)
 - [Passenger compartment 1-7, misc](#)
- Distribution rails
 - [15/1 - 15/3](#)
 - [15/4 - 15/6](#)
 - [15/7 - 15/8](#)
 - [Ignition switch](#)
- Ground connection
 - [31/1 - 31/3](#)
 - [31/4 - 31/5](#)
 - [31/6 - 31/8](#)
 - [31/9 - 31/12](#)
 - [31/13 - 31/102](#)
- Control modules
 - [Overview, Location](#)
 - [Overview, Designation](#)
- Group 23
 - [Engine management system, EMS 2000 1:2, 2:2](#)
 - [Engine management system, EMS 2000 Turbo 1:2, 2:2](#)
 - [Engine management system, Bi-fuel 1:2, 2:2](#)
 - [Engine management system, Melco 2 1:2, 2:2](#)
 - [Engine management system, Diesel 1:2, 2:2](#)
- Group 26
 - [Electric cooling fan/ AC compressor EMS 2000](#)

This is the cut pages sample. Download all 173 page(s) at: ManualPlace.com

- [Electric cooling fan/ AC compressor Melco 2](#)
- [Electric cooling fan/ AC compressor Diesel](#)
- **Group 27**
 - [Cruise control, EMS 2000](#)
 - [Cruise control, Melco 2](#)
 - [Cruise control, Diesel](#)
- **Group 32, 33**
 - [Charging circuit, Starting circuit](#)
- **Group 35**
 - [High and low beams, Fog lights](#)
 - [Tail lights/Position/Parking lights](#)
 - [License plate lighting](#)
 - [Reversing and brake lights, filament monitor](#)
 - [Interior lighting, power sunroof 1:2, 2:2](#)
 - [Key-inserted warning 1:2, 2:2](#)
 - [Beam length adjustment](#)
 - [Instrument and control lighting](#)
 - [Auxiliary lamp](#)
- **Group 36**
 - [Direction indicators and warning lights](#)
 - [Parking Assistance system](#)
 - [Wiper/ washer](#)
 - [Windshield, headlights and rear window](#)
 - [12V outlet and horn](#)
 - [12V socket, cargo compartment](#)
 - [Electronic immobilizer](#)
- **Group 37**
 - [Diagnostics sytem](#)
 - [Towing bracket wiring](#)
- **Group 38**
 - [Seat belt reminder](#)
 - [Driver information module](#)
- **Group 39**
 - [Audio level 1](#)
 - [Audio level 2](#)
 - [Audio level 3](#)
 - [CD changer](#)
 - [Handsfree](#)
- **Group 43, 52**
 - [Automatic transmission/ Vaccum pump EMS 2000](#)
- **Group 59**
 - [ABS, DSA](#)
- **Group 83, 36**
 - [Central locking and anti-theft alarm EU/ OS 1:2, 2:2](#)
 - [Central locking and anti-theft alarm USA](#)
- **Group 83, 84**
 - [Power windows and power door mirrors](#)
- **Group 84**

- [Heated rear window and heated door mirrors](#)
- **Group 85**
 - [Heated seats](#)
 - [Power seats](#)
- **Group 87**
 - [Climate control system](#)
 - [Relay, engine heater](#)
 - [Parking heater, auxiliary heater](#)
 - [Parking heater, remote start](#)
- **Group 88**
 - [Supplemental Restraint System \(SRS\)](#)
- **Connectors**
 - [44/1 EMS 2000](#)
 - [44/1 Melco 2](#)
 - [44/1 Diesel](#)
 - [44/1 BI-FUEL](#)
 - [44/2 - 44/3](#)
 - [44/4 - 44/5](#)
 - [44/6 - 44/7](#)
 - [44/8](#)
 - [44/9](#)
 - [44/10](#)
 - [44/11 - 44/12](#)
 - [44/13 S40](#)
 - [44/13 V40](#)
 - [44/14 - 44/15](#)
 - [44/16 - 44/18](#)
 - [44/19 - 44/21](#)
 - [44/22 - 44/23](#)
 - [44/24 - 44/25](#)
 - [44/26 - 44/28](#)
 - [44/31 - 44/33](#)
 - [44/34 - 44/37](#)
 - [44/38 - 44/41](#)
 - [44/42 - 44/43](#)
- **Junction points**
 - [43/300 - 43/308](#)
 - [43/309 - 43/318](#)
 - [43/319 - 43/328](#)
 - [43/329 - 43/338](#)
 - [43/339 - 43/350](#)
 - [43/351 - 43/361](#)
 - [43/362 - 43/371](#)
 - [43/372 - 43/380](#)
 - [43/381 - 43/386](#)
 - [43/387 - 43/403](#)
 - [43/404 - 43/413](#)
 - [43/414 - 43/424](#)
 - [43/425 - 43/434](#)
 - [43/500 - 43/605](#)
 - [43/606 - 43/618](#)

- [43/619 - 43/626](#)
- **Cable harness routing in vehicle**
 - [Passenger compartment and Dashbord harness](#)
 - [Engine harness EMS 2000](#)
 - [Engine harness Melco 2](#)
 - [Engine harness Diesel](#)
 - [Engine compartment harness EMS 2000](#)
 - [Engine compartment harness Bi-fuel](#)
 - [Engine compartment harness Melco 2](#)
 - [Engine compartment harness Diesel](#)
 - [Front door harness](#)
 - [Rear door harness](#)
 - [Roof harness](#)
 - [Rear harness S40](#)
 - [Trunk lid/ tailgate harness S40](#)
 - [Tailgate harness V40](#)
 - [Rear harness V40](#)
- **Component illustrations**
 - [1/1 - 2/21](#)
 - [2/23 - 2/64](#)
 - [2/192 - 3/10](#)
 - [3/11 - 3/22](#)
 - [3/23 - 3/44](#)
 - [3/50 - 3/64](#)
 - [4/3 - 4/27](#)
 - [4/28 - 4/51](#)
 - [4/75 - 6/4](#)
 - [6/5 - 6/20](#)
 - [6/21 - 6/47](#)
 - [6/48 - 7/8](#)
 - [7/9 - 7/26](#)
 - [7/27 - 7/49 EMS 2000](#)
 - [7/49 Melco - 7/60](#)
 - [7/61 - 7/76](#)
 - [7/77 - 8/2](#)
 - [8/3 - 8/24](#)
 - [8/25 - 8/43](#)
 - [9/1 - 10/14](#)
 - [10/17 - 10/42](#)
 - [10/44 - 10/218](#)
 - [11/1 - 11/2:1](#)
 - [11/2:J - 16/15 S40](#)
 - [16/15 V40 - 17/19](#)
 - [18/4 - 31/11](#)
 - [31/12 - 44/7](#)
 - [44/8 - 44/21](#)
 - [44/22 - 44/38](#)
 - [44/39 - 44/40](#)
- [Index 1:2, 2:2](#)

VOLVO
for life



VOLVO
WIRING DIAGRAM S40/V40

2004
3969202

Cars with SRS (Airbag)/SIPS bag/IC (Inflatable curtain)

Warning!

Vehicles equipped with SRS/SIPS bag/IC must be handled with extra care when making repairs. This avoids:

1. Personal injuries when performing repair work.
2. Damage or malfunction of the SRS/SIPS bag/IC system.

Work involving the SRS/SIPS bag/IC systems or other components in the vehicle that may affect the SRS/SIPS bag/IC systems must always be performed by an authorized Volvo workshop.

In case of doubt, consult the SRS and SIPS bag/IC service manual.

Is the vehicle equipped with SRS/SIPS bag/IC?

Vehicles with SRS are most easily recognized by the letters SRS in the center of the steering wheel. If the vehicle has a passenger side airbag, the letters SRS are stamped on the dashboard above the glove compartment. SRS Vehicles from 1993 and onward also have explosive seat belt tensioners. SIPS bags are only installed on SRS Vehicles from 1995 and onward. SIPS bag decals are located on the windshield and seat compartment. Vehicles with IC can be recognized by the letters IC on the C/D panel (4 door) or the B panel (5 door).

General recommendations

- Be especially careful when working on or around SRS, SIPS, and IC components.
- Make sure that no wires are pinched, frayed, or pierced.
- Never install accessories by the sensors.
- Where applicable, work on the steering wheel, steering shaft, or steering gear must be done in accordance with the methods in the SRS section of VADIS.
- Certain components of the aforementioned systems must be grounded while working. Read the appropriate sections in VADIS.
- Install no accessories in the areas between the A and B posts, the B and C posts, and the C and D posts.

Test terminal

Data link connector in the passenger compartment.

Modifications introduced up to March 2003.

Any changes made to the vehicles after this date are not included in the manual. If necessary refer to service bulletins.

Volvo models are sold in versions adapted for different markets. These adaptations depend on factors such as legal requirements, taxation, and market demands.

This manual may therefore include illustrations and text that do not apply to the vehicles in your country.

Abbreviations.....	3
How to use the wiring diagrams	4
Electrical distribution	
Overview.....	6
Fuses	
Engine compartment 11A/1-8.....	8
Engine compartment 11A/9-11	9
Engine compartment 11A/12-17	10
Engine compartment 11A/18-23	11
Engine compartment 11A/24-31	12
Passenger compartment 11B/1-6	13
Passenger compartment 11B/7-10.....	14
Passenger compartment 11B/11-14	15
Accessories 11C, 11/3	16
Relays	
Engine compartment 1-9, misc.....	17
Passenger compartment 1-7, misc.....	18
Distribution rails	
15/1 - 15/3	19
15/4 - 15/6	20
15/7 - 15/8	21
Ignition switch	22
Ground connections	
31/1 - 31/3	23
31/4 - 31/5	24
31/6 - 31/8	25
31/9 - 31/12.....	26
31/13 - 31/102	27
Control modules	
Overview, Location	28
Overview, Designation	29
Group 23	
Engine management system, EMS 2000	30
Engine management system, EMS 2000 Turbo	32
Engine management system, Bi-fuel.....	34
Engine management system, Melco 2.....	36
Engine management system, Diesel.....	38
Group 26	
Electric cooling fan/ AC compressor EMS 2000	40
Electric cooling fan/ AC compressor Melco 2	41
Electric cooling fan/ AC compressor Diesel.....	42
Group 27	
Cruise control, EMS 2000	43
Cruise control, Melco 2.....	44
Cruise control, Diesel.....	45
Group 32, 33	
Charging circuit, Starting circuit	46

Group 35	
High and low beams, Fog lights	47
Tail lights/Position/parking lights.....	48
License plate lighting.....	48
Reversing and brake lights, filament monitor	49
Interior lighting, power sunroof	50
Key-inserted warning.....	50
Beam length adjustment.....	52
Instrument and control lighting.....	53
Auxiliary lamp.....	54
Group 36	
Direction indicators and warning lights.....	55
Parking Assistance system	56
Wiper/washer.....	57
Windshield, headlights and rear window.....	57
12V outlet and horn	58
12V socket, cargo compartment	59
Electronic immobilizer	60
Group 37	
Diagnostics system.....	61
Towing bracket wiring.....	62
Group 38	
Seat belt reminder.....	63
Driver information module	64
Group 39	
Audio level 1	65
Audio level 2.....	66
Audio level 3.....	67
CD changer	68
Handsfree.....	69
Group 43, 52	
Automatic transmission/ Vacuum pump EMS 2000.....	70
Group 59	
ABS, DSA	71
Group 83, 36	
Central locking and anti-theft alarm EU/OS.....	72
Central locking and anti-theft alarm USA	74
Group 83, 84	
Power windows and power door mirrors.....	75
Group 84	
Heated rear window and heated door mirrors.....	76
Group 85	
Heated seats	77
Power seats.....	78
Group 87	
Climate control system.....	79

Order number TP 3969202
Replaces previous manual TP 3969201

Groups

Group 23	= Fuel system
Group 26	= Cooling system
Group 27	= Engine controls
Group 32	= Generator and voltage regulator
Group 33	= Starting system
Group 35	= Lighting
Group 36	= Additional electrical equipment
Group 37	= Wiring and fuses
Group 38	= Instruments
Group 39	= Other
Group 43	= Transmission
Group 52	= Vacuum hydraulic brake system
Group 59	= Brake system
Group 83	= Doors and openings
Group 84	= Exterior decorative elements etc.
Group 85	= Interior equipment
Group 87	= Climate controls
Group 88	= Internal equipment

Countries/Markets

A	= Austria
AUS	= Australia
B	= Belgium
CDN	= Canada
CH	= Switzerland
D	= Germany
DK	= Denmark
E	= Spain
EU/OS	= Markets outside USA and Canada
FIN	= Finland
GB	= Great Britain
ISR	= Israel
J	= Japan
KOR	= Korea
N	= Norway
NL	= Netherlands
S	= Sweden
USA	= United States of America
WEU	= Western Europe

Other

ABS	= Anti-lock Brake System
A/C	= Air conditioning
AUTO	= Automatic transmission
D	= Driver
ECC	= Electronic climate control system
EH	= Engine heater
EMS 2000	= EMS 2000 Engine management system
FL	= Front left
FR	= Front right
GND	= Ground
HL	= High level of equipment
L	= Left
LH	= Left-hand side
LHD	= Left-hand drive
LL	= Standard level of equipment
LPG	= Liquefied petroleum gas
MAN	= Manual transmission
MELCO	= Melco engine management system
P	= Passenger
PETROL	= Gasoline
PH	= Parking heater
R	= Right
REC	= Receiver
RH	= Right-hand side
RHD	= Right-hand drive
RL	= Rear left
RR	= Rear right
SRS	= Airbag
T	= Turbo engine
TRANS	= Transmitter
TURBO	= Turbo engine
XENON	= Xenon lamps

Colors

BL	= Blue
BN	= Brown
GN	= Green
GR	= Gray
OR	= Orange
P	= Pink
R	= Red
SB	= Black
VO	= Violet
W	= White
Y	= Yellow

How to use the wiring diagrams

The descriptions below apply in general to all wiring diagram manuals, although not all sections are necessarily contained in this manual.

A. Component designation

Every component has a component designation that consists of two parts.

The first part is a type number that describes the type of component in question, for example 3/xx.

The second part of the designation is a serial number, for example, x/2.

Combined these give a component designation, for example, 3/2.

At the end of the manual is a list of components, where, with the help of the component designation, you can read off the name of the component, for example, 3/2 = light switch.

List of type numbers

The list shows which type of component that respective type numbers refer to, for example, 3/x = switch, 6/x = electric motor, etc.

1	Battery
2	Relay
3	Switch
4	Control module
5	Driver information module
6	Electric motor
7	Sensor
8	Actuator
9	Heating element
10	Light
11	Fuse
15	Distribution rail
16	Audio
17	Service/diagnostics
18	Contact reel
19	Meter
20	Ignition component/shunt
31	Ground connection
43	Junction point
44	Connector

B. Junction points

The wiring diagrams contain numbered junction points, e.g. 43/352.

This manual contains a section with a list of junction points. This list shows all the components which are connected to each junction point.

The location of the junction points is shown in the "Cable harness routing in vehicle" section.

C. Connectors

Connectors provide a bridge between two cables harnesses and are described in the "Connectors" section.

D. Electrical distribution

Operation of the fuses and relays is shown in the "Electrical distribution" section.

E. Data communication

Today's cars are equipped with a CAN network, which transmits information. Connections to this network are shown in their entirety on the respective wiring diagrams. Complete information on CAN communication is can be found in the section titled "Data communication".

F. Abbreviations

A number of different abbreviations are used in the manual. These are explained in the section "Abbreviations".

G. Component location

There is a section at the end of the manual in which the appearance and location of components is described in numerical order.

Volvo S40 V40 2004 Wiring Diagram

Full download: <http://manualplace.com/download/volvo-s40-v40-2004-wiring-diagram/>

Electrical distribution Overview

