

Volvo Supplement V70 08 Xc70 08 S80 07 2008 Wiring Diagram

Full download: <http://manualplace.com/download/volvo-supplement-v70-08-xc70-08-s80-07-2008-wiring-diagram/>

VOLVO V70 (08-), XC70 (08-) & S80 (07-)

WIRING DIAGRAM 2008 SUPPLEMENT



TP 39127202 LATE DESIGN

Vehicles with SRS (Airbag)/SIPS bag/ IC (Inflatable curtain)

Warning!

Extra caution must be exercised when working on vehicles equipped with SRS/SIPS bag/IC in order to avoid:

1. Personal injuries when performing repair work.
2. Damage or malfunction of the SRS/SIPS bag/IC system.

Work involving the SRS/SIPS bag/IC systems or other components in the vehicle that may affect the SRS/SIPS bag/IC systems must always be performed by an authorized Volvo workshop.

In case of doubt, consult the SRS and SIPS bag/IC service manual.

Is the vehicle equipped with SRS/SIPS bag/IC?

Vehicles with SRS are most easily recognized by the letters SRS in the center of the steering wheel. If the vehicle also has a passenger side airbag, the letters SRS are stamped on the dashboard above the glove compartment. SRS vehicles from 1993 and onward also have explosive seat belt tensioners. SIPS bags are only installed on SRS vehicles from 1995 and onward. SIPS bag decals are located on the windshield and seat compartment. Vehicles with IC can be recognized by the letters IC on the C/D panel (4 door) or the B panel (5 door).

General recommendations

- Be especially careful when working on or around SRS, SIPS, and IC components.
- Make sure that no wires are pinched, frayed, or pierced.
- Never fit accessories by the sensors.
- Where applicable, work on the steering wheel, steering shaft, or steering gear must be done in accordance with the methods in the SRS section of VIDA.
- Certain components of the aforementioned systems must be grounded while working. Read the appropriate sections in VIDA.
- Install no accessories in the areas between the A and B-posts, the B and C-posts, and the C and D-posts.

Test terminal

Fuse in cargo compartment auxiliary fuse box.

Changes introduced up to and including September 2007

Any changes made to the vehicle after this date are not included in the manual. If necessary, refer to service bulletins.

Volvo models are sold in versions adapted for different markets. These adaptations depend on factors such as legal requirements, taxation, and market demands.

This manual may therefore include illustrations and text that do not apply to the vehicles in your country.

Order number: TP 39127202

TP 39127202 Supplement, can also be found on Electronic Wiring Diagram (EWD) TP 39125002. TP39127202 contains updated information for the 2008 model late design, for other electrical systems see publication TP39115202.

We retain the right to make modifications.

© Volvo Car Corporation

Table of Contents 1:2

Vehicles with SRS (Airbag)/SIPS bag/	
IC (Inflatable curtain)	2
Explanations	5
Abbreviations	5
How to use the wiring diagrams 1:2.....	6
Electrical distribution 1:2.....	8

Fuses

Engine compartment electrical center F1-F7.....	10
Engine compartment distribution box F9-F24.....	11
Engine compartment distribution box F25-F30.....	12
Engine compartment distribution box F31-F37.....	13
Engine compartment distribution box F38	14
Engine compartment electrical center F39-F44.....	15
Central Electronic Module (CEM) F1 - F11.....	16
Central Electronic Module (CEM) F13 - F19.....	17
Central Electronic Module (CEM) F20 - F28.....	18
Rear electrical center FA1-FA12	19
Distribution box in cargo compartment FB1-FB12.....	20
Rear electrical center FD1-FD7	21
Battery PF1-PF2.....	22

Relays

Relays in the engine compartment R2.....	23
Relays in the engine compartment R8-R9.....	24
Relays in the engine compartment R10-R13.....	25
Distribution box in cargo compartment RA1-RD1.....	26
Central Electronic Module (CEM)	27

Ground connections

Overview.....	28
31/1 - 31/7	29
31/10 - 31/15	30
31/47 - 31/66	31
31/67 - 31/83	32
31/84 - 31/93	33
31/94 - 31/XX10.....	34
31/XX14 - 31/AL	35

Control modules

Overview of locations.....	36
Overview designations.....	37
Data communication high speed CAN.....	38
Data communication high speed CAN 4 Cyl.....	39
Data communication LIN 1:2	40
Data communication MOST.....	42

Group 23 Fuel system

Engine management system, 5 Cyl. Diesel 1:3	43
Engine management system, 4 Cyl. 1:2	46
Engine management system, 4 Cyl. Flexifuel 1:2.....	48
Engine management system, 4 Cyl. Diesel 1:2	50
Engine management system, 6 Cyl. Turbo 1:2.....	52
Engine management system, 8 Cyl. 1:2	54
Emission control, 4 Cyl.	56
Emission control, 8 Cyl.	57

Group 26 Cooling system

Cooling fan, 4 Cyl.	58
Cooling fan, 4 Cyl. Diesel.....	59
Cooling fan, 5 Cyl. Diesel.....	60
Cooling fan, 5 Cyl. Turbo & 6 Cyl.....	61
Cooling fan, 8 Cyl.	62

Group 27 Engine controls

Cruise control 4 Cyl.....	63
Cruise control 4 Cyl. Diesel.....	64
Cruise control 5 Cyl. & 6 Cyl.....	65
Cruise control 5 Cyl. Diesel.....	66
Cruise control 8 Cyl.....	67

Group 32 Alternator and voltage regulator

Power supply	68
--------------------	----

Group 33 Starting system

Starting system 4 Cyl.....	69
----------------------------	----

Group 35 Lighting

Running/parking lights, Tail lights V70.....	70
Running/parking lights, Tail lights (Bi-Xenon) V70.....	71
Fog lights, V70	72
Brake light, V70	73
Reversing lights, V70	74
Door handle lighting LHD.....	75
Door handle lighting RHD	76

Group 36 Other electrical equipment

Direction indicator and Hazard warning flashers	
LHD, V70	77
Direction indicator and Hazard warning flashers	
RHD, V70.....	78
High-pressure headlight washer	79
Wiper/washer rear window, V70	80
Parking assistance.....	81
Keyless vehicle 4 Cyl. 1:2.....	82
Collision warning with brake servo.....	84
Alcolock	85

Table of Contents 2:2

Group 37 Wiring and fuses, Accessories

Tow hitch cable harness, 4-pin V70.....	86
Tow hitch cable harness, 7-pin V70.....	87
Tow hitch cable harness, 13-pin V70.....	88

Group 38 Instruments

Driver information module.....	89
--------------------------------	----

Group 39 Other

Audio 1:2	90
Audio Premium 1:3	92
Rear seat entertainment	95

Group 43 Transmission

Differential Electronic Module (DEM).....	96
---	----

Group 55 Parking brake

Electronic parking brake	97
--------------------------------	----

Group 87 Climate control system

Climate control system 4 Cyl. 1:2	98
---	----

Connectors..... 100

Branching points112

Cable harness routing in vehicle

Engine harness, 4 Cyl.....	117
Engine harness, 4 Cyl. Diesel.....	117
Engine harness, 8 Cyl.....	118
Harness engine compartment.....	118
Harness ceiling	119
Harnesses rear axle.....	119

Component illustrations120

Index124

List of components 1:4125

Explanations

Abbreviations

Groups

Group 23	= Fuel system
Group 26	= Cooling system
Group 27	= Engine controls
Group 32	= Alternator and voltage regulator
Group 33	= Starting system
Group 35	= Lighting
Group 36	= Additional electrical equipment
Group 37	= Wiring and fuses
Group 38	= Instruments
Group 39	= Other
Group 43	= Transmission
Group 55	= Parking brake
Group 87	= Climate control system

Ignition switch symbols

X	= Accessories (audio position)
S	= Powered upon insertion of key
15	= Contact remains connected during start
15I	= Contact is broken while starting
30	= Constant power from the battery
50	= Start

Countries/Markets

A	= Austria
AUS	= Australia
B	= Belgium
CDN	= Canada
CH	= Switzerland
D	= Germany
DK	= Denmark
E	= Spain
EU/OS	= Markets outside USA and Canada
FIN	= Finland
GB	= Great Britain
ISR	= Israel
J	= Japan
KOR	= Korea
N	= Norway
NL	= Netherlands
S	= Sweden
USA	= United States of America
WEU	= Western Europe

Other

ACC	= Adaptive Cruise Control
AUTO	= Automatic transmission
BLIS	= Blind spot information system
CAN	= CAN communication
DPY	= Display
ECC	= Electronic climate control system
ETA	= Engine throttle body
GDL	= Gas discharge lamp
HISPEED	= High speed data bus
IR	= Infrared sensor
LIN	= LIN communication
LH	= Left-hand side
LHD	= Left-hand drive
MAN	= Manual transmission
MEMORY	= Memory driver's seat
MIDSPEED	= Midspeed data bus
MMS	= Mass Movement Sensor
PETROL	= Gasoline
RH	= Right-hand side
RHD	= Right-hand drive
SCR	= Screened
SRS	= Airbag
T	= Turbocharged engine
W/O	= Without
2WD	= Two-wheel drive
4CYL, I4	= 4-cylinder engine
5CYL, I5	= 5-cylinder engine
6CYL, I6	= 6-cylinder engine
8CYL, V8	= 8-cylinder engine

Colors

BK, SB	= Black
BN	= Brown
BU, BL	= Blue
GN	= Green
GY, GR	= Gray
LGN	= Light Green
NL	= Natural
OG, OR	= Orange
PK, P	= Pink
RD, R	= Red
VT, VO	= Violet
WH, W	= White
YE, Y	= Yellow

How to use the wiring diagrams 1:2

The descriptions below apply in general to all wiring diagram manuals, although not all sections are necessarily contained in this manual.

A. Component designation

Every component has a component designation that consists of two parts.

The first part is a type number that describes the type of component in question, for example 3/xx.

The second part of the designation is a serial number, e.g. x/2.

Together, this constitutes a component designation, e.g. 3/2.

At the end of the manual is a list of components, where, with the help of the component designation, you can read off the name of the component, for example, 3/2 = light switch.

List of type numbers

The list shows which type of component that respective type numbers refer to, for example, 3/x = switch, 6/x = electric motor, etc.

1	Battery
2	Relay
3	Switch
4	Control module
5	Driver information module
6	Electric motor
7	Sensor
8	Actuator
9	Heating element
10	Light
11	Fuse
15	Electrical distribution rail/box
16	Audio
17	Service/diagnostics
18	Contact reel
19	Meter
20	Ignition component/shunt
27	Optics
31	Ground connection
73	Branching point
74	Connector

B. Branching points

The wiring diagrams contain numbered branching points, for example 73/5035.

This manual contains a section with a list of branching points. This list shows all the components that are connected to each branching point.

The location of the branching points is shown in the "Cable harness routing in vehicle" section.

C. Connectors

Connectors provide a bridge between two cable harnesses and are described in the "Connectors" section.

D. Electrical distribution

Operation of the fuses and relays is shown in the "Electrical distribution" section.

E. Data communication

Today's cars contain CAN, LIN and MOST networks that transfer information. Connections to these networks are not shown in their entirety in the respective wiring diagram. Complete information on CAN, LIN and MOST communication is found in the section "Control modules".


F. Abbreviations

A number of different abbreviations are used in the manual. These are explained in the section "Abbreviations".























G. Component location


The end of the manual contains a section that describes component appearance and location in numerical order.

How to use the wiring diagrams 2:2




List of symbols

-  = System voltage
-  = Ground connection via wiring
-  = Ground connection in component/chassis
-  = Screened wire
-  = Junction point
-  = Twisted cable
-  = Electrical connection
-  = Variant
-  = CAN communication
-  = CAN high data signal (CAN H)
-  = CAN low data signal (CAN L)
-  = LIN communication
-  = LIN communication
-  = DIN cable, coaxial cable, etc.
-  = Data communication
-  = CAN communication
-  = MOST communication
-  = MOST communication
-  = Connection with distribution box
-  = Further connection to...
-  = Connector between cable harnesses
-  = Connector connected in component




Electrical distribution 1:2

Overview, Electrical center and Cold zone in engine compartment




Electrical distribution 2:2

Overview, rear electrical center



Fuses

Engine compartment electrical center F1-F7



15/31 Engine compartment electrical center

No.	No.	Fuse function	via	A
F1	11A/1	Main fuse for fuses in CEM	4/56	50
F2	11A/2	Main fuse for fuses in CEM	4/56	50
F3	11A/3	11D/A1-11D/A12 Fuses in cargo compartment 15/32	-	60
F4	11A/4	11D/B1-11D/B12 Fuses in cargo compartment 15/32	-	60
F5	11A/5	11D/D1-11D/D7 Fuses in cargo compartment 15/32	-	50
F7	11A/7	9/42 PTC-element	-	100
continues				