



# FZ6-SS FZ6-SSC

## SERVICE MANUAL

---

EAS00010

**FZ6-SS/FZ6-SSC  
SERVICE MANUAL**

**©2003 by Yamaha Motor  
Corporation, U.S.A.**

**First edition, November 2003**

**All rights reserved. Any reproduction  
or unauthorized use without the written  
permission of Yamaha Motor Corporation,  
U.S.A. is expressly prohibited.**

**Printed in U.S.A.**

**P/N LIT-11616-17-50**

## NOTICE

This manual was produced by the Yamaha Motor Company, Ltd. primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual. Therefore, anyone who uses this book to perform maintenance and repairs on Yamaha vehicles should have a basic understanding of mechanics and the techniques to repair these types of vehicles. Repair and maintenance work attempted by anyone without this knowledge is likely to render the vehicle unsafe and unfit for use.

This model has been designed and manufactured to perform within certain specifications in regard to performance and emissions. Proper service with the correct tools is necessary to ensure that the vehicle will operate as designed. If there is any question about a service procedure, it is imperative that you contact a Yamaha dealer for any service information changes that apply to this model. This policy is intended to provide the customer with the most satisfaction from his vehicle and to conform to federal environmental quality objectives.

Yamaha Motor Company, Ltd. is continually striving to improve all of its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

### NOTE:

- This Service Manual contains information regarding periodic maintenance to the emission control system. Please read this material carefully.
- Designs and specifications are subject to change without notice.

## IMPORTANT MANUAL INFORMATION

Particularly important information is distinguished in this manual by the following.



The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!



Failure to follow WARNING instructions could result in severe injury or death to the motorcycle operator, a bystander or a person checking or repairing the motorcycle.

### CAUTION:

A CAUTION indicates special precautions that must be taken to avoid damage to the motorcycle.

### NOTE:

A NOTE provides key information to make procedures easier or clearer.

# HOW TO USE THIS MANUAL

This manual is intended as a handy, easy-to-read reference book for the mechanic. Comprehensive explanations of all installation, removal, disassembly, assembly, repair and check procedures are laid out with the individual steps in sequential order.

- ① The manual is divided into chapters. An abbreviation and symbol in the upper right corner of each page indicate the current chapter. Refer to “SYMBOLS”.
- ② Each chapter is divided into sections. The current section title is shown at the top of each page, except in Chapter 3 (“PERIODIC CHECKS AND ADJUSTMENTS”), where the sub-section title(s) appears.
- ③ Sub-section titles appear in smaller print than the section title.
- ④ To help identify parts and clarify procedure steps, there are exploded diagrams at the start of each removal and disassembly section.
- ⑤ Numbers are given in the order of the jobs in the exploded diagram. A circled number indicates a disassembly step.
- ⑥ Symbols indicate parts to be lubricated or replaced. Refer to “SYMBOLS”.
- ⑦ A job instruction chart accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc.
- ⑧ Jobs requiring more information (such as special tools and technical data) are described sequentially.

②
①

CLUTCH
ENG

**CLUTCH CLUTCH COVER**

Order	Job/Part	Qty	Remarks
<b>Removing the clutch cover</b>			
	Engine oil		Removing the parts in the order listed. Drain. Refer to “CHANGING THE ENGINE OIL” in chapter 3.
	Coolant		Drain. Refer to “CHANGING THE COOLANT” in chapter 3.
1	Coolant hose	1	Disconnect.
2	Clutch cable	1	Disconnect.
3	Clutch cover	1	
4	Clutch cover gasket	1	
5	Dowel pin	2	
For installation, reverse the removal procedure.			

CLUTCH
ENG

**REMOVING THE CLUTCH**

1. Remove:

- clutch cover ①
- gasket

**NOTE:**  
Loosen each bolt 1/4 of a turn at a time, in stages and in a criss-cross pattern. After all of the bolts are fully loosened, remove them.

2. Remove:

- compression spring bolts ①
- compression springs
- pressure plate ②
- pull rod ③
- friction plates
- clutch plates

3. Straighten the lock washer tab.

4. Loosen:

- clutch boss nut ①

**NOTE:**  
While holding the clutch boss ② with the universal clutch holder, loosen the clutch boss nut.

Universal clutch holder  
90890-04086, YM-91042

5. Remove:

- clutch boss nut ①
- lock washer ②
- clutch boss ③
- thrust plate ④
























**CHECKING THE FRICTION PLATES**

The following procedure applies to all of the friction plates.

1. Check:

- friction plate

Damage/wear → Replace the friction plates as a set.

① GEN INFO 	② SPEC 	
③ CHK ADJ 	④ CHAS 	
⑤ ENG 	⑥ COOL 	
⑦ FI 	⑧ ELEC 	
⑨ TRBL SHTG ?	⑩ 	
⑪ 	⑫ 	
⑬ 	⑭ 	
⑮ 	⑯ 	⑰ 
⑱ 	⑲ 	⑳ 
㉑ 	㉒ 	㉓ 
㉔ 	㉕ <b>New</b>	

## SYMBOLS

The following symbols are not relevant to every vehicle.

Symbols ① to ⑨ indicate the subject of each chapter.

- ① General information
- ② Specifications
- ③ Periodic checks and adjustments
- ④ Chassis
- ⑤ Engine
- ⑥ Cooling system
- ⑦ Fuel injection system
- ⑧ Electrical system
- ⑨ Troubleshooting

Symbols ⑩ to ⑰ indicate the following.

- ⑩ Serviceable with engine mounted
- ⑪ Filling fluid
- ⑫ Lubricant
- ⑬ Special tool
- ⑭ Tightening torque
- ⑮ Wear limit, clearance
- ⑯ Engine speed
- ⑰ Electrical data










Symbols ⑱ to ㉓ in the exploded diagrams indicate the types of lubricants and lubrication points.

- ⑱ Engine oil
- ⑲ Gear oil
- ⑳ Molybdenum-disulfide oil
- ㉑ Wheel-bearing grease
- ㉒ Lithium-soap-based grease
- ㉓ Molybdenum-disulfide grease

Symbols ㉔ to ㉕ in the exploded diagrams indicate the following.

- ㉔ Apply locking agent (LOCTITE®)
- ㉕ Replace the part

# TABLE OF CONTENTS

GENERAL INFORMATION		GEN INFO	<b>1</b>
SPECIFICATIONS		SPEC	<b>2</b>
PERIODIC CHECKS AND ADJUSTMENTS		CHK ADJ	<b>3</b>
CHASSIS		CHAS	<b>4</b>
ENGINE		ENG	<b>5</b>
COOLING SYSTEM		COOL	<b>6</b>
FUEL INJECTION SYSTEM		FI	<b>7</b>
ELECTRICAL SYSTEM		ELEC	<b>8</b>
TROUBLESHOOTING		TRBL SHTG	<b>9</b>

---

## CHAPTER 1 GENERAL INFORMATION

<b>MOTORCYCLE IDENTIFICATION</b> .....	1-1
VEHICLE IDENTIFICATION NUMBER .....	1-1
MODEL LABEL .....	1-1
<b>FEATURES</b> .....	1-2
OUTLINE OF FI SYSTEM .....	1-2
FI SYSTEM .....	1-3
INSTRUMENT FUNCTION .....	1-4
<b>IMPORTANT INFORMATION</b> .....	1-6
PREPARATION FOR REMOVAL AND DISASSEMBLY .....	1-6
REPLACEMENT PARTS .....	1-6
GASKETS, OIL SEALS AND O-RINGS .....	1-6
LOCK WASHERS/PLATES AND COTTER PINS .....	1-7
BEARINGS AND OIL SEALS .....	1-7
CIRCLIPS .....	1-7
<b>CHECKING THE CONNECTIONS</b> .....	1-8
<b>SPECIAL TOOLS</b> .....	1-9

## CHAPTER 2 SPECIFICATIONS

<b>GENERAL SPECIFICATIONS</b> .....	2-1
<b>ENGINE SPECIFICATIONS</b> .....	2-2
<b>CHASSIS SPECIFICATIONS</b> .....	2-10
<b>ELECTRICAL SPECIFICATIONS</b> .....	2-14
<b>CONVERSION TABLE</b> .....	2-17
<b>GENERAL TIGHTENING TORQUE SPECIFICATIONS</b> .....	2-17
<b>TIGHTENING TORQUES</b> .....	2-18
ENGINE TIGHTENING TORQUES .....	2-18
CHASSIS TIGHTENING TORQUES .....	2-21
<b>LUBRICATION POINTS AND LUBRICANT TYPES</b> .....	2-23
ENGINE .....	2-23
CHASSIS .....	2-24
<b>COOLING SYSTEM DIAGRAMS</b> .....	2-25

---

<b>ENGINE OIL LUBRICATION CHART</b> .....	2-29
<b>LUBRICATION DIAGRAMS</b> .....	2-30
<b>CABLE ROUTING</b> .....	2-36

## **CHAPTER 3**

### **PERIODIC CHECKS AND ADJUSTMENTS**

<b>INTRODUCTION</b> .....	3-1
<b>PERIODIC MAINTENANCE CHART FOR THE EMISSION CONTROL SYSTEM</b> .....	3-1
<b>GENERAL MAINTENANCE AND LUBRICATION CHART</b> .....	3-1
<b>SEAT</b> .....	3-3
<b>FUEL TANK</b> .....	3-4
REMOVING THE FUEL TANK .....	3-6
REMOVING THE FUEL PUMP .....	3-6
INSTALLING THE FUEL PUMP .....	3-7
INSTALLING THE FUEL TANK .....	3-7
<b>COWLINGS</b> .....	3-8
<b>AIR FILTER CASE</b> .....	3-9
<b>BATTERY BOX AND BATTERY BOX BRACKET</b> .....	3-10
<b>ENGINE</b> .....	3-11
ADJUSTING THE VALVE CLEARANCE .....	3-11
SYNCHRONIZING THE THROTTLE BODIES .....	3-17
ADJUSTING THE ENGINE IDLING SPEED .....	3-19
ADJUSTING THE THROTTLE CABLE FREE PLAY .....	3-20
CHECKING THE SPARK PLUGS .....	3-23
MEASURING THE COMPRESSION PRESSURE .....	3-24
CHECKING THE ENGINE OIL LEVEL .....	3-27
CHANGING THE ENGINE OIL .....	3-28
MEASURING THE ENGINE OIL PRESSURE .....	3-30
ADJUSTING THE CLUTCH CABLE FREE PLAY .....	3-32
CLEANING THE AIR FILTER ELEMENT .....	3-33
CHECKING THE THROTTLE BODY JOINTS .....	3-34
CHECKING THE FUEL AND BREATHER HOSES .....	3-35
CHECKING THE CRANKCASE BREATHER HOSE .....	3-35
CHECKING THE EXHAUST SYSTEM .....	3-36
CHECKING THE COOLANT LEVEL .....	3-37
CHECKING THE COOLING SYSTEM .....	3-38
CHANGING THE COOLANT .....	3-38



---

<b>CHASSIS</b> .....	3-42
ADJUSTING THE FRONT BRAKE .....	3-42
ADJUSTING THE REAR BRAKE .....	3-43
CHECKING THE BRAKE FLUID LEVEL .....	3-44
CHECKING THE FRONT AND REAR BRAKE PADS .....	3-45
ADJUSTING THE REAR BRAKE LIGHT SWITCH .....	3-46
CHECKING THE FRONT AND REAR BRAKE HOSES .....	3-46
BLEEDING THE HYDRAULIC BRAKE SYSTEM .....	3-47
ADJUSTING THE SHIFT PEDAL .....	3-48
ADJUSTING THE DRIVE CHAIN SLACK .....	3-49
LUBRICATING THE DRIVE CHAIN .....	3-50
CHECKING AND ADJUSTING THE STEERING HEAD .....	3-51
CHECKING THE FRONT FORK .....	3-53
ADJUSTING THE REAR SHOCK ABSORBER ASSEMBLY .....	3-54
CHECKING THE TIRES .....	3-54
CHECKING THE WHEELS .....	3-57
CHECKING AND LUBRICATING THE CABLES .....	3-58
LUBRICATING THE LEVERS AND PEDALS .....	3-58
LUBRICATING THE SIDESTAND .....	3-58
LUBRICATING THE CENTERSTAND .....	3-58
LUBRICATING THE REAR SUSPENSION .....	3-59
<b>ELECTRICAL SYSTEM</b> .....	3-60
CHECKING AND CHARGING THE BATTERY .....	3-60
CHECKING THE FUSES .....	3-66
REPLACING THE HEADLIGHT BULBS .....	3-68
ADJUSTING THE HEADLIGHT BEAMS .....	3-69

## CHAPTER 4 CHASSIS

<b>FRONT WHEEL AND BRAKE DISCS</b> .....	4-1
REMOVING THE FRONT WHEEL .....	4-3
CHECKING THE FRONT WHEEL .....	4-3
CHECKING THE BRAKE DISCS .....	4-5
INSTALLING THE FRONT WHEEL .....	4-6
ADJUSTING THE FRONT WHEEL STATIC BALANCE .....	4-7
<b>REAR WHEEL AND BRAKE DISC</b> .....	4-9
REAR WHEEL .....	4-9
REAR BRAKE DISC AND REAR WHEEL SPROCKET .....	4-10
REMOVING THE REAR WHEEL .....	4-12
CHECKING THE REAR WHEEL .....	4-13
CHECKING THE REAR WHEEL DRIVE HUB .....	4-13
CHECKING AND REPLACING THE REAR WHEEL SPROCKET .....	4-13
INSTALLING THE REAR WHEEL .....	4-14
ADJUSTING THE REAR WHEEL STATIC BALANCE .....	4-15

---

<b>FRONT AND REAR BRAKES</b> .....	4-16
FRONT BRAKE PADS .....	4-16
REAR BRAKE PADS .....	4-17
REPLACING THE FRONT BRAKE PADS .....	4-19
REPLACING THE REAR BRAKE PADS .....	4-21
FRONT BRAKE MASTER CYLINDER .....	4-23
REAR BRAKE MASTER CYLINDER .....	4-26
DISASSEMBLING THE FRONT BRAKE MASTER CYLINDER ..	4-28
CHECKING THE FRONT AND REAR BRAKE MASTER CYLINDERS .....	4-28
DISASSEMBLING THE REAR BRAKE MASTER CYLINDER ....	4-29
ASSEMBLING AND INSTALLING THE FRONT BRAKE MASTER CYLINDER .....	4-30
ASSEMBLING THE REAR BRAKE MASTER CYLINDER .....	4-32
FRONT BRAKE CALIPERS .....	4-34
REAR BRAKE CALIPER .....	4-36
DISASSEMBLING THE FRONT BRAKE CALIPERS .....	4-38
DISASSEMBLING THE REAR BRAKE CALIPER .....	4-39
CHECKING THE FRONT AND REAR BRAKE CALIPERS .....	4-40
ASSEMBLING AND INSTALLING THE FRONT BRAKE CALIPERS .....	4-41
ASSEMBLING AND INSTALLING THE REAR BRAKE CALIPER .....	4-43
<b>FRONT FORK</b> .....	4-45
FRONT FORK LEGS .....	4-45
REMOVING THE FRONT FORK LEGS .....	4-48
DISASSEMBLING THE FRONT FORK LEGS .....	4-48
CHECKING THE FRONT FORK LEGS .....	4-50
ASSEMBLING THE FRONT FORK LEGS .....	4-51
INSTALLING THE FRONT FORK LEGS .....	4-54
<b>HANDLEBAR</b> .....	4-55
REMOVING THE HANDLEBAR .....	4-56
CHECKING THE HANDLEBAR .....	4-56
INSTALLING THE HANDLEBAR .....	4-57
<b>STEERING HEAD</b> .....	4-59
UNDER BRACKET .....	4-59
REMOVING THE UNDER BRACKET .....	4-61
CHECKING THE STEERING HEAD .....	4-61
INSTALLING THE STEERING HEAD .....	4-62
<b>REAR SHOCK ABSORBER ASSEMBLY</b> .....	4-64
REMOVING THE REAR SHOCK ABSORBER ASSEMBLY .....	4-65
HANDLING THE REAR SHOCK ABSORBER .....	4-66
DISPOSING OF A REAR SHOCK ABSORBER .....	4-66
CHECKING THE REAR SHOCK ABSORBER ASSEMBLY .....	4-66
INSTALLING THE REAR SHOCK ABSORBER ASSEMBLY .....	4-67

---

<b>SWINGARM AND DRIVE CHAIN</b> .....	4-68
REMOVING THE SWINGARM .....	4-70
REMOVING THE DRIVE CHAIN .....	4-71
CHECKING THE SWINGARM .....	4-71
INSTALLING THE SWINGARM .....	4-72
CHECKING THE DRIVE CHAIN .....	4-73

## **CHAPTER 5 ENGINE**

<b>ENGINE</b> .....	5-1
DRIVE SPROCKET .....	5-1
EXHAUST PIPE .....	5-2
LEADS AND HOSES .....	5-3
ENGINE .....	5-5
INSTALLING THE ENGINE .....	5-6
<b>CAMSHAFTS</b> .....	5-8
CYLINDER HEAD COVER .....	5-8
CAMSHAFTS .....	5-9
REMOVING THE CAMSHAFTS .....	5-11
CHECKING THE CAMSHAFTS .....	5-12
CHECKING THE TIMING CHAIN, CAMSHAFT SPROCKETS, AND TIMING CHAIN GUIDES .....	5-14
CHECKING THE TIMING CHAIN TENSIONER .....	5-14
INSTALLING THE CAMSHAFTS .....	5-15
<b>CYLINDER HEAD</b> .....	5-19
REMOVING THE CYLINDER HEAD .....	5-20
CHECKING THE CYLINDER HEAD .....	5-20
INSTALLING THE CYLINDER HEAD .....	5-21
<b>VALVES AND VALVE SPRINGS</b> .....	5-22
REMOVING THE VALVES .....	5-24
CHECKING THE VALVES AND VALVE GUIDES .....	5-25
CHECKING THE VALVE SEATS .....	5-27
CHECKING THE VALVE SPRINGS .....	5-29
CHECKING THE VALVE LIFTERS .....	5-30
INSTALLING THE VALVES .....	5-30
<b>STARTER CLUTCH AND GENERATOR</b> .....	5-32
STATOR COIL ASSEMBLY .....	5-32
REMOVING THE GENERATOR .....	5-34
REMOVING THE STARTER CLUTCH .....	5-35
CHECKING THE STARTER CLUTCH .....	5-36
INSTALLING THE STARTER CLUTCH .....	5-36
INSTALLING THE GENERATOR .....	5-37

---

<b>SHIFT SHAFT</b> .....	5-39
SHIFT SHAFT AND STOPPER LEVER .....	5-39
CHECKING THE SHIFT SHAFT .....	5-41
CHECKING THE STOPPER LEVER .....	5-41
INSTALLING THE SHIFT SHAFT .....	5-41
<b>CRANKSHAFT POSITION SENSOR AND PICKUP ROTOR</b> .....	5-42
REMOVING THE PICKUP ROTOR .....	5-44
INSTALLING THE PICKUP ROTOR .....	5-44
<b>CLUTCH</b> .....	5-46
CLUTCH COVER .....	5-46
CLUTCH .....	5-48
REMOVING THE CLUTCH .....	5-49
CHECKING THE FRICTION PLATES .....	5-49
CHECKING THE CLUTCH PLATES .....	5-50
CHECKING THE CLUTCH SPRINGS .....	5-50
CHECKING THE CLUTCH HOUSING .....	5-51
CHECKING THE CLUTCH BOSS .....	5-51
CHECKING THE PRESSURE PLATE .....	5-51
CHECKING THE PULL LEVER SHAFT AND PULL ROD .....	5-52
INSTALLING THE CLUTCH .....	5-52
<b>OIL PAN AND OIL PUMP</b> .....	5-55
REMOVING THE OIL PAN .....	5-58
CHECKING THE OIL PUMP .....	5-58
CHECKING THE RELIEF VALVE .....	5-59
CHECKING THE OIL DELIVERY PIPE AND OIL PIPE .....	5-59
CHECKING THE OIL STRAINER .....	5-59
CHECKING THE OIL NOZZLES .....	5-59
ASSEMBLING THE OIL PUMP .....	5-60
INSTALLING THE OIL PUMP .....	5-60
INSTALLING THE OIL STRAINER .....	5-61
INSTALLING THE OIL PAN .....	5-61
<b>CRANKCASE</b> .....	5-62
DISASSEMBLING THE CRANKCASE .....	5-64
CHECKING THE CRANKCASE .....	5-65
CHECKING THE BEARINGS AND OIL SEALS .....	5-65
CHECKING THE TIMING CHAIN .....	5-65
ASSEMBLING THE CRANKCASE .....	5-65

---

<b>CONNECTING RODS AND PISTONS</b> .....	5-67
REMOVING THE CONNECTING RODS AND PISTONS .....	5-68
REMOVING THE CRANKSHAFT ASSEMBLY .....	5-69
CHECKING THE CYLINDER AND PISTON .....	5-69
CHECKING THE PISTON RINGS .....	5-70
CHECKING THE PISTON PINS .....	5-71
CHECKING THE BIG END BEARINGS .....	5-72
INSTALLING THE CONNECTING ROD AND PISTON (except for CAL) .....	5-76
INSTALLING THE CONNECTING ROD AND PISTON (for CAL) .....	5-79
 <b>CRANKSHAFT</b> .....	 5-83
CHECKING THE CRANKSHAFT .....	5-84
CHECKING THE CRANKSHAFT JOURNAL BEARINGS .....	5-84
INSTALLING THE CRANKSHAFT .....	5-87
 <b>TRANSMISSION</b> .....	 5-88
TRANSMISSION, SHIFT DRUM ASSEMBLY AND SHIFT FORKS .....	5-88
REMOVING THE TRANSMISSION .....	5-94
CHECKING THE SHIFT FORKS .....	5-94
CHECKING THE SHIFT DRUM ASSEMBLY .....	5-95
CHECKING THE TRANSMISSION .....	5-95
INSTALLING THE TRANSMISSION .....	5-96

## CHAPTER 6 COOLING SYSTEM

<b>RADIATOR</b> .....	6-1
CHECKING THE RADIATOR .....	6-3
INSTALLING THE RADIATOR .....	6-4
 <b>OIL COOLER</b> .....	 6-5
CHECKING THE OIL COOLER .....	6-7
INSTALLING THE OIL COOLER .....	6-7
 <b>THERMOSTAT</b> .....	 6-8
CHECKING THE THERMOSTAT .....	6-9
INSTALLING THE THERMOSTAT .....	6-10
 <b>WATER PUMP</b> .....	 6-11
DISASSEMBLING THE WATER PUMP .....	6-13
CHECKING THE WATER PUMP .....	6-14
ASSEMBLING THE WATER PUMP .....	6-14
INSTALLING THE WATER PUMP .....	6-16

---

## CHAPTER 7

### FUEL INJECTION SYSTEM

<b>FUEL INJECTION SYSTEM</b> .....	7-1
WIRING DIAGRAM .....	7-2
ECU'S SELF-DIAGNOSTIC FUNCTION .....	7-3
ALTERNATE INSTRUCTIONS OPERATION CONTROL (FAIL-SAFE ACTION) .....	7-4
FAIL-SAFE ACTIONS TABLE .....	7-4
TROUBLESHOOTING CHART .....	7-6
DIAGNOSTIC MODE .....	7-7
TROUBLESHOOTING DETAILS .....	7-13
<b>THROTTLE BODIES</b> .....	7-25
INJECTORS .....	7-27
CHECKING THE INJECTORS .....	7-28
CHECKING THE THROTTLE BODIES .....	7-28
CHECKING THE FUEL PUMP AND PRESSURE REGULATOR OPERATION .....	7-29
CHECKING AND ADJUSTING THE THROTTLE POSITION SENSOR .....	7-30
<b>AIR INDUCTION SYSTEM</b> .....	7-32
AIR INJECTION .....	7-32
AIR CUT-OFF VALVE .....	7-32
AIR INDUCTION SYSTEM DIAGRAMS .....	7-33
CHECKING THE AIR INDUCTION SYSTEM .....	7-34

## CHAPTER 8

### ELECTRICAL SYSTEM

<b>ELECTRICAL COMPONENTS</b> .....	8-1
<b>CHECKING SWITCH CONTINUITY</b> .....	8-3
<b>CHECKING THE SWITCHES</b> .....	8-4
<b>CHECKING THE BULBS AND BULB SOCKETS</b> .....	8-5
TYPES OF BULBS .....	8-5
CHECKING THE CONDITION OF THE BULBS .....	8-5
CHECKING THE CONDITION OF THE BULB SOCKETS .....	8-6
CHECKING THE LED's .....	8-7
<b>IGNITION SYSTEM</b> .....	8-8
CIRCUIT DIAGRAM .....	8-8
TROUBLESHOOTING .....	8-9

---

<b>ELECTRIC STARTING SYSTEM</b> .....	8-14
CIRCUIT DIAGRAM .....	8-14
STARTING CIRCUIT CUT-OFF SYSTEM OPERATION .....	8-15
TROUBLESHOOTING .....	8-16
<b>STARTER MOTOR</b> .....	8-19
CHECKING THE STARTER MOTOR .....	8-21
ASSEMBLING THE STARTER MOTOR .....	8-22
<b>CHARGING SYSTEM</b> .....	8-24
CIRCUIT DIAGRAM .....	8-24
TROUBLESHOOTING .....	8-25
<b>LIGHTING SYSTEM</b> .....	8-27
CIRCUIT DIAGRAM .....	8-27
TROUBLESHOOTING .....	8-29
CHECKING THE LIGHTING SYSTEM .....	8-31
<b>SIGNALING SYSTEM</b> .....	8-34
CIRCUIT DIAGRAM .....	8-34
TROUBLESHOOTING .....	8-36
CHECKING THE SIGNALING SYSTEM .....	8-36
<b>COOLING SYSTEM</b> .....	8-43
CIRCUIT DIAGRAM .....	8-43
TROUBLESHOOTING .....	8-44
<b>FUEL PUMP SYSTEM</b> .....	8-47
CIRCUIT DIAGRAM .....	8-47
FUEL PUMP SYSTEM .....	8-48
TROUBLESHOOTING .....	8-49
CHECKING THE FUEL PUMP .....	8-51
<b>SELF-DIAGNOSIS</b> .....	8-52
TROUBLESHOOTING .....	8-53


## CHAPTER 9 TROUBLESHOOTING

<b>STARTING FAILURES</b> .....	9-1
ENGINE .....	9-1
FUEL SYSTEM .....	9-1
ELECTRICAL SYSTEMS .....	9-1
<b>INCORRECT ENGINE IDLING SPEED</b> .....	9-2
ENGINE .....	9-2
FUEL SYSTEM .....	9-2
ELECTRICAL SYSTEMS .....	9-2

---

<b>POOR MEDIUM-AND-HIGH-SPEED PERFORMANCE</b> .....	9-2
ENGINE .....	9-2
FUEL SYSTEM .....	9-2
<b>FAULTY GEAR SHIFTING</b> .....	9-3
SHIFTING IS DIFFICULT .....	9-3
SHIFT PEDAL DOES NOT MOVE .....	9-3
JUMPS OUT OF GEAR .....	9-3
<b>FAULTY CLUTCH</b> .....	9-3
CLUTCH SLIPS .....	9-3
CLUTCH DRAGS .....	9-3
<b>OVERHEATING</b> .....	9-4
ENGINE .....	9-4
COOLING SYSTEM .....	9-4
FUEL SYSTEM .....	9-4
CHASSIS .....	9-4
ELECTRICAL SYSTEMS .....	9-4
<b>OVERCOOLING</b> .....	9-4
COOLING SYSTEM .....	9-4
<b>POOR BRAKING PERFORMANCE</b> .....	9-4
<b>FAULTY FRONT FORK LEGS</b> .....	9-5
LEAKING OIL .....	9-5
MALFUNCTION .....	9-5
<b>UNSTABLE HANDLING</b> .....	9-5
<b>FAULTY LIGHTING OR SIGNALING SYSTEM</b> .....	9-6
HEADLIGHT DOES NOT COME ON .....	9-6
HEADLIGHT BULB BURNT OUT .....	9-6
TAIL/BRAKE LIGHT DOES NOT COME ON .....	9-6
TAIL/BRAKE LIGHT BULB BURNT OUT .....	9-6
TURN SIGNAL DOES NOT COME ON .....	9-6
TURN SIGNAL BLINKS SLOWLY .....	9-6
TURN SIGNAL REMAINS LIT .....	9-6
TURN SIGNAL BLINKS QUICKLY .....	9-6
HORN DOES NOT SOUND .....	9-6





EAS00014


## GENERAL INFORMATION MOTORCYCLE IDENTIFICATION

EAS00017

### VEHICLE IDENTIFICATION NUMBER

The vehicle identification number ① is stamped into the right side of the steering head pipe.

# 1



EAS00018

### MODEL LABEL

The model label ① is affixed to the frame. This information will be needed to order spare parts.

EAS00896

## FEATURES


### OUTLINE OF FI SYSTEM

The main function of a fuel supply system is to provide fuel to the combustion chamber at the optimum air-fuel ratio in accordance with the engine operating conditions and the atmospheric temperature. In the conventional carburetor system, the air-fuel ratio of the mixture that is supplied to the combustion chamber is created by the volume of the intake air and the fuel that is metered by the jet used in the respective carburetor.

Despite the same volume of intake air, the fuel volume requirement varies by the engine operating conditions, such as acceleration, deceleration, or operating under a heavy load. Carburetors that meter the fuel through the use of jets have been provided with various auxiliary devices, so that an optimum air-fuel ratio can be achieved to accommodate the constant changes in the operating conditions of the engine.

As the requirements for the engine to deliver more performance and cleaner exhaust gases increase, it becomes necessary to control the air-fuel ratio in a more precise and finely tuned manner. To accommodate this need, this model has adopted an electronically controlled fuel injection (FI) system, in place of the conventional carburetor system. This system can achieve an optimum air-fuel ratio required by the engine at all times by using a microprocessor that regulates the fuel injection volume according to the engine operating conditions detected by various sensors.

The adoption of the FI system has resulted in a highly precise fuel supply, improved engine response, better fuel economy, and reduced exhaust emissions. Furthermore, the air induction system (AI system) has been placed under computer control together with the FI system in order to realize cleaner exhaust gases.




- |                                 |                              |                               |                                |
|---------------------------------|------------------------------|-------------------------------|--------------------------------|
| ① Ignition coil                 | ⑦ Intake air pressure sensor | ⑫ Coolant temperature sensor  | ⑱ Engine trouble warning light |
| ② Air filter case               | ⑧ Throttle position sensor   | ⑬ Spark plug                  | ⑲ Lean angle cut-off switch    |
| ③ Intake air temperature sensor | ⑨ Fuel injector              | ⑭ Pressure regulator          |                                |
| ④ Fuel delivery hose            | ⑩ Catalytic converter        | ⑮ Battery                     |                                |
| ⑤ Fuel tank                     | ⑪ Crankshaft position sensor | ⑯ ECU                         |                                |
| ⑥ Fuel pump                     |                              | ⑰ Fuel injection system relay |                                |

EAS00897


**FI SYSTEM**

The fuel pump delivers fuel to the injector via the fuel filter. The pressure regulator maintains the fuel pressure that is applied to the injector at only 250 kPa (2.5 kg/cm<sup>2</sup>). Accordingly, when the energizing signal from the ECU energizes the injector, the fuel passage opens, causing the fuel to be injected into the intake manifold only during the time the passage remains open. Therefore, the longer the length of time the injector is energized (injection duration), the greater the volume of fuel that is supplied. Conversely, the shorter the length of time the injector is energized (injection duration), the lesser the volume of fuel that is supplied.

The injection duration and the injection timing are controlled by the ECU. Signals that are input from the throttle position sensor, crankshaft position sensor, intake air pressure sensor, intake temperature sensor and coolant temperature sensor enable the ECU to determine the injection duration. The injection timing is determined through the signals from the crankshaft position sensor. As a result, the volume of fuel that is required by the engine can be supplied at all times in accordance with the driving conditions.



- |                                 |                              |                              |                         |
|---------------------------------|------------------------------|------------------------------|-------------------------|
| ① Fuel pump                     | ⑥ Throttle position sensor   | ⑨ Coolant temperature sensor | <b>A</b> Fuel system    |
| ② Pressure regulator            | ⑦ Intake air pressure sensor | ⑩ Crankshaft position sensor | <b>B</b> Control system |
| ③ Fuel injector                 | ⑧ ECU                        |                              |                         |
| ④ Throttle body                 |                              |                              |                         |
| ⑤ Intake air temperature sensor |                              |                              |                         |



- ① Multi-function display
- ② "SELECT" button
- ③ "RESET" button
- ④ Engine trouble warning light

## INSTRUMENT FUNCTION

### Multi-function display

The multi-function display is equipped with the following:

- a speedometer (which shows the riding speed)
- an odometer (which shows the total distance traveled)
- two tripmeters (which show the distance traveled since they were last set to zero)
- a fuel reserve tripmeter (which shows the distance traveled since the bottom segment of the fuel meter started flashing)
- a tachometer (which shows the engine speed)
- a fuel meter
- a water temperature
- a clock
- a intake air temperature
- a self-diagnosis device

### NOTE:

- Be sure to turn the key to "ON" before using the "SELECT" and "RESET" buttons.
- For the U.K. only: To switch the speedometer and odometer/tripmeter display between kilometers and miles, press the "SELECT" button for at least two seconds.

### Odometer, tripmeter and tachometer modes

Pushing the "SELECT" button switches the display between the odometer mode "ODO" and the tripmeter modes "TRIP 1" and "TRIP 2" and the tachometer mode "E" in the following order:

ODO → TRIP 1 → TRIP 2 → (TRIP F) → E → ODO

When approximately 3.6 L of fuel remain in the fuel tank, the bottom segment of the fuel meter will start flashing, and the odometer display will automatically change to the fuel reserve tripmeter mode "TRIP F" and start counting the distance traveled from that point. In that case, pushing the "SELECT" button switches the display between the various tripmeter and odometer modes in the following order:

TRIP-F → E → ODO → TRIP 1 → TRIP 2 → TRIP F

To reset a tripmeter, select it by pushing the "SELECT" button, and then push the "RESET" button for at least one second. If you do not reset the fuel reserve tripmeter manually, it will reset itself automatically and the display will return to the prior mode after refueling and traveling 5 km (3.1 mi).

### Tachometer mode

Displays the digital indication of the engine speed on the odometer section.

Air intake temperature indicator.

When "ODO" is displayed, pressing the "RESET" for a long time allows the indicator to switch displays between Clock and Air intake temperature. (It activates the clock indication when the main switch is turned OFF.)

In the Co adjustment mode, the indication automatically changes from clock (Air intake temperature) to the engine speed.