



YAMAHA

MBK 

CS50/Z ²⁰⁰²
_{5RW1-AE1}

SERVICE MANUAL

EAS00001

CS50/Z
SERVICE MANUAL
© 2002 by Yamaha Motor España, S.A.
1st Edition, September 2002
Any reprinting or use of this material
without the prior authorisation of
Yamaha Motor España, S.A.
is expressly prohibited.
Printed in Spain.

NOTICE

This manual was produced by the Yamaha Motor España, S.A., primarily for use by Yamaha/MBK dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual. Therefore, anyone who uses this book to perform maintenance and repairs on Yamaha/MBK vehicles should have a basic understanding of the mechanics and the techniques to repair these types of vehicles. Repair and maintenance work attempted by anyone without this knowledge is likely to render the vehicle unsafe and unfit for use.

Yamaha Motor España, S.A., is continually striving to improve all of its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha/MBK dealers and will appear in future editions of this manual where applicable.

NOTE: _____

Designs and specifications are subject to change without notice.

IMPORTANT INFORMATION

Particularly important information is distinguished in this manual by the following.



The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!

WARNING

Failure to follow WARNING instructions could result in severe injury or death to the scooter operator, a bystander, or a person inspecting or repairing the scooter.

CAUTION:

A CAUTION indicates special precautions that must be taken to avoid damage to the scooter.

NOTE :

A NOTE provides key information to make procedures easier or clearer.

HOW TO USE THIS MANUAL

FORMAT OF THIS MANUAL

This manual consists of chapters for the main subject categories (See "Illustrated Symbols").

First heading ①: This is a chapter with a symbol at the top right-hand side of each page.

Second heading ②: This title appears at the top of each page to the left of the chapter symbol. (For the "Inspection and periodic adjustments", chapter the third heading appears.)

Third heading ③: This is a final heading.

MANUAL FORMAT

All the procedures in this manual are organized sequentially, step by step. The information has been compiled to make reading easy for the mechanic and to provide useful reference material which contains ample explanations of all disassembly, repair, assembly and inspection procedures. A particularly important procedure ④ is placed between a lines of asterisks "***" with each procedure preceded by "•".

IMPORTANT CHARACTERISTICS

- Data and special tools are put in a box preceded by a corresponding symbol ⑤.
- A number within a circle ⑥ indicates the number of a part, and a alphabetical letter within a circle indicates data or an alignment mark ⑦, everything else is indicated by a letter within a box ⑧.
- The conditions of defective components will precede an arrow symbol and the course of action to be followed will follow the symbol ⑨.

DETAILED DIAGRAM

Each chapter provides detailed diagrams before each disassembly section, for the easy identification of disassembly/assembly procedures.

② INSPECTION AND REPAIR MOT

①


④ ③

INSPECTION AND REPAIR

CYLINDER HEAD

1. Eliminate:

- Carbon deposits
- Use a rounded scraper ①



2. Inspect:

- Warping of cylinder head
- Out of specification → Correct

Steps for measuring and correcting warp:

- Place a straight edge ① and a thickness gauge ② against the head
- Measure the warp limit.

⑤ Warp limit:
0.02 mm

- If warp is out of specification, straighten the head.

NOTE:

Rotate the head several times to avoid removing too much material from one side.

CYLINDER AND PISTON

1. Eliminate:

- Carbon deposits
- Use a rounded file ①

2. Inspect:


- Cylinder wall
- Wear/Scratches → Rectify or replace

⑨

3. Eliminate:

- Carbon deposits ① ②
- From the crown of the piston and ring slots.

⑥



SIGNAL SYSTEM ELEC

• Turn the main switch to "ON".

• Place the "↔" switch at "→" or "←".

• Check the voltage (12 V) on the "Chocolate" or "Dark Green" wire from the socket connector.

OUT OF SPECIFICATION

↓

MEETS SPECIFICATION (12V)

↓

The circuit is in good condition.

4. The "OIL" indicator light does not light up.

1. Bulb and socket

- Check the bulb and socket to see if there is continuity

NO CONTINUITY

↓

CONTINUITY

Change the bulb and/or socket.


2. Oil level switch

- Remove the oil level switch from the oil tank.
- Connect the pocket tester (1x1) to the oil level switch.

Tester cable (+) → Terminal ①

Tester cable (-) → Terminal ②

- Check the oil level gauge for continuity.



Position of switch	Good condition	Poor condition
A Position straight upward	x	○ x ○
B Position backwards	○	x x ○
⑧ Continuity	x: No continuity	

POOR CONDITION


↓

Change the oil level switch.

• If it is out of specification, rectify or replace the cylinder. Replace the piston and piston rings together.

Second case:

- Measure the diameter of the skirt of piston "P" with a micrometer.
- ⑦ 5.0 mm (0.20 in.) from the lower edge of the piston.



ILLUSTRATED SYMBOLS

(See illustration)

The symbols from ① to ⑨ are designed as thumb indices, to indicate the chapter number and index.

- ① General information
- ② Specifications
- ③ Periodic checks and adjustments
- ④ General motor revision
- ⑤ Cooling system
- ⑥ Carburetor
- ⑦ Chassis
- ⑧ Electrical system
- ⑨ Troubleshooting

The illustrated symbols from ⑩ to ⑯ are used to identify the specifications that appear in the text.

- ⑩ Refill liquid
- ⑪ Lubricant
- ⑫ Special tool
- ⑬ Torque
- ⑭ Wear, play limit
- ⑮ Motor speed
- ⑯ Ω , V, A

The illustrated symbols from ⑰ to ⑳ of the detailed diagrams indicate the grade of lubricant and the site of the lubrication point.

- ⑰ Apply motor oil
- ⑱ Apply gear oil
- ⑲ Apply molybdenum disulphide oil
- ⑳ Apply wheel bearing grease
- ㉑ Apply lightweight lithium soap base grease
- ㉒ Apply molybdenum disulphide grease
- ㉓ Apply blocking agent (LOCTITE®)
- ㉔ Use a new one
































① GEN INFO 	② SPEC 	
③ CHK ADJ 	④ ENG 	
⑤ COOL 	⑥ CARB 	
⑦ CHAS 	⑧ ELEC 	
⑨ TRBL SHTG ?	⑩ 	
⑪ 	⑫ 	
⑬ 	⑭ 	
⑮ 	⑯ 	
⑰ 	⑱ 	⑲ 
⑳ 	㉑ 	㉒ 
㉓ 	㉔ New	

TABLE OF CONTENTS

GENERAL INFORMATION	
	GEN INFO 1
SPECIFICATIONS	
	SPEC 2
PERIODIC CHECKS AND ADJUSTMENTS	
	CHK ADJ 3
ENGINE	
	ENG 4
COOLING SYSTEM	
	COOL 5
CARBURETOR	
	CARB 6
CHASSIS	
	CHAS 7
ELECTRICAL SYSTEM	
	ELEC 8
TROUBLESHOOTING	?
	TRBL SHTG 9



**GEN
INFO**


1

CHAPTER 1 GENERAL INFORMATION

SCOOTER IDENTIFICATION	1-1
FRAME SERIAL NUMBER	1-1
ENGINE SERIAL NUMBER.....	1-1
IMPORTANT INFORMATION	1-2
REPLACEMENT PARTS	1-2
GASKETS, OIL SEALS AND O-RINGS	1-2
LOCK WASHERS/PLATES AND COTTER PINS.....	1-2
BEARINGS AND OIL SEALS	1-2
CIRCLIPS	1-3
SPECIAL TOOLS	1-4

IDENTIFICATION OF SCOOTER

GEN
INFO




EAS00015

GENERAL INFORMATION SCOOTER IDENTIFICATION

FRAME SERIAL NUMBER

The frame serial number ① is stamped on the chassis.



ENGINE SERIAL NUMBER


The serial number of the engine ① is stamped on the raised portion of the rear left section of the transmission box.


NOTE:

The first three digits of these numbers are for identifying the model; the remaining digits constitute the production number of the unit.

NOTE:

Designs and specifications are subject to change without notice.






IMPORTANT INFORMATION

EAS00021

REPLACEMENT PARTS


1. Use only genuine Yamaha/MBK parts for all replacements. Use the oil and/or grease recommended by Yamaha/MBK for assembly and adjustment.



EAS00022

GASKETS, OIL SEALS AND O-RINGS


1. Replace all gaskets, seals and O-rings when overhauling the engine. All gasket surfaces, oil seal lips and O-rings must be cleaned.
2. Properly oil all mating parts and bearings during reassembly. Apply grease to the oil seal lips.



EAS00023

LOCK WASHERS/PLATES AND COTTER PINS


1. Replace all lock washers/plates ① and cotter pins after removal. Bend lock tabs along the bolt or nut flats after the bolt or nut has been tightened to specification.



EAS00024


BEARINGS AND OIL SEALS

1. Install the bearings ① and oil stops ② with their manufacturer brands or numbers facing outwards. (In other words, the stamped letters should be on the side exposed to view.) When installing oil seals, apply a light coating of lightweight lithium base grease to the seal lips. Put oil on the bearings when installing.



CAUTION: _____

Do not use compressed air to spin the bearings dry. This will damage the bearing surface.



EAS00025

CIRCLIPS










1. Check all circlips carefully before reassembly. Always replace piston pin clips after one use. Replace distorted circlips. When installing a circlip ①, make sure that the sharp-edged corner ② is positioned opposite the thrust ③ it receives. See sectional view.
④ Shaft.

EAS00027

SPECIAL TOOLS










The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools; this will help prevent damage caused by the use of inappropriate tools or improvised techniques.


When placing an order, refer to the list provided below to avoid any mistakes.

Tool No.	Tool name / Usage	Illustration
90890-01235	Rotor holding tool This tool is used to remove the flywheel magneto.	
90890-01337	Clutch spring bracket This tool is used to remove the clutch nut while holding the compression spring.	
90890-01274 -01275 -01277 -01288	Container of the crankshaft installer a Bolt of the crankshaft installer b Adapter c, Spacer d These tools are used to install the crankshaft.	
90890-01362	Flywheel puller For removing the flywheel.	
90890-01135	Crankcase separation tool This tool is used to remove the crankshaft or separate the crankcase.	
90890-01384	Oil seal guide Protects the edge of the oil seal during the installation of the secondary sliding pulley wheel.	
90890-01403	Ring nut wrench This tool is used to loosen and tighten the steering ring nut.	
90890-01701	Pulley bracket This tools is used to disassemble and assemble the secondary pulley.	
90890-03079	Thickenss gauge This tool is used to measure the clearance.	

SPECIAL TOOLS



Tool No.	Tool name / Usage	Illustration
90890-03112	<p>Pocket tester</p> <p>This instrument is very important for checking the electrical system.</p>	
90890-03113	<p>Engine tachometer</p> <p>This tool is necessary for detecting the engine rpm.</p>	
90890-01409	<p>Oil seals guide</p> <p>This tool is used to install the left oil guide of the crankcase.</p>	
90890-01410	<p>Oil seals installer</p> <p>This tool is used to install the left oil seal of the crankcase.</p>	
90890-06754	<p>Ignition checker</p> <p>This instrument is necessary to check the components of the ignition system.</p>	
90890-85505	<p>Yamaha bond No. 1215</p> <p>This bond (sealant) is used for crankcase mating surface, etc.</p>	
90890-01348	<p>Locknut wrench</p> <p>This tool is used to loosen and tighten the secondary sheave nut.</p>	
90890-01367 ① -01400 ②	<p>Front oil seals inserter Counterweight a Adapter b</p> <p>These tools are used in the installation of seals.</p>	
90890-01326 -01294	<p>T-handle Damper rod holder</p> <p>These tool are used for holding the damper rod holder when removing or installing the damper rod holder.</p>	



SPEC

2



CHAPTER 2 SPECIFICATIONS

GENERAL SPECIFICATIONS	2-1
MAINTENANCE SPECIFICATIONS	2-3
ENGINE	2-3
CHASSIS	2-5
ELECTRICAL SYSTEM	2-6
CONVERSION TABLE	2-7
GENERAL TIGHTENING TORQUE SPECIFICATIONS	2-7
TIGHTENING TORQUES	2-8
ENGINE TIGHTENING TORQUES	2-8
CHASSIS TIGHTENING TORQUES	2-9
COOLING SYSTEM (CS50Z only)	2-10
CABLE ROUTING	2-11



SPECIFICATIONS

GENERAL SPECIFICATIONS

Model	CS50	CS50Z
Dimensions: Overall length Overall width Overall height Seat height Wheelbase Minimum ground clearance	1.740 mm 675 mm 1.065 mm 770 mm / 776 mm 1.210 mm 132 mm	
Basic weight (With oil and full fuel tank):	80,5 kg	83,7 kg
Engine: Engine type Cylinder arrangement Displacement Bore x stroke Compression ratio Starting system	Plate valve, gasoline, 2-strokes air-cooled Liquid cooled Forward-inclined single cylinder 49,3 cc 40,0 x 39,2 mm 10,2 : 1 11,4 : 1 Electric and kickstarter	
Lubrication system:	Yamaha autolube	
Oil type or grade: Engine oil Transmission oil	2-strokes motor oil (JASO grade FC) SE type 10W30 SAE motor oil	
Oil capacity: Oil tank (motor oil) Transmission fluid Periodic fluid change Total amount	1,4 L 0,10 L 0,11 L	
Cooling system capacity: (Total amount)	–	0,910 L
Air filter:	Wet type element	
Fuel: Type Fuel tank capacity	Unleaded gasoline 5,5 L	
Carburetor: Type/quantity Manufacturer	PHVA12ZS/1, PY12/1 DELL'ORTO, GURTNER	PHVA12ZS/1 DELL'ORTO
Spark plug: Type/Manufacturer Spark plug gap	BR8HS/N.G.K. 0,6 ~ 0,7 mm	
Clutch type:	Dry, centrifugal automatic	
Transmission: Primary reduction system Primary reduction ratio Secondary reduction system Secondary reduction ratio Transmission type Operation	Helical gear 52/13 (4.000) Straight gearing 42/13 (3.230) 43/13 (3.310) Single speed automatic (V-belt type) Centrifugal automatic type	

GENERAL SPECIFICATIONS

SPEC







Model	CS50	CS50Z
Chassis: Frame type Front axle incline angle Steering angle base	Steel tube underbone 25° 80 mm	
Tire: Size/Type (Front) Size/Type (Rear)	110/70-12 / 47 L 120/70-12 / 51 L, 130/70-12 / 56 L	
Tire pressure (cold tire): Front Rear	175 KPa (1,75 kg/cm ²) 200 KPa (2,00 kg/cm ²)	
Maximum Load: Front Rear	175 KPa (1,75 Kg/cm ²) 225 KPa (2,25 Kg/cm ²)	
Brake: Type of front brake Activation Type of rear brake Activation	Disk brake Right hand operation Drum brake Left hand operation	
Suspension: Front suspension Rear suspension	Telescopic fork Unit swing	
Shock absorber: Front shock absorber Rear shock absorber	Coil spring/Oil damper Coil spring/Oil damper	
Wheel travel: Front wheel travel Rear wheel travel	70 mm 60 mm	
Electrical: Ignition system Generator system Battery type or model Battery capacity	DC-CDI Magnetic flywheel Maintenance free 12V 4AH	
Type of headlamp:	Bulb	
Bulb wattage/quantity: Headlight Tail/brake light Turn signal light Auxiliary light License plate light Meter lighting	12V, 35W / 35Wx1 12V, 5W / 21Wx1 12V, 10Wx2 (rear) / 12V, 16Wx2 (front) 12V, 5W x 2 12V, 5W x 1 12V, 1,2W x 2	
Indicator light voltage/quantity: Oil level warning light Turn signal indicator light High beam indicator light Coolant temperature warning light	LED 12V, 2W x 2 12V, 2W x 1	
	-	LED



MAINTENANCE SPECIFICATIONS

ENGINE

Model	CS50	CS50Z
Cylinder head: Warp limit 	0,02 mm * The lines indicate measurement with straight edge	
Cylinder: Bore size <Limit> Taper limit Out of round limit	39,993 ~ 40,012 mm <40,1 mm> 0,05 mm 0,01 mm	
Piston: Piston size Measuring point 	39,952 - 39,972 mm	39,957 - 39,997 mm
	5 mm	
	0,034 - 0,047 mm	0,029 - 0,042 mm
Piston clearance On measurement 1st	40,25 mm	
Piston rings: Cut-away section (BXT)/TYPE Top ring 2nd ring 	1.5 x 1.8 mm/Keystone 1.5 x 1.8 mm/Keystone	
End gap (installed) Top ring 2nd ring <Limit>	0,15 ~ 0,35 mm 0,15 ~ 0,35 mm <0,6 mm>	
Side clearance Top ring 2nd ring	0,03 ~ 0,05 mm 0,03 ~ 0,05 mm	
Crankshaft: 		
Crank width "A" Runout limit "C" Large end of rod side clearance "D" Small end of rod clearance "F"	37,90 ~ 37,95 mm 0,03 mm 0,2 ~ 0,5 mm 0,4 ~ 0,8 mm	

MAINTENANCE SPECIFICATIONS

SPEC



Model	CS50	CS50Z	
Automatic centrifugal clutch: Clutch shoe thickness <Limit> Clutch shoe spring free length Clutch - in revolution Clutch - stall revolution	2,0 mm <1,0 mm> 29,9 mm		
	3.350 - 3.850 r/min. 5.200 - 6.000 r/min.	3.950 - 4.450 r/min. 6.900 - 7.700 r/min.	
V-belt: V-belt width <Limit>	16,5 mm <15,7 mm>		
Transmission: Main axle eccentricity limit Drive axle eccentricity limit	0,08 mm 0,08 mm		
Pedal starting: Type Strength of pedal spring	Ratchet 150 ~ 250 g		
Air filter oil grade:	For foam air filter or air-cooled 2-stroke motor oil		
Carburetor: Type / Manufacturer / Amount Main jet / Model (M.J.) Jet needle (J.N.) Main air jet (M.A.J.) Pilot jet (P.J.) Pilot screw (P.A.S.) Valve seat size Engine idling speed Starter jet	PHVA12ZS/1 DELL'ORTO #65	PY12/1 GURTNER #62	PHVA12ZS/1 DELL'ORTO #65
	A20-3/5	B10A-2/3	A35-4/5
	ø 2.5	ø 2.0	ø 2.5
	#36	#38	#36
2 - 2 ¹ / ₄	1 ³ / ₄ - 2	1 ³ / ₄ ± 1/8	
1.2	1.4	1.2	
	1650 ~ 1950 r/min		
	#50	#42	#50

MAINTENANCE SPECIFICATIONS

SPEC



CHASSIS

Model	CS50	CS50Z
Steering system: Steering bearing type Upper Lower	Ball bearing Ball bearing	
Front suspension: Front fork travel Fork spring free length Spring rate (K ₁) (K ₂) Oil capacity Oil grade	70 mm 224 mm 1,33 Kgf/mm 2,0 Kgf/mm 45 cc ± 1 Fork oil: 10W or equivalent	
Rear suspension: Shock absorber stroke Spring free length Spring rate (K ₁) (K ₂)	60 mm 220 mm 4,58 Kgf/mm 6,12 Kgf/mm	
Wheels: Type of front wheel Type of rear wheel Size/material of front tyre Size/material of rear tyre Rim runout limit Radial Lateral	Alloy rim Alloy rim 2,75 x 12 / aluminium 3,00 x 12 / aluminium 1,0 mm 1,0 mm	
Front disc brake: Type Disc outside diameter x thickness Pad thickness <Limit> Interior diameter of pump Calliper interior diameter Brake fluid type	Single ø 190 x 3,5 mm 4,5 mm <0,5 mm> 11 mm 30 mm DOT #4	
Rear drum brake: Type Drum inside diameter <Limit> Shoe thickness <Limit>	Single cam ø 110 mm <ø 110,5 mm> 4 mm <2 mm>	
Brake levers: Free play of the front brake lever (right)/measurement Free play of the rear brake lever (left)/measurement	2 ~ 5 mm / At the end of the lever 5 ~ 10 mm / At the end of the lever	