

編 番
PART NO.
PI2N-E1-5

PARTS CATALOG

パーツカタログ

EX120-2

EQUIPMENT COMPONENTS PARTS

機器 インナーパーツ

適用号機 30001~
Serial No.

HITACHI

ま え が き

- ◎ このパーツカタログは、EX120-2 油圧ショベルに使用している油圧機器等の精密部品を掲載してあります。また、巻末に部品番号順索引を収録してあります。
部品番号順索引の中で、「*」印のあるものは、新設部品を示します。
- ◎ 当社では、製品の改良にたえず努力をはらっておりますので、パーツカタログに記載されていない変更が生じている場合があります。必要に応じて、この様な変更を盛り込んだ改訂版を出しておりますので、本機または、本パーツカタログに不明の点がございましたら、最寄りの支店または、営業所にご相談ください。
- ◎ 機械はブーム側を前、エンジン側を後、運転席側を左、その反対側を右、下部走行体は、走行モータ側を後といたします。

1. 部品のご注文について

部品をご注文の際には、次の事項を最寄りの支店または、営業所へご連絡ください。

- | | | | |
|-----------------|-------------|---|---------------------------|
| (1) 機械の型式 | [例] EX120-2 | } | キャブ右下メインフレームの銘板に明示してあります。 |
| (2) 機械の製番 | 12N-30001 | | |
| (3) 部品番号 | A810165 | } | 本パーツカタログの該当部品 |
| (4) 部品名 | O-リング | | |
| (5) 数量 | 2 | | ご注文される個数 |
| (6) 送付先の住所および宛名 | | | |

2. パーツカタログの見方

符 号 : 部品構成図内の各部品に付けられた見出し番号です。

部 品 番 号 : 部品に付けられた固有番号です。数字のみ、あるいは英字と数字の混合で構成しています。

部 品 名 : 部品の名称です。

組立品を構成する部品は、部品名の前に「・」印を付け、組立品のつぎに続けて記載しています。さらに「・」印の部品が組立品の場合は、その構成部品に「・・」印が付けてあります。以下「・」を順次増やして組立品の構成部品であることを表わしています。

数 量 : 「各機器の1セット分の個数」を示します。ただし、組立品の構成部品は、その組立品「1組分の個数」を示します。

サービスコード : サービスコード欄に記載している各記号の意味は、次の通りです。

W : その部品を取付ける為には、現地加工作業が必要ですので、当社にご相談ください。

D : 単品では交換できませんので、その部品の含まれる組部品で交換してください。

K : その部品がサービスパーツキットに含まれていることを示します。

R : 調整用シムなどのように使用する数量が号機毎に異なる事を示します。

S : 工場出荷時に組み込まれた部品でなく、修理、サービス用として供給する部品を示します。

OP : オプション部品であることを示します。標準機には付いておらず、特別注文により販売する部品です。

OS : オーバーサイズ部品を示します。

US : アンダーサイズ部品を示します。

(OS, US はスタンダードサイズ部品の次の行に、続けて記載しています。)

: このパーツカタログから、その部品の含まれている装置のリストのページに新しく記載した部品であることを示します。

適用号機 : その部品を使用している機械の「号機」を示します。[「号機」とは、機械の製番の「- (ハイフン)」以下の数字をいいます。]

適用号機欄上部には、部品全体に適用する「号機」を表示しています。

各部品毎に「号機」表示のないものは、適用号機欄上部の「号機」が適用号機になります。

各部品毎に「号機」表示のあるものは、部品毎の「号機」と適用号機欄上部の「号機」との両方を包含する「号機」が部品毎の適用号機となります。

また、先頭に「D」の文字を表示しているものは、変更切替時期を年月で表わします。

(例 ; D90 / 10 - . . . 1990年10月以降この部品を使用。)

先頭に「H」の文字を表示しているものは、機器の製造番号を表わします。機器の製造番号は、機器の銘板に刻印されており、本パーツカタログでは「号機」と区別するために「H」の文字を付けています。

先頭に「F」の文字を表示しているものは、フロントアタッチメントの「フロントNO.」を表わします。「フロントNo.」は、フロントアタッチメントの銘板に刻印されており、本パーツカタログでは「号機」と区別するために「F」の文字を付けています。

互換性 : 部品番号欄に記載している部品と代替部品欄に記載している部品との間で、互換性の生じる条件を示します。各記号の意味は次の通りです。

I : その部品の代わりに、使用できる部品の部品番号と数量を、代替部品欄に示します。

但し、代替部品欄に示す部品の代わりに、その部品を使用することはできません。

P : その部品は使用禁止になっています。代替部品欄に示す部品を使用してください。

T : 組合せで互換性があります。その部品の代わりに、代替部品欄に示す何点かの部品と組で使用してください。

Y : その部品と代替部品欄に示す部品は、無条件に互換性があることを示します。

代替部品 : 互換性欄の記号に対応して、代替に使用する部品の部品番号と数量を示します。

《注記》 : 部品をご注文の際、互換性欄に I, P, T, Y と記載されている場合、自動的に代替部品欄に示されている部品が供給されることがあります。

FOREWORD

- © This parts catalog shows the precision parts of EX120-2 Hydraulic Excavator. The numerical parts No. index is provided at the end of this parts catalog. In the parts index, a part No. with "*" mark shows a newly added part on the parts catalog.
- © This parts catalog contains the most recent information available at the time of printing, and the contents of the list are based on information in effect at that time and are subject to change without notice.
- © The references in the parts catalog of "LEFT", "RIGHT", "FRONT" and "REAR" are identified as follows.
The driver's seat is positioned "LEFT" side, and the opposite side is "RIGHT".
The front-end attachments is at the "FRONT". The counterweight is attached at the "REAR".
For the undercarriage, the travel motor is at the "REAR", and the opposite is "FRONT".

1. HOW TO ORDER PARTS

When ordering parts, Please specify the following items as shown in the following example.

	(EXAMPLE)	
(1) Model of Machine	(EX120-2)	} Shown on NAME-PLATE provided on MAIN FRAME on the lower right side of CAB
(2) Machine Serial No.	(12N-30001)	
(3) Part No.	(A810165)	} Ordering Parts
(4) Part Name	(O-RING)	
(5) Q'ty	(2)	Ordering Q'ty
(6) Purchaser's Name and Address		

2. HOW TO USE THIS PARTS CATALOG

- ITEM Item No. shows the reference No. on the machine illustration.
- PART NO. Part No. consists of a letter of the alphabet and numerals, or numerals only.
- PART NAME Components of an assembly part are shown with "." marks and are shown on the line, or lines, below the assembly part. Also, if the component with "." mark consists of further components part, these further components are shown by the marks "...".

- Q' TY** Q'ty shows the quantity used for a particular single hydraulic unit, however quantity of components shows the quantity for one assembly part.
- SERVICE CODE** Abbreviations in the column of service code have their own meaning as shown below.
- W: The part with this abbreviation shows that the part requires some work on it before installing in the machine.
 - D: The part with this abbreviation is a component of an assembly and is not available independently. The assembly part containing this part should be ordered.
 - K: This means that the part is contained in the service parts kit.
 - R: The part with this abbreviation shows that the quantity of the part is changed depending upon the machine, such as an adjusting shim etcetera.
 - S: This part is specially provided as a service part, which was not provided in the machine before from shipping the factory.
 - OP: Optional parts
 - OS: Over-sized parts
 - US: Under-sized parts
- (NOTE: Part with abbreviation "OS" or "US" is described on the line below the standard-sized part.)
- #: The part with this mark is newly added on that page of the equipment.
- SERIAL No.** Applicable machine serial No. for the part is shown in this column. Further, above this column, the applicable serial No. is shown for all parts described on that page.
- Take this serial No. if the part is not mentioned its own applicable serial No. Take the serial No. which includes both of for the part and for all parts described on the page if the part is mentioned its own applicable serial No. If the abbreviation "D" is described as headed letter instead of the serial No. it means the produced date of the machine in which the parts are used.
- (EXAMPLE: D90/10-.....produced on October 1990 and after)
- If the abbreviation "H" is described as headed letter, it means the serial No. of equipment such as PUMP, MOTOR, CONTROL VALVE and etcetera.
- If the abbreviation "F" is described as headed letter, it means the Front No. of front-end attachments such as BUCKET, BOOM, ARM and etcetera.
- ICA** ICA shows the interchangeability between the original and the improved parts. Abbreviations used in this column are as follows.
- I: Part No. in the column of 'Replaceable part' can be used instead of this part but not vice versa.
 - P: This must not be used for the machine. The part No. in the column 'Replaceable part' should be used instead.
 - T: Parts Nos. those in the column of 'Replaceable part' can be used as an assembly instead of this part.
 - Y: This part and the part in the column of 'Replaceable part' are interchangeable with each other.

•REPLACEABLE PART

Interchangeable parts Nos. and their required quantity are shown in this column.

NOTE: If interchangeable improved parts are provided for the parts which you may order, the improved parts classified as "I", "P", "T" or "Y" may be supplied.

目次
CONTENTS

PB-201
PB-A44

部品番号 PART NO.	コード CODE	部品名	PART NAME	適用号機 SERIAL NO.	頁 PAGE
ポンプ		PUMP			
9101530	-----	ポンプ; シングル	PUMP; SINGLE		---
++++++	9101530B1	・ポンプ; シングル (1/2)	・PUMP; SINGLE (1/2)		001
++++++	9101530B2	・ポンプ; シングル (2/2)	・PUMP; SINGLE (2/2)		003
4255303	0408200	・・ポンプ; ギヤ	・・PUMP; GEAR		005
++++++	9101533	・・センサ; アングル	・・SENSOR; ANGLE		007
++++++	9128251	・・センサ; アングル	・・SENSOR; ANGLE	SERVICE PARTS	009
モータ; オイル		MOTOR; OIL			
9096731	9096731	モータ; オイル (走行)	MOTOR; OIL (TRAVEL)	30001-H03196	011
9099928	-----	・バルブ; ブレーキ	・VALVE; BRAKE		---
++++++	9099928B1	・・バルブ; ブレーキ (1/2)	・・VALVE; BRAKE (1/2)		013
++++++	9099928A2	・・バルブ; ブレーキ (2/2)	・・VALVE; BRAKE (2/2)		015
9102618	9102618	・・・バルブ; リリーフ	・・・VALVE; RELIEF		017
9116375	9116375	モータ; オイル (走行)	MOTOR; OIL (TRAVEL)	H03197-H05971	019
9116373	-----	・バルブ; ブレーキ	・VALVE; BRAKE		---
++++++	9116373A1	・・バルブ; ブレーキ (1/2)	・・VALVE; BRAKE (1/2)		021
++++++	9116373A2	・・バルブ; ブレーキ (2/2)	・・VALVE; BRAKE (2/2)		023
9114687	9114687	・・・バルブ; リリーフ	・・・VALVE; RELIEF		025
9116379	9116379	モータ; オイル (走行)	MOTOR; OIL (TRAVEL)	H05972-H06584	027
9116377	-----	・バルブ; ブレーキ	・VALVE; BRAKE		---
++++++	9116377A1	・・バルブ; ブレーキ (1/2)	・・VALVE; BRAKE (1/2)		029
++++++	9116377A2	・・バルブ; ブレーキ (2/2)	・・VALVE; BRAKE (2/2)		031
9115734	9115734	・・・バルブ; リリーフ	・・・VALVE; RELIEF		033
9116383	9116383A	モータ; オイル (走行)	MOTOR; OIL (TRAVEL)	H06585-	035
9116381	-----	・バルブ; ブレーキ	・VALVE; BRAKE		---
++++++	9116381A1	・・バルブ; ブレーキ (1/2)	・・VALVE; BRAKE (1/2)		037
++++++	9116381A2	・・バルブ; ブレーキ (2/2)	・・VALVE; BRAKE (2/2)		039
9115734	9115734	・・・バルブ; リリーフ	・・・VALVE; RELIEF		(033)
4241171	0408700	モータ; オイル (旋回)	MOTOR; OIL (SWING)	30001-38115, 38120-38125 38128-38130, 38140-38145	041
4334356	0614700	モータ; オイル (旋回)	MOTOR; OIL (SWING)	38116-38119, 38126-38127 38131-38139, 38146-	043
4286401	0407800	・ロータリグループ	・ROTARY GROUP	30001-38115, 38120-38125 38128-38130, 38140-38145	045
4334357	0614800	・ロータリグループ	・ROTARY GROUP	38116-38119, 38126-38127 38131-38139, 38146-	047
4286402	0407900	・シャフト部	・SHAFT PART		049

部品番号 PART NO.	コード CODE	部 品 名	PART NAME	適用号機 SERIAL NO.	頁 PAGE
4286403	0408000	・カバー部	・COVER PART	30001-D92/04	051
4327557	0605300	・カバー部	・COVER PART	D92/05-	053
4286404	0408100	・・バルブ; リリーフ	・・VALVE;RELIEF	30001-D92/12	055
4328226	0605400	・・バルブ; リリーフ	・・VALVE;RELIEF	D93/01-	057
バルブ		VALVE			
4254646	-----	バルブ; コントロール	VALVE;CONTROL	30001-32925, 32927-32934 32936-32937, 32939-32942 32945-32988,	---
+++++++	0411800	・バルブ; コントロール (1/8)	・VALVE;CONTROL (1/8)		059
+++++++	0411900	・バルブ; コントロール (2/8)	・VALVE;CONTROL (2/8)		061
+++++++	0412000	・バルブ; コントロール (3/8)	・VALVE;CONTROL (3/8)		063
+++++++	0412100	・バルブ; コントロール (4/8)	・VALVE;CONTROL (4/8)		065
+++++++	0412200	・バルブ; コントロール (5/8)	・VALVE;CONTROL (5/8)		067
+++++++	0412300	・バルブ; コントロール (6/8)	・VALVE;CONTROL (6/8)		069
+++++++	0412400	・バルブ; コントロール (7/8)	・VALVE;CONTROL (7/8)		071
+++++++	0412500	・バルブ; コントロール (8/8)	・VALVE;CONTROL (8/8)		073
4304718	-----	バルブ; コントロール	VALVE;CONTROL	32926, 32935, 32938, 32943, 32944, 32989-	---
+++++++	0463900	・バルブ; コントロール (1/8)	・VALVE;CONTROL (1/8)		075
+++++++	0464000	・バルブ; コントロール (2/8)	・VALVE;CONTROL (2/8)		077
+++++++	0464100	・バルブ; コントロール (3/8)	・VALVE;CONTROL (3/8)		079
+++++++	0464200	・バルブ; コントロール (4/8)	・VALVE;CONTROL (4/8)		081
+++++++	0464300	・バルブ; コントロール (5/8)	・VALVE;CONTROL (5/8)		083
+++++++	0464400	・バルブ; コントロール (6/8)	・VALVE;CONTROL (6/8)		085
+++++++	0464500	・バルブ; コントロール (7/8)	・VALVE;CONTROL (7/8)		087
+++++++	0464600	・バルブ; コントロール (8/8)	・VALVE;CONTROL (8/8)		089
9101511	9101511A	バルブ; パイロット	VALVE;PILOT		091
9101512	9101512A	バルブ; パイロット	VALVE;PILOT		093
9072923	9072923D	バルブ; パイロット	VALVE;PILOT		095
4276904	0408400B	バルブ; ソレノイド	VALVE;SOLENOID		097
4254610	0408300	バルブ; フロウコントロール	VALVE;FC	30001-32925, 32927-32934 32936-32937, 32939-32942 32945-32988,	099
4304666	0635700	バルブ; フロウコントロール	VALVE;FC	32926, 32935, 32938, 32943, 32944, 32989-	101
4254613	0408500	バルブ; シャトル	VALVE;SHUTTLE		103
4254612	0408600	バルブ; シャトル	VALVE;SHUTTLE		105
4254611	0396600A	バルブ; ロック	VALVE;LOCK		107
4263925	0498500	バルブ; ホールディング	VALVE;HOLDING	30001-D93/09	109

Hitachi Ex120 2 Equipment Components Parts

Full download: <http://manualplace.com/download/hitachi-ex120-2-equipment-components-parts/>

部品番号 PART NO.	コード CODE	部 品 名	PART NAME	適用号機 SERIAL NO.	頁 PAGE
4324747	0499100	・バルブ ; リリーフ	・VALVE;RELIEF	30001-D93/09	111
4311300	0615800	バルブ ; ホールディング	VALVE;HOLDING	D93/10-	113
4263926	0498600	バルブ ; ホールディング	VALVE;HOLDING	30001-D93/09	115
4324747	0499100	・バルブ ; リリーフ	・VALVE;RELIEF	30001-D93/09	(111)
4311301	0620400	バルブ ; ホールディング	VALVE;HOLDING	D93/10-	117
4263927	0498700	バルブ ; ホールディング	VALVE;HOLDING	30001-D93/09	119
4324747	0499100	・バルブ ; リリーフ	VALVE;RELIEF	30001-D93/09	(111)
4311302	0620500	バルブ ; ホールディング	VALVE;HOLDING	D93/10-	121
4288148	0437400	バルブ	VALVE		123
シリンダ			CYLINDER		
4257642	0408800A	シリンダ ; ブーム (右)	CYL.;BOOM (R)		125
4257643	0408900A	シリンダ ; ブーム (左)	CYL.;BOOM (L)		127
4257644	0409000A	シリンダ ; アーム	CYL.;ARM		129
4269538	0409100	シリンダ ; バケツ	CYL.;BUCKET		131
4288744	0496600	シリンダ ; クラムシェル	CYL.;CLAMSHELL		133
その他			E T C .		
9101532	9101532A	センサ ; DP	SENSOR;DP		135
索 引			P A R T S I N D E X		
					137