



Owner's Installation Guide for the
***Paxton Automotive
Novi 2000 Supercharger***
for the
1985 5.0L Ford Mustang

Paxton Automotive . 1300 Beacon Place . Oxnard CA 93033
805 604-1336 . FAX (805) 604-1337

FOREWORD

This manual provides information on the installation, maintenance and service of the Paxton supercharger kit expressly designed for the 1985 5.0 Ford Mustang Contact Paxton Automotive Corporation for any additional information regarding this kit and any of these modifications at (805) 604-1336 8:00am-4:30pm PST.

An understanding of the information contained herein will help novices, as well as experienced technicians, to correctly install and receive the greatest possible benefit from their Paxton supercharger. When reference is made in this manual to a brand name, number, specific tool or technique, an equivalent product may be used in place of the item mentioned. All information, illustrations and specifications contained herein are based on the latest product information available at the time of this publication. All rights reserved to make changes at any time without notice.

© **2006 PAXTON AUTOMOTIVE**

All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, or translated into another language in any form, by any means without written permission of Paxton Automotive.

TABLE OF CONTENTS

FOREWORD *ii*

TABLE OF CONTENTS *iii*

IMPORTANT NOTE *iv*

TOOL & SUPPLY REQUIREMENTS *v*

PARTS LIST (1985 Ford 5.0L Mustang) *vii*

1. PREPARATION AND REMOVAL **1-1**

1.1 PREPARATION AND REMOVAL 1-1

2. SUPERCHARGER OIL DRAIN AND OIL FEED ASSEMBLY **2-1**

2.1 SUPERCHARGER OIL FEED ASSEMBLY 2-1

2.2 SUPERCHARGER OIL DRAIN ASSEMBLY 2-1

3. SUPERCHARGER BRACKET ASSEMBLY AND MOUNTING **3-1**

3.1 SUPERCHARGER BRACKET ASSEMBLY 3-1

3.2 CRANK PULLEY ASSEMBLY 3-1

4. FUEL PUMP REPLACEMENT **4-1**

4.1 FUEL PUMP REPLACEMENT 4-1

5. CARBURETOR ENCLOSURE INSTALLATION **5-1**

5.1 CARBURETOR ENCLOSURE INSTALLATION 5-1

5.2 THROTTLE CABLE INSTALLATION 5-3

6. AIR INLET INSTALLATION **6-1**

6.1 AIR INLET INSTALLATION (On Passenger's Side) 6-1

7. SUPERCHARGER DISCHARGE **7-1**

7.1 SUPERCHARGER DISCHARGE 7-1

8. FINAL CHECK OUT AND START UP **8-1**

8.1 INSPECT THE FOLLOWING 8-1

8.2 PERFORM THE FOLLOWING 8-1

8.3 CHECK FOR THE FOLLOWING 8-1

APPENDIX **A-1**

1016611 Asy, Mounting Bracket 5.0 Novi 2000 A-2

1016710 Asy, Crank Pulley 86-93 5.0 Novi 2000 A-3