

There are no translations available.

Audi Specific Trouble Codes

Code	Description	
P1101	O2 Sensor Circ.,Bank1	Sensor1 Voltage too Low/Air Leak
P1102	O2 Sensor Heating Circ.,Bank1	Sensor1 Short to B+
P1103	O2 Sensor Heating Circ.,Bank1	Sensor1 Output too Low
P1104	Bank1-Sensor2	Voltage too Low/Air Leak
P1105	O2 Sensor Heating Circ.,Bank1	Sensor2 Short to B+
P1106	O2 Sensor Circ.,Bank2	Sensor1 Voltage too Low/Air Leak
P1107	O2 Sensor Heating Circ.,Bank2	Sensor1 Short to B+
P1108	O2 Sensor Heating Circ.,Bank2	Sensor1 Output too Low
P1109	O2 Sensor Circ.,Bank2	Sensor2 Voltage too Low/Air Leak
P1110	O2 Sensor Heating Circ.,Bank2	Sensor2 Short to B+
P1111	O2 Control (Bank 1) System	too lean
P1112	O2 Control (Bank 1) System	too rich
P1113	Bank1-Sensor1 Internal	Resistance too High
P1114	Bank1-Sensor2 Internal	Resistant too High
P1115	O2 Sensor Heater Circ.,Bank1	Sensor1 Short to Ground
P1116	O2 Sensor Heater Circ.,Bank1	Sensor1 Open
P1117	O2 Sensor Heater Circ.,Bank1	Sensor2 Short to Ground
P1118	O2 Sensor Heater Circ.,Bank1	Sensor2 Open
P1119	O2 Sensor Heater Circ.,Bank2	Sensor1 Short to Ground
P1120	O2 Sensor Heater Circ.,Bank2	Sensor1 Open
P1121	O2 Sensor Heater Circ.,Bank2	Sensor2 Short to Ground
P1122	O2 Sensor Heater Circ.,Bank2	Sensor2 Open
P1123	Long Term Fuel Trim Add.Air.,Bank1	System too Rich
P1124	Long Term Fuel Trim Add.Air.,Bank1	System too Lean
P1125	Long Term Fuel Trim Add.Air.,Bank2	System too Rich
P1126	Long Term Fuel Trim Add.Air.,Bank2	System too Lean
P1127	Long Term Fuel Trim mult.,Bank1	System too Rich
P1128	Long Term Fuel Trim mult.,Bank1	System too Lean
P1129	Long Term Fuel Trim mult.,Bank2	System too Rich
P1130	Long Term Fuel Trim mult.,Bank2	System too Lean
P1131	Bank2-Sensor1 Internal	Resistance too High
P1132	O2 Sensor Heating Circ.,Bank1+2	Sensor1 Short to B+
P1133	O2 Sensor Heating Circ.,Bank1+2	Sensor1 Electrical Malfunction
P1134	O2 Sensor Heating Circ.,Bank1+2	Sensor2 Short to B+
P1135	O2 Sensor Heating Circ.,Bank1+2	Sensor2 Electrical Malfunction
P1136	Long Term Fuel Trim Add.Fuel,Bank1	System too Lean
P1137	Long Term Fuel Trim Add.Fuel,Bank1	System too Rich
P1138	Long Term Fuel Trim Add.Fuel,Bank2	System too Lean
P1139	Long Term Fuel Trim Add.Fuel,Bank2	System too Rich
P1140	Bank2-Sensor2 Internal	Resistance too High
P1141	Load Calculation	Cross Check Range/Performance
P1142	Load Calculation	Cross Check Lower Limit Exceeded