


REVISION RECORD LOG

REVISION NO.	DATE INSERTED
1.	
2.	
3.	
4.	
5.	

1845 & 1845S UNI-LOADERS

Parts Catalog F1277

NOTE: Discard Parts Catalog E1277.



J I Case
A Tenneco Company



Issued February, 1982

Printed in U.S.A.

790258B

1845 CASE UNI-LOADER SKID STEER LOA...
Figure Listing
001 1845 & 1845S UNI-LOADERS
004 SERIAL NUMBER LOCATION AND PROD...
010 ENGINE MOUNTING, FLYWHEEL GUARD...
012 RADIATOR AND HOSES, USED BEFORE...
014 RADIATOR AND HOSES, USED ON TRA...
016 RADIATOR AND HOSES, USED ON TRA...
018 MUFFLER AND EXHAUST SYSTEM
020 AIR CLEANER AND PRE-CLEANER MOU...
022 AIR CLEANER AND PRE-CLEANER MOU...
024 PRE-CLEANERS AND AIR CLEANER
026 COLD START AID
028 MANIFOLDS, (159) SPARK IGNITION...
030 TIMING GEAR COVER, (159) SPARK ...
032 OIL FILTER, (159) SPARK IGNITIO...
034 OIL FILTER, (159) SPARK IGNITIO...
036 CYLINDER HEAD AND COVER, (159) ...
038 VALVE MECHANISM, (159) SPARK IG...
040 CAMSHAFT, (159) SPARK IGNITION ...
042 CYLINDER BLOCK, (159) SPARK IGN...
044 CRANKSHAFT AND FLYWHEEL, (159) ...
046 PISTONS, (159) SPARK IGNITION E...
048 ENGINE GASKET KITS, (159) SPARK...
050 A135849 CARBURETOR, (159) SPARK...
052 GOVERNOR AND LINKAGE, (159) SPA...
054 FUEL LINES - GASOLINE MODELS
056 ENGINE CONTROLS - GASOLINE MODE...
058 WATER PUMP AND THERMOSTAT, (188...
060 INTAKE MANIFOLD, 188 DIESEL ENG...
062 EXHAUST MANIFOLD, 188 DIESEL EN...
064 CYLINDER HEAD AND COVER, (188) ...
066 VALVE MECHANISM, (188) DIESEL E...
068 OIL FILTER, (188) DIESEL ENGINE...
070 OIL FILTER, (188) DIESEL ENGINE...
072 TIMING GEAR COVER, (188) DIESEL...
074 CYLINDER BLOCK, (188) DIESEL EN...
076 CYLINDER BLOCK, (188) DIESEL EN...
078 PISTONS, (188) DIESEL ENGINE, P...
080 PISTONS, (188) DIESEL ENGINE, E...
082 CRANKSHAFT AND FLYWHEEL, (188) ...
084 ENGINE GASKET KITS, (188) DIESE...
086 FUEL LINES AND HAND PRIMER - DI...
088 ENGINE CONTROLS - DIESEL MODELS...
090 FUEL INJECTION AND FILTER SYSTE...
092 FUEL FILTER, (188) DIESEL ENGIN...
094 A135874 INJECTION PUMP, (188) D...
096 INJECTION PUMP DRIVE, (188) DIE...
098 INJECTION NOZZLES, (188) DIESEL...
100 A51910 STARTER, (159) SPARK IGN...
102 R39341 STARTER
104 A39839 STARTER, (188) DIESEL EN...
106 A39839 STARTER, (188) DIESEL EN...
108 R29870 STARTER, (188) DIESEL EN...
110 R29870 STARTER, (188) DIESEL EN...
112 G44891 SOLENOID, (188) DIESEL E...

114 D55127 ALTERNATOR, (159) SPARK ...
116 A38815 ALTERNATOR, (159) SPARK ...
118 D77810 ALTERNATOR, (188) DIESEL...
120 L102693 ALTERNATOR, (USES METRI...
122 A135714 ALTERNATOR, (159) SPARK...
124 STANDARD IGNITION SYSTEM, (159)...
126 INDUCTION DISCHARGE SYSTEM, (15...
128 A38970 DISTRIBUTOR, (159) SPARK...
130 A137578 DISTRIBUTOR, (159) SPAR...
132 ELECTRICAL SYSTEM, REAR HARNESS...
134 ELECTRICAL SYSTEM, REAR HARNESS...
136 ELECTRICAL SYSTEM, REAR HARNESS...
138 ELECTRICAL SYSTEM, FRONT HARNES...
140 INSTRUMENT PANEL, GAUGES AND SW...
142 LIGHTS
144 HORN
146 WINDSHIELD WIPER
148 DRIVE HYDRAULIC CIRCUITS
152 TANDEM PUMP ASSEMBLY AND MOUNTI...
154 D82186 AND D71203 DUAL PUMP
156 D66341 VARIABLE DISPLACEMENT PU...
160 D75924 VARIABLE DISPLACEMENT PU...
164 D66340 VARIABLE DISPLACEMENT PU...
168 D75925 VARIABLE DISPLACEMENT PU...
172 HYDRAULIC COOLING CIRCUIT
174 D65391 HYDROSTATIC MOTOR, CESSN...
176 D74973 HYDROSTATIC MOTOR, CESSN...
178 D78121 GEAR HEAD
180 D83254 GEAR HEAD
182 CONTROLS - FORWARD AND REVERSE,...
184 CONTROLS - FORWARD AND REVERSE,...
186 DRIVE CHAIN AND GEARS
188 AXLES AND WHEELS
190 PARKING LATCH, LATE PRODUCTION ...
192 BASIC EQUIPMENT HYDRAULIC CIRCU...
194 LOADER DUMP HYDRAULIC CIRCUIT
196 LOADER LIFT HYDRAULIC CIRCUIT, ...
198 AUXILIARY HYDRAULIC CIRCUITS, B...
200 AUXILIARY HYDRAULIC CIRCUITS, B...
202 AUXILIARY HYDRAULIC CIRCUITS, F...
204 AUXILIARY HYDRAULIC CIRCUITS, L...
206 AUXILIARY HYDRAULIC CIRCUITS, L...
208 TWO SPOOL VALVES, CESSNA NO. 30...
210 D64493 RELIEF VALVE
212 D77897 RELIEF VALVE
214 D64076 OIL FILTER, D69097 OIL F...
216 G34981 SELECTOR VALVE
216(A) D64670 AUXILIARY CONTROL VAL...
218 G100295 AND G34917 LOADER LIFT ...
220 G34926 BUCKET DUMP CYLINDER
222 G33748 4-IN-1 BUCKET CYLINDER
224 G33744 SCARIFIER CYLINDER / G33...
226 D71057 GRAPPLE CYLINDER
228 CONTROLS - LOADER LIFT AND DUMP
230 AUXILIARY CONTROLS AND VALVE MO...
232 BUCKETS, DIRT BUCKET, UTILITY B...


234 BUCKETS, FERTILIZER AND GRAIN B...
236 4-IN-1 LOADER BUCKET
238 PALLET FORK AND BRICK GUARD, D1...
240 PALLET FORK AND BRICK GUARD, D1...
242 MANURE FORK AND GRAPPLE
244 LOADER LIFT ARM, USED ON MODELS...
246 ATTACHMENT BARS
248 CENTRALIZED LUBRICATION SYSTEM
250 D71323 VACUUM PUMP AND RELATED ...
252 SCARIFIER, IDENTIFICATION PLATE...
254 COUNTRWEIGHTS & DRAWBAR, SWING ...
256 NOISE CONTROL PARTS
258 SEAT MOUNTING PARTS AND SEAT BE...
260 OPERATORS SEAT, DELUXE OPERATOR...
262 MAIN FRAME
264 GUARDS, FLOOR MATS, AND BELLY P...
266 ROLL-OVER PROTECTION STRUCTURE,...
268 ROLL-OVER PROTECTION STRUCTURE,...
272 FRONT AND SIDE SCREENS FOR FORE...
274 REAR SCREENS FOR FORESTRY MODEL...
276 ROPS ENCLOSURE, FRONT DOOR AND ...
278 ROPS ENCLOSURE, REAR WINDOW AND...
280 DECALS - GASOLINE MODELS, USED ...
282 DECALS - GASOLINE MODELS, USED ...
284 DECALS - DIESEL MODELS

4

**MODEL 1845 AND 1845S UNI-LOADERS
SERIAL NUMBER LOCATION
AND
PRODUCT IDENTIFICATION NUMBER**

**UNI-LOADER SERIAL NO. AND
PRODUCT IDENTIFICATION NO.
LOCATED ON L.H. SIDE OF
HEEL PLATE**

**ROPS SERIAL NO. LOCATED INSIDE
OF UPPER LEFT HAND CORNER**



**4 in 1 BUCKET SERIAL NO.
LOCATED ON UPPER
CENTER OF BUCKET**

**DIESEL & GASOLINE ENGINE
SERIAL NO. LOCATED LOWER
L.H. SIDE OF ENGINE**

**BUCKET SERIAL NO. LOCATED ON
BUCKET BACK SPILL GUARD**

750046 B