

Reprinted







You are now the owner of a POCLAIN.

All the components of this unit have been thoroughly checked and tested to meet the standards of quality you are entitled to expect in this field.

Your machine will remain a highly reliable tool provided you carefully observe the operating and servicing recommendations outlined in this manual, which covers the following items:

- Features and specifications of the machine
- Operation
- Basic safety rules
- Maintenance
- Quick repair instructions on : Hydraulic, Mechanical and Electrical Systems
- Attachments

Our Agents (Dealers, Subsidiary Companies, Distributors) are at your disposal to assist you in maintaining your machine in perfect working condition. Our personnel will carry out THREE MACHINE SERVICE INSPECTIONS:

- Excavator Delivery Service Inspection
- 150 Hour Service Inspection
- End of Warranty Service Inspection

These three inspections are COMPULSORY and FREE OF CHARGE.

After the expiry of the WARRANTY PERIOD, our AFTER SALES SERVICE personnel will remain at your disposal for any assistance and/or supply of "ORIGINAL SPARE PARTS", the interchangeability and quality of which are guaranteed.

Our International Technical Training Centre organises training courses for future operators:

- rapid course in machine operation
- practical knowledge of maintenance methods
- attachment changeover procedure.

Wherever you may be, our Representative (Subsidiary Company, Dealer. Distributor) is at your disposal for any information you may require.

This manual has been expressly prepared for the benefit of operators and mechanics. Consult it frequently and keep it in the special compartment provided in the machine cab.

$\langle A \rangle$	SPECIFICATIONS
$\langle B \rangle$	OPERATION
⟨¢⟩	SAFETY
(0)	MAINTENANCE
⟨ E⟩	HYDRAULIC SYSTEM47
⟨ F⟩	MECHANICAL SYSTEM49
(G)	ATTACHMENTS53
⟨Ĥ⟩	TOOLS AND SPARE PARTS55
(I)	LOGGING ATTACHMENT SUPPLEMENT57