



THIS SAFETY ALERT SYMBOL INDICATES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL, CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF PERSONAL INJURY OR DEATH.

If Safety Decals on this machine use the words Danger, Warning or Caution, which are defined as follows:

- DANGER: Indicates an immediate hazardous situation which if not avoided. will result in death or serious injury. The color associated with Danger is RED.
- **WARNING:** Indicates an potentially hazardous situation which if not avoided, will result in serious injury. The color associated with Warning is ORANGE.
- CAUTION: Indicates an potentially hazardous situation which if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices. The color associated with Caution is YELLOW.

If Safety Decals on this machine are ISO two panel Pictorial, decals are defined as follows:

- The first panel indicates the nature of the hazard.
- The second panel indicates the appropriate avoidance of the hazard.
- Background color is YELLOW.
- Prohibition symbols such as





(STOP) if used, are RED.



IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH. BEFORE USING THIS MACHINE, MAKE CERTAIN THAT EVERY **OPERATOR:**

- Is instructed in safe and proper use of the machine.
- Reads and understands the Manual(s) pertaining to the machine.
- Reads and understands ALL Safety Decals on the machine.
- Clears the area of other persons.
- Learns and practices safe use of machine controls in a safe, clear area before operating this machine on a job site.

It is your responsibility to observe pertinent laws and regulations and follow Case Corporation instructions on machine operation and maintenance.

© 2001 Case Corporation

Bur 0-00000

March, 1995 (Revised October, 1997)

CASE and IH are registered trade marks of Case Corporation

AFTER DELIVERY CHECKUP

(Owner's Name)	(Date Checkup Performed)
(Owner's Address)	
(Dealership)	(City) (State)
Tractor has been operated hours.	(Tractor Model Number) (Serial Number)
	(Fork Lift Serial Number)
TRA	ACTOR
 □ Check traction clutch. □ Check brakes. □ Check tire pressure. □ Tighten cylinder head and adjust tappets. □ Check Fuel Injection Pump timing. (Diesel Models) □ Check Fuel Filtering system. □ Check distributor timing. (Gasoline Models) □ Check spark plugs and distributor point gap. (Gasoline Models) □ Check full governed, no-load engine speed. □ Tighten all bolts (including 	 □ Check cooling system. □ Crankcase oil (Change oil and filter if necessary). □ Oil level in transmission and power steering system. □ Lubricate all pressure fittings and check oil levels. □ Check air cleaner. □ Check all breathers. □ Check steering, bearing adjustment and front wheel toe-in. □ Battery, starter, generator and
those on wheel rim).	
Check main relief valve pres sure on Fork Lift Control Valve. Lubricate all pressure fitting and check hydraulic oil	and fittings for leaks, chaf- ing, and twisting. Solution Check Fork Lift mounting bolts. Check the torque on tie rod
	bolts. Fully concerning his experience with the ns concerning maintenance or operation
that are not clear to $\ensuremath{\operatorname{him}}$. Chec	skup.
Cnec	Performed by
Signo	ed
Original - Dealer	Dealer
Duplicate-Leave in Operator's Manual for Customer Sign	nedCustomer

This is the cut pages sample. Download all 40 page(s) at: ManualPlace.com				

Case Forklift 530ck Operators Manual

Full download: http://manualplace.com/download/case-forklift-530ck-operators-manual/