



# Parts Manual

---

## TH220B Telehandler

---

S/N TBF00100 thru TBF00512



# Product and Dealer Information

Note: For product identification plate locations, see the section "Product Identification Information" in the Operation and Maintenance Manual.

Delivery Date: \_\_\_\_\_

## Product Information

Model: \_\_\_\_\_

Product Identification Number: \_\_\_\_\_

Engine Serial Number: \_\_\_\_\_

Transmission Serial Number: \_\_\_\_\_

Generator Serial Number: \_\_\_\_\_

Attachment Serial Numbers: \_\_\_\_\_

Attachment Information: \_\_\_\_\_

Customer Equipment Number: \_\_\_\_\_

Dealer Equipment Number: \_\_\_\_\_

## Dealer Information

Name: \_\_\_\_\_ Branch: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Dealer Contact

Phone Number

Hours

Sales: \_\_\_\_\_

Parts: \_\_\_\_\_

Service: \_\_\_\_\_



# EFFECTIVITY PAGE

July 14, 2006 - A - Original issue of manual.

February 2, 2007- B - Revised Manual, added Tier III engine information (Section C).

July 11, 2008 - C - Revised Manual

October 27, 2010 - D - Revised ending Serial Number to TBF00512.

# EFFECTIVITY PAGE

**S/N TBF00224 TO TBF00512**  
**TIER III ENGINE INFORMATION LOCATED IN SECTION C**

**This Page Intentionally Left Blank**



# TABLE OF CONTENTS

Name	Page	Name	Page
		FAN AR-SUCTION .....	70
		FAN GP-SUCTION .....	71
		LINES GP-COOLANT .....	72
		PUMP GP-WATER .....	78
		RADIATOR & MOUNTING GP .....	80
		RADIATOR GP .....	82
		RECOVERY GP-COOLANT .....	85
<b>MAINTENANCE PARTS</b> .....	A10		
<b>INDEX</b> .....	A13	<b>AIR INLET AND EXHAUST SYSTEM</b> .....	87
<b>MACHINE ARRANGEMENT</b> .....	1	AIR CLEANER GP .....	87
BOOM & CHASSIS AR .....	1	ELBOW GP-AIR INLET .....	89
CHASSIS AR .....	2	INDICATOR GP-AIR FILTER CHANGE .....	90
COMMON AR .....	2	LINES GP-AIR .....	91
CONVERSION AR-MACHINE .....	2	MUFFLER GP .....	94
		SHIELD GP-EXHAUST .....	95
<b>ENGINE ARRANGEMENT</b> .....	4	TURBOCHARGER GP .....	96
ENGINE & TRANSMISSION AR .....	4	<b>FUEL SYSTEM</b> .....	100
ENGINE AR-PRIMARY .....	9	LINES GP-FUEL .....	100
INSTALLATION AR-ENGINE .....	11	PUMP GP-FUEL INJECTION .....	102
		PUMP GP-FUEL TRANSFER & FILTER .....	114
<b>BASIC ENGINE</b> .....	13	TANK & MTG GP-FUEL .....	116
BELT GP-SERPENTINE .....	13	TANK GP-FUEL .....	119
BELT TENSIONER GP .....	15	<b>ELECTRICAL AND STARTING SYSTEM</b> .....	121
CAMSHAFT GP .....	16	ALTERNATOR GP-CHARGING .....	121
COVER GP-FRONT HOUSING .....	17	BATTERY & WIRING GP .....	124
COVER GP-VALVE MECHANISM .....	23	CONNECTION GP-ELECTRICAL .....	129
CRANKSHAFT GP .....	25	CONTROL & MTG GP-MACHINE .....	130
CYLINDER BLOCK GP .....	27	ELECTRONICS GP-MACHINE .....	131
CYLINDER HEAD GP .....	30	GLOW PLUG GP .....	133
DRAIN GP-ENGINE OIL .....	32	HEATER GP-JACKET WATER .....	134
DRIVE GP-FAN .....	34	INDICATOR GP-LOAD .....	138
FASTENER GP-PULLEY .....	36	INSTALLATION AR-SECURITY .....	139
FLYWHEEL GP .....	37	INSTALLATION GP-SECURITY .....	140
HOUSING GP-FLYWHEEL .....	39	LAMP GP-FLOOD .....	144
HOUSING GP-FRONT .....	42	LAMP GP-HEAD .....	145
LIFTING GP-ENGINE .....	44	LAMP GP-HEAD & SIGNAL .....	147
MOUNTING GP-ENGINE .....	45	LAMP GP-REGISTRATION PLATE .....	151
MOUNTING GP-ENGINE & TMSN .....	46	LAMP GP-STOP & TAIL .....	154
MOUNTING GP-FAN DRIVE .....	48	LAMP GP-WARNING BEACON .....	156
PAN GP-OIL .....	51	LIGHTING GP-FLOOD .....	157
PISTON & ROD GP .....	55	LIGHTING GP-FRONT .....	161
PLUG GP-ENGINE .....	56	LIGHTING GP-ROADING .....	163
VALVE MECHANISM GP .....	59	LIGHTING GP-SIGNAL .....	165
<b>LUBRICATION SYSTEM</b> .....	60	LIGHTING GP-WARNING .....	167
FILTER GP-ENGINE OIL .....	60	MOUNTING GP-LIGHTING .....	169
PUMP GP-ENGINE OIL .....	62	MOUNTING GP-WIRING .....	170
<b>COOLING SYSTEM</b> .....	63	PANEL GP-FUSE .....	171
CONNECTION GP-WATER .....	63	ROADING AR .....	173
COOLER GP-ENGINE OIL .....	65	SENSOR GP-POSITION .....	174
COOLER GP-FLTR BASE & ENG OIL .....	68	SENSOR GP-SPEED .....	175
COOLING AR-HIGH AMBIENT TEMP .....	69	SERVICE GP-MACHINE .....	176
FAN AR-REVERSIBLE .....	69	STARTING MOTOR GP-ELECTRIC .....	178
		SWITCH GP-AUXILIARY .....	179

# TABLE OF CONTENTS


Name	Page	Name	Page
SWITCH GP-DIFFERENTIAL LOCK . . . . .	180	ENCLOSURE GP-ENGINE . . . . .	310
SWITCH GP-DISCONNECT . . . . .	181	FENDER & MOUNTING GP . . . . .	314
SWITCH GP-ROCKER . . . . .	182	FRAME GP . . . . .	315
		FRAME GP-LOADER. . . . .	318
WIRING GP-AIR CONDITIONER . . . . .	186	GUARD GP-BOTTOM . . . . .	319
WIRING GP-AUXILIARY . . . . .	189	GUARD GP-ENGINE . . . . .	320
WIRING GP-BOOM . . . . .	190	HITCH AR . . . . .	324
WIRING GP-CAB . . . . .	196	HITCH GP . . . . .	325
WIRING GP-CHASSIS . . . . .	214	HITCH GP-TOWING . . . . .	331
WIRING GP-COUPLER . . . . .	218	HOOD GP . . . . .	339
WIRING GP-ELECTRONIC CONTROL . . . . .	221	PANEL GP-SOUND SUPPRESSION . . . . .	343
WIRING GP-ENGINE . . . . .	223	PIN GP-HITCH . . . . .	346
WIRING GP-FAN . . . . .	226	REFLECTOR GP . . . . .	347
WIRING GP-TRAILER . . . . .	229	<b>BRAKING SYSTEM . . . . .</b>	<b>350</b>
WIRING GP-TRANSMISSION		CONTROL GP-PARKING BRAKE . . . . .	350
CONTROL . . . . .	230	CONTROL GP-SERVICE BRAKE . . . . .	352
		CYLINDER GP-BRAKE . . . . .	353
<b>POWER TRAIN . . . . .</b>	<b>231</b>	LEVER GP-HAND CONTROL . . . . .	356
AXLE & MOUNTING GP . . . . .	231	LEVER AS . . . . .	357
AXLE AR . . . . .	233	LEVER GP-HAND CONTROL . . . . .	359
AXLE GP-DRIVE & STEERING . . . . .	234	LINES GP-SERVICE BRAKE . . . . .	360
AXLE GP-FRONT . . . . .	240	MOUNTING GP-CABLE . . . . .	363
CLUTCH GP . . . . .	243		
COUNTERSHAFT		<b>STEERING SYSTEM . . . . .</b>	<b>365</b>
GP-TRANSMISSION . . . . .	245	CYLINDER GP-STEERING . . . . .	365
DIFFERENTIAL & BEVEL GEAR GP . . . . .	246	KNOB GP-STEERING . . . . .	366
DIFFERENTIAL GP . . . . .	252	LINES GP-STEERING . . . . .	367
DRIVE GP-FLEXIBLE COUPLING . . . . .	254	STEERING COLUMN GP . . . . .	370
FILTER & MTG GP-POWER TRAIN . . . . .	255	STEERING GP-HYDRAULIC . . . . .	376
FILTER GP-OIL . . . . .	256		
FLANGE GP-WHEEL . . . . .	257	<b>HYDRAULIC SYSTEM . . . . .</b>	<b>377</b>
GEAR GP-BEVEL & PINION . . . . .	258	COOLER & MTG GP-HYDRAULIC OIL . . . . .	377
HOUSING & FLANGE GP-AXLE . . . . .	259	COOLER GP-HYDRAULIC OIL . . . . .	379
HOUSING GP-AXLE . . . . .	263	CYLINDER & MTG GP-BOOM . . . . .	380
LINES GP-DIFFERENTIAL LOCK . . . . .	267	CYLINDER & MTG GP-CARRIAGE . . . . .	382
LINES GP-TRANSMISSION OIL . . . . .	268	CYLINDER & MTG	
PLANETARY GP-FINAL DRIVE . . . . .	270	GP-COMPENSATING . . . . .	384
POWER TRAIN AR . . . . .	271	CYLINDER & MTG GP-COUPLER . . . . .	385
SHAFT GP-DRIVE . . . . .	271	CYLINDER & MTG GP-TELESCOPING . . . . .	389
SHAFT GP-INPUT . . . . .	274	CYLINDER & MTG GP-TILT . . . . .	393
SHAFT GP-OUTPUT . . . . .	275	CYLINDER & VALVE GP-BOOM . . . . .	394
SHAFT GP-PUMP DRIVE . . . . .	277	CYLINDER & VALVE GP-TELESCOPE . . . . .	395
TIRE & RIM GP . . . . .	278	CYLINDER & VALVE GP-TILT . . . . .	399
TRANSMISSION AR . . . . .	281	CYLINDER GP-BOOM . . . . .	400
TRANSMISSION GP . . . . .	282	CYLINDER GP-CARRIAGE . . . . .	401
VALVE GP-TIRE . . . . .	292	CYLINDER GP-COMPENSATING . . . . .	402
WHEEL AR . . . . .	293	CYLINDER GP-COUPLER . . . . .	404
		CYLINDER GP-HITCH . . . . .	405
<b>FRAME AND BODY . . . . .</b>	<b>296</b>	CYLINDER GP-HYDRAULIC . . . . .	406
BRACE GP-CYLINDER . . . . .	296	CYLINDER GP-MULTIPURPOSE	
CONVERSION AR-ROADING . . . . .	300	BUCKET . . . . .	407
CONVERSION GP-ROADING . . . . .	306	CYLINDER GP-TELESCOPING . . . . .	409
COVER GP-ACCESS . . . . .	308	CYLINDER GP-TILT . . . . .	412
DOOR GP-ACCESS . . . . .	309	DRAIN GP-ECOLOGY . . . . .	413

# TABLE OF CONTENTS

Name	Page	Name	Page
FITTING GP-HYDRAULIC . . . . .	414	CARRIAGE GP-FORK . . . . .	565
HYDRAULIC . . . . .	415	CARRIAGE GP-ROTATING. . . . .	567
LINES GP-AUXILIARY HYDRAULIC . . . . .	419	CARRIAGE GP-SIDESHIFT . . . . .	570
LINES GP-BOOM . . . . .	428	CLAM AS-MULTIPURPOSE BUCKET . . . . .	571
LINES GP-CHASSIS. . . . .	433	COUPLER GP-QUICK . . . . .	572
LINES GP-CONNECTING. . . . .	435	EDGE GP-CUTTING. . . . .	575
LINES GP-COUPLER . . . . .	445	FORK GP-BLOCK . . . . .	578
LINES GP-HYDRAULIC . . . . .	446	FORK GP-GRAPPLE . . . . .	579
LINES GP-HYDRAULIC FAN . . . . .	448	FORK GP-PALLET . . . . .	581
LINES GP-MULTIPURPOSE BUCKET. . . . .	449	GUARD GP-BUCKET . . . . .	584
LINES GP-PUMP. . . . .	453	GUARD GP-FORK . . . . .	587
LINES GP-TRAILER . . . . .	458	HANDLER AR-BALE . . . . .	589
MOTOR & MTG GP-HYDRAULIC FAN. . . . .	460	HANDLER GP-BALE . . . . .	591
MOUNTING GP-CYLINDER . . . . .	461	HOOK GP-LIFTING . . . . .	593
PUMP & MTG GP-HYDRAULIC . . . . .	462	HOPPER GP . . . . .	594
PUMP & MTG GP-HYDRAULIC FAN . . . . .	463	PLATE GP-CARRIAGE . . . . .	595
PUMP GP-PISTON . . . . .	465		
ROTATING GP-PUMP . . . . .	466	<b>OPERATOR STATION . . . . .</b>	<b>596</b>
TANK & MTG GP-HYDRAULIC. . . . .	467	ACCUMULATOR GP-REFRIGERANT . . . . .	596
TANK GP-HYDRAULIC. . . . .	469	AIR CONDITIONER & MOUNTING GP . . . . .	598
TRAY GP-SUPPORT. . . . .	471	AIR CONDITIONER AR . . . . .	600
VALVE & MTG GP-CONTROL . . . . .	473	AIR CONDITIONER GP. . . . .	601
KIT-HYDRAULIC . . . . .	477	ARMREST GP . . . . .	603
VALVE & MTG GP-DIVERTER . . . . .	478	BOX GP-STORAGE . . . . .	604
VALVE & MTG GP-MAIN CONTROL . . . . .	481	CAB AR-ENCLOSED ROPS . . . . .	605
VALVE AR-BANK 4 . . . . .	483	CAB AR-OPEN ROPS . . . . .	607
VALVE GP-AUXILIARY . . . . .	483	CAB GP-ENCLOSED ROPS . . . . .	608
VALVE GP-BANK 4 . . . . .	484	CAB GP-OPEN ROPS . . . . .	611
VALVE GP-COMBINATION. . . . .	487	COMPRESSOR GP-REFRIGERANT . . . . .	613
VALVE GP-CONTROL. . . . .	488	CONDENSER & MTG GP	
VALVE GP-DIVERTER . . . . .	491	REFRIGERANT. . . . .	616
VALVE GP-MANIFOLD . . . . .	493	CONTROL GP-ACCELERATION . . . . .	617
<b>IMPLEMENTS . . . . .</b>	<b>495</b>	CONTR OL G P-A IR CONDI TIONER . . . . .	618
BOOM AR . . . . .	495	CONTROL GP-HANDLE . . . . .	619
BOOM GP. . . . .	506	CONTROL GP-JOYSTICK. . . . .	620
JD HYDRAULIC COUPLER . . . . .	539	CONTROL GP-TRANSMISSION. . . . .	622
INDICATOR GP-RADIUS & ANGLE . . . . .	542	CONVERSION AR-AIR CONDITIONER . . . . .	623
INSTALLATION AR-LOAD SNSR IND . . . . .	543	COVER GP-CAB . . . . .	624
LINKAGE GP-WORK TOOL . . . . .	544	DOOR GP-CAB . . . . .	625
STOP GP-BOOM. . . . .	545	DUCT GP-AIR . . . . .	631
<b>WORK TOOLS . . . . .</b>	<b>546</b>	GUARD GP-WINDOW. . . . .	634
ARM GP-MATERIAL HANDLING . . . . .	546	HAMMER & MOUNTING GP. . . . .	635
BOOM GP-TRUSS . . . . .	547	HEATER & MTG GP-CAB . . . . .	636
BUCKET AR-GENERAL PURPOSE . . . . .	548	HEATER GP-CAB . . . . .	638
BUCKET AR-GRAPPLE . . . . .	549	HORN GP-ELECTRIC . . . . .	643
BUCKET AR-MULTIPURPOSE. . . . .	550	INSTALLATION GP-RADIO. . . . .	644
BUCKET AS-LIGHT MATERIAL . . . . .	552	LINER GP-CAB . . . . .	645
BUCKET GP-GRAPPLE. . . . .	555	LINES GP-AIR CONDITIONER . . . . .	646
BUCKET GP-LIGHT MATERIAL . . . . .	557	LINES GP-HEATER. . . . .	648
BUCKET GP-MATERIAL HANDLING . . . . .	560	MIRROR GP . . . . .	650
BUCKET GP-MULTIPURPOSE. . . . .	561	MIRROR GP-REAR VIEW. . . . .	651
BULLDOZER AS . . . . .	562	MOTOR GP-WINDOWWIPER. . . . .	658
BUCKET AS. . . . .	563	MOUNTING GP-CAB . . . . .	660
CARRIAGE AR-FORK . . . . .	564		

# TABLE OF CONTENTS

Name	Page	Name	Page
PANEL GP-INSTRUMENT .....	661		
PANEL GP-SOUND SUPPRESSION .....	663		
SCREEN GP-SUN .....	664		
SEAT BELT GP .....	665		
SEAT GP .....	667		
SEAT GP-SUSPENSION .....	669		
TANK GP-WINDOW WASHER .....	671		
TRIM GP-CAB .....	672		
WINDOW GP-CAB .....	680		
WIPER & WASHER GP-WINDOW .....	681		
<b>SERVICE EQUIPMENT AND SUPPLIES</b> .....	<b>685</b>		
BRACKET GP-TRANSPORT .....	685		
CHART GP-LIFT/LOAD EXTENSION .....	686		
FILM GP .....	687		
GREASE GUN GP .....	694		
PARTS GP-MISCELLANEOUS .....	695		
PLATE & FILM GP .....	695		
PLATE GP-IDENTIFICATION .....	750		
<b>PART NUMBER INDEX</b> .....	<b>B1</b>		
<b>TIER III</b> .....	<b>C1</b>		



# MAINTENANCE PARTS

DESCRIPTION	PART NUMBER	QTY	WHERE USED	PAGE
<b>AIR INLET AND EXHAUST SYSTEM</b>				
FILTER ELEMENT AS-AIR (PRIMARY)	206-5234	1	AIR CLEANER GP	88
FILTER ELEMENT AS-AIR (SECONDARY)	206-5235	1	AIR CLEANER GP	88
<b>BASIC ENGINE</b>				
BELT-SERPENTINE	236-3842	1	BELT GP-SERPENTINE	13
BELT-SERPENTINE (SERPENTINE)	257-5523	1	BELT GP-SERPENTINE	14
CAP AS (ENGINE OIL FILLER)	136-3608	1	COVER GP-VALVE MECHANISM	23
GASKET (VALVE COVER)	225-6451	1	COVER GP-VALVE MECHANISM	23
HOSE (CRANKCASE BREATHER)	198-9109	1	COVER GP-VALVE MECHANISM	23
PLUG-DRAIN (ENGINE OIL)	7C-0351	2	PAN GP-OIL	51
		2	PAN GP-OIL	53
<b>COOLING SYSTEM</b>				
BELT GP-SERPENTINE	236-3841	1	FAN AR-SUCTION	70
	266-6990	1	FAN AR-REVERSIBLE	69
CONNECTION GP-WATER (TEMPERATURE REGULATOR)	254-2269	1	CONNECTION GP-WATER	64
REGULATOR-WATER TEMPERATURE	225-6908	1	CONNECTION GP-WATER	63
<b>ELECTRICAL AND STARTING SYSTEM</b>				
BATTERY (12-VOLT, MAINTENANCE FREE)	3T-5760	2	BATTERY & WIRING GP	126
BATTERY (12-VOLT, 900-AMPERE)	9X-3404	1	BATTERY & WIRING GP	124
BELT-DRIVE	9X-8139	1	LAMP GP-WARNING BEACON	156
BLOCK-MINIFUSE	124-9636	2	WIRING GP-CAB	200
		2	WIRING GP-CAB	209
		2	WIRING GP-CAB	212
CIRCUIT BREAKER AS (120-AMPERE)	216-4970	1	WIRING GP-ENGINE	223
CIRCUIT BREAKER AS (135-AMPERE)	171-2213	1	ALTERNATOR GP-CHARGING	121
CIRCUIT BREAKER AS (60-AMPERE)	171-2208	1	WIRING GP-ENGINE	223
ELEMENT AS-JACKET WATER HEATER	219-3271	1	HEATER GP-JACKET WATER	136
ELEMENT AS-JACKET WATER HEATER (120-VOLT, 1000-WATT)	219-3273	1	HEATER GP-JACKET WATER	137
FUSE (10-AMPERE)	3K-8782	1	LAMP GP-WARNING BEACON	156
	113-8490	21	PANEL GP-FUSE	171
FUSE (15-AMPERE)	113-8491	7	PANEL GP-FUSE	171
FUSE (20-AMPERE)	113-8492	2	PANEL GP-FUSE	171
	232-6312	1	WIRING GP-ENGINE	223
FUSE (25-AMPERE)	113-8493	1	PANEL GP-FUSE	171
GASKET	111-7899	1	WIRING GP-CAB	197
GLOW PLUG (12-VOLT)	232-6662	4	GLOW PLUG GP	133
KEY AS-ELECTRONIC (SECURITY)	206-5162	2	ELECTRONICS GP-MACHINE	131
		1	INSTALLATION GP-SECURITY	142
		2	SERVICE GP-MACHINE	176

# MAINTENANCE PARTS

DESCRIPTION	PART NUMBER	QTY	WHERE USED	PAGE
	206-5185	1	INSTALLATION GP-SECURITY	142
KEY (BATTERY DISCONNECT)	8H-5306	1	SWITCH GP-DISCONNECT	181
LAMP AS (RED, GREEN, LED, 12-VOLT)	165-5655	1	INSTALLATION GP-SECURITY	142
		1	INSTALLATION GP-SECURITY	143
LAMP GP-FLOOD (12-VOLT) (LH)	212-9348	1	LIGHTING GP-FLOOD	160
LAMP GP-FLOOD (12-VOLT) (RH)	212-9349	1	LIGHTING GP-FLOOD	160
LAMP GP-HEAD & SIGNAL (HIGH, LOW BEAM, LH)	295-3378	1	MOUNTING GP-LIGHTING	169
LAMP GP-HEAD & SIGNAL (HIGH, LOW BEAM, RH)	295-3377	1	MOUNTING GP-LIGHTING	169
LAMP GP-WARNING BEACON (MAGNETIC MOUNT)	185-7016	1	LAMP GP-WARNING BEACON	156
LAMP-HEAD	9W-3324	1	LAMP GP-HEAD & SIGNAL	147
		1	LAMP GP-HEAD & SIGNAL	148
		1	LAMP GP-HEAD & SIGNAL	149
		1	LAMP GP-HEAD & SIGNAL	150
LAMP (12-VOLT)	210-8754	1	WIRING GP-CAB	196
LAMP (12-VOLT, 10-WATT)	195-9712	1	LAMP GP-REGISTRATION PLATE	151
LAMP (12-VOLT, 21-WATT)	9W-3326	2	LAMP GP-STOP & TAIL	154
		2	LAMP GP-STOP & TAIL	155
	226-4560	1	LAMP GP-HEAD & SIGNAL	147
		1	LAMP GP-HEAD & SIGNAL	148
		1	LAMP GP-HEAD & SIGNAL	149
		1	LAMP GP-HEAD & SIGNAL	150
LAMP (12-VOLT, 5-WATT)	084-4348	1	LAMP GP-STOP & TAIL	154
		1	LAMP GP-STOP & TAIL	155
	226-4561	1	LAMP GP-HEAD & SIGNAL	147
		1	LAMP GP-HEAD & SIGNAL	148
		1	LAMP GP-HEAD & SIGNAL	149
		1	LAMP GP-HEAD & SIGNAL	150
LAMP (12-VOLT, 55-WATT)	9W-0607	1	LAMP GP-FLOOD	144
LAMP (12-VOLT, 55-WATT, HID)	9X-8118	1	LAMP GP-WARNING BEACON	156
LENS (AMBER) (DIRECTION)	209-3090	1	LAMP GP-STOP & TAIL	154
		1	LAMP GP-STOP & TAIL	155
LENS AS (HEADLIGHT)	228-6050	1	LAMP GP-HEAD & SIGNAL	149
		1	LAMP GP-HEAD & SIGNAL	150
LENS (RED) (FOG)	209-3092	1	LAMP GP-STOP & TAIL	155
LENS (RED) (STOP, TAIL)	209-3093	1	LAMP GP-STOP & TAIL	154
		1	LAMP GP-STOP & TAIL	155
LENS (WHITE) (REVERSE)	209-3091	1	LAMP GP-STOP & TAIL	154
LOCK-MINIFUSE	124-9637	2	WIRING GP-CAB	200
		2	WIRING GP-CAB	208
		2	WIRING GP-CAB	212
<b>ENGINE ARRANGEMENT</b>				
FILTER AS-ENGINE OIL	7W-2326	1	ENGINE AR-PRIMARY	9
		1	ENGINE AR-PRIMARY	10
<b>FRAME AND BODY</b>				
REFLECTOR	9R-1499	2	REFLECTOR GP	347

# MAINTENANCE PARTS

DESCRIPTION	PART NUMBER	QTY	WHERE USED	PAGE
<b>FUEL SYSTEM</b>				
CAP AS-FILLER (FUEL)	142-8828	1	TANK GP-FUEL	119
FILTER ELEMENT AS-FUEL	1R-1804	1	PUMP GP-FUEL TRANSFER & FILTER	114
<b>HYDRAULIC SYSTEM</b>				
CAP AS-FILLER (HYDRAULIC TANK)	142-8937	1	TANK GP-HYDRAULIC	469
FILTER-BREATHER (HYDRAULIC BREATHER)	9R-9925	1	TANK GP-HYDRAULIC	469
FILTER (FLOW REGULATOR)	227-1197	1	VALVE GP-BANK 4	484
		1	VALVE GP-MANIFOLD	493
STRAINER (HYDRAULIC)	202-5350	1	TANK GP-HYDRAULIC	469
<b>LUBRICATION SYSTEM</b>				
FILTER AS-ENGINE OIL	7W-2326	1	FILTER GP-ENGINE OIL	60
<b>OPERATOR STATION</b>				
BELT (AC)	190-8143	1	COMPRESSOR GP-REFRIGERANT	614
BELT-SERPENTINE	226-0443	1	COMPRESSOR GP-REFRIGERANT	615
BLADE AS-WIPER	6V-5851	1	WIPER & WASHER GP-WINDOW	683
BLADE AS-WIPER (FRONT WINDOW)	6V-74 19	1	WIPER & WASHER GP-WINDOW	681
BLADE AS-WIPER (ROOF)	6W-3924	1	WIPER & WASHER GP-WINDOW	681
CAP-VENTED (WINDOW WASHER RESERVOIR)	8E-8292	1	TANK GP-WINDOW WASHER	671
FILTER-AIR (CAB)	116-7376	1	DUCT GP-AIR	631
	201-5023	1	DUCT GP-AIR	631
		1	HEATER GP-CAB	640
<b>POWER TRAIN</b>				
BREATHER (AXLE)	253-5024	1	AXLE GP-DRIVE & STEERING	238
BREATHER (AXLE, FRONT)	253-5024	1	AXLE GP-DRIVE & STEERING	234
		1	AXLE GP-FRONT	240
FILTER AS-OIL (ADVANCED EFFICIENCY) (POWER TRAIN)	1G-8878	1	FILTER GP-OIL	256
PLUG AS-DRAIN (MAGNETIC)	152-6144	3	AXLE GP-DRIVE & STEERING	238
		4	AXLE GP-FRONT	240
		4	AXLE GP-DRIVE & STEERING	234
PLUG AS-DRAIN (MAGNETIC) (DIFFERENTIAL)	152-6144	1	DIFFERENTIAL & BEVEL GEAR GP	246
PLUG-MAGNETIC	5P-4484	1	TRANSMISSION GP	283
		1	TRANSMISSION GP	290



# INDEX

Name	Page	Name	Page
<b>A</b>			
ACCUMULATOR GP-REFRIGERANT- WITH DESICCANT .....	596 597	BOOM GP-HEAD SECTION .....	507
AFTERCOOLER GP-AIR .....	82	BOOM GP-SECTION ONE .....	506
AIR CLEANER GP .....	87 88		
AIR CONDITIONER & MOUNTING GP .....	598	BOOM GP-TRUSS .....	547
AIR CONDITIONER AR .....	600	BOX GP-STORAGE .....	604
AIR CONDITIONER GP .....	601	BRACE GP-CYLINDER .....	296 298
ALTERNATOR GP-CHARGING .....	121	BRACKET GP-MOUNTING .....	301
ALTERNATOR GP-CHARGING-105-AMPERE ...	123	BRACKET GP-TRANSPORT .....	685
ARM GP-MATERIAL HANDLING .....	546	BRAKE GP-HYDRAULIC CALIPER .....	234 240
ARMREST GP-ADJUSTABLE .....	603	BREATHER (AXLE) .....	238
AXLE & MOUNTING GP-FRONT .....	231 233	BREATHER (AXLE, FRONT) .....	234 240
AXLE & MOUNTING GP-REAR .....	232	BUCKET AR-GENERAL PURPOSE .....	548
AXLE AR .....	233	BUCKET AR-GRAPPLE .....	549
AXLE GP-DRIVE & STEERING-FRONT .....	234	BUCKET AR-MULTIPURPOSE .....	550 551
AXLE GP-DRIVE & STEERING-REAR .....	238	BUCKET AS .....	563
AXLE GP-DRIVE & STEERING (FRONT) .....	231	BUCKET AS-LIGHT MATERIAL .....	552 553 554
AXLE GP-DRIVE & STEERING (REAR) .....	232	BUCKET GP-GRAPPLE .....	555
AXLE GP-FRONT .....	240	BUCKET GP-LIGHT MATERIAL .....	557 558 559
<b>B</b>			
BATTERY & WIRING GP-DUAL BATTERY .....	126	BUCKET GP-MATERIAL HANDLING .....	560
BATTERY & WIRING GP- WITHOUT DISCONNECT SWITCH .....	124	BUCKET GP-MULTIPURPOSE .....	561
BATTERY (12-VOLT, MAINTENANCE FREE) ...	126	BULLDOZER AS .....	562
BATTERY (12-VOLT, 900-AMPERE) .....	124		
BELT (AC) .....	614		
BELT-DRIVE .....	156		
BELT GP-SERPENTINE .....	13 14 69 70		
BELT-SERPENTINE .....	13 615		
BELT-SERPENTINE (SERPENTINE) .....	14		
BELT TENSIONER GP .....	15		
BLADE AS-WIPER .....	683		
BLADE AS-WIPER (FRONT WINDOW) .....	681		
BLADE AS-WIPER (ROOF) .....	681		
BLOCK-MINIFUSE .....	200 209 212		
BOOM & CHASSIS AR .....	1		
BOOM & CHASSIS AR- HYDRAULIC COUPLER .....	1		
BOOM AR .....	495		
<b>C</b>			
		CAB AR-ENCLOSED ROPS- POWERSYNCHRO .....	605 606
		CAB AR-OPEN ROPS-POWERSYNCHRO .....	607
		CAB GP-ENCLOSED ROPS .....	608
		CAB GP-OPEN ROPS .....	611
		CABLE GP .....	324
		CAMSHAFT GP .....	16
		CAP AS (ENGINE OIL FILLER) .....	23

# INDEX

Name	Page	Name	Page
CAP AS-FILLER (FUEL) .....	119	CONTROL GP-ENGINE ELECTRONIC .....	102
CAP AS-FILLER (HYDRAULIC TANK) .....	469		108
CAP-VENTED			
(WINDOW WASHER RESERVOIR) .....	671	CONTROL GP-HANDLE-DUAL AUXILIARY .....	619
CARRIAGE AR-FORK-SIDESHIFT .....	564	CONTROL GP-JOYSTICK .....	620
CARRIAGE GP-FORK .....	566		621
CARRIAGE GP-FORK-STANDARD .....	565	CONTROL GP-PARKING BRAKE .....	348
CARRIAGE GP-ROTATING-STANDARD .....	569		350
CARRIAGE GP-ROTATING-WIDE, 4/5 TINE ....	567	CONTROL GP-SERVICE BRAKE .....	352
CARRIAGE GP-SIDESHIFT .....	570	CONTROL GP-TRANSMISSION-	
CARRIER GP-FORK .....	567	POWERSYNCRO .....	622
	569	CONTROL GP-UNPROGRAMMED	
		(MACHINE) .....	132
		CONTROL GP-UNPROGRAMMED	
		(SEcurity) .....	176
		CONTROL GP-VOLTAGE	
		(Load PROTECTION) .....	108
		CONVERSION AR-AIR CONDITIONER .....	623
		CONVERSION AR-MACHINE-KIT .....	2
		CONVERSION AR-ROADING .....	303
		CONVERSION AR-ROADING-EAME .....	300
			305
		CONVERSION AR-ROADING-FRANCE .....	300
			304
		CONVERSION AR-ROADING-GERMANY .....	300
			303
			304
		CONVERSION AR-ROADING-ITALY .....	301
CHART GP-LIFT/LOAD EXTENSION .....	686	CONVERSION AR-ROADING-	
CHASSIS AR .....	2	UK AND IRELAND .....	305
CIRCUIT BREAKER AS (120-AMPERE) .....	223	CONVERSION GP-ROADING-GERMANY .....	306
CIRCUIT BREAKER AS (135-AMPERE) .....	121	COOLANT HEATER LINES .....	648
CIRCUIT BREAKER AS (60-AMPERE) .....	223		649
CLAM AS-MULTIPURPOSE BUCKET .....	571	COOLER & MTG GP-HYDRAULIC OIL .....	377
CLUTCH GP-FORWARD/REVERSE .....	243		378
COIL AS-SOLENOID (12-VOLT) .....	282	COOLER GP-ENGINE OIL .....	65
COMMON AR .....	2		68
COMPRESSOR GP-REFRIGERANT .....	613	COOLER GP-FLTR BASE & ENG OIL .....	68
	614		
	615	COOLER GP-HYDRAULIC OIL .....	378
CONDENSER & MTG GP-REFRIGERANT .....	616		379
CONDENSER GP-REFRIGERANT .....	616	COOLER-OIL (ENGINE) .....	68
		COOLING AR-HIGH AMBIENT TEMP-	
CONNECTION GP-ELECTRICAL-		OIL COOLER .....	69
DIVERTER VALVE .....	129	COUNTERSHAFT GP-TRANSMISSION .....	245
CONNECTION GP-WATER .....	63	COUNTERSHAFT GP-TRANSMISSION-	
	64	5-SPEED POWERSYNCRO .....	245
CONNECTION GP-WATER		COUPLER GP-QUICK .....	572
(TEMPERATURE REGULATOR) .....	64	COUPLER GP-QUICK-HYDRAULIC .....	573
CONNECTOR GP-ELECTRONIC .....	1		574
CONTROL & MTG GP-MACHINE .....	130	COVER GP-ACCESS-	
CONTROL GP-ACCELERATION .....	617	MAIN CONTROL VALVE .....	308
CONTROL GP-AIR CONDITIONER .....	186	COVER GP-CAB .....	624
	188	COVER GP-FRONT HOUSING .....	17
	618		

# INDEX

Name	Page	Name	Page
	18		250
COVER GP-VALVE MECHANISM .....	23	DIFFERENTIAL & BEVEL GEAR GP-REAR .....	246
		DIFFERENTIAL GP .....	246
			252
CRANKSHAFT GP .....	25		253
CYLINDER & MTG GP-BOOM .....	380	DIFFERENTIAL GP-FRONT .....	252
CYLINDER & MTG GP-CARRIAGE-FORK .....	382	DOOR GP-ACCESS-SERVICE DOOR .....	309
CYLINDER & MTG GP-CARRIAGE- ROTATING .....	383	DOOR GP-CAB-LOWER .....	626
CYLINDER & MTG GP-COMPENSATING .....	384		628
CYLINDER & MTG GP-COUPLER .....	385	DOOR GP-CAB-UPPER .....	625
CYLINDER & MTG GP-TELESCOPING .....	389		630
		DRAIN GP-ECOLOGY .....	413
		DRAIN GP-ENGINE OIL .....	32
			33
		DRIVE GP-FAN .....	34
		DRIVE GP-FLEXIBLE COUPLING .....	254
		DUCT GP-AIR .....	631
CYLINDER & MTG GP-TILT .....	393	<b>E</b>	
CYLINDER & VALVE GP-BOOM .....	394		
CYLINDER & VALVE GP-TELESCOPE .....	395	EDGE GP-CUTTING .....	575
	396		576
	397		577
	398	ELBOW GP-AIR INLET .....	89
CYLINDER & VALVE GP-TILT .....	399	ELECTRONICS GP-MACHINE .....	132
CYLINDER BLOCK GP .....	27	ELECTRONICS GP-MACHINE-SECURITY .....	131
	29	ELEMENT AS-JACKET WATER HEATER .....	136
CYLINDER GP-BOOM .....	400	ELEMENT AS-JACKET WATER HEATER (120-VOLT, 1000-WATT) .....	137
CYLINDER GP-BRAKE-LH .....	354	ENCLOSURE GP-ENGINE .....	310
CYLINDER GP-BRAKE-RH .....	353		321
CYLINDER GP-BRAKE (MASTER) .....	352	ENCLOSURE GP-ENGINE-OUTSIDE NACD .....	312
CYLINDER GP-CARRIAGE-SIDESHIFT .....	401	ENGINE & TRANSMISSION AR .....	4
CYLINDER GP-COMPENSATING .....	402		5
CYLINDER GP-COUPLER .....	404		6
CYLINDER GP-GRAPPLE (FORK) .....	580		7
CYLINDER GP-GRAPPLE (LH) .....	555		8
CYLINDER GP-GRAPPLE (RH) .....	555	ENGINE AR-PRIMARY .....	9
CYLINDER GP-HITCH .....	405		10
CYLINDER GP-HYDRAULIC .....	406		
	591	<b>F</b>	
CYLINDER GP-MULTIPURPOSE BUKT .....	407	FAN AR-REVERSIBLE- WITH AIR CONDITIONER .....	69
CYLINDER GP-STEERING .....	365	FAN AR-REVERSIBLE- WITHOUT AIR CONDITIONER .....	69
CYLINDER GP-TELESCOPING .....	409	FAN AR-SUCTION-WITH AIR CONDITIONER .....	70
	410	FAN AR-SUCTION- WITHOUT AIR CONDITIONER .....	70
	411	FAN GP-SUCTION-SOUND SUPPRESSION .....	71
CYLINDER GP-TILT .....	412	FASTENER GP-PULLEY .....	36
CYLINDER HEAD GP .....	30	FASTENER GP-VALVE .....	376
	31	FENDER & MOUNTING GP .....	314
<b>D</b>		FILM .....	585
DIAPHRAGM (CRANKCASE PRESSURE CONTACTOR) ...	23	FILM (AIR CONDITIONER) .....	636
DIFFERENTIAL & BEVEL GEAR GP-FRONT ...	248		

# INDEX

Name	Page	Name	Page
FILM		FILM-WARNING	
(AUXILIARY HYDRAULICS, READ OMM) . . . .	1	(CRUSH HAZARD, STAY BACK) . . . . .	589
FILM			690
(AUXILIARY HYDRAULICS, READ OMM) . . . .	695		692
FILM-CERTIFICATION (ELEVATION) . . . . .	300	FILM-WARNING (IMPALED POINT) . . . . .	549
	304		579
FILM (FUSE & RELAY) . . . . .	171		589
FILM GP . . . . .	687	FILM-WARNING (NO ACCESS PLATFORM) . . . .	690
FILM GP-EAME . . . . .	690	FILM-WARNING	
FILM GP-INFORMATION . . . . .	689	(NO ACCESS PLATFORM, READ OMM) . . . .	692
FILM GP-JOYSTICK, EUROPEAN MARKET . . . .	689	FILM-WARNING (NO HANDS, STAY BACK) . . . .	579
FILM GP-		FILM-WARNING	
JOYSTICK, NORTH AMERICAN MARKET . . . .	689	(NO WELD, NO DRILL, READ OMM) . . . . .	689
FILM GP-NACD . . . . .	692	FILTER & MTG GP-POWER TRAIN . . . . .	255
FILM-IDENTIFICATION (FIVE) . . . . .	695	FILTER-AIR (CAB) . . . . .	631
FILM-IDENTIFICATION (GROUP NUMBER) . . . .	638		640
FILM-IDENTIFICATION (GROUP NUMBER) . . . .	601	FILTER AS-ENGINE OIL . . . . .	9
FILM-IDENTIFICATION (IGNITION SWITCH) . . . .	143		10
FILM-IDENTIFICATION (LOAD RADIUS B) . . . .	542		60
FILM-IDENTIFICATION (LOAD RADIUS C) . . . .	542	FILTER AS-OIL (ADVANCED EFFICIENCY)	
FILM-IDENTIFICATION (20-KM/H) . . . . .	303	(POWER TRAIN) . . . . .	256
FILM-IDENTIFICATION (40-KM/H) . . . . .	300	FILTER BASE & ENG OIL COOLER . . . . .	68
	304		
FILM-INDICATOR (BOOM ANGLE) . . . . .	542	FILTER-BREATHER	
FILM-INDICATOR (BUCKET LEVEL) . . . . .	550	(HYDRAULIC BREATHER) . . . . .	469
FILM-INSTRUCTION		FILTER ELEMENT AS-AIR (PRIMARY) . . . . .	88
(BOOM HEIGHT, ROADING) . . . . .	306	FILTER ELEMENT AS-AIR (SECONDARY) . . . . .	88
FILM-INSTRUCTION		FILTER ELEMENT AS-FUEL . . . . .	114
(MACHINE SECURITY, READ OMM) . . . . .	142	FILTER (FLOW REGULATOR) . . . . .	484
	143		493
FILM-PANEL (AIR CONDITIONER CONTROL) . . . .	598	FILTER GP-ENGINE OIL . . . . .	9
	641		10
FILM-RATING (LOAD) . . . . .	546		60
FILM (REFLECTOR) . . . . .	301		61
	586	FILTER GP-OIL-POWER TRAIN . . . . .	256
	587	FITTING GP . . . . .	120
FILM-WARNING		FITTING GP-HYDRAULIC . . . . .	414
(BRACE, CRUSH HAZARD, READ OMM) . . . .	298	FLANGE GP-WHEEL . . . . .	257
FILM-WARNING (CLEARANCE) . . . . .	173	FLOOR MAT . . . . .	2
	305	FLYWHEEL GP . . . . .	37
FILM-WARNING (CRUSH HAZARD) . . . . .	550		38
FILM-WARNING (CRUSH HAZARD) . . . . .	594	FORK GP-BLOCK . . . . .	578
FILM-WARNING		FORK GP-GRAPPLE-LIGHT DUTY . . . . .	579
(CRUSH HAZARD, FORKS, READ OMM) . . . .	738		580
	739	FORK GP-PALLET . . . . .	581
	740		582
	741		583
	742	FRAME GP-ENGINE . . . . .	315
	743		316
	744	FRAME GP-LOADER . . . . .	318
	745	FUSE (10-AMPERE) . . . . .	156
	746		171
	747	FUSE (15-AMPERE) . . . . .	171
	748	FUSE (20-AMPERE) . . . . .	171
	749		223