



Parts Manual

TH360B Telehandler

S/N TBH00100 thru TBH01008

Product and Dealer Information

Note: For product identification plate locations, see the section "Product Identification Information" in the Operation and Maintenance Manual.

Delivery Date: _____

Product Information

Model: _____

Product Identification Number: _____

Engine Serial Number: _____

Transmission Serial Number: _____

Generator Serial Number: _____

Attachment Serial Numbers: _____

Attachment Information: _____

Customer Equipment Number: _____

Dealer Equipment Number: _____

Dealer Information

Name: _____ Branch: _____

Address: _____

Dealer Contact

Phone Number

Hours

Sales: _____

Parts: _____

Service: _____

EFFECTIVITY PAGE

July 14, 2006 - A - Original issue of manual.

February 2, 2007 - B - Revised Manual.

July 11, 2008 - C - Revised Manual

EFFECTIVITY PAGE

TABLE OF CONTENTS

Name	Page	Name	Page
		PUMP GP-WATER	62
		RADIATOR GP	64
		RECOVERY GP-COOLANT	66
		AIR INLET AND EXHAUST SYSTEM	68
		AIR CLEANER GP	68
		INDICATOR GP-AIR FILTER CHANGE	70
		LINES GP-AIR	71
		MUFFLER GP	72
		SHIELD GP-EXHAUST	73
		TURBOCHARGER GP	74
MAINTENANCE PARTS	A10	FUEL SYSTEM	76
INDEX	A13	LINES GP-FUEL	76
MACHINE ARRANGEMENT	1	PUMP GP-FUEL INJECTION	77
BOOM & CHASSIS AR	2	PUMP GP-FUEL TRANSFER & FILTER	85
CHASSIS AR	3	TANK & MTG GP-FUEL	87
COMMON AR	4	TANK GP-FUEL	90
CONVERSION AR-MACHINE	4	ELECTRICAL AND STARTING SYSTEM	91
ENGINE ARRANGEMENT	6	ALTERNATOR GP-CHARGING	91
ENGINE & TRANSMISSION AR	6	BATTERY & WIRING GP	94
ENGINE AR-PRIMARY	8	CONNECTION GP-ELECTRICAL	99
INSTALLATION AR-ENGINE	9	CONTROL & MTG GP-MACHINE	100
BASIC ENGINE	10	CONTROL GP-UNPROGRAMMED	101
BELT GP-SERPENTINE	10	ELECTRONICS GP-MACHINE	103
BELT TENSIONER GP	11	ELECTRONICS GP-WORK TOOL	104
CAMSHAFT GP	12	GLOW PLUG GP	105
COVER GP-FRONT HOUSING	13	HEATER GP-JACKET WATER	106
COVER GP-VALVE MECHANISM	17	INDICATOR GP-LOAD	110
CRANKSHAFT GP	19	INSTALLATION AR-SECURITY	112
CYLINDER BLOCK GP	21	INSTALLATION GP-SECURITY	113
CYLINDER HEAD GP	24	LAMP GP-FLOOD	117
DRAIN GP-ENGINE OIL	26	LAMP GP-HEAD & SIGNAL	118
DRIVE GP-FAN	27	LAMP GP-REGISTRATION PLATE	122
FASTENER GP-PULLEY	29	LAMP GP-STOP & TAIL	125
FLYWHEEL GP	30	LAMP GP-WARNING BEACON	127
HOUSING GP-FLYWHEEL	31	LIGHTING GP-FLOOD	128
HOUSING GP-FRONT	34	LIGHTING GP-FRONT	131
LIFTING GP-ENGINE	36	LIGHTING GP-REAR	137
MOUNTING GP-ENGINE	37	LIGHTING GP-ROADING	139
MOUNTING GP-ENGINE & TMSN	38	LIGHTING GP-WARNING	140
PAN GP-OIL	40	PANEL GP-FUSE	142
PISTON & ROD GP	42	SENSOR GP-POSITION	145
PLUG GP-ENGINE	43	SENSOR GP-SPEED	147
VALVE MECHANISM GP	46	SERVICE GP-MACHINE	148
LUBRICATION SYSTEM	47	STARTING MOTOR GP-ELECTRIC	150
FILTER GP-ENGINE OIL	47	SWITCH GP-AUXILIARY	151
PUMP GP-ENGINE OIL	49	SWITCH GP-DIFFERENTIAL LOCK	152
COOLING SYSTEM	51	SWITCH GP-DISCONNECT	153
CONNECTION GP-WATER	51	SWITCH GP-ROCKER	156
COOLER GP-ENGINE OIL	52		
COOLER GP-FLTR BASE & ENG OIL	55		
COOLING AR-HIGH AMBIENT TEMP	56		
FAN GP-SUCTION	57		
LINES GP-COOLANT	58		

TABLE OF CONTENTS

Name	Page	Name	Page
WIRING GP-AIR CONDITIONER	161	ENCLOSURE GP-ENGINE	279
WIRING GP-AUXILIARY	164	FENDER & MOUNTING GP	283
WIRING GP-AXLE LOCK	165	FRAME GP	284
WIRING GP-BOOM	166	FRAME GP-MAIN	287
WIRING GP-CAB	167	GUARD GP-BOTTOM	288
WIRING GP-CHASSIS	185	GUARD GP-LINES	289
WIRING GP-COUPLER	189	HANDHOLD GP	291
WIRING GP-ELECTRONIC CONTROL	192	HITCH GP-TOWING	292
WIRING GP-ENGINE	194	HOOD GP	296
WIRING GP-LEVELING	197	LEVELING AR-FRAME	297
WIRING GP-MACHINE	198	PANEL GP-SOUND SUPPRESSION	298
		REFLECTOR GP	302
		STEP GP	303
WIRING GP-STABILIZER	204	BRAKING SYSTEM	306
WIRING GP-TRAILER	206	CONTROL GP-PARKING BRAKE	308
WIRING GP-TRANSMISSION		LEVER AS	310
CONTROL	207	CONTROL GP-SERVICE BRAKE	311
POWER TRAIN	208	CYLINDER GP-BRAKE	312
AXLE & MOUNTING GP	208	LEVER GP-HAND CONTROL	314
AXLE AR	210	LEVER AS	316
AXLE GP-DRIVE & STEERING	211	LINES GP-BRAKE	317
AXLE GP-FRONT	217	MOUNTING GP-CABLE	322
CLUTCH GP	220		
COUNTERSHAFT		STEERING SYSTEM	323
GP-TRANSMISSION	222	CYLINDER GP-STEERING	323
DIFFERENTIAL & BEVEL GEAR GP	223	KNOB GP-STEERING	324
DIFFERENTIAL GP	225	LINES GP-STEERING	325
DRIVE GP-FLEXIBLE COUPLING	227	STEERING COLUMN GP	330
FILTER & MTG GP-POWER TRAIN	228	STEERING GP-HYDRAULIC	334
FILTER GP-OIL	229		
GEAR GP-BEVEL & PINION	230	HYDRAULIC SYSTEM	335
HOUSING & FLANGE GP-AXLE	231	COOLER & MTG GP-HYDRAULIC OIL	340
HOUSING GP-AXLE	233	COOLER GP-HYDRAULIC OIL	342
LINES GP-DIFFERENTIAL LOCK	239	CYLINDER & MTG GP-BOOM	343
LINES GP-TRANSMISSION OIL	240	CYLINDER & MTG GP-CARRIAGE	345
PLANETARY GP-FINAL DRIVE	242	CYLINDER & MTG	
POWER TRAIN AR	243	GP-COMPENSATING	347
SHAFT GP-DRIVE	243	CYLINDER & MTG GP-COUPLER	348
SHAFT GP-INPUT	246	CYLINDER & MTG GP-FRAME LEVEL	349
SHAFT GP-OUTPUT	247	CYLINDER & MTG GP-STABILIZER	351
SHAFT GP-PUMP DRIVE	248	CYLINDER & MTG GP-TELESCOPING	352
TIRE & RIM GP	250	CYLINDER & MTG GP-TILT	354
TRANSMISSION AR	255	CYLINDER & VALVE GP-AXLE LOCK	355
TRANSMISSION GP	256	CYLINDER & VALVE GP-BOOM	359
VALVE GP-TIRE	263	CYLINDER & VALVE GP-COUPLER	360
WHEEL AR	264	CYLINDER & VALVE GP-STABILIZER	361
FRAME AND BODY	268	CYLINDER & VALVE GP-TELESCOPE	362
BRACE GP-CYLINDER	268	CYLINDER & VALVE GP-TILT	363
BRACKET GP-MOUNTING	271	CYLINDER GP-BOOM	366
CONVERSION AR-ROADING	271	CYLINDER GP-CARRIAGE	367
COUNTERWEIGHT GP	275	CYLINDER GP-FRAME LEVELING	368
COVER GP-ACCESS	277	CYLINDER GP-HYDRAULIC	369
DOOR GP-ACCESS	278		

TABLE OF CONTENTS

Name	Page	Name	Page
CYLINDER GP-MULTIPURPOSE		BUCKET AR-GRAPPLE	474
BUKT	370	BUCKET AR-MULTIPURPOSE	475
CYLINDER GP-STABILIZER	372	BUCKET GP-GRAPPLE	477
CYLINDER GP-TELESCOPING	374	BUCKET GP-MATERIAL HANDLING	479
CYLINDER GP-TILT	375	BUCKET GP-MULTIPURPOSE	480
DRAIN GP-ECOLOGY	376	BULLDOZER AS	481
FITTING GP-HYDRAULIC	377	BUCKET AS	482
HYDRAULIC AR	378	CARRIAGE AR-FORK	483
HYDRAULIC AR-AUXILIARY	378	CARRIAGE GP-FORK	484
LINES GP-AUXILIARY HYDRAULIC	379	CARRIAGE GP-ROTATING	486
LINES GP-BOOM	382	CARRIAGE GP-SIDESHIFT	489
LINES GP-CONNECTING	384	CLAM AS-MULTIPURPOSE BUCKET	490
LINES GP-FRAME LEVELING	391	COUPLER GP-QUICK	495
LINES GP-HYDRAULIC	393	EDGE GP-CUTTING	499
LINES GP-MULTIPURPOSE BUCKET	398	FORK GP-BLOCK	500
LINES GP-PUMP	402	FORK GP-PALLET	501
LINES GP-STABILIZER	407	GUARD GP-BUCKET	504
MOUNTING GP-CYLINDER	408	HOOK GP-LIFTING	507
PLUG GP-CONTROL VALVE	409	HOPPER GP	508
PUMP & MTG GP-HYDRAULIC	410	 	
PUMP GP-PISTON	413	PLATE GP-CARRIAGE	512
ROTATING GP-PUMP	414	 	
TANK & MTG GP-HYDRAULIC	415	OPERATOR STATION	515
TANK GP-HYDRAULIC	416	ACCUMULATOR GP-REFRIGERANT	515
VALVE & LINES GP-LOAD CONTROL	418	AIR CONDITIONER & MOUNTING GP	517
 		AIR CONDITIONER AR	519
VALVE & MTG GP-DIVERTER	420	AIR CONDITIONER GP	520
VALVE & MTG GP-MAIN CONTROL	423	ARMREST GP	522
VALVE & MTG GP-STABILIZER	425	BOX GP-STORAGE	523
 		CAB AR-ENCLOSED ROPS	524
VALVE GP-BANK 4	430	 	
VALVE GP-CONTROL	433	CAB GP-ENCLOSED ROPS	527
VALVE GP-DIVERTER	438	 	
VALVE GP-LOAD CONTROL	440	COMPRESSOR GP-REFRIGERANT	532
VALVE GP-MANIFOLD	441	CONDENSER & MTG GP-	
VALVE GP-SOLENOID	443	REFRIGERANT	533
VALVE GP-STABILIZER CONTROL	446	CONTROL GP-ACCELERATION	534
 		CONTROL GP-AIR CONDITIONER	535
IMPLEMENTS	447	CONTROL GP-HANDLE	537
BOOM AR	447	CONTROL GP-JOYSTICK	538
BOOM GP	450	CONTROL GP-TRANSMISSION	540
CHAIN GP-BOOM	455	CONVERSION AR-AIR CONDITIONER	541
GUIDE GP-LINES	459	COVER GP-CAB	542
INDICATOR GP-RADIUS & ANGLE	461	DOOR GP-CAB	546
INSTALLATION AR-LOAD SNSR IND	463	DUCT GP-AIR	549
KIT-STABILIZER CONVERSION	463	GUARD GP-WINDOW	552
STABILIZER AR	464	HEATER & MTG GP-CAB	553
STABILIZER GP	465	HEATER GP-CAB	555
STOP GP-BOOM	469	HORN GP-ELECTRIC	560
 		INSTALLATION GP-RADIO	561
WORK TOOLS	471	KIT-MIRROR	562
ARM GP-MATERIAL HANDLING	471	LINER GP-CAB	563
BOOM GP-TRUSS	472		
BUCKET AR-GENERAL PURPOSE	473		

TABLE OF CONTENTS

Name	Page	Name	Page
LINES GP-AIR CONDITIONER	564		
LINES GP-HEATER	568		
MIRROR GP	571		
MIRROR GP-REAR VIEW	572		
MOTOR GP-WINDOW WIPER	578		
MOUNTING GP-CAB	580		
PANEL GP-INSTRUMENT	581		
SCREEN GP-SUN	590		
SEAT BELT GP	591		
SEAT GP	593		
SEAT GP-SUSPENSION	595		
TRIM GP-CAB	598		
WINDOW GP-CAB	606		
WIPER & WASHER GP-WINDOW	609		
SERVICE EQUIPMENT AND SUPPLIES	613		
BRACKET GP-TRANSPORT	613		
CHART GP-LIFT/LOAD EXTENSION	614		
FILM GP	615		
GREASE GUN GP	655		
PARTS GP-MISCELLANEOUS	656		
PLATE & FILM GP	656		
PART NUMBER INDEX	B1		

This Page Intentionally Left Blank

MAINTENANCE PARTS

DESCRIPTION	PART NUMBER	QTY	WHERE USED	PAGE
AIR INLET AND EXHAUST SYSTEM				
FILTER ELEMENT AS-AIR (PRIMARY)	206-5234	1	AIR CLEANER GP	69
FILTER ELEMENT AS-AIR (SECONDARY)	206-5235	1	AIR CLEANER GP	69
BASIC ENGINE				
BELT-SERPENTINE	236-3842	1	BELT GP-SERPENTINE	10
CAP AS (ENGINE OIL FILLER)	136-3608	1	COVER GP-VALVE MECHANISM	17
GASKET (VALVE COVER)	225-6451	1	COVER GP-VALVE MECHANISM	17
HOSE ((BREATHER) (CRANKCASE))	198-9109	1	COVER GP-VALVE MECHANISM	17
PLUG-DRAIN (ENGINE OIL)	7C-0351	2	PAN GP-OIL	40
COOLING SYSTEM				
CONNECTION GP-WATER (TEMPERATURE REGULATOR)	254-2269	1	CONNECTION GP-WATER	51
ELECTRICAL AND STARTING SYSTEM				
BATTERY (12-VOLT, MAINTENANCE FREE)	3T-5760	2	BATTERY & WIRING GP	96
BATTERY (12-VOLT, 900-AMPERE)	9X-3404	1	BATTERY & WIRING GP	94
BELT-DRIVE	9X-8139	1	LAMP GP-WARNING BEACON	127
BLOCK-MINIFUSE	124-9606	2	WIRING GP-CAB	180
CIRCUIT BREAKER AS (120-AMPERE)	216-4970	1	WIRING GP-ENGINE	194
CIRCUIT BREAKER AS (135-AMPERE)	171-2213	1	ALTERNATOR GP-CHARGING	91
CIRCUIT BREAKER AS (60-AMPERE)	171-2208	1	WIRING GP-ENGINE	194
ELEMENT AS-JACKET WATER HEATER	219-3271	1	HEATER GP-JACKET WATER	108
ELEMENT AS-JACKET WATER HEATER (120-VOLT, 1000-WATT)	219-3273	1	HEATER GP-JACKET WATER	109
FUSE (10-AMPERE)	3K-8782	1	LAMP GP-WARNING BEACON	127
	113-8490	21	PANEL GP-FUSE	142
FUSE (15-AMPERE)	113-8491	7	PANEL GP-FUSE	142
FUSE (20-AMPERE)	113-8492	2	PANEL GP-FUSE	142
	232-6312	1	WIRING GP-ENGINE	194
FUSE (25-AMPERE)	113-8493	1	PANEL GP-FUSE	142
GASKET	111-7899	1	WIRING GP-CAB	168
GLOW PLUG (12-VOLT)	232-6662	4	GLOW PLUG GP	105
KEY AS-ELECTRONIC (SECURITY)	206-5162	2	ELECTRONICS GP-MACHINE	103
		1	INSTALLATION GP-SECURITY	115
		2	SERVICE GP-MACHINE	148
	206-5165	1	INSTALLATION GP-SECURITY	115
KEY (BATTERY DISCONNECT)	8H-5306	1	SWITCH GP-DISCONNECT	153
LAMP AS (RED, GREEN, LED, 12-VOLT)	165-5655	1	INSTALLATION GP-SECURITY	115
		1	INSTALLATION GP-SECURITY	116
LAMP AS (12-VOLT)	212-9800			
LAMP GP-FLOOD (12-VOLT) (LH)	212-9348	1	LIGHTING GP-FLOOD	128
LAMP GP-FLOOD (12-VOLT) (RH)	212-9349	1	LIGHTING GP-FLOOD	128

MAINTENANCE PARTS

DESCRIPTION	PART NUMBER	QTY	WHERE USED	PAGE
LAMP GP-WARNING BEACON (MAGNETIC MOUNT)	185-7016	1	LAMP GP-WARNING BEACON	127
LAMP-HEAD	9W-3324	1	LAMP GP-HEAD & SIGNAL	118
		1	LAMP GP-HEAD & SIGNAL	119
		1	LAMP GP-HEAD & SIGNAL	120
		1	LAMP GP-HEAD & SIGNAL	121
LAMP (12-VOLT)	210-8754	1	WIRING GP-CAB	167
LAMP (12-VOLT, 10-WATT)	195-9712	1	LAMP GP-REGISTRATION PLATE	122
		1	LAMP GP-REGISTRATION PLATE	124
LAMP (12-VOLT, 21-WATT)	9W-3326	2	LAMP GP-STOP & TAIL	125
		2	LAMP GP-STOP & TAIL	126
	226-4560	1	LAMP GP-HEAD & SIGNAL	118
		1	LAMP GP-HEAD & SIGNAL	119
		1	LAMP GP-HEAD & SIGNAL	120
		1	LAMP GP-HEAD & SIGNAL	121
LAMP (12-VOLT, 5-WATT)	084-4348	1	LAMP GP-STOP & TAIL	125
		1	LAMP GP-STOP & TAIL	126
	226-4561	1	LAMP GP-HEAD & SIGNAL	118
		1	LAMP GP-HEAD & SIGNAL	119
		1	LAMP GP-HEAD & SIGNAL	120
		1	LAMP GP-HEAD & SIGNAL	121
LAMP (12-VOLT, 55-WATT)	9W-0607	1	LAMP GP-FLOOD	117
LAMP (12-VOLT, 55-WATT, HID)	9X-8118	1	LAMP GP-WARNING BEACON	127
LAMP (24-VOLT, 10-WATT)	5C-8315	1	LAMP GP-REGISTRATION PLATE	124
LENS (AMBER) (DIRECTION)	209-3090	1	LAMP GP-STOP & TAIL	125
		1	LAMP GP-STOP & TAIL	126
LENS AS (HEADLIGHT)	228-6050	1	LAMP GP-HEAD & SIGNAL	120
		1	LAMP GP-HEAD & SIGNAL	121
LENS (RED) (FOG)	209-3092	1	LAMP GP-STOP & TAIL	126
LENS (RED) (STOP, TAIL)	209-3093	1	LAMP GP-STOP & TAIL	125
		1	LAMP GP-STOP & TAIL	126
LENS (WHITE) (REVERSE)	209-3091	1	LAMP GP-STOP & TAIL	125
LOCK-MINIFUSE	124-9637	2	WIRING GP-CAB	179
ENGINE ARRANGEMENT				
BELT GP-SERPENTINE	236-3841	1	ENGINE & TRANSMISSION AR	6
FILTER AS-ENGINE OIL	7W-2326	1	ENGINE AR-PRIMARY	8
FRAME AND BODY				
BELT	295-3453	2	STEP GP	304
REFLECTOR	9R-1499	2	REFLECTOR GP	302
FUEL SYSTEM				
CAP AS-FILLER (FUEL)	295-3350	1	TANK GP-FUEL	90
FILTER ELEMENT AS-FUEL	1R-1804	1	PUMP GP-FUEL TRANSFER & FILTER	85

MAINTENANCE PARTS

DESCRIPTION	PART NUMBER	QTY	WHERE USED	PAGE
HYDRAULIC SYSTEM				
CAP AS-FILLER (HYDRAULIC TANK)	142-8937	1	TANK GP-HYDRAULIC	416
FILTER-BREATHER	9R-9925	1	TANK GP-HYDRAULIC	416
FILTER (FLOW REGULATOR)	227-1197	1	VALVE GP-BANK 4	430
		1	VALVE GP-MANIFOLD	441
STRAINER	202-5350	1	TANK GP-HYDRAULIC	416
LUBRICATION SYSTEM				
FILTER AS-ENGINE OIL	7W-2326	1	FILTER GP-ENGINE OIL	47
OPERATOR STATION				
BELT (AC)	190-8143	1	COMPRESSOR GP-REFRIGERANT	532
BLADE AS-WIPER	6V-5851	1	WIPER & WASHER GP-WINDOW	611
BLADE AS-WIPER (FRONT WINDOW)	295-3465	1	WIPER & WASHER GP-WINDOW	609
BLADE AS-WIPER (ROOF)	6W-3924	1	WIPER & WASHER GP-WINDOW	609
FILTER-AIR (CAB)	116-7376	1	DUCT GP-AIR	549
	201-5023	1	DUCT GP-AIR	549
		1	HEATER GP-CAB	557
POWER TRAIN				
BREATHER (AXLE)	253-5024	1	AXLE GP-DRIVE & STEERING	215
BREATHER (AXLE, FRONT)	253-5024	1	AXLE GP-FRONT	217
FILTER AS-OIL (ADVANCED EFFICIENCY) (POWER TRAIN)	1G-8878	1	FILTER GP-OIL	229
PLUG AS-DRAIN (MAGNETIC)	152-6144	4	AXLE GP-FRONT	217
PLUG AS-DRAIN (MAGNETIC) (DIFFERENTIAL)	152-6144	1	DIFFERENTIAL & BEVEL GEAR GP	223
PLUG AS-DRAIN (MAGNETIC) (FINAL DRIVE PLANETARY)	152-6144	4	AXLE GP-DRIVE & STEERING	211
		3	AXLE GP-DRIVE & STEERING	215
PLUG-MAGNETIC	5P-4484	1	TRANSMISSION GP	257

INDEX

Name	Page	Name	Page
A			
ACCUMULATOR GP-REFRIGERANT- WITH DESICCANT	515 516	BOOM & CHASSIS AR- MANUAL COUPLER, AUX HYDRAULICS	2 447
AIR CLEANER GP	68 69	BOOM GP-SECTION THREE	452
AIR CONDITIONER & MOUNTING GP	517	BOOM GP-SECTION TWO	453
AIR CONDITIONER AR	519	BOOM GP-SECTION 1	450
AIR CONDITIONER GP	520	BOOM GP-TRUSS	472
ALARM GP (ACTION)	199 202	BOX GP-STORAGE	523
ALTERNATOR GP-CHARGING	91	BRACE GP-CYLINDER	268 269
ALTERNATOR GP-CHARGING-105-AMPERE . . .	93	BRACE GP-CYLINDER-HEWDEN	270
ARM GP-MATERIAL HANDLING	471	BRACKET GP-MOUNTING	273
ARMREST GP-ADJUSTABLE	522	BRACKET GP-MOUNTING- FRONT ROADING LIGHTS	271
AXLE & MOUNTING GP-FRONT	209 210	BRACKET GP-TRANSPORT	613
AXLE & MOUNTING GP-REAR	208	BRAKE GP-HYDRAULIC CALIPER	212 217
AXLE AR	210	BREATHER (AXLE)	215
AXLE AR-DIFFERENTIAL LOCK	210	BREATHER (AXLE, FRONT)	217
AXLE GP-DRIVE & STEERING-FRONT	211	BUCKET AR-GENERAL PURPOSE	473
AXLE GP-DRIVE & STEERING-REAR	215	BUCKET AR-GRAPPLE	474
AXLE GP-FRONT	217	BUCKET AR-MULTIPURPOSE	475 476
B			
BATTERY & WIRING GP-DUAL BATTERY	96	BUCKET AS	482
BATTERY & WIRING GP- WITHOUT DISCONNECT SWITCH	94	BUCKET GP-GRAPPLE	477
BATTERY (12-VOLT, MAINTENANCE FREE) . . .	96	BUCKET GP-MATERIAL HANDLING	479
BATTERY (12-VOLT, 900-AMPERE)	94	BUCKET GP-MULTIPURPOSE	480
BELT	304	BULLDOZER AS	481
BELT (AC)	532	C	
BELT-DRIVE	127	CAB AR-ENCLOSED ROPS- POWERSYNCHRO	524 525
BELT GP-SERPENTINE	6 10	CAB GP-ENCLOSED ROPS	527
BELT-SERPENTINE	10	CAMSHAFT GP	12
BELT TENSIONER GP	11	CAP AS (ENGINE OIL FILLER)	17
BLADE AS-WIPER	611	CAP AS-FILLER (FUEL)	90
BLADE AS-WIPER (FRONT WINDOW)	609	CAP AS-FILLER (HYDRAULIC TANK)	416
BLADE AS-WIPER (ROOF)	609	CARRIAGE AR-FORK-SIDESHIFT	483
BLOCK-MINIFUSE	179	CARRIAGE GP-FORK	485
BOOM & CHASSIS AR	2	CARRIAGE GP-FORK-STANDARD	484
		CARRIAGE GP-ROTATING-STANDARD	488
		CARRIAGE GP-ROTATING-WIDE, 4/5 TINE	486
		CARRIAGE GP-SIDESHIFT	489
		CARRIER GP-FORK	486 488
		CHAIN GP-BOOM	455 456

INDEX

Name	Page	Name	Page
CHART GP-LIFT/LOAD EXTENSION- REAR AXLE LOCK DISABLED	614	CONVERSION AR-ROADING- UNITED KINDOM AND IRELAND	272
CHASSIS AR	3	COOLANT HEATER LINES	568
CIRCUIT BREAKER AS (120-AMPERE)	194		569
CIRCUIT BREAKER AS (135-AMPERE)	91	COOLER & MTG GP-HYDRAULIC OIL	340
CIRCUIT BREAKER AS (60-AMPERE)	194		341
CLAM AS-MULTIPURPOSE BUCKET	490	COOLER GP-ENGINE OIL	52
CLUTCH GP-FORWARD/REVERSE	220		55
COIL AS-SOLENOID (12-VOLT)	256	COOLER GP-FLTR BASE & ENG OIL	55
COMMON AR	4	COOLER GP-HYDRAULIC OIL	341
COMPRESSOR GP-REFRIGERANT	532		342
CONDENSER & MTG GP-REFRIGERANT	533	COOLER-OIL (ENGINE)	55
CONDENSER GP-REFRIGERANT	533	COOLING AR-HIGH AMBIENT TEMP- OIL COOLER	56
CONNECTION GP-ELECTRICAL- DIVERter VALVE	99	COUNTERSHAFT GP-TRANSMISSION	222
CONNECTION GP-WATER	51	COUNTERWEIGHT GP	275
CONNECTION GP-WATER (TEMPERATURE REGULATOR)	51		276
CONNECTOR GP-ELECTRONIC	2	COUPLER GP-QUICK	498
CONTROL & MTG GP-MACHINE	100	COUPLER GP-QUICK-HYDRAULIC	495
CONTROL GP-ACCELERATION	534		496
CONTROL GP-AIR CONDITIONER	161	COUPLER GP-QUICK-MANUAL	495
	163		498
	535	COVER GP-ACCESS- MAIN CONTROL VALVE	277
CONTROL GP-ENGINE ELECTRONIC	77	COVER GP-ACCESS (MAIN CONTROL VALVE)	4
	80	COVER GP-CAB	542
CONTROL GP-HANDLE-DUAL AUXILIARY	537	COVER GP-FRONT HOUSING	13
CONTROL GP-JOYSTICK	538		14
	539	COVER GP-VALVE MECHANISM	17
CONTROL GP-PARKING BRAKE	308	CRANKSHAFT GP	19
CONTROL GP-SERVICE BRAKE	311	CYLINDER & MTG GP-BOOM	343
CONTROL GP-TRANSMISSION- POWERSYNCR0	540	CYLINDER & MTG GP-CARRIAGE-FORK	345
CONTROL GP-UNPROGRAMMED	101	CYLINDER & MTG GP-CARRIAGE- ROTATING	346
	102	CYLINDER & MTG GP-COMPENSATING	347
CONTROL GP-UNPROGRAMMED (MACHINE)	104	CYLINDER & MTG GP-COUPLER	348
CONTROL GP-UNPROGRAMMED (SECURITY)	148	CYLINDER & MTG GP-FRAME LEVEL	349
CONTROL GP-VOLTAGE (LOAD PROTECTION)	77	CYLINDER & MTG GP-STABILIZER	351
CONVERSION AR-AIR CONDITIONER	541	CYLINDER & MTG GP-TELESCOPING	352
CONVERSION AR-MACHINE-KIT	4	CYLINDER & MTG GP-TILT-FORK	354
CONVERSION AR-ROADING	273	CYLINDER & VALVE GP-AXLE LOCK	355
CONVERSION AR-ROADING-EAME	272	CYLINDER & VALVE GP-BOOM	359
CONVERSION AR-ROADING-FRANCE	272	CYLINDER & VALVE GP-COUPLER	360
CONVERSION AR-ROADING-ITALY	271	CYLINDER & VALVE GP-STABILIZER	361
		CYLINDER & VALVE GP-TELESCOPE	362

INDEX

Name	Page	Name	Page
CYLINDER & VALVE GP-TILT	363		
	364	ENGINE & TRANSMISSION AR	6
CYLINDER BLOCK GP	21		7
	23	ENGINE AR-PRIMARY	8
CYLINDER GP-BOOM	366		
		F	
CYLINDER GP-BRAKE-LH	313	FAN GP-SUCTION-SOUND SUPPRESSION	57
CYLINDER GP-BRAKE-RH	312	FASTENER GP-PULLEY	29
CYLINDER GP-BRAKE (MASTER)	311	FASTENER GP-VALVE	334
CYLINDER GP-CARRIAGE-SIDESHIFT	367	FENDER & MOUNTING GP-	
CYLINDER GP-FRAME LEVELING	368	GERMANY, ITALY	283
CYLINDER GP-GRAPPLE (LH)	477	FILM	505
CYLINDER GP-GRAPPLE (RH)	477		
CYLINDER GP-HYDRAULIC	369	FILM (AIR CONDITIONER)	553
CYLINDER GP-MULTIPURPOSE BUKT	370	FILM	
CYLINDER GP-STABILIZER	372	(AUXILIARY HYDRAULICS, READ OMM)	2
	373		
CYLINDER GP-STEERING	323	FILM (B)	461
CYLINDER GP-TELESCOPING	374	FILM (C)	461
CYLINDER GP-TILT	375	FILM-CERTIFICATION (ELEVATION)	272
CYLINDER HEAD GP	24	FILM (D)	461
	25	FILM (FUSE & RELAY)	142
		FILM GP	272
D			615
DIAPHRAGM			624
(CRANKCASE PRESSURE CONTACTOR) ...	17		643
			652
DIFFERENTIAL & BEVEL GEAR GP-REAR	223		653
DIFFERENTIAL GP	223	FILM GP-CZECH	617
	225		651
	226	FILM GP-DANISH	619
DIFFERENTIAL GP-FRONT	225		632
DOOR GP-ACCESS-SERVICE DOOR	278	FILM GP-DUTCH	620
DOOR GP-CAB-LOWER	546	FILM GP-EAME	637
		FILM GP-ENGLISH	616
DOOR GP-CAB-UPPER	548		640
		FILM GP-FINNISH	621
DRAIN GP-ECOLOGY	376	FILM GP-FRENCH	626
DRAIN GP-ENGINE OIL	26		646
DRIVE GP-FAN	27		648
DRIVE GP-FLEXIBLE COUPLING	227	FILM GP-GERMAN	628
DUCT GP-AIR	549	FILM GP-GREEK	636
		FILM GP-HUNGARIAN	635
E		FILM GP-ICELANDIC	633
EDGE GP-CUTTING	499	FILM GP-INFORMATION	634
ELECTRONICS GP-MACHINE	104	FILM GP-ITALIAN	630
ELECTRONICS GP-MACHINE-SECURITY	103	FILM GP-JOYSTICK, EUROPEAN MARKET	632
		FILM GP-	
ELEMENT AS-JACKET WATER HEATER	108	JOYSTICK, NORTH AMERICAN MARKET	632
ELEMENT AS-JACKET WATER HEATER			
(120-VOLT, 1000-WATT)	109		
ENCLOSURE GP-ENGINE	279		

INDEX

Name	Page	Name	Page
FILM GP-NORWEGIAN	644	FILTER AS-OIL (ADVANCED EFFICIENCY) (POWER TRAIN)	229
FILM GP-POLISH	639	FILTER BASE & ENG OIL COOLER	55
FILM GP-PORTUGUESE	622	FILTER-BREATHER	416
FILM GP-RUSSIAN	618	FILTER ELEMENT AS-AIR (PRIMARY)	69
FILM GP-SLOVAKIAN	651	FILTER ELEMENT AS-AIR (SECONDARY)	69
FILM GP-SPANISH	627	FILTER ELEMENT AS-FUEL	85
	647		
	649		
FILM GP-SWEDISH	623	FILTER (FLOW REGULATOR)	430
FILM GP-TURKISH	645		441
FILM-IDENTIFICATION (GROUP NUMBER)	555	FILTER GP-ENGINE OIL	8
FILM-IDENTIFICATION (GROUP NUMBER)	520		47
FILM-IDENTIFICATION (IGNITION SWITCH)	116		48
FILM-IDENTIFICATION (LABEL)	101	FILTER GP-OIL-POWER TRAIN	229
FILM-IDENTIFICATION (LOAD RADIUS B)	111	FITTING GP-HYDRAULIC- QUICK DISCONNECT	377
FILM-IDENTIFICATION (LOAD RADIUS C)	111	FLANGE GP-WHEEL	231
FILM-IDENTIFICATION (LOAD RADIUS D)	111		232
FILM-INDICATOR (BUCKET LEVEL)	475	FLOOR MAT	4
FILM-INSTRUCTION		FLYWHEEL GP	30
(MACHINE SECURITY, READ OMM)	115	FORK GP-BLOCK	500
	116	FORK GP-PALLET	501
FILM-PANEL (AIR CONDITIONER CONTROL)	517		502
	558		503
FILM-RATING (LOAD)	471	FRAME GP-ENGINE	284
			285
FILM (REFLECTOR)	273	FRAME GP-MAIN	287
	506	FUSE (10-AMPERE)	127
FILM-WARNING			142
(BRACE, CRUSH HAZARD, READ OMM)	269	FUSE (15-AMPERE)	142
FILM-WARNING (CLEARANCE)	272	FUSE (20-AMPERE)	142
FILM-WARNING (CRUSH HAZARD)	475		194
	508	FUSE (25-AMPERE)	142
FILM-WARNING			
(CRUSH HAZARD, STAY BACK)	463		
FILM-WARNING (CRUSH HAZARD, STAY BACK) (HAND)	637		
	643		
FILM-WARNING (CRUSH HAZARD, STAY BACK) (REAR)	643		
FILM-WARNING (IMPALED POINT)	474		
FILM-WARNING (NO ACCESS PLATFORM)	464		
FILM-WARNING			
(NO ACCESS PLATFORM, READ OMM)	185		
	643		
FILM-WARNING			
(NO WELD, NO DRILL, READ OMM)	634		
FILTER & MTG GP-POWER TRAIN	228		
FILTER-AIR (CAB)	549		
	557		
FILTER AS-ENGINE OIL	8		
	47		

G

GASKET	168
GASKET (VALVE COVER)	17
GAUGE AS-OIL LEVEL (DIPSTICK) (ENGINE) ...	40
GAUGE GP-PRESSURE	656
GEAR GP-BEVEL & PINION	223
	230
GEAR GP-RING	231
	232
GLOW PLUG GP	105
GLOW PLUG (12-VOLT)	105
GREASE GUN GP	655
GUARD GP-BOTTOM-ENGINE	288
GUARD GP-BUCKET-FRONT	504
	505
GUARD GP-BUCKET-ITALY	506
GUARD GP-LINES	289
	290

INDEX

Name	Page	Name	Page
GUARD GP-WINDOW	552	HYDRAULIC AR	378
GUIDE GP-LINES	459	HYDRAULIC AR-AUXILIARY	378
	460		
H		I	
HANDHOLD GP	291	INDICATOR AS-AIR FILTER CHANGE	70
HANDLE GP-MODULAR	537	INDICATOR GP-AIR FILTER CHANGE	70
	539	INDICATOR GP-BOOM ANGLE	461
HARNESS AS-CAB	178	INDICATOR GP-LOAD	110
HARNESS AS-ENGINE	194		111
HARNESS AS-ROOF	178	INDICATOR GP-RADIUS & ANGLE	111
HARNESS AS-SENSOR (BOOM)	201	INDICATOR GP-RADIUS & ANGLE-BOOM	461
HARNESS AS-SWITCH		INDICATOR GP-RADIUS & ANGLE-	
(DIFFERENTIAL LOCK)	152	REAR AXLE LOCK DISABLED	462
HARNESS AS-WIRING (SERVICE PORT)	178	INDICATOR-LEVEL	602
HEATER & MTG GP-CAB	553	INDICATOR-OIL	416
HEATER GP-CAB	555	INSTALLATION AR-ENGINE	9
	558	INSTALLATION AR-LOAD SNSR IND-	
HEATER GP-CAB-KIT	557	HYDRAULIC LOCKOUT	463
HEATER GP-JACKET WATER	106	INSTALLATION AR-SECURITY	112
	107	INSTALLATION GP-RADIO	561
	108	INSTALLATION GP-SECURITY	113
	109		116
HITCH GP-TOWING	292	INSTALLATION GP-SECURITY-KEY	115
HOOD GP-SOUND SUPPRESSION	296		
HOOK-COAT	602	K	
HOOK GP-LIFTING	507	KEY AS-ELECTRONIC (SECURITY)	103
HOPPER GP	508		115
HORN AS	581		148
		KEY (BATTERY DISCONNECT)	153
HORN AS (24-VOLT, LOW TONE)	187	KIT-BEARING	413
HORN GP-ELECTRIC	560	KIT-BOOT (SUSPENSION SEAT)	594
			595
HOSE (CRANKCASE BREATHER)	17	KIT-BRAKE CALIPER	212
HOUSING & FLANGE GP-AXLE-LH	232	KIT-BRAKE LINING	212
HOUSING & FLANGE GP-AXLE-RH	231	KIT-CAM (COUNTERCLOCKWISE)	212
HOUSING GP-AXLE-LH	236		218
HOUSING GP-AXLE-RH	235	KIT-CONNECTING PLUG (6-PIN)	131
HOUSING GP-AXLE-			133
WITH DIFFERENTIAL LOCK	233		271
HOUSING GP-AXLE-		KIT-CONTROL	413
W/O DIFFERENTIAL LOCK	237	KIT-CRANKSHAFT BEARING (0.25-MM OS)	19
HOUSING GP-FLYWHEEL	31	KIT-CRANKSHAFT BEARING (0.5-MM OS)	19
HOUSING GP-FRONT	34	KIT-CRANKSHAFT BEARING (0.76-MM OS)	19
		KIT-DAMPER (SEAT)	594
HOUSING GP-TRANSMISSION	256		595
		KIT-MIRROR	562
		KIT-PIVOT	333
		KIT-PLANETARY CARRIER	242
		KIT-RECEPTACLE (3-PIN)	145
			187
			310
		KIT-RECEPTACLE (6-PIN)	131

INDEX

Name	Page	Name	Page
	133	LAMP GP-HEAD & SIGNAL (LH)	135
	271	LAMP GP-HEAD & SIGNAL (RH)	135
KIT-RIDE CONTROL (SUSPENSION SEAT)	594	LAMP GP-HEAD & SIGNAL (TURN SIGNAL, LH)	131
	595	LAMP GP-HEAD & SIGNAL (TURN SIGNAL, RH)	131
KIT-ROD BEARING (0.25-MM OS)	19	LAMP GP-REGISTRATION PLATE	122
KIT-ROD BEARING (0.51-MM OS)	19		123
KIT-ROD BEARING (0.76-MM OS)	19		124
KIT-SEAL	346	LAMP GP-STOP & TAIL	126
	413	LAMP GP-STOP & TAIL-REAR, RH	125
	442	LAMP GP-WARNING BEACON	127
	443	LAMP GP-WARNING BEACON (MAGNETIC MOUNT)	127
KIT-SEAL (WATER JACKET)	108	LAMP-HEAD	118
	109		119
KIT-SEAT (BACK)	594		120
	595		121
	596	LAMP (12-VOLT)	167
KIT-SEAT (BOTTOM)	595	LAMP (12-VOLT, 10-WATT)	122
	596		124
KIT-SENSOR (AIR PRESSURE)	80	LAMP (12-VOLT, 21-WATT)	118
KIT-SPIDER	212		119
	215		120
	218		121
KIT-SPIDER & BEARING	245		125
			126
		LAMP (12-VOLT, 5-WATT)	118
KIT-STOP (SUSPENSION SEAT)	594		119
	595		120
	596		121
KIT-TILT LEVER	333		125
KIT-VALVE (FLOW REGULATOR)	441		126
KIT-VALVE (FLOW REGULATOR)	430	LAMP (12-VOLT, 55-WATT)	117
KIT-VALVE (PRIORITY)	430	LAMP (12-VOLT, 55-WATT, HID)	127
KIT-VALVE (SHUTTLE)	430	LAMP (24-VOLT, 10-WATT)	124
	441	LENS (AMBER) (DIRECTION)	125
KIT-WEIGHT ADJUSTER (SUSPENSION SEAT)	594		126
	595	LENS AS (HEADLIGHT)	120
KNOB GP-STEERING	324		121
		LENS (RED) (FOG)	126
		LENS (RED) (STOP, TAIL)	125
			126
		LENS (WHITE) (REVERSE)	125
LAMP AS (RED, GREEN, LED, 12-VOLT)	115	LEVELING AR-FRAME	297
	116	LEVER AS	310
LAMP AS (12-VOLT)	199		316
	202	LEVER GP-HAND CONTROL	315
LAMP GP-DOME	167	LEVER GP-HAND CONTROL- PARKING BRAKE	314
LAMP GP-FLOOD-CAB	117	LIFTING GP-ENGINE	36
LAMP GP-FLOOD (12-VOLT) (LH)	128	LIGHTING GP-FLOOD	128
LAMP GP-FLOOD (12-VOLT) (RH)	128	LIGHTING GP-FLOOD-BOOM	128
LAMP GP-HEAD & SIGNAL-LH	119	LIGHTING GP-FLOOD-CAB	129
	121	LIGHTING GP-FRONT-LH DIP	133
LAMP GP-HEAD & SIGNAL-RH	118		
	120		

L