



# Parts Manual

---

## **TH330B Telehandler**

---

S/N TBG00100 thru TBG00867



# Product and Dealer Information

Note: For product identification plate locations, see the section "Product Identification Information" in the Operation and Maintenance Manual.

Delivery Date: \_\_\_\_\_

## Product Information

Model: \_\_\_\_\_

Product Identification Number: \_\_\_\_\_

Engine Serial Number: \_\_\_\_\_

Transmission Serial Number: \_\_\_\_\_

Generator Serial Number: \_\_\_\_\_

Attachment Serial Numbers: \_\_\_\_\_

Attachment Information: \_\_\_\_\_

Customer Equipment Number: \_\_\_\_\_

Dealer Equipment Number: \_\_\_\_\_

## Dealer Information

Name: \_\_\_\_\_ Branch: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Dealer Contact

Phone Number

Hours

Sales: \_\_\_\_\_

Parts: \_\_\_\_\_

Service: \_\_\_\_\_



## EFFECTIVITY PAGE

July 14, 2006 - A - Original issue of manual.

February 2, 2007 - B - Revised Manual, added Tier III engine information (Section C).

July 11, 2008 - C - Revised Manual

# EFFECTIVITY PAGE

**S/N TBG00347 TO TBG00867**  
**TIER III ENGINE INFORMATION LOCATED IN SECTION C**

**This Page Intentionally Left Blank**





# TABLE OF CONTENTS


Name	Page	Name	Page
SWITCH GP-AUXILIARY	171	ENCLOSURE GP-ENGINE	299
SWITCH GP-DIFFERENTIAL LOCK	172	FENDER & MOUNTING GP	303
SWITCH GP-DISCONNECT	173	FRAME GP	304
SWITCH GP-ROCKER	174	FRAME GP-MAIN	307
WIRING GP-AIR CONDITIONER	176	GUARD GP-BOTTOM	308
WIRING GP-AUXILIARY	179	GUARD GP-ENGINE	309
WIRING GP-BOOM	180	HITCH AR	313
WIRING GP-CAB	181	HITCH GP	314
WIRING GP-CHASSIS	199	HITCH GP-TOWING	320
WIRING GP-COUPLER	203	HOOD GP	328
WIRING GP-ELECTRONIC CONTROL	206	PANEL GP-SOUND SUPPRESSION	332
WIRING GP-ENGINE	208	PIN GP-HITCH	336
WIRING GP-FAN	211	REFLECTOR GP	337
WIRING GP-TRAILER	213		
WIRING GP-TRANSMISSION CONTROL	214	<b>BRAKING SYSTEM</b>	340
<b>POWER TRAIN</b>	215	CONTROL GP-PARKING BRAKE	340
AXLE & MOUNTING GP	215	CONTROL GP-SERVICE BRAKE	342
AXLE AR	217	CYLINDER GP-BRAKE	343
AXLE GP-DRIVE & STEERING	218	LEVER GP-HAND CONTROL	345
AXLE GP-FRONT	224	LEVER AS	347
CLUTCH GP	227	LEVER GP-HAND CONTROL	349
COUNTERSHAFT		LINES GP-SERVICE BRAKE	350
GP-TRANSMISSION	229	MOUNTING GP-CABLE	353
DIFFERENTIAL & BEVEL GEAR GP	230	<b>STEERING SYSTEM</b>	355
DIFFERENTIAL GP	236	CYLINDER GP-STEERING	355
DRIVE GP-FLEXIBLE COUPLING	238	KNOB GP-STEERING	356
FILTER & MTG GP-POWER TRAIN	239	LINES GP-STEERING	357
FILTER GP-OIL	240	STEERING COLUMN GP	360
FLANGE GP-WHEEL	241	STEERING GP-HYDRAULIC	366
GEAR GP-BEVEL & PINION	242	<b>HYDRAULIC SYSTEM</b>	367
HOUSING & FLANGE GP-AXLE	243	COOLER & MTG GP-HYDRAULIC OIL	367
HOUSING GP-AXLE	247	COOLER GP-HYDRAULIC OIL	369
LINES GP-DIFFERENTIAL LOCK	251	CYLINDER & MTG GP-BOOM	370
LINES GP-TRANSMISSION OIL	252	CYLINDER & MTG GP-CARRIAGE	372
PLANETARY GP-FINAL DRIVE	254	CYLINDER & MTG	
POWER TRAIN AR	255	GP-COMPENSATING	374
SHAFT GP-DRIVE	255	CYLINDER & MTG GP-COUPLER	375
SHAFT GP-INPUT	258	CYLINDER & MTG GP-TELESCOPING	376
SHAFT GP-OUTPUT	259	CYLINDER & MTG GP-TILT	377
SHAFT GP-PUMP DRIVE	261	CYLINDER & VALVE GP-BOOM	378
TIRE & RIM GP	262	CYLINDER & VALVE GP-TELESCOPE	379
TRANSMISSION AR	270	CYLINDER & VALVE GP-TILT	380
TRANSMISSION GP	271	CYLINDER GP-BOOM	381
VALVE GP-TIRE	281	CYLINDER GP-CARRIAGE	382
WHEEL AR	282	CYLINDER GP-COMPENSATING	383
		CYLINDER GP-COUPLER	384
<b>FRAME AND BODY</b>	287	CYLINDER GP-HITCH	385
BRACE GP-CYLINDER	287	CYLINDER GP-MULTIPURPOSE	
BRACE GP-LIFT CYLINDER	288	BUCKET	386
CONVERSION AR-ROADING	289	CYLINDER GP-TELESCOPING	388
CONVERSION GP-ROADING	295	CYLINDER GP-TILT	389
COVER GP-ACCESS	297	DRAIN GP-ECOLOGY	390
DOOR GP-ACCESS	298	FITTING GP-HYDRAULIC	391

# TABLE OF CONTENTS

Name	Page	Name	Page
HYDRAULIC AR . . . . .	392	CARRIAGE GP-ROTATING . . . . .	488
HYDRAULIC AR-AUXILIARY . . . . .	392	CARRIAGE GP-SIDESHIFT . . . . .	491
HYDRAULIC AR-TRAILER . . . . .	393	CLAM AS-MULTIPURPOSE BUCKET . . . . .	492
LINES GP-AUXILIARY HYDRAULIC . . . . .	394	COUPLER GP-QUICK . . . . .	493
LINES GP-BOOM . . . . .	396	EDGE GP-CUTTING . . . . .	496
LINES GP-CHASSIS . . . . .	398	FORK GP-BLOCK . . . . .	499
LINES GP-CONNECTING . . . . .	399	FORK GP-GRAPPLE . . . . .	500
LINES GP-COUPLER . . . . .	409	FORK GP-PALLET . . . . .	502
LINES GP-HYDRAULIC . . . . .	410	GUARD GP-BUCKET . . . . .	505
LINES GP-HYDRAULIC FAN . . . . .	412	GUARD GP-FORK . . . . .	508
LINES GP-MULTIPURPOSE BUCKET . . . . .	413	HANDLER AR-BALE . . . . .	510
LINES GP-PUMP . . . . .	417	HANDLER GP-BALE . . . . .	512
LINES GP-TRAILER . . . . .	422	HOOK GP-LIFTING . . . . .	514
MOTOR & MTG GP-HYDRAULIC FAN . . . . .	424	HOPPER GP . . . . .	515
MOUNTING GP-CYLINDER . . . . .	425	PLATE GP-CARRIAGE . . . . .	516
PUMP & MTG GP-HYDRAULIC . . . . .	426		
PUMP & MTG GP-HYDRAULIC FAN . . . . .	427	<b>OPERATOR STATION . . . . .</b>	<b>517</b>
PUMP GP-PISTON . . . . .	429	ACCUMULATOR GP-REFRIGERANT . . . . .	517
ROTATING GP-PUMP . . . . .	430	AIR CONDITIONER & MOUNTING GP . . . . .	519
TANK & MTG GP-HYDRAULIC . . . . .	431	AIR CONDITIONER AR . . . . .	521
TANK GP-HYDRAULIC . . . . .	433	AIR CONDITIONER GP . . . . .	522
VALVE & MTG GP-CONTROL . . . . .	435	ARMREST GP . . . . .	524
KIT-HYDRAULIC . . . . .	439	BOX GP-STORAGE . . . . .	525
VALVE & MTG GP-DIVERTER . . . . .	440	CAB AR-ENCLOSED ROPS . . . . .	526
VALVE & MTG GP-MAIN CONTROL . . . . .	443	CAB AR-OPEN ROPS . . . . .	528
VALVE GP-BANK 4 . . . . .	445	CAB GP-ENCLOSED ROPS □ □ □ □ □ □ □ □ □ □	529
VALVE GP-COMBINATION . . . . .	448	CAB GP-OPEN ROPS □ □ □ □ □ □ □ □ □ □	532
VALVE GP-CONTROL . . . . .	449	COMPRESSOR GP-REFRIGERANT . . . . .	534
VALVE GP-DIVERTER . . . . .	452	CONDENSER & MTG GP-REFRIGERANT . . . . .	537
VALVE GP-MANIFOLD . . . . .	454	CONTROL GP-ACCELERATION . . . . .	538
		CONTROL GP-AIR CONDITIONER . . . . .	539
<b>IMPLEMENTS . . . . .</b>	<b>456</b>	CONTROL GP-HANDLE . . . . .	540
BOOM AR . . . . .	456	CONTROL GP-JOYSTICK . . . . .	541
BOOM GP □ . . . . . □ . . . . . □	458	CONTROL GP-TRANSMISSION . . . . .	543
GUIDE GP-LINES . . . . . □ . . . . . □	461	CONVERSION AR-AIR CONDITIONER . . . . .	544
INDICATOR GP-RADIUS & ANGLE □ □ □ □ □ □ □ □ □ □	463	COVER GP-CAB . . . . .	545
INSTALLATION AR-LOAD SNSR IND . . . . .	464	DOOR GP-CAB . . . . .	546
LINKAGE GP-WORK TOOL . . . . .	465	DUCT GP-AIR . . . . .	552
STOP GP-BOOM . . . . .	466	GUARD GP-WINDOW . . . . .	555
JD HYDRAULIC COUPLER . □ □ □ □ □ □ □ □ □ □	466a	HAMMER & MOUNTING GP . . . . .	556
<b>WORK TOOLS . . . . .</b>	<b>467</b>	HEATER & MTG GP-CAB . . . . .	557
ARM GP-MATERIAL HANDLING . . . . .	467	HEATER GP-CAB . . . . .	559
BOOM GP-TRUSS . . . . .	468	HORN GP-ELECTRIC . . . . .	564
BUCKET AR-GENERAL PURPOSE . . . . .	469	INSTALLATION GP-RADIO . . . . .	565
BUCKET AR-GRAPPLE . . . . .	470	LINER GP-CAB . . . . .	566
BUCKET AR-MULTIPURPOSE . . . . .	471	LINES GP-AIR CONDITIONER . . . . .	567
BUCKET AS-LIGHT MATERIAL . . . . .	473	LINES GP-HEATER . . . . .	569
BUCKET GP-GRAPPLE . . . . .	476	MIRROR GP . . . . .	571
BUCKET GP-LIGHT MATERIAL . . . . .	478	MIRROR GP-REAR VIEW . . . . .	572
BUCKET GP-MATERIAL HANDLING . . . . .	481	MOTOR GP-WINDOW WIPER . . . . .	580
BUCKET GP-MULTIPURPOSE . . . . .	482	MOUNTING GP-CAB . . . . .	582
BULLDOZER AS . . . . .	483	PANEL GP-INSTRUMENT . . . . .	583
BUCKET AS . . . . .	484	SCREEN GP-SUN . . . . .	585
CARRIAGE AR-FORK . . . . .	485	SEAT BELT GP . . . . .	586
CARRIAGE GP-FORK . . . . .	486		

# TABLE OF CONTENTS

Name	Page	Name	Page
SEAT GP .....	588		
SEAT GP-SUSPENSION .....	590		
TANK GP-WINDOW WASHER .....	592		
TRIM GP-CAB .....	593		
WINDOW GP-CAB .....	601		
WIPER & WASHER GP-WINDOW .....	602		
<b>SERVICE EQUIPMENT AND SUPPLIES</b> .....	<b>606</b>		
BRACKET GP-TRANSPORT .....	606		
CHART GP-LIFT/LOAD EXTENSION .....	607		
FILM GP .....	608		
GREASE GUN GP .....	615		
PLATE & FILM GP .....	616		
PLATE GP-IDENTIFICATION .....	671		
<b>PART NUMBER INDEX</b> .....	<b>B1</b>		
<b>TIER III</b> .....	<b>C1</b>		



# MAINTENANCE PARTS

DESCRIPTION	PART NUMBER	QTY	WHERE USED	PAGE
<b>AIR INLET AND EXHAUST SYSTEM</b>				
FILTER ELEMENT AS-AIR (PRIMARY)	206-5234	1	AIR CLEANER GP	87
FILTER ELEMENT AS-AIR (SECONDARY)	206-5235	1	AIR CLEANER GP	87
<b>BASIC ENGINE</b>				
BELT-SERPENTINE	236-3842	1	BELT GP-SERPENTINE	14
BELT-SERPENTINE (SERPENTINE)	257-5523	1	BELT GP-SERPENTINE	15
CAP AS (ENGINE OIL FILLER)	136-3608	1	COVER GP-VALVE MECHANISM	22
GASKET (VALVE COVER)	225-6451	1	COVER GP-VALVE MECHANISM	22
HOSE (CRANKCASE BREATHER)	198-9169	1	COVER GP-VALVE MECHANISM	22
PLUG-DRAIN (ENGINE OIL)	7C-0351	2	PAN GP-OIL	50
		2	PAN GP-OIL	52
<b>COOLING SYSTEM</b>				
BELT GP-SERPENTINE	236-3841	1	FAN AR-SUCTION	69
	266-6990	1	FAN AR-REVERSIBLE	68
CONNECTION GP-WATER (TEMPERATURE REGULATOR)	254-2269	1	CONNECTION GP-WATER	63
<b>ELECTRICAL AND STARTING SYSTEM</b>				
BATTERY (12-VOLT, MAINTENANCE FREE)	3T-5760	2	BATTERY & WIRING GP	119
BATTERY (12-VOLT, 900-AMPERE)	9X-3404	1	BATTERY & WIRING GP	117
BELT-DRIVE	9X-8139	1	LAMP GP-WARNING BEACON	148
BLOCK-MINIFUSE	124-9636	2	WIRING GP-CAB	185
		2	WIRING GP-CAB	194
		2	WIRING GP-CAB	197
CIRCUIT BREAKER AS (120-AMPERE)	216-4970	1	WIRING GP-ENGINE	208
CIRCUIT BREAKER AS (135-AMPERE)	171-2213	1	ALTERNATOR GP-CHARGING	114
CIRCUIT BREAKER AS (60-AMPERE)	171-2208	1	WIRING GP-ENGINE	208
ELEMENT AS-JACKET WATER HEATER	219-3271	1	HEATER GP-JACKET WATER	128
ELEMENT AS-JACKET WATER HEATER (120-VOLT, 1000-WATT)	219-3273	1	HEATER GP-JACKET WATER	129
FUSE (10-AMPERE)	3K-8782	1	LAMP GP-WARNING BEACON	148
	113-8490	21	PANEL GP-FUSE	163
FUSE (15-AMPERE)	113-8491	7	PANEL GP-FUSE	163
FUSE (20-AMPERE)	113-8492	2	PANEL GP-FUSE	163
	232-6312	1	WIRING GP-ENGINE	208
FUSE (25-AMPERE)	113-8493	1	PANEL GP-FUSE	163
GASKET	111-7899	1	WIRING GP-CAB	182
GLOW PLUG (12-VOLT)	232-6662	4	GLOW PLUG GP	125
KEY AS-ELECTRONIC (SECURITY)	206-5162	2	ELECTRONICS GP-MACHINE	123
		1	INSTALLATION GP-SECURITY	134
		2	SERVICE GP-MACHINE	168
	206-5165	1	INSTALLATION GP-SECURITY	134
KEY (BATTERY DISCONNECT)	8H-5306	1	SWITCH GP-DISCONNECT	173
LAMP AS (RED, GREEN, LED, 12-VOLT)	165-5655	1	INSTALLATION GP-SECURITY	134

# MAINTENANCE PARTS

DESCRIPTION	PART NUMBER	QTY	WHERE USED	PAGE
			1 INSTALLATION GP-SECURITY	135
LAMP GP-FLOOD (12-VOLT) (LH)	212-9348		1 LIGHTING GP-FLOOD	152
LAMP GP-FLOOD (12-VOLT) (RH)	212-9349		1 LIGHTING GP-FLOOD	152
LAMP GP-HEAD & SIGNAL (HIGH, LOW BEAM, LH)	195-0190		1 MOUNTING GP-LIGHTING	161
LAMP GP-HEAD & SIGNAL (HIGH, LOW BEAM, RH)	195-0199		1 MOUNTING GP-LIGHTING	161
LAMP GP-WARNING BEACON (MAGNETIC MOUNT)	185-7016		1 LAMP GP-WARNING BEACON	148
LAMP HEAD	9W-3324		1 LAMP GP-HEAD & SIGNAL	139
			1 LAMP GP-HEAD & SIGNAL	140
			1 LAMP GP-HEAD & SIGNAL	141
			1 LAMP GP-HEAD & SIGNAL	142
LAMP (12-VOLT)	210-8754		1 WIRING GP-CAB	181
LAMP (12-VOLT, 10-WATT)	195-9712		1 LAMP GP-REGISTRATION PLATE	143
LAMP (12-VOLT, 21-WATT)	9W-3326		2 LAMP GP-STOP & TAIL	146
			2 LAMP GP-STOP & TAIL	147
	226-4560		1 LAMP GP-HEAD & SIGNAL	139
			1 LAMP GP-HEAD & SIGNAL	140
			1 LAMP GP-HEAD & SIGNAL	141
			1 LAMP GP-HEAD & SIGNAL	142
LAMP (12-VOLT, 5-WATT)	084-4348		1 LAMP GP-STOP & TAIL	146
			1 LAMP GP-STOP & TAIL	147
	226-4561		1 LAMP GP-HEAD & SIGNAL	139
			1 LAMP GP-HEAD & SIGNAL	140
			1 LAMP GP-HEAD & SIGNAL	141
			1 LAMP GP-HEAD & SIGNAL	142
LAMP (12-VOLT, 55-WATT)	9W-0607		1 LAMP GP-FLOOD	136
LAMP (12-VOLT, 55-WATT, HID)	9X-8118		1 LAMP GP-WARNING BEACON	148
LENS (AMBER) (DIRECTION)	209-3090		1 LAMP GP-STOP & TAIL	146
			1 LAMP GP-STOP & TAIL	147
LENS AS (HEADLIGHT)	228-6050		1 LAMP GP-HEAD & SIGNAL	141
			1 LAMP GP-HEAD & SIGNAL	142
LENS (RED) (FOG)	209-3092		1 LAMP GP-STOP & TAIL	147
LENS (RED) (STOP, TAIL)	209-3093		1 LAMP GP-STOP & TAIL	146
			1 LAMP GP-STOP & TAIL	147
LENS (WHITE) (REVERSE)	209-3091		1 LAMP GP-STOP & TAIL	146
LOCK-MINIFUSE	124-9637		2 WIRING GP-CAB	185
			2 WIRING GP-CAB	193
			2 WIRING GP-CAB	197
<b>ENGINE ARRANGEMENT</b>				
FILTER AS-ENGINE OIL	7W-2326		1 ENGINE AR-PRIMARY	10
			1 ENGINE AR-PRIMARY	11
<b>FRAME AND BODY</b>				
REFLECTOR	9R-1499		2 REFLECTOR GP	337
<b>FUEL SYSTEM</b>				
CAP AS-FILLER (FUEL)	295-3350		1 TANK GP-FUEL	112
FILTER ELEMENT AS-FUEL	1R-1804		1 PUMP GP-FUEL TRANSFER & FILTER	107

# MAINTENANCE PARTS

DESCRIPTION	PART NUMBER	QTY	WHERE USED	PAGE
<b>HYDRAULIC SYSTEM</b>				
CAP AS-FILLER (HYDRAULIC TANK)	142-8937	1	TANK GP-HYDRAULIC	433
FILTER-BREATHER (HYDRAULIC BREATHER)	9R-9925	1	TANK GP-HYDRAULIC	433
FILTER (FLOW REGULATOR)	227-1197	1	VALVE GP-BANK 4	445
		1	VALVE GP-MANIFOLD	454
STRAINER (HYDRAULIC)	202-5350	1	TANK GP-HYDRAULIC	433
<b>LUBRICATION SYSTEM</b>				
FILTER AS-ENGINE OIL	7W-2326	1	FILTER GP-ENGINE OIL	59
<b>OPERATOR STATION</b>				
BELT (AC)	190-8143	1	COMPRESSOR GP-REFRIGERANT	535
BELT-SERPENTINE	226-0443	1	COMPRESSOR GP-REFRIGERANT	536
BLADE AS-WIPER	6V-5851	1	WIPER & WASHER GP-WINDOW	604
BLADE AS-WIPER (FRONT WINDOW)	295-3465	1	WIPER & WASHER GP-WINDOW	602
BLADE AS-WIPER (ROOF)	6W-3924	1	WIPER & WASHER GP-WINDOW	602
CAP-VENTED (WINDOW WASHER RESERVOIR)	8E-8292	1	TANK GP-WINDOW WASHER	592
FILTER-AIR (CAB)	116-7376	1	DUCT GP-AIR	552
	201-5023	1	DUCT GP-AIR	552
		1	HEATER GP-CAB	561
<b>POWER TRAIN</b>				
BREATHER (AXLE)	253-5024	1	AXLE GP-DRIVE & STEERING	222
BREATHER (AXLE, FRONT)	253-5024	1	AXLE GP-DRIVE & STEERING	218
		1	AXLE GP-FRONT	224
FILTER AS-OIL (ADVANCED EFFICIENCY) (POWER TRAIN)	1G-8878	1	FILTER GP-OIL	240
PLUG AS-DRAIN (MAGNETIC)	152-6144	3	AXLE GP-DRIVE & STEERING	222
		4	AXLE GP-FRONT	224
		4	AXLE GP-DRIVE & STEERING	218
PLUG AS-DRAIN (MAGNETIC) (DIFFERENTIAL)	152-6144	1	DIFFERENTIAL & BEVEL GEAR GP	230
PLUG-MAGNETIC	5P-4484	1	TRANSMISSION GP	272
		1	TRANSMISSION GP	279



# INDEX

Name	Page	Name	Page
<b>A</b>			
ACCUMULATOR GP-REFRIGERANT- WITH DESICCANT .....	517	BOX GP-STORAGE .....	525
	518	BRACE GP-CYLINDER .....	287
AFTERCOOLER GP-AIR .....	81	BRACE GP-LIFT CYLINDER .....	288
AIR CLEANER GP .....	86	BRACKET GP-MOUNTING .....	290
	87	BRACKET GP-TRANSPORT .....	606
AIR CONDITIONER & MOUNTING GP .....	519	BRAKE GP-HYDRAULIC CALIPER .....	218
AIR CONDITIONER AR .....	521		224
AIR CONDITIONER GP .....	522	BREATHER (AXLE) .....	222
ALTERNATOR GP-CHARGING .....	114	BREATHER (AXLE, FRONT) .....	218
ALTERNATOR GP-CHARGING-105-AMPERE ...	116		224
ARM GP-MATERIAL HANDLING .....	467	BUCKET AR-GENERAL PURPOSE .....	469
ARMREST GP-ADJUSTABLE .....	524	BUCKET AR-GRAPPLE .....	470
AXLE & MOUNTING GP-FRONT .....	215	BUCKET AR-MULTIPURPOSE .....	471
	217		472
AXLE & MOUNTING GP-REAR .....	216	BUCKET AS .....	484
AXLE AR .....	217	BUCKET AS-LIGHT MATERIAL .....	473
AXLE GP-DRIVE & STEERING-FRONT .....	218		474
AXLE GP-DRIVE & STEERING-REAR .....	222		475
AXLE GP-DRIVE & STEERING (FRONT) .....	215	BUCKET GP-GRAPPLE .....	476
AXLE GP-DRIVE & STEERING (REAR) .....	216	BUCKET GP-LIGHT MATERIAL .....	478
AXLE GP-FRONT .....	224		479
			480
		BUCKET GP-MATERIAL HANDLING .....	481
		BUCKET GP-MULTIPURPOSE .....	482
		BULLDOZER AS .....	483
<b>B</b>			
BATTERY & WIRING GP-DUAL BATTERY .....	119	<b>C</b>	
BATTERY & WIRING GP- WITHOUT DISCONNECT SWITCH .....	117	CAB AR-ENCLOSED ROPS- POWERSYNCHRO .....	526
BATTERY (12-VOLT, MAINTENANCE FREE) ...	119		527
BATTERY (12-VOLT, 900-AMPERE) .....	117	CAB AR-OPEN ROPS-POWERSYNCHRO .....	528
BELT (AC) .....	535	CAB GP-ENCLOSED ROPS .....	529
BELT-DRIVE .....	148	CAB GP-OPEN ROPS .....	532
BELT GP-SERPENTINE .....	14	CABLE GP .....	313
	15	CAMSHAFT GP .....	17
	68	CAP AS (ENGINE OIL FILLER) . . . . .	22
	69		
BELT-SERPENTINE .....	14	CAP AS-FILLER (FUEL) .....	112
	536	CAP AS-FILLER (HYDRAULIC TANK) .....	433
BELT-SERPENTINE (SERPENTINE) .....	15	CAP-VENTED (WINDOW WASHER RESERVOIR) .....	592
BELT TENSIONER GP .....	16	CARRIAGE AR-FORK-SIDESHIFT .....	485
BLADE AS-WIPER .....	604	CARRIAGE GP-FORK .....	487
BLADE AS-WIPER (FRONT WINDOW) .....	602	CARRIAGE GP-FORK-STANDARD .....	486
BLADE AS-WIPER (ROOF) .....	602	CARRIAGE GP-ROTATING-STANDARD .....	490
BLOCK-MINIFUSE .....	185	CARRIAGE GP-ROTATING-WIDE, 4/5 TINE ...	488
	194	CARRIAGE GP-SIDESHIFT .....	491
	197	CARRIER GP-FORK .....	488
			490
BOOM & CHASSIS AR .....	1	CHART GP-LIFT/LOAD EXTENSION .....	607
BOOM AR .....	456	CHASSIS AR .....	2
		CIRCUIT BREAKER AS (120-AMPERE) .....	208
BOOM GP-HEAD SECTION .....	459	CIRCUIT BREAKER AS (135-AMPERE) .....	114
BOOM GP-SECTION 1 .....	458	CIRCUIT BREAKER AS (60-AMPERE) .....	208
BOOM GP-TRUSS .....	468		

# INDEX

Name	Page	Name	Page
CLAM AS-MULTIPURPOSE BUCKET .....	492	COOLER GP-FLTR BASE & ENG OIL .....	67
CLUTCH GP-FORWARD/REVERSE .....	227	COOLER GP-HYDRAULIC OIL .....	368
COIL AS-SOLENOID (12-VOLT) .....	271	COOLER-OIL (ENGINE) .....	369
COMMON AR .....	2	COOLING AR-HIGH AMBIENT TEMP-	
COMPRESSOR GP-REFRIGERANT .....	534	OIL COOLER .....	68
	535	COUNTERSHAFT GP-TRANSMISSION .....	229
	536	COUNTERSHAFT GP-TRANSMISSION-	
CONDENSER & MTG GP-REFRIGERANT .....	537	5-SPEED POWERSYNCR0 .....	229
CONDENSER GP-REFRIGERANT .....	537	COUPLER GP-QUICK .....	493
CONFIGURATION AR .....	3	COUPLER GP-QUICK-HYDRAULIC .....	494
CONNECTION GP-ELECTRICAL-			495
DIVERter VALVE .....	121	COVER GP-ACCESS-	
CONNECTION GP-WATER . . . . .	63	MAIN CONTROL VALVE .....	297
CONNECTION GP-WATER		COVER GP-CAB .....	545
(TEMPERATURE REGULATOR) .....	63	COVER GP-FRONT HOUSING .....	18
CONNECTOR GP-ELECTRONIC .....	1		19
CONTROL & MTG GP-MACHINE .....	122	COVER GP-VALVE MECHANISM . . . . .	22
CONTROL GP-ACCELERATION .....	538	CRANKSHAFT GP .....	24
CONTROL GP-AIR CONDITIONER .....	176	CYLINDER & MTG GP-BOOM .....	370
	178	CYLINDER & MTG GP-CARRIAGE-FORK .....	372
	539	CYLINDER & MTG GP-CARRIAGE-	
CONTROL GP-ENGINE ELECTRONIC .....	101	ROTATING .....	373
	104	CYLINDER & MTG GP-COMPENSATING .....	374
CONTROL GP-HANDLE-DUAL AUXILIARY .....	540	CYLINDER & MTG GP-COUPLER .....	375
CONTROL GP-JOYSTICK .....	541	CYLINDER & MTG GP-TELESCOPING .....	376
	542	CYLINDER & MTG GP-TILT .....	377
CONTROL GP-PARKING BRAKE .....	340	CYLINDER & VALVE GP-BOOM .....	378
CONTROL GP-SERVICE BRAKE .....	342	CYLINDER & VALVE GP-TELESCOPE .....	379
CONTROL GP-TRANSMISSION-		CYLINDER & VALVE GP-TILT .....	380
POWERSYNCR0 .....	543	CYLINDER BLOCK GP .....	26
CONTROL GP-UNPROGRAMMED			28
(MACHINE) .....	124	CYLINDER GP-BOOM .....	381
CONTROL GP-UNPROGRAMMED		CYLINDER GP-BRAKE-LH .....	344
(SEcurity) .....	168	CYLINDER GP-BRAKE-RH .....	343
CONVERSION AR-AIR CONDITIONER .....	544	CYLINDER GP-BRAKE (MASTER) .....	342
CONVERSION AR-MACHINE-KIT .....	3	CYLINDER GP-CARRIAGE-SIDESHIFT .....	382
CONVERSION AR-ROADING-EAME .....	289	CYLINDER GP-COMPENSATING .....	383
	294	CYLINDER GP-COUPLER .....	384
CONVERSION AR-ROADING-FRANCE .....	289	CYLINDER GP-GRAPPLE (FORK) .....	501
	293	CYLINDER GP-GRAPPLE (LH) .....	476
CONVERSION AR-ROADING-GERMANY .....	289	CYLINDER GP-GRAPPLE (RH) .....	476
	292	CYLINDER GP-HITCH .....	385
CONVERSION AR-ROADING-ITALY .....	290	CYLINDER GP-HYDRAULIC .....	512
	294	CYLINDER GP-MULTIPURPOSE BUKT .....	386
CONVERSION AR-ROADING-		CYLINDER GP-STEERING .....	355
UK AND IRELAND .....	293	CYLINDER GP-TELESCOPING .....	388
CONVERSION GP-ROADING-GERMANY .....	295	CYLINDER GP-TILT .....	389
COOLANT HEATER LINES .....	569	CYLINDER HEAD GP .....	29
	570		30
COOLER & MTG GP-HYDRAULIC OIL .....	367		
	368		
COOLER GP-ENGINE OIL .....	64		
	67		

# INDEX

Name	Page	Name	Page
<b>D</b>			
DIAPHRAGM (CRANKCASE PRESSURE CONTACTOR) □□□□	22	FAN GP-SUCTION-SOUND SUPPRESSION . . . .	70
DIFFERENTIAL & BEVEL GEAR GP-FRONT . . .	232	FASTENER GP-PULLEY . . . . .	35
	234	FASTENER GP-VALVE . . . . .	366
DIFFERENTIAL & BEVEL GEAR GP-REAR . . . .	230	FENDER & MOUNTING GP . . . . .	303
DIFFERENTIAL GP . . . . .	230	FILM . . . . .	506
	236	FILM (AIR CONDITIONER) . . . . .	557
	237	FILM (AUXILIARY HYDRAULICS, READ OMM) . . . .	1
DIFFERENTIAL GP-FRONT . . . . .	236	FILM (AUXILIARY HYDRAULICS, READ OMM) . . . .	616
DOOR GP-ACCESS-SERVICE DOOR . . . . .	298	FILM-CERTIFICATION (ELEVATION) . . . . .	289
DOOR GP-CAB-LOWER . . . . .	547		293
	549	FILM (FUSE & RELAY) . . . . .	163
DOOR GP-CAB-UPPER . . . . .	546	FILM GP-EAME . . . . .	611
	551	FILM GP-IDENTIFICATION . . . . .	608
DRAIN GP-ECOLOGY . . . . .	390	FILM GP-INFORMATION . . . . .	610
DRAIN GP-ENGINE OIL . . . . .	31	FILM GP-JOYSTICK, EUROPEAN MARKET . . . .	610
	32	FILM GP- JOYSTICK, NORTH AMERICAN MARKET . . . .	610
DRIVE GP-FAN . . . . .	33	FILM GP-NACD . . . . .	613
DRIVE GP-FLEXIBLE COUPLING . . . . .	238	FILM-IDENTIFICATION (EIGHT) . . . . .	3
DUCT GP-AIR . . . . .	552	FILM-IDENTIFICATION (FIVE) . . . . .	3
<b>E</b>			
EDGE GP-CUTTING . . . . .	496	FILM-IDENTIFICATION (FOUR) . . . . .	3
	497	FILM-IDENTIFICATION (GROUP NUMBER) . . . .	559
	498	FILM-IDENTIFICATION (GROUP NUMBER) . . . .	522
ELBOW GP-AIR INLET . . . . .	88	FILM-IDENTIFICATION (HEWDEN) . . . . .	3
ELECTRONICS GP-MACHINE . . . . .	124	FILM-IDENTIFICATION (IGNITION SWITCH) . . . .	135
ELECTRONICS GP-MACHINE-SECURITY . . . .	123	FILM-IDENTIFICATION (LOAD RADIUS B) . . . .	463
ELEMENT AS-JACKET WATER HEATER . . . . .	128	FILM-IDENTIFICATION (LOAD RADIUS C) . . . .	463
ELEMENT AS-JACKET WATER HEATER (120-VOLT, 1000-WATT) . . . . .	129	FILM-IDENTIFICATION (NINE) . . . . .	3
ENCLOSURE GP-ENGINE . . . . .	299	FILM-IDENTIFICATION (ONE) . . . . .	3
	310	FILM-IDENTIFICATION (SEVEN) . . . . .	3
ENCLOSURE GP-ENGINE-OUTSIDE NACD . . . .	301	FILM-IDENTIFICATION (SIX) . . . . .	3
ENGINE & TRANSMISSION AR . . . . .	5	FILM-IDENTIFICATION (THREE) . . . . .	3
	6	FILM-IDENTIFICATION (TH330B) . . . . .	288
	7	FILM-IDENTIFICATION (TWO) . . . . .	3
	8	FILM-IDENTIFICATION (ZERO) . . . . .	3
	9	FILM-IDENTIFICATION (20-KM/H) . . . . .	292
ENGINE AR-PRIMARY . . . . .	10	FILM-IDENTIFICATION (40-KM/H) . . . . .	289
	11		292
		FILM-INDICATOR (BOOM ANGLE) . . . . .	463
		FILM-INDICATOR (BUCKET LEVEL) . . . . .	471
		FILM-INSTRUCTION (BOOM HEIGHT, ROADING) . . . . .	295
		FILM-INSTRUCTION (MACHINE SECURITY, READ OMM) . . . . .	134
			135
		FILM-LOAD CHART . . . . .	607
		FILM-PANEL (AIR CONDITIONER CONTROL) . . . .	519
			562
FAN AR-REVERSIBLE- WITH AIR CONDITIONER . . . . .	68	FILM-RATING (LOAD) . . . . .	467
FAN AR-REVERSIBLE- WITHOUT AIR CONDITIONER . . . . .	68	FILM (REFLECTOR) . . . . .	290
FAN AR-SUCTION-WITH AIR CONDITIONER . . .	69		507
FAN AR-SUCTION- WITHOUT AIR CONDITIONER . . . . .	69		508
<b>F</b>			

# INDEX

Name	Page	Name	Page
FILM-WARNING (BRACE, CRUSH HAZARD, READ OMM) . . . .	288	FITTING GP-HYDRAULIC . . . . .	391
FILM-WARNING (CLEARANCE) . . . . .	165	FLANGE GP-WHEEL . . . . .	241
	293	FLOOR MAT . . . . .	2
FILM-WARNING (CRUSH HAZARD) . . . . .	471	FLYWHEEL GP . . . . .	36
FILM-WARNING (CRUSH HAZARD) . . . . .	515		37
FILM-WARNING (CRUSH HAZARD, FORKS, READ OMM) . . . .	659	FORK GP-BLOCK . . . . .	499
	660	FORK GP-GRAPPLE-LIGHT DUTY . . . . .	500
	661		501
	662	FORK GP-PALLET . . . . .	502
	663		503
	664		504
	665	FRAME GP-ENGINE . . . . .	304
	666		305
	667	FRAME GP-MAIN . . . . .	307
	668	FUSE (10-AMPERE) . . . . .	148
	669		163
	670	FUSE (15-AMPERE) . . . . .	163
FILM-WARNING (CRUSH HAZARD, STAY BACK) . . . . .	510	FUSE (20-AMPERE) . . . . .	163
	611		208
	613	FUSE (25-AMPERE) . . . . .	163
FILM-WARNING (IMPALED POINT) . . . . .	470		
	500	<b>G</b>	
	510	GASKET . . . . .	182
FILM-WARNING (NO ACCESS PLATFORM) . . . .	611	GASKET (VALVE COVER) . . . . .	20
FILM-WARNING (NO ACCESS PLATFORM, READ OMM) . . . .	613		22
FILM-WARNING (NO HANDS, STAY BACK) . . . .	500	GAUGE AS-OIL LEVEL (DIPSTICK) (ENGINE) □□□□	50
FILM-WARNING (NO WELD, NO DRILL, READ OMM) . . . . .	610		52
FILTER & MTG GP-POWER TRAIN . . . . .	239	GAUGE GP-PRESSURE . . . . .	3
FILTER-AIR (CAB) . . . . .	552	GEAR GP-BEVEL & PINION . . . . .	230
	561		242
FILTER AS-ENGINE OIL . . . . .	10	GEAR GP-RING . . . . .	243
	11		244
	59	GLOW PLUG GP . . . . .	125
FILTER AS-OIL (ADVANCED EFFICIENCY) (POWER TRAIN) . . . . .	240	GLOW PLUG (12-VOLT) . . . . .	125
FILTER BASE & ENG OIL COOLER . □ . . . . □ . . . . □	67	GREASE GUN GP . . . . .	3
FILTER-BREATHER (HYDRAULIC BREATHER) . . . . .	433		615
FILTER ELEMENT AS-AIR (PRIMARY) . . . . .	87	GUARD GP-BOTTOM-ENGINE . . . . .	308
FILTER ELEMENT AS-AIR (SECONDARY) . . . . .	87	GUARD GP-BUCKET-FRONT . . . . .	505
FILTER ELEMENT AS-FUEL . . . . .	107		506
FILTER (FLOW REGULATOR) . . . . .	445	GUARD GP-BUCKET-ITALY . . . . .	507
	454	GUARD GP-ENGINE . . . . .	309
FILTER GP-ENGINE OIL . . . . .	10		310
	11	GUARD GP-FORK . . . . .	509
	59	GUARD GP-FORK-ITALY . . . . .	508
	60	GUARD GP-WINDOW . . . . .	555
FILTER GP-OIL-POWER TRAIN . . . . .	240	GUIDE GP-LINES . . . . .	461
FITTING GP . . . . .	113		462
		<b>H</b>	
		HAMMER & MOUNTING GP-CAB . . . . .	556