



LT2138 Tractor  
Air Intake And Filter



LT2138 Tractor  
Air Intake And Filter

Page 2 of 75


Ref #	Part Number	Qty	S/P/F	Description
1	KH-12-755-84	1	S	Kit, Fuel Recovery (Incl. Ref #2-4, 7-10, 12, 15-17)
2	KH-12-041-01	1	/P	Gasket, Carburetor
3	KH-M-0629116	2		Stud, M6 x 1.0 x 116
4	KH-12-041-02	1	/P	Gasket, Air Cleaner
5	KH-12-123-07	1	/P	Tube, Air Cleaner
6	KH-12-094-06	1		Base, Air Cleaner
7	KH-12-041-09	1	/P	Gasket, Collector Plate
8	KH-12-211-02	1		Bolt, Carriage, M6 x 1.0 x 22
9	KH-12-109-08	1		Cup, Fuel Spit Back
10	KH-12-018-06-S	1	/P	Retainer, Ring
11	759-3547	1	S	Element, Air Cleaner
12	KH-24-032-03	1	/P	Seal, Inner Air Cleaner
13	KH-52-083-01	1	S	Pre-Cleaner, Element
14	KH-12-096-37	1		Cover, Air Cleaner Element
15	KH-12-100-01	1	/P	Wingnut, Element Cover
16	KH-12-096-41	1	S	Cover, Air Cleaner Base
17	KH-25-341-03	1	/P	Knob, Air Cleaner Cover



LT2138 Tractor  
Battery, Electrical Components And Switches

Page 4 of 75

Ref #	Part Number	Qty	S/P/F	Description
1	629-3068A	1	S	Wire Harness, Main
2	783-0462	1	/P	Bracket, PTO Switch Retainer
3	710-0936	A/R		Screw, Truss Hd Tapp, #6 x .62
4	629-3072A	1		Wire Harness, S.A.M.
5	710-0237	1	/P	Screw, Hex Cap, 5.16-24 x .625 GR5
6		1		Battery Cable Hardware
	710-3015	2	/P	Screw
	712-0271	2	/P	Sems Nut
7	721-0342	1	S	Gasket, Silicone
8	723-04016	1		Strap, Battery Retainer
9	759-3476A	1	S	Key, Ignition (Set of 2)
10	725-0340	1		Cover, Terminal Black
11	725-1346	1	S	Nut, Ignition Switch
12	725-1347	1	/P	Cap, Ignition Switch
13	725-1365	1	S	Bulb, Indicator
14	725-3243	2		Fuse, 25 Amp
15	725-1648	1	S	Relay
16	725-3007A	1	/P	Cover, Terminal Red
17	725-3159	1	S	Hour Meter
18	725-3284	1	S	Switch, Ignition
19	725-3164A	1	S	Switch, Interlock (Brake)
20	725-3166	1	S	Switch, Snap Mount
21	725-3233	1	S	Switch, PTO
22	725-3166	1	S	Switch, Snap Mount Seat
23	725-3237	1		Cover, Terminal Red
24	736-0607	1	/P	Washer, External Lock, 5/16
25	729-0357	2		Holder, Fuse w/Mounting Clip
26	925-1707D	1	/P	Battery
27	725-3242	1	S	Adapter, PTO Harness
28	725-0157	4	/P	Tie, Self-Clinch Cable
30	726-0154	9	S	Tie, Pushmount
31	726-3055	9		Clip, Cable
32	726-0161	2		Clip, Wire



LT2138 Tractor  
Blower Housing And Baffles

Page 6 of 75

Ref #	Part Number	Qty	S/P/F	Description
1	KH-M-0545010	3	/P	Screw, Hex Flange, M5 x .8 x 10
2	KH-12-063-08	1	/P	Baffle, Cylinder Head
3	KH-M-645016-S	3	/P	Screw, Hex Flange, M5 x .8 x 16
4	KH-25-154-02	3		Clip, Mounting
5	KH-12-063-15-S	1		Baffle, Cylinder
6	KH-12-146-07	1	/P	Plate, Blower Housing
7	KH-12-086-37	3		Screw, w/Washer M5 x .8 x 20
8	KH-12-027-55	1	S	Housing, Blower
9	KH-12-063-10	1		Baffle, Intake Side
10	KH-M-550010-S	2		Screw, Hex Flange, M5 x 0.8 x 10
11	KH-24-468-10	1		Washer, Plain 1/4"

