

# WIRING DIAGRAM

## **DAIHATSU**

---

# **CHARADE**

### **FOREWORD**

This WIRING DIAGRAM describes the electrical wiring diagram for Type HC Engine-mounted vehicle (G102 or G112) and Type CB Engine-mounted vehicle (G100).

As for the inspection or repair method of the each electrical part, please refer to the WORKSHOP MANUAL for ENGINE or CHASSIS.

The contents and specifications in this book may be partly revised without advance notice and without incurring any obligation.

Published in November, 1988

**DAIHATSU MOTOR CO., LTD.**

# SYSTEM INDEX

SYSTEMS	LOCATION		
	TYPE HC-E E/G	TYPE HC-C E/G	TYPE CB E/G
Air Conditioner	1-4	1-5	1-5
Alternator & Regulator	1-1	1-2	1-2
Automatic Transmission ECU	4-2	4-2	4-2
Battery	1-1	1-1	1-1
Central Door Lock	2-7	2-7	2-7
Cigar Lighter	2-5	2-5	2-5
Clock	2-5	2-5	2-5
Combination Meter	3-2	3-2	3-2
Daylight Relay	2-3	2-3	2-3
Dim-dip Relay	2-4	2-4	2-4
Distributor	1-1	1-1	1-1
EFI ECU	7-2	—	4-5 (CB-80)
Electronic Door Mirror	2-6	2-6	2-6
Front Wiper & Washer	3-7	3-7	3-7
Headlamp	2-3	2-3	2-3
Headlamp Cleaner	3-7	3-7	3-7
heater	1-3	1-7	1-7
Horn	3-5	3-5	3-5
Ignition Coil	1-1	1-1	1-1 (except CB-80 and CB-90) 4-3 (CB-80) 5-1 (CB-90)
Luggage Room Lamp	3-6	3-6	3-6
Light-on-Warning Buzzer	3-5	3-5	3-5
Power Window	2-6	2-6	2-6
Radiator Fan Motor	1-6	1-6	1-6
Radio	2-5	2-5	2-5
Rear Window Defogger	3-6	3-6	3-6
Rear Wiper & Washer	3-7	3-7	3-7
Room Lamp	3-7	3-7	3-5
Side lamp	2-1	2-1	2-1
Sun Roof	3-1	3-1	3-1
Starter	1-4	1-1	1-1
Stop Lamp	3-6	3-6	3-6
Turn Signal & Hazard Lamp	3-4	3-4	3-4

(A/C) 30A 1.25B-R  
 ↑ To condenser fan relay (1-4)