

F1000T

Spare parts list

Tracked Paver

F1000T s/n 10002134CEC004555 -

Engine: QSB6.7-C225, IV/T4



General information

Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability. Any unauthorized use or copying of the contents or any part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers, and drawings.

Instructions for use

This spare parts list contains no safety regulations and is merely intended to assist in the ordering of spare parts.

For information about operating, servicing, or repairing, the relevant Safety and operating instructions must be consulted at all costs.

Please observe the safety instructions listed in the relevant Safety and operating instructions!

Contents

F1000T (IV/T4) s/n 10002134CEC004555 -

F1000T (IV/T4) s/n 10002134CEC004555 -	1
--	---

Service, repair and wear part kits

Service kit, track paver, T4i	3
4812269054 Kit, start up, 100 Hrs	5
4812269055 Kit, Maintenance, 500 Hrs	7
4812269056 Kit, Maintenance, 1000 Hrs	9

4812224490 Auger extensions

4812224490 Auger extensions	11
D722182100 Extension, left	13
D722182200 Extension, right	15
D299010014 Kit, Inboard bearing, A	17
4812224489 Auger extensions	19
4812269057 Kit, hopper skirt	21
4812244099 Kit, Hopper skirt - Low version	23
4812269058 Kit, Chain, conveyor drive, track paver	25

4812224488 Auger extensions

4812224488 Auger extensions	27
D722182300 Extension, left	29
D722182400 Extension, right	31
4812269060 Kit, guide, conveyor	33
4812269061 Kit, wear plate	35
4812269062 Kit, sprocket, conveyor	37
4812224504 Screed connecting parts	39
D717954677 Kit, outboard bearing	41
4812269064 Kit, conveyor bearing	43
4812269086 Kit, rear plate, wheel	45
4812269087 Kit, rear plate, track	47
Auger lubrication	49
4812222082 Key	51
4812269105 Kit, Auger reinforcement	53
D717955090 Uptime kit	55

Frame assembly, 10' crawler paver

Frame assembly, 10' crawler paver	57
Front conveyor cover, assembly	61
Guide pole, assembly	63
Adjustable scraper, assembly	65
Fume extractor, assembly	67
4812222081 Beading, sealing plate	69
4812223634 Cover, air filter, assembly	71

F1000T/W engine system

F1000T/W engine system	73
------------------------	----

Engine system

Engine system	75
---------------	----

Engine part

Engine part	79
4812222043 Air cleaner	81
Hose, engine oil drain	83
Mounting Bracket Assembly	85

Cooling system

Cooling system	87
481222304 Combi cooler	91
Exhaust system	93

Platform, assembly

Platform, assembly	95
LH operator station, assembly	98
RH operator station, assembly	102
Side doors, platform, assembly	105
Footwell, assembly	107
Divider complete, assembly	109
Cooler shroud, assembly	112
Anti slip tape, assembly	116
Door assembly	119
Foam complete, assembly	123
Seat lock, assembly	126
Hood frame, assembly	129
Storage box	131
Fuel tank, assembly	133

Pump drive, assembly

Pump drive, assembly	137
481220078 Gear box, splitter	142
D717191000 Pump, propel front, assembly	147
D717191500 Pump, propel rear, assembly	158
D717192500 Pump, auger tandem, assembly	170
D717193001 Pump, vibration	180
4812222519 Gear pump, fan drive	183
D717193500 Pump, generator, assembly	185
Fittings, assembly	194

Hydraulic component, assembly

Hydraulic component, assembly	197
D717091001 Auger lift cylinder	203
D717091503 Cylinder, screed level, front	205
D717091501 Cylinder, hopper pivot	207
Accumulator, Track tension circuit	209

Valve bank, rear, work function

Valve bank, rear, work function	211
---	-----

D717091507 Valve bank, rear work function

D717091507 Valve bank, rear work function	213
D717953711 HIC, rear valve	215

Front manifold

Front manifold	217
4812200104 Front manifold	219

HIC assy, propel gearbox & pump

HIC assy, propel gearbox & pump	222
D717090503 HIC,propel gearbox & pump	225

Valve assy, vibration

Valve assy, vibration	227
D717091508 Valve, vibration	229
4812220876 Filter, auger charge oil	231

Assembly, hydraulic tank

Assembly, hydraulic tank	233
------------------------------------	-----

4812220770 Assembly, hydraulic filter tier IV	237
Assembly, tow point indicator	239
Hose kit	241
Case drain manifold assembly	247
Electrical system, assembly	
Electrical System Assembly	249
Generator drive	
Generator drive	253
D717100501 Generator 34kw	255
D717100506 Motor, hydraulic	257
Kit, lovejoy coupling	259
4812246972 Assembly, DC control panel	261
4812223611 Assembly, battery box	
Assembly, battery box	265
4812220887 Battery switch mount	267
4812246958 Assembly, operator console, LH	
4812246958 Assembly, Operator Console LH	269
D717101501 Controller, propel handle	
D717101501 Controller, propel handle	273
4812270342 Maintained center	275
4812246959 Assembly, operator console, RH	
4812246959 Assembly Operator Console RH	277
D717101501 Controller, propel handle	
D717101501 Controller, propel handle	See page 273
4812270342 Maintained center	See page 275
D717104500 Assembly, AC main panel	281
Lighting system Tier IV	283
Auger & conveyor controls	286
Conveyor, assembly	
Conveyor, assembly	289
Assembly, conveyor drive complete	
Assembly, conveyor drive complete	291
Assembly, Motor and gear box	293
Assembly, Drive, conveyor	295
Assembly, tension	297
Assembly, conveyor chain	299
Conveyor lubrication assembly	301
Hopper, assembly 10FT	
Hopper, assembly	303
Hopper assembly, left side	305
Hopper assembly, right side	307
Track, assembly	
Track, assembly	309
Screed leveling guide assembly	311
RH track undercarriage assembly	
RH track undercarriage assembly	313
Drive subassembly	

Drive subassembly	317
D717170600 Gearbox, track drive	319
D717171014 Motor, propel	323
D717170639 Cylinder, track tension	328
Assembly, hub, idler wheel	331
Bogie assembly	333

LH track undercarrage assembly

LH track undercarrage assembly	335
Bogie assembly	See page 333
D717170639 Cylinder, track tension	See page 328
Assembly, hub, idler wheel	See page 331

Drive subassembly

Drive subassembly	See page 317
D717170600 Gearbox, track drive	See page 319
D717171014 Motor, propel	See page 323

Auger, assembly

Auger, assembly	339
-----------------	-----

Auger assembly without flight

Auger assembly without flight	342
-------------------------------	-----

D722180000 Auger

D722180000 Auger	345
D754111500 Pipeline, grease, auger	347
D722181600 Auger	349
D756183300 Auger gear	351
D722183400 Engine support	355
Hose retention, assembly	357
Auger lubrication	See page 49

Screed arm, assembly

Screed arm, assembly	359
Assembly, slope arm	362
Decal installation	365

Accessories

Accessories	370
4812222082 Key	See page 51
D717955090 Uptime kit	See page 55
D717906000 Rooding lights assembly	373
Beacon assembly	375
4812224333 Wash down, assembly	377
D717905000 Auxiliary power panel	379
4812224504 Screed connecting parts	See page 39

4812223939 Push roller crosshead

4812223939 Push roller crosshead	381
4812223943 Roller assembly	383

Optional Equipment

Optional Equipment	385
D717102501 Leveling control	387
4812224489 Auger extensions	See page 19
4812222838 Option, Tunnel extensions kit	389
4812222846 Hand rail assembly	391
4812200293 Front extension screed	393
D717906000 Rooding lights assembly	See page 373

4812224490 Auger extensions

4812224490 Auger extensions See page 11
D722182100 Extension, left See page 13
D722182200 Extension, right See page 15

4812224488 Auger extensions

4812224488 Auger extensions See page 27
D722182300 Extension, left See page 29
D722182400 Extension, right See page 31

4812222847 Kit, wide width paving

4812222847 Kit, wide width paving 395
4812222838 Option, Tunnel extensions kit See page 389
4812224357 Kit, mounting components 398
D722182300 Extension, left See page 29
D722182100 Extension, left See page 13
D722182400 Extension, right See page 31
D722182200 Extension, right See page 15

4812244902 AUS country package

4812244902 AUS country package 402
Assembly, tow point indicator See page 239

Appendix B:Parts Index 405

F1000T (IV/T4) s/n 10002134CEC004555 - F1000T (IV/T4) s/n 10002134CEC004555 -

**NO DRAWING
AVAILABLE
FOR THIS BOM**

Item	Part No.	Name	Qty	L	SN INFO
1	4812200036	Frame, assembly	1		
2		F1000T/W engine system	1		
3		Platform, assembly	1		
4	4812242660	Fuel tank, assembly	1		
5	4812200014	Pump drive, assembly	1		
6		Hydraulic component, assembly	1		
7	4812223607	Electrical system, assembly	1		
8	4812222834	Conveyor, assembly	1		
9	4812223423	Hopper, assembly 10FT	1		
10	4812223300	Track, assembly	1		
11	4812222835	Auger, assembly	1		
12	4812223532	Screed arm, assembly	1		
13	4812200019	Decal installation	1		
14		Accessories	1		
15		Optional Equipment	1		

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Apr 17 01:29:27 MDT 2015

Service, repair and wear part kits Service kit, track paver, T4i

**NO DRAWING
AVAILABLE
FOR THIS BOM**

Item	Part No.	Name	Qty	L	SN INFO
1	4812269054	Kit, startup, 100hr	1		
2	4812269055	Kit, maintenance, 500hr	1		
3	4812269056	Kit, maintenance, 1000hr	1		
4	D299010014	Kit, inboard bearing	1		
5	4812224489	Kit, 11", auger extension	1		
6	4812224490	Kit, 17", auger extension	1		
7	4812224488	Kit, 34", auger extension	1		
8	4812269057	Kit, hopper front	1		
9	4812244099	Kit, hopper skirt-low version	1		
10	4812269058	Kit, chain, conveyor dirve	1		
11	4812269060	Kit, guide. conveyor	1		
12	4812269061	Kit, wear plate	1		
13	4812269062	Kit, sprocket, conveyor	1		
14	4812224504	Kit, screed, disconnect	1		
15	D717954677	Kit, outboard bearing	1		
16	4812269064	Kit, conveyor bearing	1		
17	4812269086	Kit, rear plate, wheel	1		
18	4812269087	Kit, rear plate, track	1		
19	4812200217	Auger lubrication	1		
20	D717955090	Uptime kit	1		
21	4812222082	Key replacement kit	1		
22	4812269105	Kit, Auger reinforcement	1		

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Apr 17 01:29:27 MDT 2015

Service, repair and wear part kits 4812269054 Kit, start up, 100 Hrs

**NO DRAWING
AVAILABLE
FOR THIS BOM**

Item	Part No.	Name	Qty	L	SN INFO
1	4812220916	Pre-fuel filter element	1		
2	4812220918	Fuel filter element	1		
3	4812220885	Filter, replacement	1		
4	4812269104	Kit, seal	1		
5	4812220749	Element, hg pr filter	1		
6	4812269103	Kit, seal	1		
7	D717951135	Kit, seal rkm400	1		
8	4812220771	Element, filter	1		

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Apr 17 01:29:27 MDT 2015

Service, repair and wear part kits 4812269055 Kit, Maintenance, 500 Hrs

**NO DRAWING
AVAILABLE
FOR THIS BOM**

Item	Part No.	Name	Qty	L	SN INFO
1	4812220919	Engine oil filter	1		
2	4812220916	Pre-fuel filter element	1		
3	4812220918	Fuel filter element	1		
4	4812220921	Airfilter main	1		
5	4812220922	Airfilter safety	1		

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Apr 17 01:29:27 MDT 2015

Service, repair and wear part kits 4812269056 Kit, Maintenance, 1000 Hrs


**NO DRAWING
AVAILABLE
FOR THIS BOM**

Item	Part No.	Name	Qty	L	SN INFO
1	4812220919	Engine oil filter	1		
2	4812220916	Pre-fuel filter element	1		
3	4812220918	Fuel filter element	1		
4	4812220921	Airfilter main	1		
5	4812220922	Airfilter safety	1		
6	4812220920	Belt, v-ribbed	1		
7	4812220885	Filter, replacement	1		
8	4812269104	Kit, seal	1		
9	4812220749	Element, hg pr filter	1		
10	4812269103	Kit, seal	1		
11	D717951135	Kit, seal rkm400	1		
12	4812220771	Element, filter	1		

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Apr 17 01:29:28 MDT 2015

4812224490 Auger extensions 4812224490 Auger extensions



Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Apr 17 01:29:28 MDT 2015

Dynapac F1000t Paver Spare Parts List 4812243642

Full download: <http://manualplace.com/download/dynapac-f1000t-paver-spare-parts-list-4812243642/>

Spare parts list

F1000T (IV/T4) s/n 10002134CEC004555 -

Item	Part No.	Name	Qty	L	SN INFO
1	D722182100	Extension, left	1		
2	D722182200	Extension, right	1		

Refer to Parts Online for the most up to date information. The printed information might be outdated.

Fri Apr 17 01:29:28 MDT 2015