Quick Table of Contents			
Introduction	1		
Electric Power System	7		
Heating and Air Conditioning System 25			
Troubleshooting	41		

PART 1: INTRODUCTION Safety Signals

# **PART 1: INTRODUCTION**

# **Safety Signals**

A number of alerting messages are in this manual. Please read and follow them. They are there for your protection and information. These messages can help you avoid injury to yourself and your passengers, and help prevent costly damage to the vehicle.

Key symbols and "signal words" are used to indicate what kind of message is going to follow. Pay special attention to instructions prefaced by symbols and signal words "WARNING," "CAUTION," or "NOTE." Please do not ignore any of these alerts.



#### WARNING:

When you see this symbol and word, the message that follows is especially vital. This signals something that can cause injury or even death. This message will tell you what the hazard is, what can happen if you don't heed the warning, and how to avoid it. For example:



WARNING! Do not carry additional fuel containers in your vehicle. Fuel containers, either full or empty, may leak, explode, and cause or feed a fire. Do not carry extra fuel containers. Even empty ones are dangerous.



CAUTION:


This symbol and word signals something that could damage your vehicle. For example:



CAUTION: Continuing to operate your vehicle with insufficient oil pressure will cause serious engine damage.

Safety Signals PART 1: INTRODUCTION

### NOTE:



NOTE: Pumping the accelerator will not assist in starting the engine.

Please take the time to read these messages when you see them, and remember:

# WARNING!

Something that could cause an injury or even death.

### **CAUTION:**

Something that could cause damage to your vehicle.

# NOTE:

Useful information.