




PARTS BOOK

FOR THE FORD - FERGUSON TRACTOR



JANUARY 1946

Harry Ferguson, Inc.
DETROIT 3, MICHIGAN

for Blanton

600-16

650-16

4-tires

2-tires

✓

13800
2200

13900
29900

194

28

15800

38000

(81)

Copyright 1946

HARRY FERGUSON INC.

INDEX

2N TRACTOR PARTS LIST AND SUPPLEMENT

Group		Page
→	NUMERICAL PARTS INDEX—TRACTOR	2
1	DRIVERS' SEAT and RELATED PARTS	9
2	LIFT COVER and RELATED PARTS	11
3	LIFT SHAFT and RELATED PARTS	13
4	HYDRAULIC PUMP ASSEMBLY	15
5	UPPER and LOWER LINKS and RELATED PARTS	17
6	LEVELING BOX ASSEMBLY and RELATED PARTS	19
7	9N-700-A—POWER TAKE OFF ASSEMBLY	20
8	9N-700-C—POWER TAKE OFF ASSEMBLY	20
9	HYDRAULIC P.T.O. SHIFTER LEVER, FORK and RELATED PARTS	21
10	POWER TAKE OFF GEAR, HOUSING and PULLEY ASSEMBLY	23
11	FRONT and REAR WHEELS (RUBBER) and RELATED PARTS	25
12	FRONT and REAR WHEELS (STEEL) and RELATED PARTS	27
13	BRAKES	29
14	BRAKE PEDALS and SHAFT	30
15	CENTER HOUSING and RELATED PARTS	31
16	REAR AXLE SHAFT HOUSING, and RELATED PARTS	33
17	DIFFERENTIAL ASSEMBLY with DRIVE GEAR and PINION	35
18	STEERING GEAR and RELATED PARTS	37
19	GEAR SHIFTER LEVER and RELATED PARTS	41
20	TRANSMISSION	43
21	CLUTCH GROUP	45
22	ENGINE—FINAL—not illustrated	46
23	CYLINDER BLOCK with SLEEVES and BEARING CAPS	47
24	CYLINDER BLOCK ASSEMBLY with PISTONS, CONN. RODS, CAM and CRANK SHAFTS and GEARS	49
25	LEFT SIDE ENGINE ASSEMBLY	51
26	RIGHT SIDE ENGINE ASSEMBLY	53
27	GENERATOR ASSEMBLY	55
28	WATER PUMP ASSEMBLY and RELATED PARTS	56
29	AIR CLEANER ASSEMBLY	57
30	CARBURETOR ASSEMBLY	59
31	DISTRIBUTOR and COIL ASSEMBLY	61
32	GOVERNOR ASSEMBLY	63
33	STARTER and DRIVE ASSEMBLY	65
34	ELECTRICAL WIRING and RELATED PARTS	67
35	OIL FILTER, OIL GAUGE, CONTROL RODS and RELATED PARTS	69
36	HOOD ASSEMBLY, SIDE PANELS, FUEL TANK, SEDIMENT BULB and RELATED PARTS	71
37	FRONT AXLE and RELATED PARTS	75
38	MUFFLER ASSEMBLY and RELATED PARTS	76
39	SHIPPING KIT	76
→	NUMERICAL PARTS INDEX SUPPLEMENT	77
40	ACCESSORIES and TOOLS	79
41	GENERATOR BELT ADJUSTING KIT	79
42	LIGHTING KIT	80
43	STABILIZER	81
44	INDUSTRIAL TRACTOR FRAME	82
45	INDUSTRIAL TRACTOR CONVERSION PARTS	82
46	P.T.O. CONVERSION KIT	83
47	KEROSENE VAPORIZER	85
48	KEROSENE CONVERSION PARTS	86
49	MAGNETO and DRIVE ASSEMBLY	87
50	MAGNETO IDLER PULLEY	88
51	MAGNETO CONVERSION PARTS	89
52	STEEL WHEEL EXTENSION	89
→	STANDARD PARTS INDEX	90

SMALL - IN DRAWER

LOWER BIN

UNDER QUARTER

X on top Bin #1

KON RACK

TRACTOR NUMERICAL PARTS INDEX

PART NUMBER	NAME	GROUP	PAGE	PART NUMBER	NAME	GROUP	PAGE
9N-400-A	SEAT ASSY.....	1	9	9N-588	CHAIN & ANCHOR.....	5	17
9N-400-C	SEAT.....	1	9	N.S. 9N-591	CHAIN.....	6	19
X 9N-404	SPRING.....	1	9	9N-594	LEVER.....	6	19
N.S. 48Z-441	PLATE.....	25	51	9N-595	PIN.....	6	19
9N-500	HYDRAULIC.....	2	11	9N-596	ANCHOR.....	6	19
9N-501	COVER.....	2	11	9N-597	ANCHOR.....	6	19
9N-502	GASKET.....	15	31	9N-598	CHAIN.....	6	19
N.S. 9N-503	CHAIN.....	5	17	N.S. 2N-599	QUADRANT & LEVER.....	2	11
9N-504	FORK.....	3	13	N.S. 9N-599	QUADRANT & LEVER.....	2	11
9N-505	CHAIN.....	5	17	9N-600	HYDRAULIC PUMP.....	4	15
N.S. 9N-507	EYE.....	5	17	9N-604	BASE.....	4	15
9N-508-B	ANCHOR.....	5	17	N.S. 9N-605-A	BASE.....	4	15
9N-510-A	CYLINDER.....	3	13	N.S. 9N-606	VALVE CHAMBER.....	4	15
9N-510-B	CYLINDER.....	3	13	N.S. 9N-607	VALVE CHAMBER.....	4	15
2N-512	LEVER.....	2	11	9N-609	CLAMP.....	4	15
N.S. 9N-513-C	FORK BOTTOM.....	3	13	9N-611	GASKET.....	4	15
2N-514	CONTROL LEVER & FRICTION PLATE.....	2	11	N.S. 9N-612	LINCH PIN CLIP & CHAIN.....	5	17
N.S. 9N-514	CONTROL LEVER & FRICTION PLATE.....	2	11	- 9N-613	GASKET.....	4	15
9N-515-A	QUADRANT.....	2	11	- 9N-614	GASKET.....	4	15
2N-516	PLATE.....	2	11	9N-615	PISTON.....	4	15
9N-517	SHAFT.....	2	11	9N-617	CAM BLOCK.....	4	15
9N-518	DISC.....	2	11	9N-618	CAM.....	4	15
9N-520	RETAINER.....	2	11	9N-621	VALVE CHAMBER.....	4	15
- 9N-521	STOP.....	2	11	9N-622	VALVE CHAMBER.....	4	15
- 9N-522	WASHER.....	2	11	2N-624	SUPPORT.....	2	11
9N-523-A	GASKET.....	16	33	9N-625	VALVE BUSHING.....	4	15
9N-523-B	GASKET.....	16	33	9N-626	GUIDE.....	4	15
N.S. 9N-524-B	FORK TOP.....	3	13	9N-627	SOCKET.....	4	15
9N-525-B	SEAT.....	2	11	- 9N-628	VALVE.....	4	15
9N-526	CONNECTING ROD.....	3	13	- 9N-629	VALVE.....	4	15
9N-527	PLATE.....	2	11	N.S. 9N-630	CONTROL VALVE.....	4	15
9N-529	FELT.....	2	11	N.S. 9N-632	SPRING.....	4	15
9N-530	PISTON.....	3	13	N.S. 9N-635	CHECK VALVE.....	4	15
9N-531	BUSHING.....	3	13	- 9N-636	PLUG.....	4	15
- 9N-532	GASKET.....	2	11	N.S. - 9N-637	RETAINER.....	4	15
9N-533	RING.....	3	13	- 9N-638	VALVE.....	4	15
9N-535	ROCKER.....	5	17	- 9N-640	VALVE.....	4	15
9N-539	SPRING.....	3	13	N.S. 9N-641	CLIP.....	4	15
9N-540	FORK.....	3	13	N.S. 9N-642	STEM.....	4	15
N.S. 9N-541-A	PLUNGER.....	2	11	N.S. 9N-643	BAR.....	4	15
9N-541-B	PLUNGER.....	2	11	9N-644	SPRING.....	4	15
9N-543	ARM.....	3	13	9N-645	SPRING.....	4	15
9N-544	SHAFT.....	3	13	- 9N-646	SPRING.....	4	15
9N-545	RAM ARM.....	3	13	- 9N-647	SPRING.....	4	15
N.S. 9N-546-A	YOKE.....	2	11	9N-649	BUSHING.....	4	15
9N-546-B	YOKE.....	2	11	2N-666-B	LINK.....	5	17
9N-547-A	SPRING.....	2	11	N.S. 9N-700-A	POWER TAKE OFF.....	7	20
9N-547-B	SPRING.....	2	11	N.S. 9N-700-B	POWER TAKE OFF.....	7	20
- 9N-550	LOCKWASHER.....	3	13	X 9N-700-C	POWER TAKE OFF.....	8	20
9N-551	WASHER.....	3	13	9N-703	OIL SEAL.....	8	20
- 9N-552	GASKET.....	3	13	X 9N-710-A	SHAFT & SLEEVE.....	7	20
- 9N-553	GASKET.....	3	13	X 9N-710-B	SHAFT & SLEEVE.....	8	20
- 9N-554	BEARING.....	6	19	9N-712	BEARING.....	7	20
9N-555	LINK.....	5	17	9N-713	GEAR.....	10	23
X 9N-556	LINK.....	5	17	9N-714	WASHER.....	7	20
9N-560	PIN.....	5	17	9N-715	BEARING.....	8	20
9N-562-B	PLATE.....	16	33	9N-716	HUB.....	9	21
9N-563	SHAFT.....	16	33	2N-717	SLEEVE.....	9	21
X 9N-564	ROD.....	6	19	10 9N-718	SUPPORT.....	9	21
9N-565	BOX.....	6	19	9N-719	RAIL.....	9	21
9N-566	KNUCKLE.....	6	19	9N-720	FORK.....	9	21
9N-567	TUBE.....	15	31	9N-721	PLATE.....	9	21
9N-568	GEAR.....	6	19	9N-722	STOP.....	9	21
9N-569	LEVELING BOX.....	6	19	9N-723	LEVER.....	9	21
N.S. 9N-573-A	CHAIN.....	5	17	9N-724	WASHER.....	7	20
9N-573-B	CHAIN.....	5	17	N.S. 9N-725-B	SHAFT.....	7	20
2N-574	PIN.....	5	17	N.S. 9N-725-C	SHAFT.....	8	20
2N-575	RING.....	5	17	2N-726	CAP.....	8	20
N.S. 2N-576	LINK.....	5	17	9N-727	SEAL.....	7	20
2N-576-B	LINK.....	5	17	9N-728-B	CASE.....	7	20
N.S. 9N-577	LINK.....	5	17	9N-729	SPRING.....	7	20
N.S. 9N-578	CHAIN, ANCHOR & RING PIN.....	5	17	9N-730	GUIDE.....	7	20
9N-579	SHAFT.....	6	19	9N-731	RING.....	7	20
9N-582	CLEVIS.....	6	19	9N-733-A	COVER.....	7	20
9N-583-A	CLIP & CHAIN.....	5	17	9N-733-B	COVER.....	8	20
9N-583-B	CLIP & CHAIN.....	5	17	9N-734	RETAINER.....	7	20
9N-585	FORK.....	6	19	9N-735-A	SLEEVE.....	7	20
9N-587-B	EYE BOLT.....	6	19	9N-735-B	SLEEVE.....	8	20
				N.S. 9N-737	GEAR.....	10	23
				9N-740-A	PULLEY.....	10	23

NOTE: N.S. indicates—NOT SERVICED. Part number appears in this catalog for reference only.

TRACTOR NUMERICAL PARTS INDEX—Continued

PART NUMBER	NAME	GROUP	PAGE	PART NUMBER	NAME	GROUP	PAGE		
N.S.	9N-740-B	PULLEY	10	23	9N-2209-B	BRAKE	13	29	
	9N-741	COVER	10	23	9N-2210-B	BRAKE	13	29	
	9N-743	CONE	10	23	N.S.	9N-2211-B	PLATE	13	29
	9N-744	CUP	10	23	9N-2213-B	PLATE	13	29	
N.S.	9N-745	GEAR	10	23	9N-2217	FELT RING	13	29	
	9N-746	SHAFT	10	23	9N-2227-A	BUSHING	13	29	
	9N-747-A	GASKET	10	23	x	9N-2247	SHAFT	14	30
	9N-747-B	GASKET	10	23	o	9N-2248	COLLAR	14	30
	9N-747-C	GASKET	10	23		9N-2252	RING	13	29
N.S.	9N-748	HOUSING	10	23		9N-2279	CLIP	34	67
	9N-749	SEAL	10	23		9N-2304	BRACKET	13	29
	9N-750	SEAL	10	23	x	9N-2324	ARM	14	30
	9N-752	CONE	10	23	x	9N-2455-A	PEDAL WITH CAP	14	30
	9N-753	CUP	10	23		9N-2456-A	PEDAL WITH CAP	14	30
	9N-754	RING	10	23		78-2477	BUSHING	16	33
N.S.	9N-756-A	SLEEVE	7	20		9N-2786	PAWL	14	30
N.S.	9N-756-B	SLEEVE	8	20		9N-2796	SECTOR	14	30
x	9N-760	GEAR, HOUSING & PULLEY	10	23		9N-3006-A	AXLE	37	75
	9N-761	COVER	10	23	N.S.	9N-3007-A	AXLE	37	75
	9N-762	HOUSING & BEARING CUP	10	23		9N-3008-A	AXLE	37	75
N.S.	9N-1010-A	WHEEL, TIRE & TUBE	11	25		9N-3010-A	AXLE	37	75
N.S.	9N-1010-C	WHEEL & SKID BAND	12	27	N.S.	2N-3029	SUPPORT	37	75
	2N-1012	NUT	11	25		9N-3029	SUPPORT	37	75
	9N-1012	NUT	11	25	✓	2N-3029-B	SUPPORT	37	75
x	9N-1015-A	RIM & SPIDER	11	25		9N-3039	BUSHING	37	75
	9N-1015-C	DISC & RIM	12	27	N.S.	2N-3105	SPINDLE	37	75
	9N-1033-A	SKID BAND	12	27		9N-3105	SPINDLE	37	75
	9N-1033-C	SKID BAND	12	27		2N-3106	SPINDLE	37	75
N.S.	9N-1100-A	WHEEL & LUG	12	27	✓	2N-3109	BUSHING	37	75
N.S.	9N-1100-B	WHEEL & LUG	12	27		9N-3122	PIN	37	75
	9N-1104-A-4	HUB	11	25		9N-3123-A	BEARING	37	75
x	9N-1104-A-1-3	HUB	11	25		2N-3126	PIN	37	75
N.S.	9N-1106-A	HUB	11	25		2N-3126-B	PIN	37	75
	78-1107	BOLT	11	25		2N-3126-D	PIN	37	75
	9N-1107-B	BOLT	11	25	✓	2N-3126-E	PIN	37	75
	9N-1108-C	RIM & BAND	11	25		9N-3126-A	PIN	37	75
	9N-1108-D	RIM & BAND	11	25		2N-3130	ARM	37	75
	9N-1108-F	WHEEL & BAND	12	27		9N-3130	ARM	37	75
	9N-1108-G	WHEEL & BAND	12	27		2N-3131	ARM	37	75
	9N-1117	BOLT	16	33		9N-3131	ARM	37	75
	9N-1122-D	DISC	11	25	x	11A-3289-A	END	37	75
	9N-1122-E	DISC	11	25	x	9N-3304	LINK	37	75
	9N-1126	DRUM	16	33	x	9N-3305	LINK	37	75
N.S.	9N-1139	CAP	11	25		9N-3324	COVER	37	75
	2N-1139-B	CAP	11	25	-	78-3332	COVER	37	75
	9N-1155	BOLT	12	27	-	78-3336	RETAINER	37	75
	9N-1158-A	LUG	12	27	x	2N-3405	ROD	37	75
	9N-1158-B	LUG	12	27		9N-3440	CAP	21	45
N.S.	9N-1170	REAR WHEEL & TIRE	11	25		9N-3442	SPACER	21	45
N.S.	9N-1170-D	WHEEL & DISC	12	27		9N-3512-A	PANEL	18	39
	9N-1190-B	SEAL	11	25		9N-3512-B	PANEL	18	39
	9N-1195	WASHER	37	75		9N-3517	BUSHING	18	37
	9N-1191	SPACER	11	25		9N-3525	SHAFT & PINION	18	37
	B-1201	CONE & ROLLER	11	25		9N-3526	SECTOR	18	39
	B-1202	CUP	11	25		9N-3527	SECTOR	18	39
	B-1216	CONE & ROLLER	11	25		9N-3528	SEAL	37	75
	B-1217	CUP	11	25		9N-3540	SHAFT	18	39
10	9N-2019	SHOE & LINING	13	29		9N-3543-A	WASHER	18	39
N.S.	9N-2020	SHOE	13	29		9N-3543-B	WASHER	18	39
10	92Y-2021-A	LINING	13	29		9N-3543-C	WASHER	18	39
	9N-2030	EQUALIZER	13	29		9N-3550-A	HOUSING	18	39
	9N-2034	SPRING	13	29		9N-3550-C	HOUSING	18	39
	9N-2035	SPRING	13	29	N.S.	9N-3551-A	HOUSING	18	37
	9N-2036	SPRING	13	29		9N-3551-D	HOUSING	18	37
N.S.	79-2038	STEM	13	29		9N-3551-E	HOUSING	18	37
	9N-2040	BRACKET	13	29		B-3552	CUP	18	37
	9N-2041	WEDGE	13	29		9N-3563-A	WASHER	18	39
	81T-2042	LINK	13	29		9N-3563-B	WASHER	18	39
	9N-2043	CAP	13	29		9N-3563-C	WASHER	18	39
	9N-2050	WEDGE	14	30		68-3571-A	ROLLER	18	37
	78-2067-C	CAP	13	29		9N-3573	CONE	18	37
	9N-2068	SPRING	13	29	-	9N-3593-B	GASKET	18	37
	9N-2069	PIN	13	29	-	9N-3594	GASKET	18	37
	78-2071	CUP	13	29		9N-3598	RETAINER	18	37
N.S.	78-2085	PIN	13	29		2N-3600	WHEEL	18	37
N.S.	78-2086	SPRING	13	29	N.S.	9N-3600-B	WHEEL	18	37
	81T-2104	STUD	13	29		B-3609	KEY	18	37
	81T-2108	STEM	13	29		9N-3627	CAP	18	37
	91A-2133	NUT	35	69		9N-3660	SEAL	18	37
						9N-3661	RETAINER	18	37
						9N-3669	CAP	18	37

NOTE: N.S. indicates—NOT SERVICED. Part number appears in this catalog for reference only.

TRACTOR NUMERICAL PARTS INDEX—Continued

PART NUMBER	NAME	GROUP	PAGE	PART NUMBER	NAME	GROUP	PAGE
9N-3670	PACKING.....	18	37	N.S. 9N-6005-A	ENGINE.....	22	69
2N-3673	WASHER.....	18	37	N.S. 9N-6006-A	ENGINE ASSY.....	25	51
9N-3673	WASHER.....	18	37	9N-6010	CYLINDER BLOCK		
2N-3679	LOCK—CYLINDER				WITH SLEEVES		
	& WIRE.....	18	39		AND BEARING.....	23	47
9N-3685-A	KEY.....	18	39	9N-6011	CYLINDER BLOCK.....	25	51
9N-3685-B	KEY.....	18	39	N.S. 9N-6014	CYLINDER BLOCK.....	23	47
9N-3686-C	LOCK & CYLINDER.....	18	39	9N-6017	COVER.....	26	53
9N-3699	SPRING.....	18	37	9N-6018	GASKET.....	26	53
2N-4012-A	HOUSING.....	16	33	9N-6019-B	COVER.....	26	53
N.S. 9N-4012-B	HOUSING.....	16	33	9N-6020	GASKET.....	26	53
2N-4013-A	HOUSING.....	16	33	9N-6022	GASKET.....	32	63
N.S. 9N-4013-B	HOUSING.....	16	33	9N-6043	PLUG.....	23	47
N.S. 2N-4014-A	HOUSING.....	16	33	9N-6050-B	HEAD.....	25	51
N.S. 2N-4015-A	HOUSING.....	16	33	9N-6051	GASKET.....	25	51
N.S. 9N-4024	HOUSING.....	15	31	99A-6055	SLEEVE.....	23	47
9N-4025	HOUSING.....	15	31	40-6057-B	INSERT.....	23	47
2N-4035	GASKET.....	16	33	52-6057-B	INSERT.....	23	47
9N-4124	RETAINER & CUP.....	16	33	18-6066	STUD.....	25	51
9N-4129	GASKET.....	7	20	40-6066	STUD.....	25	51
9N-4130-B	GASKET.....	16	33	2N-6110-A	PISTON.....	24	49
9N-4131	GASKET.....	15	31	99A-6135-A	PIN.....	24	49
9N-4132	COLLAR.....	16	33	78-6140	RETAINER.....	24	49
N.S. 9N-4133	RETAINER.....	16	33	9N-6149-A	RING SET.....	24	49
9N-4150	TROUGH.....	15	31	N.S. 99A-6150-A	RING.....	24	49
9N-4195	BLOCK.....	15	31	N.S. 99A-6153-A	RING.....	24	49
9N-4201	DIFFERENTIAL.....	17	35	9N-6200-B	ROD.....	24	49
9N-4203	GEAR & PINION.....	17	35	N.S. 9N-6205-B	ROD.....	24	49
9N-4204	GEAR CASE.....	17	35	21A-6207-A3	BUSHING.....	24	49
N.S. 79-4205	CASE.....	17	35	21A-6207-B3	BUSHING.....	24	49
N.S. 9N-4206	CASE.....	17	35	N.S. 9N-6210	CAP.....	24	49
9N-4207	GEAR & CASE.....	17	35	9N-6211-A	LINER.....	24	49
BB-4208	WIRE.....	17	35	9N-6211-C	LINER.....	24	49
79-4210-A1	GEAR.....	17	35	18-6212	NUT.....	24	49
9N-4211	SPIDER.....	17	35	N.S. 9N-6250-A	CAM SHAFT.....	24	49
91T-4215	PINION.....	17	35	9N-6250-B	CAM SHAFT.....	24	49
BB-4216-C	SCREW.....	17	35	48-6256	GEAR.....	24	49
BB-4221-B	CONE & ROLLER.....	17	35	91A-6256-A	GEAR.....	24	49
9N-4221	ROLLER & CONE.....	16	33	91A-6256-B	GEAR.....	24	49
BB-4222	CUP.....	16	33	91A-6258	RING.....	24	49
9N-4222	CUP.....	16	33	91A-6266	SEAL.....	23	47
79-4228	WASHER.....	17	35	9N-6303	CRANKSHAFT.....	24	49
9N-4229-A	SHIM.....	16	33	48-6306	GEAR.....	24	49
9N-4229-B	SHIM.....	16	33	40-6310	SLINGER.....	26	53
9N-4229-C	SHIM.....	16	33	2N-6312	PULLEY.....	26	53
79-4230	WASHER.....	17	35	B-6319-A	RATCHET.....	26	53
9N-4232	AXLE SHAFT WITH			9N-6325	CAP.....	23	47
	BEARING RETAINER,			9N-6330	CAP.....	23	47
	SEAL & COLLAR.....	16	33	9N-6331-A	LINER.....	24	49
9N-4234-B	SHAFT & FLANGE.....	16	33	9N-6331-C	LINER.....	24	49
91T-4236	GEAR.....	17	35	9N-6333-A	LINER.....	24	49
9N-4251	SEAL.....	16	33	9N-6333-C	LINER.....	24	49
BB-4256	PIN.....	17	35	91A-6335	SEAL.....	23	47
9N-4605	SHAFT.....	15	31	9N-6345	STUD.....	23	47
79-4609	PINION.....	17	35	9N-6346	STUD.....	23	47
N.S. 79-4610	PINION.....	17	35	91A-6347	PACKING.....	23	47
BB-4614-B	SLEEVE.....	17	35	B-6348	NUT.....	23	47
BB-4616-B	CUPS.....	17	35	9N-6375	FLYWHEEL.....	26	53
BB-4621-B	CONE & ROLLER.....	17	35	N.S. 9N-6380	FLYWHEEL.....	26	53
BB-4625-B1	BEARING.....	17	35	9N-6384	GEAR.....	26	53
BB-4626-C	RACE.....	17	35	B-6387	DOWEL.....	26	53
BB-4627	RING.....	17	35	B-6388	WIRE.....	26	53
B-4634	NUT.....	17	35	18-6397	DOWEL.....	26	53
B-4636-A	LOCKWASHER.....	17	35	91A-6500-A	ROD.....	24	49
9N-4662	GASKET.....	15	31	40-6505-A1	VALVE.....	24	49
BB-4667	WASHER.....	17	35	9N-6505-A	VALVE.....	24	49
N.S. BB-4668-B	SLEEVE.....	17	35	40-6510-B	BUSHING.....	24	49
9N-5182	DRAWBAR.....	5	17	40-6512	RETAINER.....	24	49
X 9N-5230-A	MUFFLER.....	38	76	2NC-6513	SPRING.....	24	49
9N-5251	CLAMP.....	38	76	40-6514-B	RETAINER.....	24	49
9N-5252	BRACKET & CLAMP.....	38	76	2N-6520	COVER.....	26	53
9N-5255	PIPE.....	38	76	N.S. 9N-6520	COVER.....	26	53
9N-5260	BRACKET.....	38	76	9N-6521	GASKET.....	26	53
X 9N-5290	SHIELD.....	38	76	9N-6603	BODY.....	23	47
9N-5293	CLAMP.....	38	76	N.S. 9N-6604	BODY.....	23	47
M-5334	CEMENT.....	13	29	N.S. 52-6606	STUD.....	23	47
9N-5370	CHAIN & WEDGE.....	5	17	9N-6608	GEAR & SHAFT.....	24	49
N.S. 9N-5372	STAY.....	5	17	52-6610-B	GEAR.....	24	49
N.S. 9N-5373	STAY.....	5	17	9N-6612-A	BUSHING.....	23	47
9N-5374	STAY.....	5	17	52-6614-B	GEAR.....	24	49
9N-5375	STAY.....	5	17				

NOTE: N.S. indicates—NOT SERVICED. Part number appears in this catalog for reference only.

+ Big Hole Bottom Bands

Small in *Woods*
Under Center

TRACTOR NUMERICAL PARTS INDEX—Continued

PART NUMBER	NAME	GROUP	PAGE	PART NUMBER	NAME	GROUP	PAGE
9N-6615	TUBE & SCREEN COVER	24	49	40-7549	FACING	21	45
9N-6619	GASKET	24	49	91A-7550	DISC ASSY.	21	45
52-6634	WIRE	24	49	9N-7561	HUB	21	45
9N-6654	SPRING	26	53	9N-7562	SPRING	21	45
01A-6663	PLUNGER	26	53	09A-7563	PLATE & COVER ASSY.	21	45
68-6666	NUT	26	53	78-7580	BEARING ASSY.	21	45
1GA-6669	GASKET	26	53	B-7600-A	BEARING	26	53
9N-6675	OIL PAN	25	51	70-7600-B	BEARING	26	53
B-6700-A	PACKING	25	51	B-7609	RETAINER	26	53
9N-6710	GASKET	25	51	2N-8005	RADIATOR ASSY.	36	73
9N-6711	GASKET	25	51	9N-8005	RADIATOR ASSY.	36	73
9N-6730	DRAIN PLUG & SCREEN	25	51	9N-8032-A	PAD	36	73
91A-6734	GASKET	25	51	2N-8100	CAP ASSY.	36	71
9N-6750	INDICATOR	25	51	9N-8100	CAP ASSY.	36	71
9N-6763	PIPE	25	51	40-8115	DRAIN COCK ASSY.	36	73
9N-6766	CAP	25	51	40-8125-A	PAD	36	73
9N-7000	TRANSMISSION	20	43	2N-8146	SHROUD	36	73
9N-7005-B	CASE ASSY.	21	45	9N-8206-D	GRILLE ASSY.	36	71
N.S. 9N-7006-B	CASE	21	45	9N-8215	PLATE (Ferguson)	36	71
2N-7010	PLUG	21	45	2N-8260	HOSE	36	73
9N-7011	GASKET	21	45	9N-8260	HOSE	36	73
60 2N-7017-A	GEAR	20	43	9N-8286	HOSE	36	73
9N-7020	TUBE	23	47	60-8287	CLAMP	36	73
2N-7023	MATCHED GEAR SET	20	43	9N-8430-B	SUPPORT	36	71
9N-7050	RETAINER	20	43	90 9N-8501	WATER PUMP ASSY.	28	56
78-7052	SEAL	20	43	N.S. 9N-8505	HOUSING	28	56
9N-7061	SHAFT	20	43	9N-8507	GASKET	28	56
9N-7066	CONE & ROLLER	20	43	9N-8508	COVER	28	56
9N-7067	CUP	20	43	78-8512	IMPELLER	28	56
9N-7070	RING	20	43	9N-8513	GASKET	28	56
9N-7085	RETAINER	20	43	9N-8518	HOUSING ASSY.	28	56
9N-7086	GASKET	20	43	9N-8520	BUSHING	28	56
9N-7100	GEAR	20	43	79-8530	BEARING ASSY.	28	56
9N-7101	GEAR	20	43	68-8551	SEAL ASSY.	28	56
9N-7111	COUNTERSHAFT	20	43	9N-8557	WASHER	28	56
2N-7113-A	GEAR	20	43	N.S. 18-8558	SEAL	28	56
9N-7120	BEARING	20	43	68-8560-B	SPRING	28	56
9N-7134	RETAINER	20	43	68-8574	WIRE	28	56
9N-7135-A	SHIM	20	43	9N-8575-A1	THERMOSTAT	36	73
9N-7135-F	SHIM	20	43	9N-8576	RING	28	56
9N-7135-G	SHIM	20	43	78-8600	FAN ASSY.	48	86
9N-7137-A	INDICATOR	15	31	9N-8600-B	FAN ASSY.	28	56
9N-7137-B	INDICATOR	15	31	9N-8600-C	FAN ASSY.	28	56
9N-7140	SHAFT	20	43	9N-8606	PULLEY	28	56
9N-7141	GEAR & BUSHING ASSY.	20	43	9N-8620-A	BELT	28	56
N.S. 9N-7142	GEAR	20	43	9N-8620-B	BELT	28	56
9N-7143-A	BUSHING	20	43	9N-9002	FUEL TANK ASSY.	36	71
9N-7155	PIN	20	43	9N-9030	FILLER CAP ASSY.	36	73
9N-7158-C	COVER	15	31	9N-9067	PAD	36	71
60 9N-7209	LEVER	19	41	9N-9121-A	ANTI-RATTLER	36	71
N.S. 9N-7210	LEVER	19	41	9N-9126	ADAPTER	36	71
9N-7221	PIN	19	41	2N-9155-B	FUEL VALVE	36	73
9N-7223-A	GASKET	21	45	9N-9155-A	FUEL VALVE	36	73
9N-7223-B	GASKET	21	45	9N-9160	GASKET	36	73
9N-7225	PLATE	19	41	2N-9161	SCREEN	36	73
9N-7227	SPRING	19	41	9N-9161	SCREEN	36	73
9N-7228-A	SEAT	19	41	9N-9162	BOWL	36	73
9N-7229-A	LOCK	19	41	2N-9163	NUT	36	73
9N-7229-B	LOCK	19	41	N.S. 9N-9164-A	VALVE BODY ASSY.	36	73
9N-7230-A	FORK	19	41	2N-9166	WIRE ASSY.	36	73
9N-7230-B	FORK	19	41	9N-9273	OIL GAUGE ASSY.	35	69
9N-7231-A	FORK	19	41	9N-9282-A	FUEL LINE ASSY.	36	73
9N-7231-B	FORK	19	41	9N-9425	MANIFOLD	26	53
79-7234	SPRING	19	41	9N-9447	GASKET	30	59
9N-7240	ROD	19	41	9N-9448	GASKET	26	53
9N-7241	ROD	19	41	9N-9510-A	CARBURETOR	30	59
9N-7277	SEAL	19	41	N.S. 9N-9511	BODY ASSY.	30	59
9N-7334	ROD	21	45	N.S. 9N-9515	BODY ASSY.	30	59
9N-7503	SHAFT & ARM	21	45	9N-9519	GASKET	30	59
9N-7508	BUSHING	14	30	9N-9530	NOZZLE	30	59
40-7508-A	BUSHING	21	45	9N-9533	JET	30	59
B-7510	SHAFT	21	45	9N-9536-A	RATCHET ASSY.	30	59
9N-7511	ARM	21	45	9N-9539	SPRING	30	59
48-7515	CLUTCH RELEASE SHAFT FORK	21	45	9N-9540-A	SPRING	30	59
N.S. 9N-7519	PEDAL	14	30	9N-9541	NEEDLE	30	59
9N-7520	PEDAL ASSY.	14	30	9N-9546	SHAFT & LEVER ASSY.	30	59
9N-7530	ROD & YOKE ASSY.	21	45	9N-9549	FLY ASSY.	30	59
				9N-9550-A	FLOAT & LEVER ASSY.	30	59
				9N-9553	ELBOW & STRAINER ASSY.	30	59
				9N-9558-A	SHAFT	30	59

NOTE: N.S. indicates—NOT SERVICED. Part number appears in this catalog for reference only.

*in small drawers
phaset*

TRACTOR NUMERICAL PARTS INDEX—Continued

PART NUMBER	NAME	GROUP	PAGE	PART NUMBER	NAME	GROUP	PAGE
9N-9563	GASKET	30	59	9N-10138-C	PLATE	27	55
9N-9564	VALVE & GASKET ASSY.	30	59	N.S. 9N-10139-C	PLATE	27	55
9N-9565-A	NEEDLE ASSY.	30	59	B-10141	CUP	27	55
9N-9569	GASKET	30	59	18-10142	BAND	33	65
9N-9578	SPRING	30	59	18-10146	RETAINER	27	55
9N-9581-A	SHAFT & LEVER ASSY.	30	59	18-10147	WICK	27	55
N.S. 9N-9584	VALVE	30	59	9N-10151-C	BRACKET	27	55
9N-9585-A	FLY	30	59	9N-10163	RING	27	55
9N-9586	VENTURI	30	59	2N-10167	BRACKET	27	55
9N-9589	SPRING	30	59	9N-10175-C	COIL	27	55
9N-9591	RETAINER	30	59	2N-10176	BOLT	27	55
9N-9596	JET	30	59	2N-10177	SPRING	27	55
N.S. 9N-9599	SEAT	30	59	2N-10178	BRACKET	27	55
90 9N-9600-C2	AIR CLEANER ASSY.	29	57	2N-10179	CLAMP & BRACKET	41	79
9N-9600-D	AIR CLEANER ASSY.	29	57	2N-10180	NUT	27	55
9N-9602-C1	COVER ASSY.	29	57	2N-10181	SERVICE KIT	27	55
9N-9602-C2	COVER ASSY.	29	57	81A-10208	INSULATOR	27	55
9N-9602-C3	COVER ASSY.	29	57	81A-10211	SCREW	27	55
9N-9603	DECAL	36	73	9N-10212	SEAL	27	55
9N-9608	GASKET	30	59	9N-10214	RETAINER	27	55
N.S. 9N-9609-C1	BODY ASSY.	29	57	9N-10505-B	CUT-OUT ASSY.	34	67
N.S. 9N-9609-C2	BODY ASSY.	29	57	B-10563	INSULATOR	34	67
N.S. 9N-9609-D	BODY ASSY.	29	57	B-10564	BOLT	34	67
9N-9610	SCREW	30	59	9N-10597-B	PLATE	34	67
9N-9612	TOGGLE LOCK ASSY.	29	57	2N-10655-A	BATTERY	34	67
9N-9619-C1	SCREEN	29	57	2N-10655-B	BATTERY	34	67
9N-9619-C2	SCREEN	29	57	2N-10657	BATTERY	34	67
9N-9619-C3	SCREEN	29	57	9N-10661	DECAL	36	73
9N-9622-A	PACKING	30	59	01A-10720	PLUG	34	67
9N-9623	GASKET	29	57	2N-10721	COVER	34	67
9N-9623-B	GASKET	29	57	01A-10726	INSULATOR	34	67
9N-9628-C1	CLAMP ASSY.	29	57	2N-10728	BAR	34	67
9N-9628-C2	CLAMP ASSY.	29	57	9N-10728-C	BAR	34	67
9N-9652	HOSE	29	57	110 2N-10732	SUPPORT	34	67
9N-9653	CLAMP	29	57	9N-10737	PLATE	36	73
9N-9658-C1	OIL CUP ASSY.	29	57	9N-10748	BAR	34	67
9N-9658-C2	OIL CUP ASSY.	29	57	9N-10850-B	AMMETER	34	67
9N-9658-D	OIL CUP ASSY.	29	57	9N-10879	BRACKET	34	67
9N-9678	SPRING	29	57	120 9N-11001	STARTER & DRIVE ASSY.	33	65
9N-9692	PLUG	30	59	9N-11002	STARTER ASSY.	33	65
9N-9694	STRAINER	30	59	52-11005	ARMATURE ASSY.	33	65
9N-9700-A	ROD ASSY.	35	69	18-11036	WASHER	33	65
9N-9703	KNOB CHOKE	18	39	18-11049	PLATE ASSY.	33	65
2N-9802	SHAFT ASSY.	35	69	18-11056	BRUSH ASSY.	33	65
9N-9805	ROD	18	37	B-11059	SPRING	33	65
9N-9806	SPRING	18	37	N.S. 18-11075	FRAME ASSY.	33	65
9N-9807	LEVER	18	37	18-11083	COIL	33	65
9N-9810	SOCKET ASSY.	35	69	18-11085	COIL	33	65
9N-9812	RETAINER	18	37	18-11091	BOLT	33	65
9N-9815-B	ROD ASSY.	35	69	18-11094	WASHER	33	65
9N-9818-A	ROD ASSY.	35	69	18-11102	TERMINAL	33	65
9N-9819-A	PIN	18	37	18-11107	BUSHING	33	65
9N-9820	QUADRANT	18	37	52-11130-A	PLATE ASSY.	33	65
9N-9824-A2	BRACKET	35	69	52-11350-C	DRIVE ASSY.	33	65
9N-9827	SPRING	35	69	52-11365-B	PIN	33	65
9N-9828	PIN	35	69	52-11366-B	SCREW & SHAFT ASSY.	33	65
9N-9914	JET	30	59	52-11367	PINION & BARREL ASSY.	33	65
100 2N-10000	GENERATOR ASSY.	27	55	52-11368	SPRING	33	65
9N-10005-C	ARMATURE	27	55	52-11369	SPRING	33	65
9N-10036	WIRE	27	55	52-11370	RING	33	65
68-10044	SCREW	27	55	52-11372	PLATE	33	65
40-10051	HOLDER	27	55	52-11373	RING	33	65
40-10057	SPRING	27	55	52-11375	SPRING	33	65
9N-10057	SPRING	27	55	9N-11450-A	SWITCH ASSY.	19	41
40-10069	BRUSH	27	55	9N-11450-B	SWITCH ASSY.	19	41
9N-10069-A	FIELD BRUSH ASSY.	27	55	9N-11467	GASKET	19	41
9N-10069-B	BRUSH & WIRE ASSY.	27	55	9N-11506	BUTTON ASSY.	19	41
40-10070	BRUSH	27	55	9N-11511	ROD	19	41
N.S. 9N-10078-C	FRAME ASSY.	27	55	9N-11512	ROD	19	41
18-10088	DOWEL	27	55	9N-11515	LEVER	19	41
9N-10094	BEARING	27	55	9N-11664	PLUG	18	39
9N-10096-A	RING	27	55	9N-12000	DISTRIBUTOR & COIL ASSY.	31	61
9N-10096-C	RING	27	55	9N-12024	COIL ASSY.	31	61
9N-10098	RETAINER	27	55	9N-12100	DISTRIBUTOR ASSY.	31	61
18-10120	BOLT	27	55	9N-12106-B	HOUSING	31	61
9N-10121	RETAINER	27	55	9N-12112	CONDUIT	34	67
9N-10122	SEAL	27	55	9N-12113-A	SEAL	34	67
9N-10128-B	BEARING	27	55	91A-12114	GASKET	31	61
9N-10129-B	PLATE	27	55				
9N-10130-B	PULLEY	27	55				

NOTE: N.S. indicates—NOT SERVICED. Part number appears in this catalog for reference only.

TRACTOR NUMERICAL PARTS INDEX—Continued

PART NUMBER	NAME	GROUP	PAGE	PART NUMBER	NAME	GROUP	PAGE
9N-12137	BAIL	31	61	9N-16938-C	COVER ASSY.	36	71
9N-12139	BASE & CLAMP ASSY.	31	61	9N-16938-D	COVER ASSY.	36	71
X 91A-12140	GASKET	31	61	9N-16948-B	SPRING	36	71
X 9N-12143	GASKET	31	61	2N-17003	SHIPPING KIT	39	76
9N-12144	CLAMP	31	61	9N-17005-A	TOOL BOX	36	73
B-12145	RIVET	31	61	9N-17005-B	TOOL BOX	36	73
91A-12146	SPRING	31	61	9N-17014	WRENCH	39	76
9N-12147	CAP	31	61	01A-17017-B	SPARK PLUG WRENCH	39	76
48-12148	SCREW	25	51	01A-17021	MONKEY WRENCH	39	76
9N-12150	BREAKER	31	61	9N-17040	CRANK	39	76
9N-12151	PLATE ASSY.	31	61	2N-17125-A	GREASE GUN	39	76
91A-12159	SCREW	31	61	2N-17128-A	ADAPTER	39	76
N.S. 9N-12162	ARM	31	61	9N-18179-A	SHAFT & DRIVER ASSY.	32	63
91A-12174	WASHER	31	61	9N-18182	BEARING	32	63
91A-12177	RETAINER	31	61	9N-18183	SEAL	32	63
91A-12179	WASHER	31	61	9N-18184	BUSHING	32	63
9N-12187	SHAFT, CAM & WEIGHTS ASSY.	31	61	2N-18185	BODY ASSY.	32	63
9N-12188	WEIGHT ASSY.	31	61	N.S. 9N-18185-A	BODY ASSY.	32	63
9N-12200	ROTOR ASSY.	31	61	N.S. 9N-18185-B	BODY ASSY.	32	63
91A-12212	RETAINER	31	61	9N-18186-B	RACE ASSY.	32	63
B-12213	WASHER	33	65	9N-18187-A	DRIVE SHAFT ASSY.	32	63
N.S. 68-12219	CONTACT	31	61	9N-18188-B	RACE	32	63
9N-12250-B	RESISTOR	34	67	9N-18189	LEVER ASSY.	32	63
9N-12278	INSULATOR	34	67	9N-18190	LEVER ASSY.	32	63
2N-12281-B	WIRE & CONDUIT ASSY.	34	67	9N-18191-B	BASE	32	63
9N-12283	WIRE	34	67	9N-18192	BEARING	32	63
9N-12284	WIRE	34	67	9N-18194	BASE	32	63
9N-12286	WIRE	34	67	9N-18195	CLIP	32	63
9N-12287	WIRE	34	67	9N-18196	SPRING	32	63
91A-12300	CONDENSER ASSY.	31	61	N.S. 9N-18197-B	RACE	32	63
9N-12405	SPARK PLUG	34	67	170 9N-18200-C	GOVERNOR ASSY.	32	63
B-12410	GASKET	19	41	180 9N-18215-C	PIPE	29	57
01A-12410-A	GASKET	34	67	9N-18222	GEAR	32	63
9N-13603	WIRE	34	67	9N-18224	PIN	32	63
9N-14300-A	CABLE ASSY.	34	67	9N-18225	DECAL	29	57
9N-14300-C	CABLE ASSY.	34	67	9N-18235	FORK	32	63
9N-14301	CONNECTOR ASSY.	34	67	9N-18241	SHIM	32	63
9N-14377	CONNECTOR ASSY.	34	67	9N-18354	KIT	31	61
2N-14401	WIRING	34	67	9N-18376	KIT	30	59
9N-14401-B	WIRING	34	67	9N-18634	DECAL	35	69
9N-14401-C	WIRING	34	67	9N-18635	DECAL	35	69
N.S. 9N-14401-E	WIRING	34	67	9N-18649	KIT	35	69
9N-14431-A	CABLE ASSY.	34	67	9N-18660	OIL FILTER & BRACKET ASSY.	35	69
9N-14431-B	CABLE ASSY.	34	67	N.S. 9N-18662	CARTRIDGE ASSY.	35	69
9N-14498	WIRE	34	67	2N-18666	TUBE ASSY.	35	69
51-14550-A	SUPPORT	34	67	9N-18666	TUBE ASSY.	35	69
9N-14564	BRACKET	34	67	2N-18667	TUBE ASSY.	35	69
9N-16312	FENDER ASSY.	11	25	9N-18668	GASKET	35	69
2N-16600	PLATE (Ford)	36	71	01A-18675	GASKET	35	69
9N-16612-B	HOOD TOP ASSY.	36	71	9N-18676	TUBE ASSY.	35	69
9N-16612-C	HOOD TOP ASSY.	36	71	9N-18677	SPACER	35	69
2N-16618	PANEL ASSY.	36	71	9N-18678	NUT	35	69
2N-16619	PANEL ASSY.	36	71	9N-18679	ADAPTER	35	69
9N-16625	STUD & HANDLE	36	71	9N-18685	ADAPTER	35	69
9N-16651	RETAINER	36	71	9N-18686	ELBOW	35	69
9N-16656	TONGUE	36	71	9N-18687	COVER	35	69
9N-16689	HINGE	36	71	9N-18688	GASKET	35	69
9N-16938-B	COVER ASSY.	36	71	01A-18689	GASKET	35	69
				01A-18691-A	CAP SCREW	35	69

B-14585 clip .02
 B-14586 " .02