

## SECTION 206-09A Anti-Lock Control

VEHICLE APPLICATION: 2008.0 Transit

CONTENTS	PAGE
<b>ELECTRICAL SCHEMATICS</b>	
Anti-Lock Control — Vehicles Built Up To: 31-01-2007.....	206-09A-2
Anti-Lock Control — Vehicles Built From: 01-02-2007, Vehicles Built Up To: 31-08-2007..	206-09A-4
Anti-Lock Control — Vehicles Built From: 01-09-2007, Vehicles Built Up To: 31-10-2008..	206-09A-6
Anti-Lock Control — Vehicles Built From: 01-11-2008.....	206-09A-8
<b>ELECTRICAL CONNECTORS</b>	
Anti-Lock Brake System (ABS) Module — A.....	206-09A-11
Anti-Lock Brake System (ABS) Module — B.....	206-09A-12
Anti-Lock Brake System (ABS) Module — C.....	206-09A-13
Front Wheel Speed Sensor LH.....	206-09A-13
Front Wheel Speed Sensor RH.....	206-09A-13
Rear Wheel Speed Sensor LH.....	206-09A-13
Rear Wheel Speed Sensor RH.....	206-09A-14